
# WindTrue: Sensitivity analysis applied to DANAERO wind turbine

Prashant Kumar Benjamin Sanderse




#### Workflow




# NURBS based parametrization

### Non-Uniform Rational Basis Spline (NURBS)



$$S(x) = \sum_{i=0}^{N-1} c_i B_{i,p}(x)$$

## Non-Uniform Rational Basis Spline (NURBS)




# Why NURBS?

- -> Represent complex shapes with very few points
- -> Flexibility to design a large variety of shapes
- -> Easy to obtain high-order polynomials

Goal: Obtain perturbed chord/twist from a given reference curves

Goal: Obtain perturbed chord/twist from a given reference curves

**Step 1:** Sample locations from the reference curve




Goal: Obtain perturbed chord/twist from a given reference curves

\_\_\_\_

**Step 1:** Sample locations from the reference curve

Step 2: Compute control points at sampled location via inversion

$$S(x) = \sum_{i=0}^{N-1} c_i B_{i,p}(x) \implies \mathbf{Bc} = \mathbf{S}$$
known known





Goal: Obtain perturbed chord/twist from a given reference curves


**Step 1:** Sample locations from the reference curve


Step 2: Compute control points at sampled location via inversion

$$S(x) = \sum_{i=0}^{N-1} c_i B_{i,p}(x) \implies \mathbf{Bc} = \mathbf{S}$$
known known












Step 3: Perturb control point values using some PDF



Step 3: Perturb control point values using some PDF



**Step 4:** Sample perturbed curves



# Global sensitivity analysis

# Global sensitivity analysis

- -> Goal is to rank the uncertain parameters in the order of importance
- -> Global approaches cover the uncertainty spaces more exhaustively
- -> Better able to capture uncertainty in the model output

# Sobol sensitivity indices

**Main idea:** Decompose the variance of model output in terms of contribution from individual input parameters and their combinations.

$$V(y) = \sum_{i} V_i + \sum_{i,j} V_{i,j} + \text{higher order terms}$$

First order indices

$$S_1 = \frac{V_1}{V}, S_2 = \frac{V_2}{V}, \dots$$

Second order indices

$$S_{1,2} = \frac{V_{1,2}}{V}, S_{1,3} = \frac{V_{1,3}}{V}, \dots$$

# Sobol sensitivity indices

**Main idea:** Decompose the variance of model output in terms of contribution from individual input parameters and their combinations.

$$V(y) = \sum_{i} V_i + \sum_{i,j} V_{i,j} + \text{higher order terms}$$

First order indices

$$S_1 = \frac{V_1}{V}, S_2 = \frac{V_2}{V}, \dots$$


Second order indices

$$S_{1,2} = \frac{V_{1,2}}{V}, S_{1,3} = \frac{V_{1,3}}{V}, \dots$$

We use adaptive Polynomial Choas Expansion (Least angle regression) to compute variances


# Sensitivity analysis results


## Geometric Uncertainty



10% (uniformly distributed) uncertainty in chosen control point

### Sobol indices





**Power** 

**Axial Force** 

# Operation Uncertainty

#### Yaw

Truncated Gaussian [mean = 0, std = 2, LB = -10, UB = 10]

#### WindSpeed


Weibull distribution [Scale = 6.1, Shape = 50]

#### **RPM**


Truncated Gaussian [mean = 12.3, std = 1, LB = 10, UB = 14]


#### **PitchAngle**

Truncated Gaussian [mean = 0.15, std = 1, LB = -2, UB = 2]



#### Sobol indices





Power Axial Force

-> Yaw angle is least sensitive parameter

### Next Steps:

- -> Determine realistic amount of perturbations for uncertain parameters
- -> Parametrization for other random inputs, model-form uncertainty
- -> Include other BEM codes in the workflow and perform comparisons