

Post Processor Questionnaire

Customer Information

Company Name	HONEYRING
Sales status	Post-sale

Machine Information

1	Machine tool Manufacturer :	CMS UK Ltd
2	Model Number or Series :	Athena
3	How many axes on machine? 3, 4 or 5	5

NC Controller Details

4	Controller Name :	Osai
5	Series :	OPEN_M
6	Units used :	MM

The following items are applicable only in case of 4-axis and 5-axis machines

7	Tilting Axis Details	
	a. Rotates around which Axes? (X Y or Z)	Y
	b. Denoted by which letter? (A, B or C)	B
	c. Is this axis on the Table or Head ?	Head
	d. Tilting Axis Limits	+/- 120'

8	Rotary Axis Details	
	a. Rotates around which Axes? (X Y or Z)	Z
	b. Denoted by which letter? (A, B or C)	C
	c. Is this axis on the Table or Head ?	Head
	d. Rotary Axis Limits	+/- 360

9	Does Controller have 5 axis Rotary Tool Length Compensation (RTCP) ? Sometimes called tool tip programming control.	Yes
10	If not then, If Rotary axis centers do not intersect then enter the offset distance between the axes	(TCP,1) 0
11	Does controller support Workplane Transformation? (like Cycle 19 in Heid)	Yes UPR Command

[Here are a few Example Programmes](#)



Start Programme

```
; (Program Name) cut1
; (Description)
; 28 Jul 15
;
;Tool=02, Name=12 Bull-Nosed Endmill, Diameter=10
;
(DAN)
(UPR)
(TCP)
G71
G600
;*****
E200=1      ;ORIGIN
E201=0      ;X POSITION
E202=0      ;Y POSITION
E203=0      ;Z POSITION
;
E210=-125 ;G79 Safe Z Value, Edit as Required
;*****
G0 G79 ZE210 ;Safe Z
G0 G79 Y-200
G0 G79 B-75 C0
;*****
(UAO,E200)
(UTO,E200,XE201,YE202,ZE205)
;*****
G356
;(GTO,TC_#) ;Tool Label Call
"TC_1" ; Tool label
;Tool Change Start
(DIS,"12 Bull-Nosed Endmill")
T2 M06
M01
h2
M3 S16000
G0 G79 ZE210 ;Safe Z
G16 XY
;Tool Change End
G79 Y-100.0
G0 B0. C0.
G0 X75.666 Y444.536 B0. C0.
G0 X75.666 Y444.536
G0 Z130.
(TCP,1)
Z129.
G1 Z124. F1000.0
```



```
G3 X91.83 Y436.092 R32.071 F3000.0
X98.689 Y435.336 R37.196
X109.785 Y437.156 R32.013
X115.711 Y440.024 R31.423
X122.372 Y445.108 R39.293
X127.495 Y451.87 R26.692
```

Tool Change in Programme (Note Cancellations)

```
Y147.276
G00 Z50.0
Tool Change
M5 S0
h0
(DIS, "")
(TCP)
(UPR)
(DAN)
G79 G0 ZE210
G79 B0 C0
"TC_2" ; Tool label
T12 M6
/S12000 M3
h12
G90 G71
G79 G0 ZE100
G79 B0 C0
(TCP,1)
(DIS, "LOAD-CUTTER-6.35")
X84.425Y76.675
Z200
G01 Z50.0 F4000
Z-5.0 F1000
X228.075 F2000
```

Programme End

```
G00 Z250.0
M05 S0
G0
h0
(DIS, "")
```



(DAN)

(UPR)

(TCP)

G601

G0 G79 ZE210

G0 G79 B0 C0

G0 G79 Z0

G0 G79 Y0

M30