# 掌握音樂的未來:

# 智慧娛樂

# 音樂全新愛場

嵌入式智慧系統創新應用就業養成班 第 48 期 第五組

您準備好體驗音樂的全新世界了嗎?我們 的智慧音響不僅帶來寫品質的音樂享受, 還將音樂與科技完美結合,為您帶來前所 表育的聽覺饗宴。

指導老師:詹民進 老師

此部分負責組員: 陳麒元

中華民國112年8月



# 一、 前言:

「在現代快節奏的生活中,您是否在放鬆娛樂時渴望一個 能夠同時提供高品質音樂和無與倫比體驗的環境?我們的全新 智慧娛樂音響將為您帶來驚喜和改變;並藉由燈光讓生活中的 每一刻都有其獨特的氛圍和情感,因此我們的智慧氣氛燈將成 為您的創意工具,讓您根據心情隨心打造各種光影場景。同 時,在這個多變的時代,安全問題變得日益嚴峻。我們的智慧 警衛不僅是一個產品,更是您安全的守護者,為您打造全方位 的保護網。」



# 二、 價值展示

我們相信,音樂可以成為您運動的最佳伴侶。我們的智慧音響不僅提供了卓越的音質,更讓您的娛樂放鬆過程更加愉快和振奮。您可以隨意切換歌曲,調整音量,或是播放放鬆的頻率音樂,甚至是可以自彈自唱,達到徹底放鬆狀態;也可以利用氣氛燈的切換,徹底融入在這個只有自己的時刻。

而當您沈浸在自我的小世界時,也不用擔心會有其他人的 打擾或是干擾,當你切換至警訊衛兵模式時,就會幫助注意周 遭環境,當已有人靠近時會發出燈光及聲音的警訊通知。

# 三、 產品特點:

- 多種燈效:智慧氣氛燈擁有多種燈光效果,包括柔和燈光、彩虹燈效、節奏跳動等,營造出不同的情感氛圍。
- 音樂互動:我們的氣氛燈支援音樂同步功能,讓您的燈光 隨著節奏變化,打造極具震撼的視聽效果。
- 即時警訊:我們的智慧警衛具即時警報功能,一旦偵測到可疑動態,立即發出警訊,確保您可第一時間做出應對。


## 四、 功能展示:



- 當燈光調控模式時,若利用紅外線偵測到人時開啟七彩霓虹 燈閃爍,若無人則暫停
- 在闖入偵測模式,若利用紅外線偵測到人時蜂鳴器及燈光發 出警告訊號,若無人則暫停
- 在音樂娛樂的部分,除了可以播放預設的背景及歌曲音樂之外,還可以在娛樂間中自彈自唱,進入娛樂的殿堂。

## 五、 團隊堅持:

我們深知音樂對於您的情感和心靈的重要性。因此,我們的智慧音響不僅注重技術,更追求卓越的音質。堅持四大目標,讓每一個音符每個休息的瞬間,都如同鑽石一般晶瑩剔透,讓您沉浸在音樂的海洋中。」



# 六、 客戶見證:

- ▶ 「'這是我使用過的最好的音響,音質真的太出色了!無論 在跑步還是娛樂時,都讓我感到更有動力。」
- ▶ 「'從使用了這個智慧音響後,我的音樂體驗得到了質的飛躍。無論在家中還是辦公室,它都為我帶來了無比的享受。'-張先生」
- ▶ 「在寒冷的冬夜,您可以調整為柔和的暖色調,讓溫暖的 燈光點綴整個房間,讓您感到宜人舒適。」

▶ 「準備好改變您的運動體驗了嗎?立刻掃描下方連結,線上體驗智慧音響,享受優質音樂和無比舒適的運動。」
https://www.youtube.com/watch?v=t0RlmHF2i5g





立即體驗智能娛樂的未來!點擊下方連結,帶你實際享受



您的智能家居為您的生活帶來無與倫比的便利和享受。

# 七、 支援與聯繫:


如果您對我們的產品有任何疑問或需要支援,請隨時聯繫 我們的 MEME48-第五組服務團隊,我們將竭誠為您提供幫助。

# 八、 產品與硬體說明:

# (一) 硬體介紹

1. 開發版:DMA-4412L





- (1). 中央處理器:Samsung Exynos 4412-SCP (核心為 ARM Cortex A9)
- (2). 作業系統:Linux3.0.8 / Android4.2/4.4
- (3). 內建高性能 ARM-Mali-400 MP 3D 圖形引擎和 2D 圖形引擎。
- (4). 內建 NFC, Mpeg-1/2/4/VC-1/H. 263/H. 264 的硬體編碼與解碼。
- (5). 支援 5 吋高解析度 LCD+電容式多點觸控板 (IIC 介面)。
- (6). USB Wi-Fi 無線上網、藍芽 BT2.0+EDR 傳輸功能。
- (7). 支援攝像功能, IIC CMOS 及 USB CMOS 介面。
- (8). 3G Modem 通話、上網、簡訊功能(USB 外接介面)。
- (9). HDMI 1.4, 1080p/60Hz 高清輸出。
- (10).GPS 配合 Google MAP 定位及導航使用。

DMA-4412L 是一款 ARM Coretex-A9 四核開發平台,採用

Samsung Exvnos4412 (Exvnos4412 Quad) 設計。主頻提升至


1.5 GHz,其自帶 128/64 位元內部匯流排結構,32/32KB 的資料/指令一級緩存,1024KB 的二級緩存,可以實現 2000DMIPS (每秒 2 億指令集)的高性能運算能力。採用 32nm 低功率制程,運算能力和功耗方面分別比 45nm 工藝的 Exynos 4210 提升 25%和降低 40%左右,另外其內建高性能 ARM Mali-400 MP 3D 圖形引擎和 2D 圖形引擎,多邊形生成率為 44M 三角形/秒,圖元填充率可達 1.6G 圖元/秒,支援 DX9、SM3.0、OpenGL2.0 等 PC 級別顯示技術,支援全高清、多標準的視頻編碼,流暢播錄 1080p 視頻檔,內建 MFC,支援 MPEG-1/2/4、VC-1、H.263、H.264 編解碼,支援數位 TV 輸出,完美的展現了 Samsung Exynos4412 晶片的功能。




# 2. 人體紅外線感測器


<b>萨坚品</b> 新	HC-SR501人體版應模塊	
工作電壓範圍	直流电壓4.5-20V	
靜態電流	<50uA	
電平輸出	高3.3 V /低0V	
關發方式	L不可重複觸發/H重複觸發(默認重複觸發)	
延時時間	0.5-2005(可調)可製作範圍零點幾秒-幾十分鐘	
封鎖時間	2.55(默認)可製作範圍零點幾秒-幾十秒	
電路板外形尺寸	32mm*24mm	
威應角度	<100度推角	
工作温度	-15-+70度	
延應透鏡尺寸	直徑:23mm(預設)	

# (二)線路圖





## 九、 軟體架構說明



### (一) Kernel 程式設計

1. Buzzer (有源蜂鳴器)部分




Figure 7. Exynos 4412 外觀及接腳圖

#### (1). 使用接腳

在有源蜂鳴器上,預計設計成兩個蜂鳴器搭配開啟,在腳位的部分,分配的腳位為 Pin 2 及 Pin 13 腳,說明如下圖所示:

```
#define PIN EXYNOS4_GPX0(0) //pin2
#define PIN2 EXYNOS4_GPD0(2) //pin13
```

### (2). 使用主編號及裝置名稱

```
#define DEVICE_MAJOR 235
#define DEVICE_NAME "buzzer"
```

#### (3). 程式進入點

進入核心底層後,Server 會先進入 init()內將暫存器開啟、建立需使用的模組(buzzer),及給予 Major 號碼提供註冊;再離開 Kernel 時,會進入 exit()裡面將原本建立及註冊的資料做一個清除的動作。

```
static struct class *buzzer_class;
static int __init buzzer_init(void)
   int retval;
    retval = register_chrdev(DEVICE_MAJOR, DEVICE_NAME, &buzzer_fops);
    if(retval < 0)</pre>
       printk("Buzzer driver register success!\n");
   buzzer_class = class_create(THIS_MODULE, "buzzer");
       if (IS_ERR(buzzer_class))
       printk(KERN_WARNING "Can't make node %d\n",DEVICE_MAJOR);
              return PTR_ERR(buzzer_class);
   device_create(buzzer_class, NULL, MKDEV(DEVICE_MAJOR, 0), NULL, DEVICE_NAME);
   printk("Buzzer driver make node success!\n");
} « end buzzer_init »
static void __exit buzzer_exit(void)
   device_destroy(buzzer_class,MKDEV(DEVICE_MAJOR, 0));
   class_destroy(buzzer_class);
    printk("Buzzer driver remove node success!\n");
    gpio_free(PIN);
    gpio_free(PIN2);
   unregister_chrdev(DEVICE_MAJOR, DEVICE_NAME);
   printk("Buzzer driver release success!\n");
module_init(buzzer_init);
module_exit(buzzer_exit);
static struct file_operations buzzer_fops =
                      THIS MODULE,
    owner
    read
                      buzzer_read2,
    write
                      buzzer_write,
    unlocked_ioctl : buzzer_ioctl,
                : buzzer_open,
    open
    release
                 : buzzer_release,
};
```

#### (4). 開啟裝置

在 open 函數中先使用變數來檢查 PIN 變數是否可以使用,加上 if()判斷式,若不能創立則發出"PIN1 fail"的訊息,並將資料釋放 (gpio free)。

```
static int buzzer_open(struct inode *inode, struct file *filp)
    printk("open in kernel\n");
/*PPIDP GPIO PDP}*/
    ret=gpio_request(PIN,DEVICE_NAME);
ret=gpio_request(PIN2,DEVICE_NAME);
    if(ret<0){
         printk(KERN_EMERG "PIN fail !\n");
printk(KERN_INFO "%s: %s unable to get TRIG gpio\n", DEVICE_NAME, __func__ );
gpio_free(PIN);
         gpio_free(PIN2);
return ret;
     // Set gpios directions
    //s3c_gpio_cfgpin(PIN, S3C_GPIO_OUTPUT);
//gpio_set_value(EXYNOS4_GPB(0),1);
    if( gpio_direction_output( PIN, 0) < 0 )</pre>
                                                        // Set pin 2 as output with default value 0
         printk( KERN_INFO "%s: %s unable to set TRIG gpio as output\n", DEVICE_NAME, __func__ );
         ret = -EBUSY;
return(ret);
    if( gpio_direction_output( PIN2, \theta) < \theta ) // Set pin 2 as output with default value \theta
         printk( KERN_INFO "%s: %s unable to set TRIG gpio as output\n", DEVICE_NAME, __func__ );
         return(ret);
     return 0:
static int buzzer_release(struct inode *inode, struct file *filp)
     printk("buzzer release\n");
```

#### (5). 腳位控制

有關蜂鳴器驅動程式是使用 GPD2 的 I/O 腳位來實現,透過 ioctl 的指令中的 cmd 去控制蜂鳴器開或關與發出長短音,以下是部分程式碼。

```
static long buzzer_ioctl(struct file *file, unsigned int cmd, unsigned long arg)
    int ret = \theta;
    int num;
printk("cmd=%d\n",cmd);
                                    根據接收的訊息,決定開關
   -switch(cmd)
    case BUZZER ON:
        printk("on\n");
         ret = copy_from_user(&num, (int*)arg, sizeof(int));
        if (ret != 0)
             printk("gpio_ioctl: copy_from_user failed\n");
return(-EFAULT);
        printk("num = %d\n", num);
         buzzer_on(num);
    break;
case BUZZER_OFF:
   printk("of\n");
        ret = copy_from_user(&num, (int *)arg, sizeof(int));//arg = 3-->num = 3
if (ret != 0)
            printk("gpio_ioctl: copy_from_user failed\n");
return(-EFAULT);
         printk("num = %d\n",num);
        buzzer_off(num);
    break;
} « end switch cmd »
    return 0;
 « end buzzer_ioctl »
```

# 而以下是在 ioctl 中有調用到的函數。

```
static void buzzer_off(int buzzer_num)
      //int gpj2dat,gpj3dat;
switch(buzzer_num)
            case 1://buzzer1
                 printk("buzzer_off\n");
gpio_direction_output(PIN,0);
           break;
case 2://buzzer3
printk("buzzer_off\n");
gpio_direction_output(PIN2,0);
                  break;
            default:
                  break;
static void buzzer_on(int buzzer_num)
      //int gpj2dat,gpj3dat;
switch(buzzer_num)
            case 1://buzzer1
   printk("buzzer_on\n");
   gpio_direction_output(PIN,1);
            break;
case 2://buzzer3
printk("buzzer_on\n");
                  gpio_direction_output(PIN2,1);
                  break;
            default:
                 break;
```

13

#### (6). Test 執行測試檔

建立一 C 語言執行測試檔案,來與 Kernel 互相連結,在 test 檔裡可以清楚看到蜂鳴器需要使用的 operation 是 open 函數及 read 函數;而 open 在 Kernel 裡的 /dev 下 buzzer 此裝置後,Exynos 4412 才可使用 pin 腳(pin 2、pin 13)進行發送及接收訊號;在 while 迴圈中使用 read 函數將超音波感測器的 feed back 回饋訊號傳到變數 buf,再將其列印到 console 上,其中 feed back 訊號已經由 Kernel 中換算成距離單位,若可以印出距離單位的數值,表示開啟裝置、讀取數值成功,傳至 console 也成功,若否,則 ret 檢查用的變數,會 exit。

```
15
    int main(int argc, char *argv[])
16
17
              int fd;
18
              int val = -1;
19
               int num = 1;
20
              fd= open (DEVICE BLTEST, O RDONLY); //opendev
21
              if(fd<0){
22
                   perror ("can not open device");
23
                   exit(1);
24
25
              while (1) {
26
                   printf("please select number to control buzzer\n");
                   printf("1:buzzer-1: 2:buzzer-2: 3:exit : ->");
27
                  scanf("%d", &val);
printf("\n");
28
29
30
                   if(val !=3) {
31
                       printf("select led on or off: 1:ON 3:OFF: ->");
                       scanf("%d", &num);
printf("\n");
33
34
35
                   switch (val) {
36
                            if (num == BUZZER ON)
                               ioctl(fd,BUZZER_ON,&val);
39
                            else if(num == BUZZER OFF)
40
                                ioctl(fd,BUZZER OFF,&val);
41
42
                           break;
43
                        case 2:
44
                            if (num == BUZZER ON)
45
                               ioctl(fd,BUZZER ON,&val);
46
                            else if (num == BUZZER OFF)
47
                               ioctl(fd,BUZZER OFF,&val);
48
49
                        case 3:
50
                           close (fd);
51
                       default:
52
                           return 0:
53
54
55
               //close(fd);
              return 0;
57
58
```

2. Infrared(紅外線感測器)部分

#### (1). 使用接腳

在紅外線感測器上,分配的腳位為 Pin 6、Pin 8 及 Pin 10 腳

```
#define PIN EXYNOS4_GPX0(2) //pin6
#define BLING EXYNOS4_GPX0(3) //pin8
#define LED EXYNOS4_GPX0(6) //LED pin10
```

(2). 使用主編號及裝置名稱

```
#define DEVICE_MAJOR 233
#define DEVICE_NAME "infrared"
```

(3). 程式進入點

進入核心底層後,Server 會先進入 init()內將暫存器開啟、建立需使用的模組 (buzzer),及給予 Major 號碼提供註冊;再離開 Kernel 時,會進入 exit()裡面將原本建立及註冊的資料做一個清除的動作。

```
static struct file_operations infrared_fops =
{
   owner : THIS_MODULE,
   read : infrared_read,
   open : infrared_open,
   unlocked_ioctl : infrared_ioctl,
   release : infrared_release,
};
```

使用 infrared init 函式進行裝置建立與註冊

```
static struct class *infrared_class;
static int __init infrared_init(void)
    int ret;
/* DID DU DEVICE_MAJOR, DEVICE_NAME */
ret = register_chrdev(DEVICE_MAJOR, DEVICE_NAME, &infrared_fops);
        printk(KERN_WARNING "Can't get major %d\n", DEVICE_MAJOR);
        return ret;
    printk("Infrared driver register success!\n");
    infrared_class = class_create(THIS_MODULE, "Infrared");
    if (IS_ERR(infrared_class))
        printk(KERN_WARNING "Can't make node %d\n", DEVICE_MAJOR);
        return PTR_ERR(infrared_class);
    device_create(infrared_class, NULL, MKDEV(DEVICE_MAJOR, 0), NULL, DEVICE_NAME);
    printk("Infrared driver makes node successfully!\n");
} « end infrared_init
static void __exit infrared_exit(void)
    device_destroy(infrared_class,MKDEV(DEVICE_MAJOR, 0));
    class_destroy(infrared_class);
    printk("Infrared driver remove node successfully!\n");
    gpio_free(PIN)
    unregister_chrdev(DEVICE MAJOR, DEVICE NAME)
    printk("Infrared driver released successfully!\n");
module_init(infrared_init);
module_exit(infrared_exit);
```

#### (4). 開啟裝置

在 open 函數中先使用變數來檢查 PIN 變數是否可以使用,加上 if()判斷式,若不能創立則發出"PIN1 fail"的訊息,並將資料釋放 (gpio free)。

```
static int infrared_open(struct inode *inode, struct file *filp)
    /*22122 GPIO 222}*/
    int ret;
printk("open in kernel\n");
    /*22122 GPIO 222}*/
    gpio_free (PIN);
    ret=gpio_request(PIN,DEVICE_NAME);
    if(ret<0)
        printk(KERN_EMERG "%d failed !\n",PIN);
printk(KERN_INFO "%s: %s unable to get TRIG gpio\n", DEVICE_NAME, __func__ );
        gpio_free(PIN);
        return ret;
    // Set gpios directions
    //s3c_gpio_cfgpin(PIN, S3C_GPIO_INPUT); //@NPIN@}@t@m@ @@AG@O@@@\@@
    printk ("<1>----BLING open----\n");
    gpio_free (BLING);
ret = gpio_request(BLING, "BLING");
    if (ret<0){</pre>
        printk("<1> ---ret error---");
        ret = -EBUSY;
        return(ret);
    gpio_direction_output(BLING,0);
    /* ---- D] Dw L E D---- */
printk("<1>----LED open-----\n");
    gpio_free (LED);
    ret = gpio_request(LED, "LED");
    if (ret<0){</pre>
        printk("<1> ---ret error---");
         ret = -EBUSY;
        return(ret);
    gpio_direction_output(LED, 0);
    return 0;
} « end infrared open »
```

#### (5). 腳位控制

有關蜂鳴器驅動程式是使用 GPD2 的 I/O 腳位來實現,透過 ioctl 的指令中的 cmd 去控制蜂鳴器開或關與發出長短音,以下是部分程式碼。

```
static long infrared_ioctl(struct file *file, unsigned int cmd, unsigned long arg){
    int ret;
    //int num;
printk("cmd=%d\n",cmd);
    switch (cmd){
        case 0:
            mode = cmd;
printk ("<1>----case 0_ warming condition----\n");
            break:
        case 1:
            mode = cmd:
             printk ("<1>----case 1_ party condition----\n");
             break;
        default : // APPDD arg = 3 ---> mode = 3
            ret = copy_from_user(&mode, (int *)arg, sizeof(int));
            if (ret != 0){
    printk ("<1>---gpio_ioctlEGcopy from user failed----\n");
                 return (-EFAULT);
            }
            break;
    gpio_set_value(LED, 0);
    gpio_set_value(BLING, 0);
    return 0:
```

#### (6). 裝置讀取

在 open 結束後,則會到 read 函數中進行讀取數值的動作,放到 value 位置,並傳送至上層(copy to user)。

```
static ssize_t infrared_read(struct file *file, int* value, size_t size, loff_t *off)
    size_t ret;
    if (mode == 0){ //warming
        int data:
        printk("<1> reading _data = %d\n", gpio_get_value(PIN));
        local_irq_disable();
        data = gpio_get_value(PIN);
        gpio_set_value(LED, gpio_get_value(PIN));
        local_irq_enable();
        ret = copy_to_user(&value, (int *)data, sizeof(data));
        //ret = copy_to_user(value, data, sizeof(data));
        if (ret<0){
            printk("<1> ---ret error---");
    }else if (mode == 1){ //party
        int data;
        printk("<1> reading _data = %d\n", gpio_get_value(PIN));
        local_irq_disable();
        data = gpio_get_value(PIN);
        gpio_set_value(BLING, gpio_get_value(PIN));
        local_irq_enable();
        ret = copy_to_user(&value, (int *)data, sizeof(data));
        //ret = copy_to_user(value, &data, sizeof(data));
        if (ret<0){
           printk("<1> ---ret error---");
    }else{;
        gpio_set_value(LED, 0);
        gpio_set_value(BLING, 0);
    return 0;
} « end infrared_read »
```

#### (7). Test 執行測試檔

建立一 C 語言執行測試檔案,來與 Kernel 互相連結,在 test 檔裡可以清楚看到蜂鳴器需要使用的 operation 是 open 函數及 read 函數;而 open 在 Kernel 裡的 /dev 下 buzzer 此裝置後,Exynos 4412 才可使用 pin 腳(pin 2、pin 13)進行發送及接收訊號;在 while 迴圈中使用 read 函數將超音波感測器的 feed back 回饋訊號傳到變數 buf,再將其列印到 console 上,其中 feed back 訊號已經由 Kernel 中換算成距離單位,若可以印出距離單位的數值,表示開啟裝置、讀取數值成功,傳至 console 也成功,若否,則 ret 檢查用的變數,會 exit。

```
int main(int argc, char *argv[])
         int infret = -1;
         int val, condition;
         int freq = 1200;
         open_infrared();
while(1)
             printf("please select number for condition\n");
printf("1:Motion detection 2:situational mode 3:exit : ->");
scanf("%d", &condition);
printf("\n");
              switch(condition){
                      ioctl(infraredfd,0,infrared_OPEN);
                      break;
                  case 2:
                      ioctl(infraredfd,1,infrared_OPEN);
                      break;
                  case 3:
                      close_infrared();
                  default:
                      return 0:
              //infraredfd detection
              infret = read(infraredfd, &val, sizeof(val));
             if(infret<0){
                  printf("Reading infrared data error!\n");
              if (val == 1){
    printf("Alert ! Someone detected!\n");
    printf("LED ON! \n");
              }else{
                  printf("no one!\n");
printf("Buzzer OFF! \n");
              sleep(2);
         } « end while 1 »
         return 0:
} « end main »
static void open_infrared(void){
     infraredfd = open(DEVICE_INFRARED,O_RDONLY); //Open infrared device
     if (infraredfd < 0){
          perror("Open Infrared device failed!!\n");
          exit(1);
     //return infraredfd;
static void close_infrared(void){
     if (infraredfd > 0){
          close(infraredfd);
          infraredfd = -1;
    }
}
```

3. Passive Buzzer (無源蜂鳴器)部分

#### (1). 使用接腳

在無源蜂鳴器上,預計設計成兩個蜂鳴器搭配開啟,在腳位的部分,分配的腳位為 Pin 15 腳,說明如下圖所示:

```
#define MOTOR_PWM_GPIO EXYNOS4_GPD0(3) //pin15
```

#### (2). 使用主編號及裝置名稱

```
#define DEVICE_MAJOR 238
#define DEVICE_NAME "passive_buzzer"

#define MAGIC_NUMBER 'L'
#define PWM_IOCTL_SET_FREQ __IO(MAGIC_NUMBER, 1)
#define PWM_IOCTL_STOP __IO(MAGIC_NUMBER, 0)
#define PWM_IOCTL_INPUT_FREQ | _IO(MAGIC_NUMBER, 2)
#define PWM_IOCTL_SET_FREQ_TIME __IO(MAGIC_NUMBER, 3)
```

#### (3). 程式進入點

進入核心底層後,Server 會先進入 init()內將暫存器開啟、建立需使用的模組(buzzer),及給予 Major 號碼提供註冊;再離開 Kernel 時,會進入 exit()裡面將原本建立及註冊的資料做一個清除的動作。

```
static struct class *passive_buzzer_class;
static int __init passive_buzzer_init(void)
    int retval;
    //int ret;
    retval = register_chrdev(DEVICE_MAJOR,DEVICE_NAME,&passive_buzzer_fops);
    if(retval < 0)</pre>
        printk(KERN_WARNING "Can't get major %d\n", DEVICE_MAJOR);
        return retval;
    }
    printk("passive_buzzer driver register success!\n");
    passive_buzzer_class = class_create(THIS_MODULE, "passive_buzzer");
        if (IS_ERR(passive_buzzer_class))
        printk(KERN_WARNING "Can't make node %d\n",DEVICE_MAJOR);
                 return PTR_ERR(passive_buzzer_class);
    device create(passive buzzer class, NULL, MKDEV(DEVICE MAJOR, 0), NULL, DEVICE NAME);
    printk("passive_buzzer driver make node success!\n");
} « end passive_buzzer_init »
static void __exit passive_buzzer_exit(void)
    gpio_free(MOTOR_PWM_GPIO);
    device_destroy(passive_buzzer_class,MKDEV(DEVICE_MAJOR, 0));
   class_destroy(passive_buzzer_class);
    printk("passive_buzzer driver remove node success!\n");
unregister_chrdev(DEVICE_MAJOR, DEVICE_NAME);
    printk("passive_buzzer driver release success!\n");
module_init(passive_buzzer_init);
module_exit(passive_buzzer_exit);
```

#### (4). 開啟裝置

在 open 函數中先使用變數來檢查 PIN 變數是否可以使用,加上 if()判斷式,若不能創立則發出"PIN1 fail"的訊息,並將資料釋放 (gpio free)。

```
static int passive_buzzer_open(struct inode *inode, struct file *filp)
{ /*22122 GPIO 222}*/
    int ret1 = -1;
    int ret2 = -1;
    ret1 = gpio_request( MOTOR_PWM_GPIO, DEVICE_NAME);
    if( ret1 < 0 ) // request pin 2
        printk( KERN_INFO "%s: %s unable to get TRIG gpio\n", DEVICE_NAME, __func__ );
        gpio_free(MOTOR_PWM_GPIO);
        return(ret1);
    ret2 = gpio_direction_output( MOTOR_PWM_GPIO, 0);
    if( ret2 < 0 ) // Set pin 2 as output with default value 0</pre>
        printk( KERN_INFO "%s: %s unable to set TRIG gpio as output\n", DEVICE_NAME, __func__ );
ret2 = -EBUSY;
        return(ret2);
    s3c_gpio_cfgpin(MOTOR_PWM_GPIO, S3C_GPIO_OUTPUT);
    return 0;
} « end passive_buzzer_open »
```

### (5). 腳位控制

有關蜂鳴器驅動程式是使用 GPD2 的 I/O 腳位來實現,透過 ioctl 的指令中的 cmd 去控制蜂鳴器開或關與發出長短音,以下是部分程式碼。

```
static long passive_buzzer_ioctl(struct file *file, unsigned int cmd, unsigned long arg, unsigned long duration)
     int delay1_us, sing_time;
     int q;
int ret = 0;
    switch (cmd) {| case PMM_IOCIL_SET_FREQ: if (arg == 0) return -EINVAL;
                 printk("<1>passive_buzzer_CTL\n");
delay1_us = (int)arg;
printk("cmd = %d\n freq = %d\n", cmd, delay1_us);
                for(q=50;q>0;q--){
    gpio_direction_output(MOTOR_PWM_GPIO, 1);
    ude1sy(delay1_us);
    gpio_direction_output(MOTOR_PWM_GPIO, 0);
    udelay(PWM_IN_FREQ - delay1_us);
           case PWM_IOCTL_STOP;
          case PWM_IOCTL_INPUT_FREQ:
if (arg == 0)
                 if (arg == 0)
return -EINVAL;
                 printk("(1)passive_buzzer_CTL\n");
delay1_us = (int)arg;
printk("cmd = %d\n freq = %d\n", cmd, delay1_us);
                 for(q=10;q>0;q--){
    gpio_direction_output(MOTOR_PWM_GPIO, 1);
    ndalay(delay1_us);
    gpio_direction_output(MOTOR_PWM_GPIO, 0);
    udelay(PWM_IN_FREQ - delay1_us);
              case PWM_IOCIL_SET_FREQ_TIME:
                     printk("<1>passive_buzzer_SET\n");
                      delay1_us = (int)arg;
                     int ret;
                     ret = copy_from_user(&sing_time, (int*)duration, sizeof(int));
                     printk("sing_time = %d\n",sing_time);
printk("cmd = %d\n freq = %d\nduration = %d\n", cmd, delay1_us,sing_time);
                     for(q=sing_time;q>0;q--){
                            gpio_direction_output(MOTOR_PWM_GPIO, 1);
ndelay(delay1_us);
                            gpio_direction_output(MOTOR_PWM_GPIO, 0);
udelay(PWM_IN_FREQ - delay1_us);
              default:
                     break;
      } « end switch cmd >
} « end passive_buzzer_ioctl »
```

#### (6). Test 執行測試檔

建立一 C 語言執行測試檔案,來與 Kernel 互相連結,在 test 檔裡可以清楚看到蜂鳴器需要使用的 operation 是 open 函數及 read 函數;而 open 在 Kernel 裡的 /dev 下 buzzer 此裝置後,Exynos 4412 才可使用 pin 腳(pin 2、pin 13)進行發送及接收訊號;在 while 迴圈中使用 read 函數將超音波感測器的 feed back 回饋訊號傳到變數 buf,再將其列印到 console 上,其中 feed back 訊號已經由 Kernel 中換算成距離單位,若可以印出距離單位的數值,表示開啟裝置、讀取數值成功,傳至 console 也成功,若否,則 ret 檢查用的變數,會 exit。

```
int main(int argc, char *argv[])
           int melody[] = {
    // HAPPY BIRTHDAY SONG
    // https://github.com/hibit-dev/buzzer/blob/master/src/other/happy_birthday/happy_birthday.ino
                 NOTE_C4,4, NOTE_C4,8, NOTE_D4,4, NOTE_C4,4,
NOTE_F4,4, NOTE_C4,2, NOTE_C4,8, NOTE_C4,8,
NOTE_D4,4, NOTE_C4,4, NOTE_C4,8, NOTE_F4,2,
NOTE_C4,4, NOTE_C4,8, NOTE_C5,4, NOTE_A4,4, NOTE_F4,4, NOTE_E4,4,
NOTE_D4,4, REST.1, NOTE_C5,4, NOTE_A8,8, NOTE_A4,4, NOTE_F4,4,
NOTE_G4,4, NOTE_F4,2,
           int notes = sizeof(melody) / sizeof(melody[0]) / 2;
fd - open("/dev/passive_buzzer", 0);
if(fd<0)(</pre>
                 perror("can not open device fileL /dev/passive_buzzer\n");
            while(1){
                 printf("please select number to control passive_buzzer\n");
printf("l:Set Frequence 2:Echo from 200-5000HZ 3:sing a song 4:exit -> ");
scanf("%d", &val);
//printf("\n");
                  switch(val) {
                       return 0
                       return 0;
case 1:
    printf("1: pleae set frequence \n");
    scanf("%d",&frequence);
    freq = (int)frequence*1000;
    //printf("4: pleae set duration \n");
    //scanf("%d",&duration);
    //duration = (int)duration*100;
    printf("
                             ioctl(fd, PWM_IOCTL_INPUT_FREQ, freq,0);
                              //usleep(200000);
                                   for(i=200:i<=8000:i=i+50){
                                      freq = (int)i*1000;
                                       printf("--
                                         ioctl(fd, PWM_IOCTL_INPUT_FREQ, freq,0);
                                         //usleep(200000);
                            case 3:
                                   for (thisNote = 0; thisNote < notes * 2; thisNote = thisNote + 2) {
                                         int tempo - 120;// change this to make the song slower or faster int wholenote = (60000 * 4) / tempo;
                                          int noteDuration;
                                          // calculates the duration of each note
                                          divider = melody[thisNote + 1];
                                          if (divider > 0) {
                                         if (divider > 0) {
    // regular note, just proceed
    noteDuration = wholenote / divider;
} else if (divider < 0) {
    // dotted notes are represented with negative durations!!
    noteDuration = wholenote / abs(divider);
    noteDuration *= 1.5; // increases the duration in half for dotted notes</pre>
                                          //for frequence
                                          i=melody[thisNote];
                                          freq - (int)i*1000;
                                         printf("----\n");
                                         printf("freq = %d, duration = %d\n", freq, noteDuration);
                                         //ioctl(fd, PWM_IOCTL_SET_FREQ_TIME, freq,noteDuration);
ioctl(fd, PWM_IOCTL_INPUT_FREQ, freq,0);
usleep(noteDuration*400);
                            default:
                                   break;
              return 0;
```

# (二) JNI 程式設計

Java Native Interface (JNI)是可以讓 Java applications 跟用其它語言 (諸如 C,C++)寫成的應用程式或程式庫互相呼叫使用。在 java 下的 C/C++程式如果要使用 Java 的資料型別,型別名稱前必須要加上「j」,例如:「int」變成「jint」,「long」變成「jlong」,「String」變成「jstring」,都是小寫字母。

#### 1. Buzzer (有源蜂鳴器)部分

將原本的 C 語言轉成類似函式的功能,提供 Java 層來呼叫,也就是 Java Call C,以下是藉由 javah 指令,從 java 做出的 header(.h)檔案。

```
/* DO NOT EDIT THIS FILE - it is machine generated */
      #include <jni.h>
     /* Header for class tw com dmatek buzzer Linux buzzer */
   ##ifndef _Included_tw_com_dmatek_buzzer_Linux_buzzer #define _Included_tw_com_dmatek_buzzer_Linux_buzzer
   #ifdef _cplusplus
=extern "C" {
    -#endif
10
      * Class:
                    tw com dmatek buzzer Linux buzzer
11
      * Method:
                    openbuzzer
      * Signature: ()I
14
      JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1buzzer_openbuzzer
15
        (JNIEnv *, jclass);
16
17
18
19
      * Class:
                     tw com dmatek buzzer Linux buzzer
20
      * Method:
                     closebuzzer
21
      * Signature: ()I
22
23
      JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1buzzer_closebuzzer
24
        (JNIEnv *, jclass);
26
      * Class:
27
                    tw com dmatek buzzer Linux buzzer
      * Method:
                    send
29
      * Signature: (II)I
      JNIEXPORT jint JNICALL Java tw com dmatek buzzer Linux 1buzzer send
        (JNIEnv *, jclass, jint, jint);
   #ifdef _cplusplus
34
      -#endif
36
      #endif
```

#### 而針對做出的.h 檔案,進行函數的實際實作,相關的檔案如下。

```
#include <string.h>
     #include <jni.h>
     //#include "tw_com_dmatek_buzzer_Linux_buzzer.h"
     #include <stdio.h>
     #include <stdlib.h> //system
     #include <fcntl.h>
     #include <errno.h>
     #include <unistd.h>
     #include ux/delay.h>
    #include <sys/ioctl.h>
     #include "buzzer jni.h"
                                                 對應的 driver 在 Kernel 中註冊的名稱。
     #define BUZZER TEST 3
                             "/dev/buzzer"
     #define DEVICE BLTEST
16
17
     JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1buzzer_openbuzzer
18
        (JNIEnv* env, jclass thiz)
           fd= open (DEVICE BLTEST, O RDONLY);
          return fd;
22
23
      JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1buzzer_closebuzzer
        (JNIEnv* env, jclass thiz)
26
            close (fd);
27
28
29
30
31
       JNIEXFORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_lbuzzer_send (JNIEnv* env, jclass thiz, jint buzzer_num, jint on_off)
            ioctl(fd,on_off,&buzzer_num);
34
            return 0;
```

接下來需要開啟 VM 來將資料做一個輸出轉檔的動作;首先要進入 jni 的資料夾中,檢查附檔名 Androidmk 檔及原檔是否正確;並下指令(ndk-build)讓原檔進行 Compile 動作,得到 libxxx.so 檔案。

編譯產生 so 檔後,還需要 eclipse 來模擬 app 使用層,並得到 apk 檔案;在要開啟的資料夾中,必須包含環境變數(env)及固定資料夾(src、res等),才可以去執行模擬。

#### 2. infrared 部分

將原本的 C 語言轉成類似函式的功能,提供 Java 層來呼叫,也就是 Java Call C,以下是藉由 javah 指令,從 java 做出的 header(.h)檔案。

```
/* DO NOT EDIT THIS FILE - it is machine generated */
/* Header for class tw_com_dmatek_buzzer_Linux_infrared */
#ifndef _Included_tw_com_dmatek_buzzer_Linux_infrared
#define _Included_tw_com_dmatek_buzzer_Linux_infrared
#ifdef _cplusplus
extern "C" {
#endif
#z
 * Class: tw_com_dmatek_buzzer_Linux_infrared

* Method: openinfrared

* Signature: ()I
JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_linfrared_openinfrared
  (<u>JNIEnv</u> *, jclass);
 * Class: tw_com_dmatek_buzzer_Linux_infrared
* Method: closeinfrared
* Signature: ()I
*/
JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_linfrared_closeinfrared
   (<u>JNIEnv</u> *, jclass);
/*
* Class:
                 tw_com_dmatek_buzzer_Linux_infrared
ioctl_infrared
 * Method:
  * Signature: (I)I
JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1infrared_ioctl_1infrared
  (<u>JNIEnv</u> *, jclass, jint);
 /*

* Class: tw_com_dmatek_buzzer_Linux_infrared

* Method: read_infrared

* Signature: ()I

*/
JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_1infrared_read_1infrared
  (<u>JNIEnv</u> *, jclass);
#ifdef __cplusplus
#endif
#endif
```

而針對做出的.h 檔案,進行函數的實際實作,相關的檔案如下。

```
#include (string.h)
#include (jni.h)
#include (stdio.h)
#include (stdib.h) //system
#include (fcntl.h)
#include <error.h>
#include <unistd.h>
//#include finux/delay.h>
#include <sys/ioctl.h>
#define DEVICE_BLTEST "/dev/infrared"
#define infrared_OPEN 1
#define infrared_STOP 0
static int infraredfd = -1;
int fd,infret,val;
INTEXPORT jint INICALL Java tw com dmatek buzzer Linux 1infrared openinfrared
   (JNIEnv * env, jclass thiz)
     fd= open(DEVICE_BLTEST,O_RDONLY);
return fd;
INIEXPORT jint INICALL Java_tw_com_dmatek_buzzer_Linux_linfrared_closeinfrared
 (JNIEnv * env, jclass thiz)
       printf("EXIT\n");
       close(fd);
return 0;
JNIEXPORT jint JNICALL Java_tw_com_dmatek_buzzer_Linux_linfrared_ioctl_linfrared
  (JNIEnv * env, jclass thiz, jint condition_num)
       ioctl(fd,condition_num,infrared_OPEN);
INTEXPORT jint INICALL Java_tw_com_dmatek_buzzer_Linux_linfrared_read_linfrared
  (JNIEnv * env, jclass thiz)
       infret = read(fd, &val, sizeof(val));
       return val;
```

3. Passive Buzzer (無源蜂鳴器)部分

將原本的 C 語言轉成類似函式的功能,提供 Java 層來呼叫,也就是 Java Call C,以下是藉由 javah 指令,從 java 做出的 header(.h)檔案。

```
| The color of the continuation of the color of the color
```

而針對做出的.h 檔案,進行函數的實際實作,相關的檔案如下。

```
NOTE C4,4, NOTE C4,0, NOTE D4,0, NOTE C4,0, 
                       int notes - sizeof(melody) / sizeof(melody[0]) / 2;
                       #define DEVICE BLTEST "/dev/passive buzzer"
                     Int fd;
INTEMPORT jint JNICALL Java_com_ispan_android_piano_Linux_lpassive_lbuzzer_open_lpassive_lbuzzer
(JNIENY* env, jclass thiz)
                       JNIEXFORT jint JNICALL Java_com_ispan_android_piano_Linux_ipassive_1buzzer_close_1passive_1buzzer (JNIEnv * env, jclass thiz)
                     JNIEMPORT jint JNICALL Java_com_ispan_android_piano_Linux_lpassive_lbuzzer_send_lpassive_lbuzzer
(JNIEMv * env, jolass thiz, jint frequence, jint duration)
                     ioctl(fd,FMM_IOCTL_INFUT_FREQ,frequence,0);
return 0;
JNIEXPORT jint JNICALL Java_com_ispan_android_piano_Linux_lpassive_lbuzzer_play_lrun_lpassive_lbuzzer (JNIEnv * env, jclass thiz)
                     icetl(fd, PWM_IOCTL_INPUT_FREQ, freq, 0);
JNIEXFORT jint JNICALL Java_com_ispan_android_piano_Linux_lpassive_lbuzzer_play_lmusic_lpassive_lbuzzer 
(JNIENV * env, jclass thiz,jint frequence)
                     for(thisNote = 0; thisNote < notes * 2; thisNote = thisNote + 2) {
   int tempo = 120;// change this to make the song slower or faster
   int wholenote = (60000 * 4) / tempo;</pre>
                                          int noteDuration;
                                        int noteDuration;
// calculates the duration of each note
int divider = melody[thisNote + 1];
if (divider > 0) {
    // regular note, just proceed
                                         noteDuration - wholenote / divider;
} else if (divider < 0) {
// dotted notes are represented with negative durations!!
                                                     noteDuration - wholenote / abs(divider);
noteDuration *= 1.5; // increases the duration in half for dotted notes
                                          //for frequence
                                       //for frequence
int i=melody[thisNote];
int freq = (int)i*1000;
//ioctl(fd, prm_loctL_SET_FREO_TIME, freq,noteDuration);
ioctl(fd, prm_locTL_INPUT_FREO, freq,0);
usleep(noteDuration*400);
```

接下來需要開啟 VM 來將資料做一個輸出轉檔的動作;首先要進入 jni 的資料夾中,檢查附檔名 Androidmk 檔及原檔是否正確;並下指令(ndk-build)讓原檔進行 Compile 動作,得到 libxxx.so 檔案。

編譯產生 SO 檔後,還需要 eclipse 來模擬 app 使用層,並得到 apk 檔案;在要開啟的資料夾中,必須包含環境變數(env)及固定資料夾(src、res等),才可以去執行模擬。

## (三) Application-MyCombine.apk(第一支 Android App 程式)

#### 1. 主程式

其中使用執行緒做為各動作處理,如下所示:

```
public class BuzzerActivity extends Activity {
   private static final String TAG = BuzzerActivity.class.getSimpleName();
   public int state1=0, state2=0;
   public int buzzer_on = 1;
   public int buzzer_off = 3;
   public int fd = 0;
       private Handler mThreadHandler:
       private HandlerThread mThread;

/** Called when the activity is first created. */
       @Override
       public void OnCreate(Bundle savedInstanceState) {
              super.onCreate(savedInstanceState);
setContentView(R.layout.main);
Log.d(TAG, "find View");
findViews();
Log.d(TAG, "Set Listener");
setListeners();
              fd = Linux_buzzer.openbuzzer();
                      Log.d(TAG,<mark>"open device fail!");</mark>
Toast.makeText(BuzzerActivity.this, <mark>"open device fail!"</mark>,Toast.LENGTH_SHORT ).show();
//finish();
                             Toast.makeText(BuzzerActivity.this, "open device success!", Toast.LENGTH_SHORT ).show();
                            Log.d(TAG, "open device success!");
              fd = Linux_infrared.openinfrared();
                      Log.d(TAG,<mark>"open infrared device fail!"</mark>);
Toast.makeText(BuzzerActivity.this, <mark>"open infrared device fail!"</mark>,Toast.LENGTH_SHORT ).show();
                        //finish():
                             Log.d(TAG, "open device success!");
              //let Worker standby, and wait for mission
mThread = new HandlerThread("name");
//start detection
              mThread.start();
              mThreadHandler = new Handler(mThread.getLooper());
      } « end onCreate »
   private Handler mUI Handler = new Handler(){
      public void habdlerMessage(Message msg)[
            super.handleMessage(msg);
//mmtxt_infrared.setText("read data=",Integer.toString(msg.getData().getInt("read",0)));
mmtxt_infrared.setText(String.valueOf(Linux_infrared.read_infrared()));
   };
   private static boolean top = false;
private Runnable r1 = new Runnable(){
         public void run(){
              int read_value = Linux_infrared.read_infrared();
Bundle readBundle = new Bundle();
readBundle.putInt("read", read_value);
msg.setData(readBundle);
mUI_Handler.sendMessage(msg);
                                //Toast.makeText(Buzzer_Control_Activity.this, Integer.toString(msg.getData().getInt("read",0)),Toast.LENGTH_SHORT ).show();
                               if(read_value ==0 && getTitle()=="Warming Sensor Start!!!"){
   int i;
   for(i=0;i<5;i++){
        Linux_buzzer.send(1,buzzer_on);
        Linux_buzzer.send(2,buzzer_on);
        Thread.sleep(100);
        Linux_buzzer.send(1,buzzer_off);
        Linux_buzzer.send(2,buzzer_off);
        Thread.sleep(100);
}</pre>
                                Thread.sleep(2000);
                             } a end try ** catch (InterruptedException e) {
   // TODO Auto-generated catch block
   e.printStackTrace();
  } w end while |top w
} w end run w
} w end {anon class_73} » ;
```

```
private Button mbutton1;
  private Button mbutton2;
  private Button mbutton3;
  private Button mbutton4;
  private Button mbutton5;
  private TextView view_welcome;
  private Button mmyButton_WARMING;
  private Button mmyButton_PARTY;
  private Button mmyButton_RESET;
  private TextView mmtxt_infrared;
//取得畫面的按鈕物件的控制權
  private void findViews(){
       mbutton1 = (Button) findViewById(R.id.myButton1);
       mbutton2 = (Button) findViewById(R.id.myButton1_1);
mbutton3 = (Button) findViewById(R.id.myButton2);
       mbutton4 = (Button) findViewById(R.id.myButton2_1);
mbutton5 = (Button) findViewById(R.id.myButton3);
       mmyButton_WARMING = (Button)findViewById(R.id.myButton_WARMING);
       mmyButton_PARTY = (Button)findViewById(R.id.myButton_PARTY);
mmyButton_RESET = (Button)findViewById(R.id.myButton_reset);
       view_welcome = (TextView) findViewById(R.id.text);
       mmtxt infrared = (TextView)findViewById(R.id.textView infrared);
//Listen for button clicks
  private void setListeners(){
       mbutton1.setOnClickListener(button1_listener);
       mbutton1.setOnClickListener(button2_listener);
mbutton3.setOnClickListener(button3_listener);
       mbutton4.setOnClickListener(button4_listener);
mbutton5.setOnClickListener(button5_listener);
       mmyButton_WARMING.setOnClickListener(mmyButton_WARMING_listener);
       mmyButton_PARTY.setOnClickListener(mmyButton_PARTY_listener);
       mmyButton_RESET.setOnClickListener(mmyButton_RESET_listensr);
 private Button.OnClickListener mmyButton_WARMING_listener=new Button.OnClickListener(){
     public void onClick(View v){
              Toast.makeText(BuzzerActivity.this, "mmyButton_WARNING_listener",Toast.LENGTH_SHORT ).show();
             Linux_infrared.ioctl_infrared(0);
Linux_infrared.ioctl_infrared(0);
              setTitle("Warming Sensor Start!!!");
             top=false;
mThreadHandler.post(r1);
         }catch(Exception e)
              Toast.makeText(BuzzerActivity.this, "input_error", Toast.LENGTH_SHORT ).show();
    }
};
 public void onClick(View v){
             Toast.makeText(BuzzerActivity.this, "mmyButton_PARTY_listener", Toast.LENGTH_SHORT ).show();
//Linux_infrared_and_led.ioctl_infrared(3);
Linux_infrared.ioctl_infrared(1);
Linux_infrared.ioctl_infrared(1);
Linux_infrared.ioctl_infrared(1);
Linux_infrared.ioctl_infrared(1);
              setTitle("PARTY Sensor Start!!!");
              top=false;
              mThreadHandler.post(r1);
         }catch(Exception e){
              Toast.makeText(BuzzerActivity.this, "input_error", Toast.LENGTH_SHORT ).show();
         //mThreadHandler.post(r1);
.};
```

```
private Button.OnClickListener mmyButton_RESET_listensr=new Button.OnClickListener(){
    public void onClick(View v){
        try{
             Toast.makeText(BuzzerActivity.this, "mmyButton_RESET_listensr",Toast.LENGTH_SHORT ).show(); Linux_infrared.ioctl_infrared(3);//close all setTitle("Sensor Stop!!!");
             top=true
         }catch(Exception e){
             Toast.makeText(BuzzerActivity.this, "input_error", Toast.LENGTH_SHORT ).show();
};
private Button.OnClickListener button1_listener=new Button.OnClickListener(){
    public void onClick(View v){
         try{
    Toast.makeText(BuzzerActivity.this, "button1_listener", Toast.LENGTH_SHORT ).show();
             Linux_buzzer.send(1,buzzer_on);
         }catch(Exception e){
             Toast.makeText(BuzzerActivity.this, "input error", Toast.LENGTH_SHORT ).show();
}; private Button.OnClickListener button2_listener=new Button.OnClickListener(){
    public void onClick(View v){
         try{
    Toast.makeText(BuzzerActivity.this, "button2_listener", Toast.LENGTH_SHORT ).show();
    Linux_buzzer.send(1,buzzer_off);
         }catch(Exception e){
             Toast.makeText(BuzzerActivity.this, "input_error",Toast.LENGTH_SHORT ).show();
};
private Button.OnClickListener button3_listener=new Button.OnClickListener(){
    public void onClick(View v){
         try{
    Toast.makeText(BuzzerActivity.this, "button3_listener", Toast.LENGTH_SHORT ).show();
    Linux_buzzer.send(2, buzzer_off);
}
        }catch(Exception e){
              Toast.makeText(BuzzerActivity.this, <mark>"input_error"</mark>,Toast.LENGTH_SHORT ).show();
        }
.};
private Button.OnClickListener button4_listener=new Button.OnClickListener(){
     public void onClick(View v){
               Toast.makeText(BuzzerActivity.this, <mark>"button4_listener"</mark>,Toast.LENGTH_SHORT ).show();
         Linux_buzzer.send(2,buzzer_on);
}catch(Exception e){
               Toast.makeText(BuzzerActivity.this, "input_error", Toast.LENGTH_SHORT ).show();
private Button.OnClickListener button5_listener=new Button.OnClickListener(){
     public void onClick(View v){
          try{
    Toast.makeText(BuzzerActivity.this, "button5_listener", Toast.LENGTH_SHORT ).show();
    Linux_buzzer.closebuzzer();
               if(mThreadHandler != null){
                   mThreadHandler.removeCallbacks(r1);
               if(mThread != null){
                   mThread.quit();
               finish();
          }catch(Exception e){
               Toast.makeText(BuzzerActivity.this, "input_error", Toast.LENGTH_SHORT ).show();
};
```

```
private void openOptionDiaglog(){
         Toast.makeText(BuzzerActivity.this, "about Buzzer", Toast.LENGTH_SHORT ).show();
         //to create warming box
         new AlertDialog.Builder(BuzzerActivity.this)
         .setTitle(R.string.about title)
         .setMessage(R.string.about_msg)
         .setPositiveButton("Confirm", new DialogInterface.OnClickListener() {
              @Override
              public void onClick(DialogInterface dialoginterface,int i){}
         .setNegativeButton(R.string.homepage_lebel, new DialogInterface.OnClickListener() {
              @Override
              public void onClick(DialogInterface dialog, int which) {
// TODO Auto-generated method stub
                  //Homepage
                  Uri uri = Uri.parse("http://tw.yahoo.com/");
Intent intent = new Intent(Intent.ACTION_VIEW,uri);
startActivity(intent);
         })
         .show();
    } « end openOptionDiaglog »
    protected static final int MENU_ABOUT = Menu.FIRST;
    protected static final int MENU_QUIT = Menu.FIRST+1;
    @Override
    public boolean onCreateOptionsMenu(Menu menu) {
         // TODO Auto-generated method stub
         // TODO AUTO-generated metrou studies menu.add(0,MENU_ABOUT,0,"開於").setIcon(android.R.drawable.ic_menu_help);
menu.add(0,MENU_QUIT,0,"結束").setIcon(android.R.drawable.ic_menu_close_clear_cancel);
         return super.onCreateOptionsMenu(menu);
    public boolean onOptionsItemSelected(MenuItem item) {
         // TODO Auto-generated method stub
         switch(item.getItemId()){
         case MENU ABOUT:
             openOptionDiaglog();
         case MENU_QUIT:
             finish();
             break;
         return super.onOptionsItemSelected(item);
    }
} « end BuzzerActivity »
```

#### 2. 呼叫程式

透過 Linuxc.java 去呼叫 JNI 相關函式

## 透過 Linuxc.java 去呼叫 JNI 相關函式

```
package tw.com.dmatek.buzzer;
import android.util.Log;

public class Linux_infrared {
    static{
        try{
            Log.i("JNI", "Try to load libinfared.so");

            System.loadLibrary("infared");
        }catch(UnsatisfiedLinkError ule){
            Log.i("JNI", "Warming: Could not load libinfared.so");
        }}

    public static native int openinfrared();
    public static native int closeinfrared();
    public static native int ioctl_infrared(int condition_num);
    public static native int read_infrared();
}
```

最後,從 VMware 編譯得到的 so 檔及 apk 檔,接下來就要放入 Samsung Exynos 4412 中;首先,要先在 4412 建立網路與 tftp32 做連接,測試成功,已可以取得封包。建立完連線後,必須把剛剛產出的 apk 檔及 libxxx.so 檔放入 Android 層相對應的資料夾下,使其載入使用 busybox 指令並下參數將 apk 檔案需放入/app 下,而 so 檔案則放入/lib 下,讀取 100%時表示已完成傳送。

# (四) Application-MyPiano.apk(第二支 Android App 程式)

#### 1. 主程式

```
public class MyPianoActivity extends Activity [
      private static final String TAG=MyPianoActivity.class.getSimpleName();
public int fd=0;
public int freq;
/** Called when the activity is first created. */
       @Override
       public void OnCreate(Bundle savedInstanceState) {
             super.onCreate(savedInstanceState);
setContentView(R.layout.main);
Log.d(TAG, "findView");
findViews();
Log.d(TAG, "Set Listenser");
             setListeners();
              fd = Linux_passive_buzzer.open_passive_buzzer();
             if(fd(0){
                    id<0){
Log.d(TAG,<mark>"open device fall!!");</mark>
Toast.makeText(MyPianoActivity.this, <mark>"open device fall!!"</mark>, Toast.LENGTH_SHORT).show();
             else
                    Log.d(TAG, "open device success!!");
Toast.makeText(MyPianoActivity.this, "open device success!!", Toast.LENGTH_SHORT).show();
                1
      }
      private Button mButton_run;
private Button mButton_music;
private Button mButton_exit;
private View view_fa_minus;
      private View view_fa_minus;

private View view_so_minus;

private View view_la_minus;

private View view_do;

private View view_re;

private View view_fa;

private View view_fa;

private View view_so;

private View view_so;
      private View view_la;
private View view_si;
       private void findViews(){
               mButton_run = (Button)findViewById(R.id.button_run);
mButton_music = (Button)findViewById(R.id.button_nusic);
                mButton_exit = (Button)findViewById(R.id.button_exit);
               view_fa_minus = (View)findViewById(R.id.buttom_fa_minus);
view_so_minus = (View)findViewById(R.id.buttom_so_minus);
               view_so_minus = (view)findViewById(R.id.buttom_so_minus);
view_la_minus = (View)findViewById(R.id.buttom_la_minus);
view_si_minus = (View)findViewById(R.id.buttom_si_minus);
view_do = (View)findViewById(R.id.buttom_do);
view_re = (View)findViewById(R.id.buttom_re);
                view_mi = (View)findViewById(R.id.buttom_mi)
               view_fa = (View)findViewById(R.id.buttom_fa);
view_so = (View)findViewById(R.id.buttom_so);
                view_la = (View)findViewById(R.id.buttom_la);
                view_si = (View)findViewById(R.id.buttom_si);
       private void setListeners(){
               Log.d(TAG, "Set Listenser")
               mButton_run.setOnClickListener(mButton_run_listener);
mButton_music.setOnClickListener(mButton_music_listener);
                mButton_exit.setOnClickListener(mButton_exit_listener);
               view_fa_minus.setOnClickListener(view_fa_minus_listener);
view_so_minus.setOnClickListener(view_so_minus_listener);
view_la_minus_setOnClickListener(view_la_minus_listener);
               view_ia_minus.setOnClickListener(view_ia_minus_listener);
view_si_minus.setOnClickListener(view_si_minus_listener);
view_do.setOnClickListener(view_do_listener);
view_re.setOnClickListener(view_re_listener);
view_mi.setOnClickListener(view_mi_listener);
               view_fa.setOnClickListener(view_fa_listener)
                view_so.setOnClickListener(view_so_listener);
                view_la.setOnClickListener(view_la_listener);
                view_si.setOnClickListener(view_si_listener);
```

```
private Button.OnClickListener mButton_run_listener=new Button.OnClickListener(){
     public void onClick(View v){
          try{
    Toast.makeText(MyPianoActivity.this, "氣氛音樂",Toast.LENGTH_SHORT ).show();
    Linux_passive_buzzer.play_run_passive_buzzer();
}catch(Exception e){
    Toast.makeText(MyPianoActivity.this, "mButton_music_listener_error",Toast.LENGTH_SHORT ).show();
}
    3
  rivate Button.OnClickListener mButton_music_listener=new Button.OnClickListener(){
     public void onClick(View v){
          try{
    Toast.makeText(MyPianoActivity.this, "指放收曲",Toast.LENGTH_SHORT ).show();
    Linux_passive_buzzer.play_music_passive_buzzer();
}catch(Exception e){
    Toast.makeText(MyPianoActivity.this, "mButton_music_listener_error",Toast.LENGTH_SHORT ).show();
}
    3
  rivate Button.OnClickListener mButton_exit_listener=new Button.OnClickListener(){
     public void onClick(View v){
          try{
    Toast.makeText(MyPianoActivity.this, "EXIT", Toast.LENGTH_SHORT ).show();
    Linux_passive_buzzer.close_passive_buzzer();
    finish();
}catch(Exception e){
    Toast.makeText(MyPianoActivity.this, "mButton_music_listener_error", Toast.LENGTH_SHORT ).show();
}
    3
  rivate View.OnClickListener view_fa_minus_listener=new View.OnClickListener() {
    public void onClick(View <u>v</u>) {
// TODO Auto-generated method stub
           } catch(Exception e){
Toast.makeText(MyPianoActivity.this, "button_fa_minus_error", Toast.LENGTH_SHORT ).show();
```

#### (部分程式)

#### 2. 呼叫程式

透過 Linuxc.java 去呼叫 JNI 相關函式

### 3. 4412 開發板執行


最後,從 VMware 編譯得到的 so 檔及 apk 檔,接下來就要放入 Samsung Exynos 4412 中

- (1). 首先,要先在4412建立網路連接,測試成功,已可以取得封包。
- (2). 建立完連線後,必須把剛剛產出的 apk 檔及 libxxx.so 檔放入 Android 層相對應的資料夾下(/system/app)及(/system/libs),而驅動程式所屬位置則在/system/bin;使其載入使用 busybox 指令,讀取 100%時表示已完成傳送。
- (3). 本次採手動配置驅動程式並開啟權限,所以在驅動程式所在目錄下執行 #insmod buzzer.ko #insmod passivebuzzer.ko #insmod indrared.ko
- (4). 安裝驅動程式成功後尚需至設備目錄/dev/下開啟權限 #chmod 777 buzzer #chmod 777 passivebuzzer #chmod 777 indrared
- (5). 點選 APP 就可以正式使用了~~~

# 十、 測試結果

# 啟動燈光氣氛模式,並利用紅外線偵測是否有人:

當紅外線偵測到人時,送訊號至 WS2812B LED 燈條,開啟 LED 燈光調節 氣氛。



# ● 啟動哨兵警衛氣氛模式,並利用紅外線偵測是否有人:

當紅外線偵測到人時,送訊號至 LED 及有源蜂鳴器,開啟 LED 閃爍以及蜂鳴器警告。



# ● 影訊娛樂模式:

在音樂娛樂的部分,包含三大功能,帶您進入音訊娛樂的殿堂

- (1). 可以當成鋼琴自彈自唱
- (2). 播放預設歌曲音樂
- (3). 播放預設氣氛頻率音樂

