Alignment trap: not handling swp instruction
Alignment trap: not handling instruction e1003092 at [<c030fe94>]
Unhandled fault: alignment exception (0x801) at 0x0000005e
Internal error: : 801 [#1] PREEMPT
Modules linked in: 8188eu(O) mgpio(O) vpd_master(PO) vpd_slave(PO) loop_comm(PO) gs(PO) audio_drv(O) codec(PO)
CPU: 0   Tainted: P   0   (3.3.0 #139)
PC is at mutex_lock+0x8/0x14
LR is at pipe_wait+0x7c/0x88
pc : [<c030fe98>]   lr : [<c0098ec0>]   psr: 20000013
sp : c3423e20   ip : 00000000   fp : c36f8420
r10: 00000000   r9 : 00000000   r8 : 00000000
r7 : fffffdee   r6 : c003632c   r5 : c3423e24   r4 : c36f8420
r3 : c3423e30   r2 : 00000000   r1 : 00000001   r0 : 0000005e
Flags: nzCv   IRQs on   FIQs on   Mode SVC_32   ISA ARM   Segment user
Control: 0000397f   Table: 03444000   DAC: 00000015
Process eth0_run.sh (pid: 426, stack limit = 0xc3422270)
Stack: (0xc3423e20 to 0xc3424000)
3e20: c3446fb8 00000000 c341a9e0 c003632c c3423e30 c3423e30 00000000 c3422000
3e40: c3423f30 c00998f0 c35898b8 c007e414 c3446fb8 00000029 00000000 00000080
3e60: c3423f30 0000081f 00000000 c3412b40 c36f8450 c08b7464 befa2fff c3423eb0
3e80: c3412b40 c3423f30 fffffdee 00000000 00000000 00000000 00000000 c0090190
3ea0: 00000000 00000000 00000000 c3423f80 c342e230 c342e23c 00000000 00000001
3ec0: ffffffff c3412b40 00000000 00000000 00000000 00000000 c341a9e0 c044e794
3ee0: 00000000 00000000 00000000 00000000 c044c874 befa1ca8 00000080 000aa298
3f00: 00000080 00000001 00000001 c0008310 c0041830 c341a9e0 c044eb68 00000001
3f20: 000008f5 c0009b08 c3422000 00000000 befa1cd8 00000080 c37466e0 c3412b40
3f40: 00000080 befa1cd8 c3423f80 00000000 00000000 00000000 00000001 c0090d84
3f60: b6f13068 c6be68a0 c3412b40 befa1cd8 00000080 00000003 00000000 c0090ee8
3f80: 00000000 00000000 c3422000 00000000 00000080 befa1cd8 b6f1349c c0009b08
3fa0: c3422000 c0009960 00000080 befa1cd8 00000003 befa1cd8 00000080 000a88a8
3fc0: 00000080 befa1cd8 b6f1349c 00000003 befa1c90 000a88c8 00000001 00000001
3fe0: 00000003 befa1c78 0000e68c b6ed439c 60000010 00000003 00000000 00000000
[<c030fe98>] (mutex_lock+0x8/0x14) from [<c0098ec0>] (pipe_wait+0x7c/0x88)
[<c0098ec0>] (pipe_wait+0x7c/0x88) from [<c00998f0>] (pipe_read+0x3ec/0x4e4)
[<c00998f0>] (pipe_read+0x3ec/0x4e4) from [<c0090190>] (do_sync_read+0xac/0xf4)
[<c0090190>] (do_sync_read+0xac/0xf4) from [<c0090d84>] (vfs_read+0xac/0x140)
[<c0090d84>] (vfs_read+0xac/0x140) from [<c0090ee8>] (sys_read+0x40/0x70)
[<c0090ee8>] (sys_read+0x40/0x70) from [<c0009960>] (ret_fast_syscall+0x0/0x2c)
Code: eb0003a8 eafffff2 e3a02000 e1003092 (e3530001)

取 ip 地址时 先判断是否 有 ip 地址，有的话 再去取就不会有这个打印