

# **Maintenance Checksheets**

DC Controls. Unit 6, Tallaght Business Centre, Tallaght Dublin 24. 01-4416651 www.dccontrols.ie

**Project: Holiday Inn Express** 

Date: 03/03/2023

Contact: Joe 0851148122

**Engineers: Dean Hayden & Jordan Finlay** 



Project: Holiday Inn Express Date: 03/03/2023

Controller Type/Num: Trend IQ4E Base Controller								
Point Type	Point Number	Description	Units					
ΑI	1	Outside Air Temperature	°C					
ΑI	2	AHU-01 Supply Duct Temperature	°C					
		AHU-01 Supply Air Setpoint	°C					
ΑI	3	AHU-02 Pre-Electric Heater Temperature	°C					
ΑI	4	AHU-02 Supply Duct Temperature	°C					
		AHU-02 Supply Air Setpoint						
ΑI	5	AHU-02 Extract Air Temperature	°C					
ΑI	6	HWS Calorifier Tank Temperature	°C					
ΑI	7	HWS Calorifier Tank Return Temperature	°C					
		DHW Flow Setpoint						
DI	8	DIM4 No.1	On/Off					
DI	9	DIM4 No.2	On/Off					
UI	10	Spare	-					
AVO	11	IO-RMA#1	0-10V					
AV0	12	IO-RM2#1	0-10V					
AVO	13	AHU-01 Electric Heater Battery 3 Modulating Ctrl	0-10V					
AVO	14	IO-RMA#2	0-10V					
AVO	15	AHU-02 Electric Heater Battery Modulating Ctrl	0-10V					
AVO	16	IO-RMA#3	0-10V					

Faulty Operating Correctly
Yes
Yes
Yes
Yes
Yes
Yes
-
Yes

		Engineers: Dean Hayden & Jord	aan Finiay
Make	Model	Notes	Engineer
Make	Model		
Trend	TB/TO	7.71'C	KC/HB
Trend	TB/TI-S	17.79°C	KC/HB
		18'C	
Trend	TB/TI-S	17.47°C	KC/HB
Trend	TB/TI-S	18.3°C	KC/HB
		18'C	
Trend	TB/TI-S	20°C	KC/HB
Trend	TB/TI-S	70°C	KC/HB
Trend	TB/TI-S	64.4°C	KC/HB
		59'C	
Sontay	IO-DIM4		KC/HB
Sontay	IO-DIM4		KC/HB
			KC/HB
Sontay	IO-RMA		кс/нв
Sontay	IO-RM2		KC/HB
			кс/нв
Sontay	IO-RMA		кс/нв
	_		кс/нв
Sontay	IO-RMA		кс/нв



Project: Holiday Inn Express Date: 03/03/2023

Controller Type/Num: Trend 16DI									
Point Type	Point Number	Description	Units						
DI	1	Fire Alarm	On/Off						
DI	2	Gas Dectection Alarm	On/Off						
DI	3	AHU-01 Supply Fan Airflow Switch	On/Off						
DI	4	AHU-01 Electric Heater Battery High Limit	On/Off						
DI	5	AHU-02 Supply Fan Airflow Switch	On/Off						
DI	6	AHU-02 Electric Heater High Limit	On/Off						
DI	7	AHU-02 Extract Fan Airflow Switch	On/Off						
DI	8	EF-01 Kitchen Extract CT Switch	On/Off						
DI	9	EF-02 Kitchen Extract CT Switch	On/Off						
DI	10	Mains Water Meter Pulse signal	On/Off						
DI	11	Main Gas Meter Pulse signal	On/Off						
DI	12	DHW Cold Feed to Hotel Water Meter signal	On/Off						
DI	13	CWS Consumption Water Meter signal	On/Off						
DI	14	BCWS to Kitchens Water Meter signal	On/Off						
DI	15	DHW to Kitchens Water Meter signal	On/Off						
DI	16	DHW Return to Kitchens Water Meter signal	On/Off						

Sta	itus
Operating Correctly	Faulty
Yes	

		5	
Make	Model	Notes	Engineer
Make	Model		
			KC/HB
			KC/HB
			кс/нв
			KC/HB
			KC/HB
			кс/нв
			кс/нв
			KC/HB
			кс/нв
			KC/HB



Project: Holiday Inn Express	Date: 03/03/2023
Contact: Joe 0851148122	Engineers: Dean Hayden & Jordan Finlay

COI	Contact. Joe 0851146122									
Con	Controller Type/Num: RMA#1				itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI	1	AHU-01 Supply Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		KC/HB
Con	trolle	r Type/Num: RMA#2		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI	1	AHU-02 Supply Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		кс/нв
Con	trolle	Type/Num: RMA#3		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI	1	AHU-02 Extract Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		кс/нв
Con	trolle	Type/Num: RM2#1		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI			On/Off	Yes			Sontay	IO-RM2		кс/нв
DI	2	AHU-01 Electric Heater Batteries 2 Enable	On/Off	Yes			Sontay	IO-RM2		KC/HB



Project: Holiday Inn Express

Date: 03/03/2023

Contact: Joe 0851148122

Engineers: Dean Hayden & Jordan Finlay

Cont	Controller Type/Num: DIM4#1				atus	Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty				
DI	1	AHU-01 Panel Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		кс/нв
DI	2	AHU-01 Bag Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		KC/HB
DI	3	AHU-02 Supply Panel Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		KC/HB
DI	4	AHU-02 Supply Bag Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		кс/нв
		Controller Type/Num: DIM4#2							
Cont	•	r Type/Num: DIM4#2		Sta	atus	Make	Model	Notes	Engineer
Cont Point Type	•	Type/Num: DIM4#2  Description	Units	Store Operating Correctly	atus Faulty	Make	Model	Notes	Engineer
	rolle: Point		Units On/Off	Operating		Make	Model	Notes	Engineer  KC/HB
Point Type	Point Number	Description		Operating Correctly		Make	Model	Notes	
Point Type $\Box$	Point Number	Description  Cold Water Booster Fault	On/Off	Operating Correctly		Make	Model	Notes	кс/нв

#### Notes:

- 1. HWS return pump cover missing off of pump and live cables are exposed. Type; Grundfoss 32-120 F B.
- 2. ELE Meter 11-20 is reading the same as ELE Meter 21-30. Further investigation required.
- 3. A number of switches were found in hand on the MCC door, Tested and working in auto. Switches were for Gas Fired Heater 1-5, Ef-04
- 4. Mains water meter is reading 0 for Hourly, Monthly and yearly. Further investigation required.
- 5. Boiler 3 is fault in the field and on the pane door, Joe is aware of this issue, By Others
- 6. Boiler 4 went into fault in the field and on the panel door while on site, same issue as 3 & 5, Joe was made aware of this issue, By Others
- 7.Boiler 5 has a leak, water puddle infront of unit
- 8. Time was ahead by 6 minutes, now operating on correct times
- 9. BMS IP: 10.1.0.11
- 10. BMS web Login: Username: InTouch Engineer Password: 4232



Project: Holiday Inn Express Date: 03/03/2023

nits  //Off //Off //Off //Off  //Off  //Off //Of	Operating Correctly Yes	Faulty	Notes  On Off On Off On Off 50Hz 18.0°C 18.0°C On On On Off On Off On On Off On On On Off On On FoHz 19.6°C 10% Off 17.25°C	Engineer  DH/JF
N/Off N/Off N/Off Hz C C N/Off N/Off N/Off N/Off N/Off N/Off N/Off N/Off M/Off	Yes		Off On Off 50Hz 18.0°C 18.0°C On On On Off On Off On On Off On	DH/JF
MOFF	Yes		On Off 50Hz 18.0°C 18.0°C On On On Off On Off On On On Off On	DH/JF
//Off Hz °C °C //Off //Off //Off //Off //Off //Off //Off Hz °C % //Off //Off % //Off	Yes		Off 50Hz 18.0°C 18.0°C 0n On Off On Off 100 On	DH/JF
Hz °C NOff NOff NOff NOff NOff NOff NOff NOf	Yes		50Hz 18.0°C 18.0°C On On Off On Off On On On Off On On On On On 50Hz 19.6°C 10% Off	DH/JF
°C °C  I/Off  I/Off  I/Off  I/Off  I/Off  I/Off  CC  Hz	Yes		18.0°C 18.0°C On On Off On Off On SoHz 19.6°C 10% Off	DH/JF
°C  //Off  //Off  //Off  //Off  //Off  //Off  //Off  Hz  °C  %  //Off	Yes		18.0°C On On Off On On SoHz 19.6°C 10% Off	DH/JF
I/Off I/Off I/Off I/Off I/Off I/Off I/Off I/Off I/C	Yes		On On Off On On On SoHz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF
//Off //Off //Off //Off Hz °C % //Off °C	Yes		On Off On On SoHz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF
n/Off n/Off n/Off Hz °C % n/Off °C	Yes		Off On On 50Hz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF DH/JF
N/Off N/Off Hz °C % N/Off °C	Yes		On On 50Hz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF DH/JF
h/Off Hz °C % h/Off  C Hz	Yes Yes Yes Yes Yes Yes Yes Yes Yes		On 50Hz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF DH/JF
Hz °C % //Off °C	Yes Yes Yes Yes Yes Yes Yes		50Hz 19.6°C 10% Off	DH/JF DH/JF DH/JF DH/JF
°C % i/Off °C Hz	Yes Yes Yes Yes Yes Yes		19.6°C 10% Off	DH/JF DH/JF DH/JF
% i/Off °C Hz	Yes Yes Yes Yes		10% Off	DH/JF DH/JF
r/Off °C Hz	Yes Yes Yes		Off	DH/JF
°C Hz	Yes Yes			
Hz	Yes		17.25°C	רח /ונ
			5	חם/זר
°C			50Hz	DH/JF
	Yes		18.0°C	DH/JF
/Off	Yes		On	DH/JF
°C	Yes		18.37°C	DH/JF
%	Yes		100.00%	DH/JF
%	Yes		100.00%	DH/JF
%	Yes		40.00%	DH/JF
%	Yes		49.00%	DH/JF
%	Yes		100.00%	DH/JF
/Off	Yes		Off	DH/JF
%	Yes		100.00%	DH/JF
/Off	Yes		Off	DH/JF
%	Yes		10.00%	DH/JF
%	Yes		100%	DH/JF
/Off	Yes		Off	DH/JF
trs	Yes		5789.9 Ltrs	DH/JF
trs	Yes		355.5 Ltrs	DH/JF
trs	Yes		113 Ltrs	DH/JF
trs	Yes		18.4 Ltrs	DH/JF
/Off	Yes		Off	DH/JF
/Off	Yes		On	DH/JF
m3	Yes		14.36 m3	DH/JF
m3	Yes		0.6 m3	DH/JF
n3	Yes		1423.83 m3	DH/JF
n3	Yes		66.46 m3	DH/JF
/Off	Yes		Off	DH/JF
/Off	Yes		Off	DH/JF
/Off	Yes		Off	DH/JF
/Off	Yes		Off	DH/JF
	/Off /C % % % % /Off % /Off % /Off trs trs /Off /Off /Off /Off /Off /Off /Off /Of	PC Yes /Off Yes /Off Yes PC Yes /Off Yes PC	Yes	SOHz   SOHZ

CWS Tank 2 Low Level	On/Off	Yes	Off	DH/JF
DHW Cold To Hotel Meter	On/Off	Yes	Off	DH/JF
DHW Cold To Hotel Daily	Ltrs	Yes	6.46 Ltrs	DH/JF
DHW Cold To Hotel Monthly	Ltrs	Yes	219.91 Ltrs	DH/JF
DHW Cold To Hotel Yearly	Ltrs	Yes	581.26Ltrs	DH/JF
DHW Flow Setpoint	°C	Yes	59.0°C	DH/JF
DHW Hot Return	On/Off	Yes	On	DH/JF
DHW Hot Return Fail	On/Off	Yes	Off	DH/JF
DHW Return To Kitchen Meter	On/Off	Yes	Off	DH/JF
DHW Return To Kitchen Meter Hourly	Ltrs	Yes	0 Ltrs	DH/JF
DHW Return To Kitchen Meter Monthly	Ltrs	Yes	0 Ltrs	DH/JF
DHW Return To Kitchen Meter Yearly	Ltrs	Yes	0 Ltrs	DH/JF
DHW Return To Kitchen Meter Daily	Ltrs	Yes	0 Ltrs	DH/JF
DHW To Kitchen Meter Daily	Ltrs	Yes	100 Ltrs	DH/JF
DHW To Kitchen Meter Hourly	Ltrs	Yes	0 Ltrs	DH/JF
DHW To Kitchen Meter Yearly	Ltrs	Yes	4700 Ltrs	DH/JF
DHW To Kitchen Meter Monthly	Ltrs	Yes	200 Ltrs	DH/JF
DHW To Kitchen Meter	On/Off	Yes	Off	DH/JF
DIM4 Multiplexer No.1	011/011	Yes	8.35	DH/JF
DIM4 Multiplexer No.2		Yes	120.58	DH/JF
EF 01 Enable	On/Off	Yes	0n	DH/JF
EF 01 GF Area			+ + +	
	On/Off	Yes	On	DH/JF
EF 01 Kitchen Extract A/F	On/Off	Yes	On	DH/JF
EF 02 Enable	On/Off	Yes	On	DH/JF
EF 02 GF Toilet Extract	On/Off	Yes	On	DH/JF
EF 02 Kitchen Extract A/F	On/Off	Yes	On	DH/JF
EF 03 Bedrooms Enable	On/Off	Yes	On	DH/JF
EF 03 Enable Speed	%	Yes	75.00%	DH/JF
EF 03 Supply Fan Airflow Fail	On/Off	Yes	Off	DH/JF
EF 03 Twin Fan Airflow	On/Off	Yes	On	DH/JF
EF 03 Twin Fan Speed Signal	%	Yes	75.00%	DH/JF
EF 04 Bedrooms Enable	On/Off	Yes	On	DH/JF
EF 04 Enable Speed	%	Yes	63.00%	DH/JF
EF 04 Supply Fan Airflow Fail	On/Off	Yes	Off	DH/JF
EF 04 Twin Fan Airflow	On/Off	Yes	On	DH/JF
EF 04 Twin Fan Speed Signal	%	Yes	63.00%	DH/JF
EF 05 Enable	On/Off	Yes	On	DH/JF
EF 05 Supply Fan Airflow Fail	On/Off	Yes	Off	DH/JF
EF 05 Twin Fan Airflow	On/Off	Yes	On	DH/JF
EF 06 Enable	On/Off	Yes	On	DH/JF
EF 06 Linen Room Fail	On/Off	Yes	Off	DH/JF
EF 06 Twin Fan Airflow	On/Off	Yes	On	DH/JF
EF 07 Enable	On/Off	Yes	On	DH/JF
EF 07 Extract Plant Room Fail	On/Off	Yes	Off	DH/JF
EF 07 Twin Fan Airflow	On/Off	Yes	On	DH/JF
EF 01 & 02 Enable Signal	%	Yes	100.00%	DH/JF
ELE Meter 1 kWh	kWh	Yes	1604271 Kwh	DH/JF
			<del>-</del>	
ELE Meter 2 kWh	kWh	Yes	329728 kwh	DH/JF
ELE Meter 3 kWh	kWh	Yes	85094.4 kwh	DH/JF
ELE Meter 4 kWh	kWh	Yes	333824 kwh	DH/JF
ELE Meter 5 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 6 kWh	kWh	Yes	207872 kwh	DH/JF
ELE Meter 7 kWh	kWh	Yes	98304kwh	DH/JF
ELE Meter 8 kWh	kWh	Yes	215040 kwh	DH/JF
ELE Meter 9 kWh	kWh	Yes	258867.2 kwh	DH/JF
ELE Meter 10 kWh	kWh	Yes	85540 Kwh	DH/JF

ELE Meter 11 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 12 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 13 kWh	kWh	Yes	10150.4 kwh	DH/JF
ELE Meter 14 kWh	kWh	Yes	464486.4 kwh	DH/JF
ELE Meter 15 kWh	kWh	Yes	100864 kwh	DH/JF
ELE Meter 16 kWh	kWh	Yes	109056 kwh	DH/JF
ELE Meter 17 kWh	kWh	Yes	96256 kwh	DH/JF
ELE Meter 18 kWh	kWh	Yes	95232 kwh	DH/JF
ELE Meter 19 kWh	kWh	Yes	100352 kwh	DH/JF
ELE Meter 20 kWh	kWh	Yes	119296 kwh	DH/JF
ELE Meter 21 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 22 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 23 kWh	kWh	Yes	10150.4 kwh	DH/JF
ELE Meter 24 kWh	kWh	Yes	464486.4 kwh	DH/JF
ELE Meter 25 kWh	kWh	Yes	100864 kwh	DH/JF
ELE Meter 26 kWh	kWh	Yes	109056 kwh	DH/JF
ELE Meter 27 kWh	kWh	Yes	96256 kwh	DH/JF
ELE Meter 28 kWh	kWh	Yes	95232 kwh	DH/JF
ELE Meter 29 kWh	kWh	Yes	100352 kwh	DH/JF
ELE Meter 30 kWh	kWh	Yes	119296 kwh	DH/JF
EF 01 Fail	On/Off	Yes	Off	DH/JF
EF 02 Fail	On/Off	Yes	Off	DH/JF
Fire Alarm	On/Off	Yes	On	DH/JF
Gas Detection	On/Off	Yes	On	DH/JF
Gas Fired Heater 1	On/Off	Yes	On	DH/JF
Gas Fired Heater 2	On/Off	Yes	On	DH/JF
Gas Fired Heater 3	On/Off	Yes	On	DH/JF
Gas Fired Heater 4	On/Off	Yes	On	DH/JF
Gas Fired Heater 5	On/Off	Yes	On	DH/JF
Gas Fire Water 1 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 2 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 3 Fault	On/Off	Yes	On	DH/JF
Gas Fire Water 4 Fault	On/Off	Yes	On	DH/JF
Gas Fire Water 5 Fault	On/Off	Yes	On	DH/JF
Gas Heater Rotate	On/Off	Yes	Off	DH/JF
Gas Meter Usage Daily	m3	Yes	0 m3	DH/JF
Gas Meter Usage Monthly	m3	Yes	0 m3	DH/JF
Gas Meter Usage Hourly	m3	Yes	0 m3	DH/JF
			 L	<i>'</i>



Project: Holiday Inn Express Date: 03/03/2023

Timeclocks	Hours
AHU 1	Mon-Fri 08:00-18:00,Sat & Sun Off
AHU 2	Mon-Fri 08:00-18:00,Sat & Sun Off
Domestic Hot Water	On 24/7
EF 01 Ground Floor Area	Mon-Fri & Sun 06:00-24:00, Sat 05:00-24:00
EF 02 Toilet Extract	Mon-Sun 05:00-22:00
EF 03 Bedrooms	Mon-Sun 08:00-19:00
EF 04 Bedrooms	Mon-Sun 08:00-19:00
EF 05 Kitchen Extract	Mon-Sun 05:00-23:00
EF 06 Basement Area	Mon-Sun 05:00-24:00
Plantroom Fans(SF01 + EF07)	On 24/7