Dynamic bicycle model

Alessio Russo, Carmelo Valore July 5, 2020

1 Simple dynamic model




Figure 1: Bicycle model

$$m_T \ddot{x} = F_{xF} cos(\psi + \delta) + F_{xR} cos(\psi) - F_{yF} sin(\psi + \delta) - F_{yR} sin(\psi)$$

$$m_T \ddot{y} = F_{xF} sin(\psi + \delta) + F_{xR} sin(\psi) + F_{yF} cos(\psi + \delta) + F_{yR} cos(\psi)$$

$$I_T \ddot{\psi} = F_{xF} asin(\delta) + F_{yF} acos(\delta) - F_{yR} b$$

$$(1)$$

$$\alpha_F = \arctan(\frac{\dot{y} + a\dot{\psi}\cos(\psi)}{\dot{x} - a\dot{\psi}\sin(\psi)}) - (\delta + \psi)$$

$$\alpha_R = \arctan(\frac{\dot{y} - b\dot{\psi}\cos(\psi)}{\dot{x} + b\dot{\psi}\sin(\psi)}) - \psi$$
(2)

At first, as state vector this has been used:

$$z1 = x$$

$$z2 = y$$

$$z3 = \psi$$

$$z4 = \dot{x}$$

$$z5 = \dot{y}$$

$$z6 = \dot{\psi}$$
(3)

So that

$$\dot{z}_{1} = z_{4}
\dot{z}_{2} = z_{5}
\dot{z}_{3} = z_{6}
\dot{z}_{4} = \frac{F_{xF}cos(z_{3} + \delta) + F_{xR}cos(z_{3}) - F_{yF}sin(z_{3} + \delta) - F_{yR}sin(z_{3})}{m_{T}}
\dot{z}_{5} = \frac{F_{xF}sin(z_{3} + \delta) + F_{xR}sin(z_{3}) + F_{yF}cos(z_{3} + \delta) + F_{yR}cos(z_{3})}{m_{T}}
\dot{z}_{6} = \frac{F_{xF}asin(\delta) + F_{yF}acos(\delta) - F_{yR}b}{I_{T}}$$
(4)

With slip angles

$$\alpha_F = \arctan(\frac{z_5 + az_6 \cos(z_3)}{z_4 - az_6 \sin(z_3)}) - (\delta + z_3)$$

$$\alpha_R = \arctan(\frac{z_5 - bz_6 \cos(z_3)}{z_4 + bz_6 \sin(z_3)}) - z_3$$
(5)

Now instead of using \dot{x} and \dot{y} , v_T and α_T have been used. The trasformations are the following:

$$\dot{x} = v_T cos(\psi + \alpha_T)$$

$$\dot{y} = v_T sin(\psi + \alpha_T)$$

$$\ddot{x} = \dot{v_T} cos(\psi + \alpha_T) - v_T (\dot{\psi} + \dot{\alpha_T}) sin(\psi + \alpha_T)$$

$$\ddot{y} = \dot{v_T} sin(\psi + \alpha_T) + v_T (\dot{\psi} + \dot{\alpha_T}) cos(\psi + \alpha_T)$$
(6)

Substituting and simplyfing with the help of Matlab

$$\dot{v_T} = \frac{F_{xF}cos(\alpha_T - \delta) + F_{xR}cos(\alpha_T) + F_{yF}sin(\alpha_T - \delta) + F_{yR}sin(\alpha_T)}{m_T}$$

$$\dot{\alpha_T} = \frac{-F_{xF}sin(\alpha_T - \delta) - F_{xR}sin(\alpha_T) + F_{yF}cos(\alpha_T - \delta) + F_{yR}cos(\alpha_T) - m_Tv_T\dot{\psi}}{m_Tv_T}$$

$$\ddot{\psi} = \frac{F_{xF}asin(\delta) + F_{yF}acos(\delta) - F_{yR}b}{I_T}$$
(7)

$$\alpha_F = \arctan(\frac{v_T sin(\alpha_T) + a\dot{\psi}}{v_T cos(\alpha_T)}) - \delta$$

$$\alpha_F = \arctan(\frac{v_T sin(\alpha_T) - b\dot{\psi}}{v_T cos(\alpha_T)})$$
(8)

The new state and the state equations are

$$x1 = x$$

$$x2 = y$$

$$x3 = \psi$$

$$x4 = v_T$$

$$x5 = \alpha_T$$

$$x6 = \dot{\psi}$$

(9)

2 Pacejka tyre model

The following Pacejka tyre model (Magic Formula) has been used, taking as inputs the body slip angle α , the vertical load F_z and the lateral friction coefficient

 μ_y

$$F_y = -\frac{\mu_y}{\mu_{y0}} (F_{y0} + Sv) \tag{10}$$

With

$$F_{y0} = Dsin(Carctan(B\alpha_{eq} - E(B\alpha_{eq} - arctan(B\alpha_{eq}))))$$

$$\alpha_{eq} = \frac{\mu_{y0}}{\mu_{y}}(\alpha + S_{h})$$

$$C = a_{0}$$

$$D = (a_{1}F_{z} + a_{2})F_{z}BCD = a_{3}sin(2arctan(\frac{F_{z}}{a_{4}}))(1 - a_{5}|\gamma|)$$

$$B = BCD/CD$$

$$E = a_{6}F_{z} + a_{7}$$

$$S_{h} = a_{8}\gamma + a_{9}F_{z} + a_{10}$$

$$S_{v} = a_{11}F_{z}\gamma + a_{12}F_{z} + a_{13}$$

$$(11)$$

Where a_i , $i \in \{0,...,13\}$, are the parameters of the Pacejka model, whose value and meaning can be seen in the Appendix.

3 Aerodynamic force

The following changes have been done in the previous model to take into account for the aerodynamic force $F_A = \frac{1}{2}\rho C_x S v^2$ in the same direction of v_T but in the opposite side, and $F_{Lift} = \frac{1}{2}\rho C_z S v^2$ that "pushes" the vehicle to be sticked on the ground

$$\dot{x_4} = \frac{F_{xF}cos(x_5 - \delta) + F_{xR}cos(x_5) + F_{yF}sin(x_5 - \delta) + F_{yR}sin(x_5) - \frac{1}{2}\rho C_x S v^2}{m_T}$$

$$\vdots$$

$$(12)$$

$$F_z = mg + \frac{1}{2}\rho C_z S v^2$$

$$(13)$$

4 Fuel consumption

The following changes have been done in the previous model to take fuel consumption into account. A simplified version has been used, in which the Power is

computed (P_e) and multiplied by a coefficient (C_{fuel}) that expresses the relation among mass loss (in terms of fuel consumption) and power provided

$$P_e = (F_{xF} + F_{xR})v_T$$

$$\dot{m} = P_e C_{fuel}$$
(14)

5 Tyre wear

The following have been added in the previous model to take into account for wear of the rubber compound of the tyre. The model is called Archard model, and it makes use of the vertical pression $(P_z = \frac{F_z}{Area})$, the longitudinal velocity of the wheels $(v_{xF} \text{ and } v_{xR})$ and some parameters (such as $K_{wear}[-]$ and $H[\frac{N}{m^2}]$). The model output is the wear depth over the time (\dot{h}) , that will be then converted into mm^3 of wasted material. Here the Archard model formulation is shown

$$\dot{h} = \frac{K_{wear} P_{load} v_{xi}}{H}$$
where $i \in \{F, R\}$ (15)

6 Banking

Taking into account the shape of the road we introduce other terms in the model equations. As can be seen in figure 2 and 3 we first consider the resultant lateral force F_{LAT} acting on the vehicle, after this step we are able to find the equilibrium on the Z axis that allows to compute the value of F_{Nx} .

$$F_{LAT} = F_{uR} + F_{xF}sin(\delta) + F_{uF}cos(\delta)$$
 (16)

$$mg + F_{Lift}cos(\gamma) + F_{LAT}sin(\gamma) = F_{Nz}$$

 $F_{Nx} = F_{Nz}tan(\gamma)$ (17)

As can be seen from this figure, the contribution of this lateral force acting on the vehicle will add some new terms in the equations of the model. Along the direction of v_T the contribution of the force is $F_{Nx}sin(\alpha_T)$, while on the orthogonal direction it is represented by the force $F_{Nx}cos(\alpha_T)$.




Figure 2: Lateral forces acting on the vehicle




Figure 3: Equilibrium on Z axis

In the end the final equations will be:

$$\dot{x}_{4} = \frac{F_{xF}cos(x_{5} - \delta) + F_{xR}cos(x_{5}) + F_{yF}sin(x_{5} - \delta) + F_{yR}sin(x_{5}) - \frac{1}{2}\rho C_{x}Sv^{2} + F_{Nx}sin(x_{5})}{m_{T}}$$

$$\dot{x}_{5} = \frac{-F_{xF}sin(x_{5} - \delta) - F_{xR}sin(x_{5}) + F_{yF}cos(x_{5} - \delta) + F_{yR}cos(x_{5}) - m_{T}x_{4}x_{6} + F_{Nx}cos(x_{5})}{m_{T}x_{4}}$$
(18)




Figure 4: Terms affecting the model equations

7 Appendix

In this section we will define the values given to the different parameters.

$$a0 = 1.4[-] - \text{Shape factor}$$

$$a1 = 0[1/kN] - \text{Load dependency of lateral friction (*1000)}$$

$$a2 = 1100[-] - \text{Lateral friction level (*1000)}$$

$$a3 = 1100[N/deg] - \text{Maximum cornering stiffness}$$

$$a4 = 10[kN] - \text{Load at maximum cornering stiffness}$$

$$a5 = 0 - \text{Camber sensitivity of cornering stiffness}$$

$$a6 = 0 - \text{Load dependency of curvature factor}$$

$$a7 = -2[-] - \text{Curvature factor level}$$

$$a8 = 0 - \text{Camber sensitivity of horizontal shift}$$

$$a9 = 0 - \text{Load dependency of horizontal shift}$$

$$a10 = 0 - \text{Horizontal shift level}$$

$$a11 = 0 - \text{Combined load and camber sensitivity of vertical shift}$$

$$a12 = 0 - \text{Load dependency of vertical shift}$$

$$a13 = 0 - \text{Vertical shift level}$$

$$\gamma = 0[rad] - \text{Camber angle}$$

$$\mu_{lateral} = 0.3[-] - \text{Lateral friction coefficient}$$

$$C_x=0.8[-] - - - \text{Drag coefficient}$$

$$C_z=1.5[-] - - \text{Lift coefficient}$$

$$rho=1.225[\frac{kg}{m^3}] - - - \text{Density of air}$$

$$Area=2[m] - - - \text{Area of the vehicle on which the air goes through}$$

 $vel_{max}=50[rac{m}{s}]$ ——Maximum velocity of the vehicle $vel_{init}=20[rac{m}{s}]$ ——Initial velocity of the vehicle $yPos_{init}=-5.625[m]$ ——Initial y position of the vehicle

$$C_{fuel} = 3x10^-7[\frac{s^2}{m^2}] - - - \text{Fuel consumption coefficient}$$

$$K_{wear} = 10^- 9 [-] - Tyre wear parameter$$

$$H = 60 [\frac{N}{m^2}] - Tyre wear parameter$$