Filename: SINS2.pro

Title: SSLS SINS.2 Reflectometer Branchline


Author: Carl Cork

Version: Description:

```
0001
     PROGRAM Actuator_SM
0002
0003 VAR CONSTANT
                          : STRING := '192.168.1.11';
0004
          strAddress
0005
                          : WORD := 502;
          wPort
0006
                          : BYTE := 1;
          bTD
0007
          tTCP_Timeout: TIME := t#100ms;
0008
          tTCP_Watchdog : TIME := t#10s;
0009 END_VAR
0010 VAR
0011
                          : Actuator; (* Actuator control and status object *)
          oActuator
0012
0013
                          : UINT; (* total numbers of successful Transfers *)
          uiSuccessful
0014
          uiFailing
                                     (* total numbers of failing Transfers
                          : UINT;
0015 END_VAR
     (* Actuator State Machine *)
0001
0002
     CASE oActuator.wState OF
          10: (* RESET: reset connection *)
0003
0004
              xActuatorReady := FALSE;
0005
              oActuator.xConnect := FALSE;
0006
              CONNECT();
0007
              oActuator.wState := 15;
8000
0009
          15: (* INIT: Initialize connection *)
0010
              oActuator.xConnect := TRUE;
0011
              CONNECT();
0012
              oActuator.wState := 20;
0013
          20: (* CONNECTING: wait for TCP connection*)
0014
0015
              CONNECT();
0016
              IF oActuator.oMBMaster.xIS_CONNECTED THEN
0017
                  oActuator.xBusy := FALSE;
0018
                  oActuator.wState := 30;
0019
              END_IF
0020
0021
          30: (* INITIALIZING: wait for servo on *)
0022
              STATUS READ():
0023
              IF oActuator.xDataReadv THEN
0024
                  (* test for EMGS ON or PWR OFF *)
0025
                  IF (oActuator.awStatus[5].15 OR NOT oActuator.awStatus[5].13 ) THEN
0026
                      (* Wait for this condition to be satisfied *)
0027
                      oActuator.wState := 30;
0028
                  (* test for ALMH alarm *)
0029
                  ELSIF oActuator.awStatus[5].10 THEN
0030
                      (* try to reset alarm *)
0031
                      oActuator.wState := 31;
                  (* test for SV servo OFF or PEND OFF *)
0032
0033
                  ELSIF (NOT oActuator.awStatus[5].12) OR (NOT oActuator.awStatus[5].3) THEN
0034
                      (* try to turn on servo *)
0035
                      oActuator.wState := 33;
0036
                  (* test for HEND homing complete *)
0037
                  ELSIF NOT oActuator.awStatus[5].4 THEN
0038
                      (* try to HOME motor *)
0039
                      oActuator.wState := 35;
0040
                  ELSE
0041
                      (* ready to receive position commands *)
0042
                      oActuator.wState := 40;
0043
                  END_IF
0044
              END_IF
0045
0046
          31: (* ALRS ON: reset alarm *)
0047
              (* first assert ALRS *)
0048
              oActuator.wCommand := 16#0100;
0049
              DRG1_WRITE();
0050
              IF oActuator.xDataReady THEN
0051
                  (* next step is to clear ALRS flag *)
0052
                  oActuator.wState := 32;
0053
              END_IF
0054
          32: (* ALRS OFF: clear flag *)
0055
              (* clear ALRS flag *)
0056
0057
              oActuator.wCommand := 16#0000;
```

```
0058
              DRG1_WRITE();
0059
              IF oActuator.xDataReady THEN
0060
                   (* finish initialization *)
0061
                  oActuator.wState := 30;
0062
              END_IF
0063
0064
          33: (* SON: turn on servo *)
0065
              oActuator.wCommand := 16#1000;
0066
              DRG1_WRITE();
0067
              IF oActuator.xDataReady THEN
0068
                   (* finish initialization *)
0069
                  oActuator.wState := 30;
              END_IF
0070
0071
0072
          35: (* HOME OFF: reset HOME flag *)
0073
               (* leave SON ON *)
0074
              oActuator.wCommand := 16#1000;
0075
              DRG1_WRITE();
0076
              IF oActuator.xDataReady THEN
0077
                   (* now set the flag *)
0078
                  oActuator.wState := 36;
              END_IF
0079
0080
          36: (* HOME ON: set HOME flag *)
0081
0082
               (* SON | HOME *)
0083
              oActuator.wCommand := 16#1010;
0084
              DRG1_WRITE();
0085
              IF oActuator.xDataReady THEN
0086
                  (* wait for HEND *)
0087
                  oActuator.wState := 37;
0088
              END_IF
0089
          37: (* HEND: wait for home to finish *)
0090
              STATUS_READ();
0091
0092
              IF oActuator.xDataReady THEN
0093
                   (* test for HEND *)
0094
                   IF NOT oActuator.awStatus[5].4 THEN
0095
                       (* not home yet *)
0096
                       oActuator.wState := 37;
0097
                  ELSE
0098
                       (* ready to receive position commands *)
0099
                       oActuator.wState := 40;
0100
                  END IF
0101
              END_IF
0102
0103
          40: (* IDLING: wait for new destination *)
0104
              STATUS_READ();
0105
               IF oActuator.xDataReady THEN
0106
                   (* New target? *)
0107
                   IF wActuatorTarget <> wActuatorPosition THEN
0108
                       (* update target *)
0109
                       PCMD_WRITE();
0110
                       xActuatorReady := FALSE;
0111
                       oActuator.wState := 50;
0112
                  ELSE
0113
                       (* continue idling *)
0114
                       STATUS_READ();
0115
                       xActuatorReady := TRUE;
0116
                       oActuator.wState := 40;
0117
                  END_IF
0118
              END_IF
0119
0120
          50: (* STARTING: set new target position*)
0121
              PCMD_WRITE();
0122
              IF oActuator.xDataReady THEN
0123
                   (* started, now test for motion complete *)
0124
                   STATUS_READ();
0125
                   oActuator.wState := 60;
0126
              END_IF
0127
0128
          60: (* MOVING: wait until move is completed*)
0129
              STATUS_READ();
0130
              IF oActuator.xDataReady THEN
```

```
0131
                  (* wStatus & PEND ? *)
0132
                  IF oActuator.awStatus[5].3 THEN
0133
                     (* Move complete, goto IDLING *)
0134
                      uiSuccessful := uiSuccessful + 1;
0135
                      STATUS_READ();
0136
                     oActuator.wState := 40;
                  ELSE
0137
0138
                      (* Still moving, test again *)
0139
                      STATUS_READ();
0140
                     oActuator.wState := 60;
0141
                  END_IF
0142
              END_IF
0143
0144
          ELSE (* Should never get here *)
0145
             oActuator.xConnect := FALSE;
0146
              oActuator.wState := 10;
0147 END_CASE
CONNECT (ST)
0001 (* CONNECT *)
0002
      (* initiate TCP connection *)
0003
0004 (* Delay before initiating connection *)
     (*BEGDEBUG oActuator.tonConnect(IN := oActuator.xConnect, PT := DWORD_TO_TIME((BYTE_TO_DWORD(bID) * 100)));
0005
0006
     oActuator.tonConnect(IN := oActuator.xConnect, PT := t#100ms);
0007
0008 (* Connect *)
0009 oActuator.xSend := FALSE;
0010 oActuator.oMBMaster(
0011
          xCONNECT
                        := oActuator.tonConnect.O,
0012
          strIP_ADDRESS
                             := strAddress,
0013
          wPORT
                             := wPort,
0014
          bUNIT_ID
                         := bID,
0015
            bFUNCTION_CODE := 16#03,
                                              (*ReadHoldingCoils*)
0016
            wREAD_ADDRESS:= 16#9000,
0017
            wread_Quantity := 10,
            ptREAD_DATA
0018
                             := ADR(oActuator.awStatus[0]),
0019
          wWRITE_ADDRESS
                             := 0,
0020
          wWRITE OUANTITY
                             := 0,
0021
          ptSEND_DATA
                             := 0,
0022
          tTIME_OUT
                             := tTCP_Timeout,
0023
          tCON_WATCHDOG
                             := tTCP_Watchdog,
0024
          xSEND
                             := oActuator.xSend
0025
          );
0026
0027 (* Test for connection error *)
0028 IF oActuator.oMBMaster.wError <> 0 THEN
0029
          (* error, return to RESET *)
0030
          uiFailing := uiFailing + 1;
0031
          oActuator.xConnect := FALSE;
0032
          oActuator.wState := 10;
0033 END_IF
```



```
DRG1_WRITE (ST)
0001 (* DRG1_WRITE*)
0002 (* Write to DRG1 command register *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
        oActuator.xBusy := TRUE;
0007
        oActuator.xSend := TRUE;
0008 END_IF
0009
0010 (* set DRG1 command register *)
0011 oActuator.oMBMaster(
0012
        xCONNECT := oActuator.tonConnect.Q,
0013
         strIP_ADDRESS := strAddress,
0014
         wPORT
                           := wPort,
0015
         bUNIT_ID := bID,
0016
          bFUNCTION_CODE := 16#06,
                                          (*WriteSingleRegister*)
0017
           wread_address:= 0,
0018
           wREAD_QUANTITY := 0,
           ptREAD_DATA := 0,
IRITE ADDRESS := 16
0019
0020
                          := 16#0D00,
         wWRITE_ADDRESS
```

```
0021
         wWRITE OUANTITY
0022
         ptSEND DATA
                            := ADR(oActuator.wCommand),
0023
         tTIME_OUT
                            := tTCP_Timeout,
0024
         tCON_WATCHDOG
                           := tTCP_Watchdog,
0025
         xSEND
                             := oActuator.xSend
0026
         );
0027
0028 (* Test for transaction complete *)
0029 IF oActuator.oMBMaster.wError <> 0 THEN
0030
         (* error, return to INIT *)
0031
         uiFailing := uiFailing + 1;
0032
        oActuator.xConnect := FALSE;
0033
        oActuator.xBusy := FALSE;
0034
        oActuator.xDataReady := FALSE;
0035
        oActuator.wState := 10;
0036 ELSIF NOT oActuator.xSend THEN
0037
        oActuator.xBusy := FALSE;
0038
         oActuator.xDataReady := TRUE;
0039 ELSE
0040
     oActuator.xDataReady := FALSE;
0041 END_IF
PCMD_WRITE (ST)
0001 (* PCMD_WRITE *)
0002
     (* Write to PCMD target position register *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
         oActuator.wTarget := wActuatorTarget;
0007
         oActuator.xBusy := TRUE;
0008
         oActuator.xSend := TRUE;
0009 END_IF
0010
     (* set PCMD target position *)
0011
0012 oActuator.oMBMaster(
0013
         xCONNECT
                        := oActuator.tonConnect.Q,
0014
         strIP ADDRESS
                            := strAddress,
0015
         wPORT
                             := wPort,
0016
         bUNIT ID
                        := bID,
0017
           bFUNCTION_CODE := 16#06,
                                            (*WriteSingleRegister*)
0018
            wREAD\_ADDRESS := 0,
0019
           wREAD_QUANTITY := 0,
0020
            ptREAD_DATA
                           := 0,
0021
         wWRITE_ADDRESS
                            := 16#9901,
0022
         wWRITE_QUANTITY
                            := 1,
0023
         ptSEND_DATA
                            := ADR(oActuator.wTarget),
0024
         tTIME_OUT
                            := tTCP_Timeout,
0025
         tCON_WATCHDOG
                           := tTCP_Watchdog,
0026
         xSEND
                            := oActuator.xSend
0027
0028
0029 (* Test for transaction complete *)
0030 | IF oActuator.oMBMaster.wError <> 0 THEN
0031
         (* error, return to RESET *)
0032
         uiFailing := uiFailing + 1;
0033
         oActuator.xConnect := FALSE;
0034
         oActuator.xBusy := FALSE;
0035
        oActuator.xDataReady := FALSE;
0036
        oActuator.wState := 10;
0037 ELSIF NOT oActuator.xSend THEN
0038
       oActuator.xBusy := FALSE;
0039
         oActuator.xDataReady := TRUE;
0040
     ELSE
0041
         oActuator.xDataReady := FALSE;
0042 | END_IF
STATUS_READ (ST)
0001 (* STATUS_READ *)
0002
     (* read status registers PNOW thru STAT *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
         oActuator.xBusy := TRUE;
0007
         oActuator.xSend := TRUE;
```

```
0008
     END IF
0009
0010
     (* Get actuator status words *)
0011 oActuator.oMBMaster(
0012
         xCONNECT
                         := oActuator.tonConnect.Q,
0013
         strIP_ADDRESS
                            := strAddress,
0014
                            := wPort,
0015
         bUNIT_ID
                       := bID,
0016
           bFUNCTION_CODE := 16#03,
                                             (*ReadHoldingCoils*)
0017
           wREAD_ADDRESS:= 16#9000,
0018
           wREAD_QUANTITY := 10,
0019
           ptREAD_DATA
                           := ADR(oActuator.awStatus[0]),
0020
         wWRITE_ADDRESS
                            := 0,
0021
         wWRITE_QUANTITY
                            := 0,
0022
         ptSEND_DATA
                            := 0,
0023
         tTIME_OUT
                            := tTCP_Timeout,
0024
         tCON_WATCHDOG
                            := tTCP_Watchdog,
0025
         xSEND
                             := oActuator.xSend
0026
0027
0028 (* Test for transaction complete *)
0029 IF oActuator.oMBMaster.wError <> 0 THEN
0030
         (* error, return to RESET *)
0031
         uiFailing := uiFailing + 1;
0032
         oActuator.xConnect := FALSE;
0033
         oActuator.xBusy := FALSE;
0034
         oActuator.xDataReady := FALSE;
0035
         oActuator.wState := 10;
0036 ELSIF NOT oActuator.xSend THEN
0037
        wActuatorPosition := oActuator.awStatus[1];
0038
         wActuatorAlarm := oActuator.awStatus[2];
0039
         wActuatorStatus := oActuator.awStatus[5];
         oActuator.xBusy := FALSE;
0040
0041
         oActuator.xDataReady := TRUE;
0042 ELSE
0043
       oActuator.xDataReady := FALSE;
0044 | END_IF
PLC_PRG (PRG-ST)
0001 PROGRAM PLC_PRG
0002 VAR CONSTANT
0003
         (* Version control *)
0004
         cversion_major : word := 0;
                                        (* Version major index *)
0005
         cVERSION_MINOR : WORD := 1;
                                         (* Version minor index *)
0006
0007
         (* BR_SELECTOR indexes *)
0008
         cSINS01 : WORD := 1;
                                         (* SINS.1 branchline *)
                                         (* SINS.2 branchline *)
0009
         cSINS02
                         : WORD := 2;
0010
         cYAG
                         : WORD := 3;
                                         (* YAG screen *)
0011
0012
         (* Actuator Limits *)
0013
         cBR_SELECTOR_UL : WORD := 10000;
0014
         cactuator_target: array [1..3] of word := 0,9566,7225;
0015 END_VAR
0016
0017
     VAR
     (* ******* Supervisory Control ******* *)
0018
0019
      (* PFC_OUT DISCRETES *)
     (* %MX0.0 .. %MX639.15
0020
                                 *)
0021
         SC_RESET_REQUIRED AT %MX0.0:BOOL;
0022
          (* 1 SPARE *)
0023
         SC_ATB AT %MX0.2: BOOL := TRUE;
0024
         SC_AFB AT %MX0.3: BOOL := FALSE;
0025
         (* 4 SPARE *)
0026
0027
         SC_PE101_PSL AT %MX0.8:BOOL;
0028
         SC_PE201_PSL AT %MX0.9:BOOL;
0029
         SC_PE202_PSL AT %MX0.10:BOOL;
0030
          (* 1 SPARE *)
0031
0032
         SC_RP2110_AT_SPEED AT %MX0.12:BOOL;
0033
         SC_RP2111_AT_SPEED AT %MX0.13:BOOL;
0034
         SC_PE2110_PSL AT %MX0.14:BOOL;
0035
          SC_PE2111_PSL AT %MX0.15:BOOL;
```

```
0036
0037
          SC PE203 OK AT %MX1.0:BOOL;
0038
          SC_PE203_PSL_HI AT %MX1.1:BOOL;
0039
          SC_PE203_PSL_MIDHI AT %MX1.2:BOOL;
0040
          SC_PE203_PSL_MIDLO AT %MX1.3:BOOL;
0041
          SC_PE203_PSL_LO AT %MX1.4:BOOL;
0042
          (* 3 SPARE *)
0043
0044
          SC_PE211_OK AT %MX1.8:BOOL;
0045
          SC_PE211_PSL_HI AT %MX1.9:BOOL;
0046
          SC_PE211_PSL_MIDHI AT %MX1.10:BOOL;
0047
          SC_PE211_PSL_MIDLO AT %MX1.11:BOOL;
0048
          SC_PE211_PSL_LO AT %MX1.12:BOOL;
          (* 3 SPARE *)
0049
0050
0051
          SC_PE212_OK AT %MX2.0:BOOL;
0052
          SC_PE212_PSL_HI AT %MX2.1:BOOL;
0053
          SC_PE212_PSL_MIDHI AT %MX2.2:BOOL;
0054
          SC_PE212_PSL_MIDLO AT %MX2.3:BOOL;
0055
          SC_PE212_PSL_LO AT %MX2.4:BOOL;
0056
          (* 3 SPARE *)
0057
0058
          SC_LL211_LID_CLOSED AT %MX2.8:BOOL;
0059
          SC_LL211_ARM_RETRACTED AT %MX2.9:BOOL;
0060
          (* 6 SPARE *)
0061
          SC_V100_OPEN AT %MX3.0:BOOL;
0062
0063
          SC_V100_CLOSED AT %MX3.1:BOOL;
          (* 6 SPARE *)
0064
0065
0066
          SC_V101_BEAM_PASS AT %MX3.8:BOOL;
          SC_V101_OPEN AT %MX3.9:BOOL;
0067
          SC_V101_CLOSED AT %MX3.10:BOOL;
0068
0069
          SC_V101_OPEN_PERMIT AT %MX3.11:BOOL;
0070
          SC_V101_CLOSE_PERMIT AT %MX3.12:BOOL;
0071
          SC_V101_OPEN_CMD AT %MX3.13:BOOL;
          SC_V101_NOT_SYMBOL AT %MX3.14:BOOL;
0072
0073
          (* 1 SPARE *)
0074
0075
          SC_V201_BEAM_PASS AT %MX4.0 : BOOL;
          SC_V201_OPEN AT %MX4.1 : BOOL;
0076
          SC_V201_CLOSED AT %MX4.2 : BOOL;
0077
0078
          SC_V201_OPEN_PERMIT AT %MX4.3 : BOOL;
0079
          SC_V201_CLOSE_PERMIT AT %MX4.4 : BOOL;
0800
          SC_V201_OPEN_CMD AT %MX4.5 : BOOL;
0081
          SC_V201_NOT_SYMBOL AT %MX4.6:BOOL;
0082
          (* 1 SPARE *)
0083
0084
          SC_V202_OPEN AT %MX4.8 : BOOL;
0085
          SC_V202_CLOSED AT %MX4.9 : BOOL;
0086
          SC_V202_BEAM_PASS AT %MX4.10 : BOOL;
0087
          (* 5 SPARE *)
0088
0089
          SC_V203_BEAM_PASS AT %MX5.0 : BOOL;
0090
          SC_V203_OPEN AT %MX5.1 : BOOL;
0091
          SC_V203_CLOSED AT %MX5.2 : BOOL;
0092
          SC_V203_OPEN_PERMIT AT %MX5.3 : BOOL;
          SC_V203_CLOSE_PERMIT AT %MX5.4 : BOOL;
0093
          SC_V203_OPEN_CMD AT %MX5.5 : BOOL;
0094
          SC_V203_NOT_SYMBOL AT %MX5.6:BOOL;
0095
0096
          (* 1 SPARE *)
0097
0098
          SC_V204_BEAM_PASS AT %MX5.8 : BOOL;
0099
          SC_V204_OPEN AT %MX5.9 : BOOL;
0100
          SC_V204_CLOSED AT %MX5.10 : BOOL;
0101
          SC_V204_OPEN_PERMIT AT %MX5.11 : BOOL;
0102
          SC_V204_CLOSE_PERMIT AT %MX5.12 : BOOL;
0103
          SC_V204_OPEN_CMD AT %MX5.13 : BOOL;
0104
          SC_V204_NOT_SYMBOL AT %MX5.14:BOOL;
0105
          (* 1 SPARE *)
0106
          (* 1 SPARE *)
0107
0108
          SC_RPV211_OPEN AT %MX6.1 : BOOL;
```

```
0109
          SC_RPV211_CLOSED AT %MX6.2 : BOOL;
0110
          (* 2 SPARE *)
0111
          SC_RPV211_OPEN_CMD AT %MX6.5 : BOOL;
0112
          (* 2 SPARE *)
0113
0114
          (* 3 SPARE *)
0115
          SC_VENT211_SLOW_CMD AT %MX6.11 : BOOL;
0116
          SC_VENT211_FAST_CMD AT %MX6.12 : BOOL;
0117
          (* 3 SPARE *)
0118
0119
          (* 1 SPARE *)
          SC_TPV211_OPEN AT %MX7.1 : BOOL;
0120
0121
          SC_TPV211_CLOSED AT %MX7.2 : BOOL;
0122
          (* 2 SPARE *)
0123
          SC_TPV211_OPEN_CMD AT %MX7.5 : BOOL;
0124
          (* 2 SPARE *)
0125
0126
          (* 1 SPARE *)
0127
          SC_SLOTV211_OPEN AT %MX7.9 : BOOL;
0128
          SC_SLOTV211_CLOSED AT %MX7.10 : BOOL;
0129
          SC_SLOTV211_OPEN_PERMIT AT %MX7.11 : BOOL;
0130
          SC_SLOTV211_CLOSE_PERMIT AT %MX7.12 : BOOL;
0131
          SC_SLOTV211_OPEN_CMD AT %MX7.13 : BOOL;
0132
          SC_SLOTV211_CLOSE_CMD AT %MX7.14 : BOOL;
0133
          SC_SLOTV211_NOT_SYMBOL AT %MX7.15:BOOL;
0134
0135
          (* 1 SPARE *)
          SC_RPV212_OPEN AT %MX8.1 : BOOL;
0136
          SC_RPV212_CLOSED AT %MX8.2 : BOOL;
0137
0138
          (* 2 SPARE *)
0139
          SC_RPV212_OPEN_CMD AT %MX8.5 : BOOL;
0140
          (* 2 SPARE *)
0141
0142
          (* 3 SPARE *)
0143
          SC_VENT212_SLOW_CMD AT %MX8.11 : BOOL;
0144
          SC_VENT212_FAST_CMD AT %MX8.12 : BOOL;
          (* 3 SPARE *)
0145
0146
          (* 1 SPARE *)
0147
0148
          SC_TPV212_OPEN AT %MX9.1 : BOOL;
0149
          SC_TPV212_CLOSED AT %MX9.2 : BOOL;
0150
          (* 2 SPARE *)
0151
          SC_TPV212_OPEN_CMD AT %MX9.5 : BOOL;
0152
          (* 2 SPARE *)
0153
0154
          SC_RP2110_ON AT %MX9.8 : BOOL;
0155
          SC_RP2110_ON_CMD AT %MX9.9 : BOOL;
0156
          (* 6 SPARE *)
0157
0158
          SC_RP2111_ON AT %MX10.0 : BOOL;
0159
          SC_RP2111_ON_CMD AT %MX10.1 : BOOL;
0160
          (* 3 SPARE *)
0161
          SC_TP201_VENT_ENABLE_CMD AT %MX10.5 : BOOL;
0162
          SC_TP201_VENT_NOT_SYMBOL AT %MX10.6 : BOOL;
0163
          (* 1 SPARE *)
0164
          SC_TP201_OK AT %MX10.8 : BOOL;
0165
          SC_TP201_ON AT %MX10.9 : BOOL;
0166
          SC_TP201_OFF AT %MX10.10 : BOOL;
0167
          SC_TP201_ON_PERMIT AT %MX10.11 : BOOL;
0168
0169
          SC_TP201_OFF_PERMIT AT %MX10.12 : BOOL;
          SC_TP201_ON_CMD AT %MX10.13 : BOOL;
0170
          SC_TP201_NOT_SYMBOL AT %MX10.14:BOOL;
0171
0172
          (* 1 SPARE *)
0173
0174
          SC_TP211_OK AT %MX11.0 : BOOL;
0175
          SC_TP211_ON AT %MX11.1 : BOOL;
          SC_TP211_OFF AT %MX11.2 : BOOL;
0176
0177
          (* 5 SPARE *)
0178
0179
          SC_TP212_OK AT %MX11.8 : BOOL;
          SC_TP212_ON AT %MX11.9 : BOOL;
0180
          SC_TP212_OFF AT %MX11.10 : BOOL;
0181
```

```
0182
          (* 5 SPARE *)
0183
0184
          SC_LL_ACTUATOR_OK AT %MX12.0 : BOOL;
0185
          SC_LL_PE101_PSL AT %MX12.1 : BOOL;
0186
          SC_LL_PE201_PSL AT %MX12.2 : BOOL;
0187
          SC_LL_V202_OPN AT %MX12.3 : BOOL;
0188
          SC_LL_PE202_PSL AT %MX12.4 : BOOL;
0189
          SC_LL_PE203_OK AT %MX12.5 : BOOL;
0190
          SC_LL_PE203_PSL_LO AT %MX12.6 : BOOL;
0191
          SC_LL_TP201_OK AT %MX12.7 : BOOL;
0192
          (* 8 SPARE *)
0193
          SC_LL_ES_CONFIG_OK AT %MX13.0 : BOOL;
0194
          SC_LL_LL_CONFIG_OK AT %MX13.1 : BOOL;
0195
0196
          SC_LL_PE211_OK AT %MX13.2 : BOOL;
0197
          SC_LL_PE212_OK AT %MX13.3 : BOOL;
0198
          SC_LL_RP2111_ON AT %MX13.4 : BOOL;
0199
          SC_LL_PE2111_PSL AT %MX13.5 : BOOL;
0200
          SC_LL_TP211_TURBO_OK AT %MX13.6 : BOOL;
0201
          SC_LL_TP212_TURBO_OK AT %MX13.7 : BOOL;
0202
          SC_LL_PE2111_PSL_ES AT %MX13.8 : BOOL;
0203
          SC_LL_PE2111_PSL_LL AT %MX13.9 : BOOL;
0204
          (* 6 SPARE *)
0205
      (* PFC_IN DISCRETES
0206
                                   *)
0207
      (* %MX640.0 .. %MX1279.15
                                   *)
          SC_RESET_REQ AT %MX640.0 : BOOL;
0208
0209
          (* 15 SPARE *)
0210
0211
          SC_V101_OPN_REQ AT %MX641.0 : BOOL;
0212
          SC_V101_CLS_REQ AT %MX641.1 : BOOL;
          SC_V201_OPN_REQ AT %MX641.2 : BOOL;
0213
0214
          SC_V201_CLS_REQ AT %MX641.3 : BOOL;
          (* 2 RESERVED *)
0215
          SC_V203_OPN_REQ AT %MX641.6 : BOOL;
0216
0217
          SC_V203_CLS_REQ AT %MX641.7 : BOOL;
          SC_V204_OPN_REQ AT %MX641.8 : BOOL;
0218
          SC_V204_CLS_REQ AT %MX641.9 : BOOL;
0219
0220
          SC_TP201_ON_REQ AT %MX641.10 : BOOL;
0221
          SC_TP201_OFF_REQ AT %MX641.11 : BOOL;
          SC_TP201_VENT_ENABLE_REQ AT %MX641.12 : BOOL;
0222
          SC_TP201_VENT_DISABLE_REQ AT %MX641.13 : BOOL;
0223
0224
          (* 2 SPARE *)
0225
0226
          SC_SLOTV211_OPN_REQ AT %MX642.0 : BOOL;
0227
          SC_SLOTV211_CLS_REQ AT %MX642.1 : BOOL;
0228
          (* 14 SPARE *)
0229
0230
      (* PFC_OUT WORDs
                          *)
0231
      (* %MW1280 .. %MW3711
0232
          (* Version Numbers *)
0233
          SC_VERSION_MAJOR AT %MW1280 : WORD;
0234
          SC_VERSION_MINOR AT %MW1281 : WORD;
0235
          (* 2 RESERVED *)
0236
0237
          (* Analog vacuum pressure *)
          SC_PE101_PIY AT %MW1284 : WORD;
0238
          SC_PE201_PIY AT %MW1285 : WORD;
0239
          SC_PE202_PIY AT %MW1286 : WORD;
0240
          SC_PE203_HI_PIY AT %MW1287 : WORD;
0241
0242
          SC_PE203_LO_PIY AT %MW1288 : WORD;
0243
          SC_PE211_HI_PIY AT %MW1289 : WORD;
0244
          SC_PE211_LO_PIY AT %MW1290 : WORD;
0245
          SC_PE212_HI_PIY AT %MW1291 : WORD;
0246
          SC_PE212_LO_PIY AT %MW1292 : WORD;
0247
          (* 3 SPARE *)
0248
0249
          (* State Machine current command values *)
0250
          SC_BR_CMD_VAL AT %MW1296 : WORD;
          SC_ES_CMD_VAL AT %MW1297 : WORD;
0251
0252
          SC_LL_CMD_VAL AT %MW1298 : WORD;
0253
          (* 5 SPARE *)
0254
```

```
0255
          (* State Machine current values *)
0256
          SC BR STATE AT %MW1304 : WORD;
0257
          SC_ES_STATE AT %MW1305 : WORD;
0258
          SC_LL_STATE AT %MW1306 : WORD;
0259
          (* 5 SPARE *)
0260
0261
0262
      (* PFC_IN WORDs
      (* %MW3712 .. %MW4927 *)
0263
0264
          (* State Machine current command requests *)
0265
          SC_BR_CMD_REQ AT %MW3712 : WORD;
          SC_ES_CMD_REQ AT %MW3713 : WORD;
0266
          SC_LL_CMD_REQ AT %MW3714 : WORD;
0267
          (* 5 SPARE *)
0268
0269
0270
0271
      (* ***** Internal Variables ***** *)
0272
0273
          count : BYTE;
0274
          count2 : BYTE;
0275
          a_num : BYTE;
0276
0277
          (* Request to reset latched faults *)
0278
          RESET_REQ : BOOL;
0279
0280
          (* Vacuum Interlocks *)
0281
          PE101_PSL_LO: BOOL;
0282
          PE201_PSL_LO: BOOL;
0283
          PE202_PSL_LO: BOOL;
0284
          PE203_PIY_OK: BOOL;
0285
          PE203_PSH_HI: BOOL;
0286
          PE203_PSH_MIDHI: BOOL;
          PE203_PSL_MIDLO: BOOL;
0287
          PE203_PSL_LO: BOOL;
0288
          PE211_PIY_OK: BOOL;
0289
0290
          PE211_PSH_HI: BOOL;
0291
          PE211_PSH_MIDHI: BOOL;
0292
          PE211_PSL_MIDLO: BOOL;
          PE211_PSL_LO: BOOL;
0293
0294
          PE212_PIY_OK: BOOL;
0295
          PE212_PSH_HI: BOOL;
0296
          PE212_PSH_MIDHI: BOOL;
0297
          PE212_PSL_MIDLO: BOOL;
0298
          PE212_PSL_LO: BOOL;
0299
          RP211_PSL: BOOL;
0300
          BP211_PSL: BOOL;
0301
0302
          (* Valve Positions *)
0303
          V100_OPN: BOOL;
0304
          V100_CSD: BOOL;
0305
          V101_OPN: BOOL;
          V101_CSD: BOOL;
0306
          V201_OPN: BOOL;
0307
0308
          V201_CSD: BOOL;
          V202_OPN: BOOL;
0309
0310
          V202_CSD: BOOL;
          V203_OPN: BOOL;
0311
0312
          V203_CSD: BOOL;
0313
          V204_OPN: BOOL;
0314
          V204_CSD: BOOL;
0315
          VPV211_OPN: BOOL;
0316
          VPV211_CSD: BOOL;
0317
          RPV211_OPN: BOOL;
0318
          RPV211_CSD: BOOL;
0319
          TPV211_OPN: BOOL;
0320
          TPV211_CSD: BOOL;
0321
          LLV211_OPN: BOOL;
          LLV211_CSD: BOOL;
0322
          VPV212_OPN: BOOL;
0323
          VPV212_CSD: BOOL;
0324
0325
          RPV212_OPN: BOOL;
0326
          RPV212_CSD: BOOL;
0327
          TPV212_OPN: BOOL;
```

```
0328
          TPV212_CSD: BOOL;
0329
0330
          (* Pump Status *)
0331
          TP201_OK: BOOL;
0332
          TP201_ON: BOOL;
0333
          TP201_READY: BOOL;
0334
          TP211_OK: BOOL;
0335
          TP211_READY: BOOL;
0336
          TP212_OK: BOOL;
0337
          TP212_READY: BOOL;
0338
          RP211_ON: BOOL;
0339
          BP211_ON: BOOL;
0340
0341
          (* LoadLock Status *)
0342
          LL211_LID_CLOSED: BOOL;
0343
          LL211_ARM_RETRACTED: BOOL;
0344
0345
          (* Configuration Interlocks *)
0346
          ES_CONFIG_OK: BOOL;
0347
          LL_CONFIG_OK: BOOL;
0348
0349
          (* Latched Interlocks *)
0350
          LL_ACTUATOR_OK: BOOL;
0351
          LL_PE101_PSL_LO: BOOL;
          LL_PE201_PSL_LO: BOOL;
0352
0353
          LL_V202_OPN: BOOL;
0354
          LL_PE202_PSL_LO: BOOL;
0355
          LL_PE203_PIY_OK: BOOL;
0356
          LL_PE203_PSL_LO: BOOL;
0357
          LL_TP201_OK: BOOL;
0358
          LL_ES_CONFIG_OK: BOOL;
0359
          LL_LL_CONFIG_OK: BOOL;
0360
          LL_PE211_PIY_OK: BOOL;
          LL_PE212_PIY_OK: BOOL;
0361
          LL_BP211_ON: BOOL;
0362
0363
          LL_TP211_OK: BOOL;
          LL_TP212_OK: BOOL;
0364
0365
0366
          Reset_Required: BOOL;
0367
0368
          (* IAI Actuator Data and Commands *)
0369
          ACTUATOR_AT_TARGET: WORD;
0370
          ACTUATOR_CMD: WORD;
0371
          ACTUATOR_OK: BOOL;
0372
0373
          (* Valve and Pump requests *)
0374
          V101_OPN_REQ_SC: BOOL;
0375
          V101_CLS_REQ_SC: BOOL;
0376
          V201_OPN_REQ_SC: BOOL;
0377
          V201_CLS_REQ_SC: BOOL;
0378
          V203_OPN_REQ_SC: BOOL;
0379
          V203_CLS_REQ_SC: BOOL;
          V204_OPN_REQ_SC: BOOL;
0380
0381
          V204_CLS_REQ_SC: BOOL;
0382
          V204_CLS_REQ_ES: BOOL;
0383
          VPV211_SLOW_OPN_REQ_ES: BOOL;
          VPV211_SLOW_CLS_REQ_ES: BOOL;
0384
          VPV211_FAST_OPN_REQ_ES: BOOL;
0385
          VPV211_FAST_CLS_REQ_ES: BOOL;
0386
          RPV211_OPN_REQ_ES: BOOL;
0387
0388
          RPV211_CLS_REQ_ES: BOOL;
0389
          TPV211_OPN_REQ_ES: BOOL;
0390
          TPV211_CLS_REQ_ES: BOOL;
0391
          LLV211_OPN_REQ_SC: BOOL;
0392
          LLV211_CLS_REQ_SC: BOOL;
0393
          LLV211_CLS_REQ_ES: BOOL;
0394
          LLV211_CLS_REQ_LL: BOOL;
0395
          VPV212_SLOW_OPN_REQ_LL: BOOL;
0396
          VPV212_SLOW_CLS_REQ_LL: BOOL;
0397
          VPV212_FAST_OPN_REQ_LL: BOOL;
0398
          VPV212_FAST_CLS_REQ_LL: BOOL;
0399
          RPV212_OPN_REQ_LL: BOOL;
          RPV212_CLS_REQ_LL: BOOL;
0400
```

```
0401
          TPV212_OPN_REQ_LL: BOOL;
0402
          TPV212_CLS_REQ_LL: BOOL;
0403
0404
          TP201_ON_REQ_SC: BOOL;
0405
          TP201_OFF_REQ_SC: BOOL;
          TP201_VENT_ENABLE_REQ_SC: BOOL;
0406
          TP201_VENT_DISABLE_REQ_SC: BOOL;
0407
0408
0409
          RP211_ON_REQ_ES: BOOL;
0410
          RP211_ON_REQ_LL: BOOL;
0411
          TP211_ON_REQ_ES: BOOL;
0412
          TP211_OFF_REQ_ES: BOOL;
0413
          TP212_ON_REQ_LL: BOOL;
0414
          TP212_OFF_REQ_LL: BOOL;
0415
0416
          (* State Machine States and Controls*)
0417
          BR_STATE: BR_ST := BR_ERROR;
0418
          BR_REQUEST: BR_REQ := BR_NONE_REQ;
0419
          ES_STATE: PV_ST := PV_ERROR;
0420
          ES_REQUEST: PV_REQ := PV_NONE_REQ;
0421
          LL_STATE: PV_ST := PV_ERROR;
0422
          LL_REQUEST: PV_REQ := PV_NONE_REQ;
0423
0424
          (* Valves *)
0425
          V101: VALVE_FB;
0426
          V201: VALVE_FB;
0427
          V203: VALVE_FB;
0428
          V204: VALVE_FB;
0429
0430
          VPV201: VALVE_FB;
0431
          VPV211_SLOW: VALVE_FB;
0432
          VPV211_FAST: VALVE_FB;
0433
          RPV211: VALVE_FB;
0434
          TPV211: VALVE_FB;
0435
0436
          LLV211: VALVE_BI_FB;
0437
0438
          VPV212_SLOW: VALVE_FB;
0439
          VPV212_FAST: VALVE_FB;
0440
          RPV212: VALVE_FB;
0441
          TPV212: VALVE_FB;
0442
0443
          (* Pumps *)
0444
          TP201: TP_FB;
0445
0446
          RP211: RP FB:
0447
          BP211_ON_CMD: BOOL := TRUE; (* always on *)
0448
0449
          TP211: TP_FB;
0450
          TP212: TP_FB;
0451
      END_VAR
0452
0001
      (* Evaluate Inputs *)
0002
      Process_Inputs();
0003
      SC_Inputs();
0004
      Actuator_Inputs();
0005
0006
      (* Temporary interlock bypasses *)
0007
      Bypasses();
8000
0009
      (* Internal logic *)
0010
      Fault_Logic();
0011
0012
      BR_SM();
0013
      ES_SM();
0014
      LL_SM();
0015
0016
                  (* must go before Valves() *)
      Pumps();
0017
      Valves();
0018
0019
      (* Evaluate Outputs *)
0020
      Actuator_Outputs();
0021
      SC_Outputs();
```

```
0022
     Process_Outputs();
0023
0024
      (* Clear rising edge requests *)
0025 Clear_Reqs();
Actuator_Inputs (ST)
0001
     (* Process Actuator Inputs *)
0002
0003
     ACTUATOR_OK := NOT (wActuatorStatus.10 OR wActuatorStatus.12);
0004
0005
     IF (xActuatorReady) THEN
0006
          FOR count2:=1 TO 4 DO
0007
              IF (wActuatorPosition = cACTUATOR_TARGET[count2]) THEN
8000
                  ACTUATOR_AT_TARGET := count2;
0009
                  EXIT;
0010
              END_IF;
0011
          END_FOR;
0012
     ELSE
0013
          ACTUATOR_AT_TARGET := 0;
0014 END_IF;
Actuator_Outputs (ST)
0001
     (* IAI Actuator Outputs *)
0002
0003
      IF ACTUATOR_CMD <> 0 THEN
0004
          wActuatorTarget := cACTUATOR_TARGET[ACTUATOR_CMD] ;
0005
     TEND_IF
BR_SM (ST)
0001
      (* State Machine for BRanchline selection *)
0002
0003
      (* Always test for BR_ERROR first *)
0004
     IF NOT LL_ACTUATOR_OK THEN
0005
         BR_STATE := BR_ERROR;
0006
     END_IF
0007
0008
     CASE BR_STATE OF
0009
          BR_ERROR:
0010
              (* Leave in place *)
0011
              ACTUATOR_CMD := 0;
0012
0013
              IF LL_ACTUATOR_OK THEN
0014
                  BR_STATE := BR_SINS1_SELECTING;
0015
              END_IF
0016
0017
          BR_SINS1_SELECTING:
0018
              (* Move actuator to SINS.1 *)
0019
              ACTUATOR_CMD := cSINS01;
0020
0021
              (* Wait for motion to complete *)
0022
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0023
                  BR_STATE := BR_SINS1_READY;
0024
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0025
                  BR_STATE := BR_SINS1_SELECTING;
0026
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0027
                  BR_STATE := BR_SINS2_SELECTING;
0028
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0029
                  BR_STATE := BR_YAG_SELECTING;
0030
              END_IF
0031
0032
          BR_SINS1_READY:
0033
              (* Keep at SINS.1 *)
0034
              ACTUATOR_CMD := cSINS01;
0035
0036
              (* Look for state change request *)
0037
              IF BR_REQUEST = BR_NONE_REQ THEN
0038
                  BR_STATE := BR_SINS1_READY;
0039
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0040
                  BR_STATE := BR_SINS1_READY;
0041
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0042
                  BR_STATE := BR_SINS2_SELECTING;
0043
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0044
                  BR_STATE := BR_YAG_SELECTING;
              END_IF
0045
```

```
0046
0047
          BR SINS2 SELECTING:
0048
              (* Move actuator to SINS.2 *)
0049
              ACTUATOR_CMD := cSINS02;
0050
0051
              (* Wait for motion to complete *)
0052
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0053
                  BR_STATE := BR_SINS2_READY;
0054
              (* Else look for state change request *)
0055
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0056
                  BR_STATE := BR_SINS1_SELECTING;
0057
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0058
                  BR_STATE := BR_SINS2_SELECTING;
0059
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0060
                  BR_STATE := BR_YAG_SELECTING;
0061
              END IF
0062
0063
          BR_SINS2_READY:
0064
              (* Keep at SINS.2 *)
0065
              ACTUATOR_CMD := cSINS02;
0066
              (* Look for state change request *)
0067
0068
              IF BR_REQUEST = BR_NONE_REQ THEN
0069
                  BR_STATE := BR_SINS2_READY;
0070
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0071
                  BR_STATE := BR_SINS1_SELECTING;
0072
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0073
                  BR_STATE := BR_SINS2_READY;
0074
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0075
                  BR_STATE := BR_YAG_SELECTING;
0076
              END_IF
0077
          BR_YAG_SELECTING:
0078
              (* Move actuator to YAG *)
0079
0800
              ACTUATOR_CMD := cYAG;
0081
0082
              (* Wait for motion to complete *)
0083
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0084
                  BR_STATE := BR_YAG_READY;
0085
              (* Else look for state change request *)
0086
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0087
                  BR_STATE := BR_SINS1_SELECTING;
0088
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0089
                  BR_STATE := BR_SINS2_SELECTING;
0090
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0091
                  BR_STATE := BR_YAG_SELECTING;
0092
              END_IF
0093
0094
          BR_YAG_READY:
0095
              (* Keep at YAG *)
              ACTUATOR_CMD := cYAG;
0096
0097
0098
              (* Look for state change request *)
0099
              IF BR_REQUEST = BR_NONE_REQ THEN
                  BR_STATE := BR_YAG_READY;
0100
0101
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
                  BR_STATE := BR_SINS1_SELECTING;
0102
0103
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0104
                  BR_STATE := BR_SINS2_SELECTING;
0105
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0106
                  BR_STATE := BR_YAG_READY;
0107
              END_IF
0108
0109
0110
              BR_STATE := BR_ERROR;
0111
     END_CASE;
Bypasses (ST)
0001
      (* Temporary Bypass Logic *)
0002
          (* Will remove this after initial testing *)
0003
          ACTUATOR_OK := TRUE;
0004
          ES_CONFIG_OK := TRUE;
0005
          LL_CONFIG_OK := TRUE;
0006
```

```
0007
          (* For testing during DP repair
0008
          V100 OPN := TRUE;
          V100_CSD := FALSE;
0009
0010
0011
          V101_OPN := TRUE;
          V101_CSD := FALSE;
0012
0013
          V201_OPN := TRUE;
0014
          V201_CSD := FALSE;
0015
0016
0017
          V202_OPN := FALSE;
0018
          V202_CSD := TRUE;
0019
0020
          V203_OPN := FALSE;
0021
          V203_CSD := TRUE;
0022
           *)
Clear_Reqs (ST)
0001
     (* Clear all edge-triggered supervisory requests *)
0002
0003
      SC_RESET_REQ := 0;
0004
0005
      SC_V101_OPN_REQ := 0;
0006
     SC_V101_CLS_REQ := 0;
0007
0008
     SC_V201_OPN_REQ := 0;
0009
      SC_V201_CLS_REQ := 0;
0010
0011
      SC_V203_OPN_REQ := 0;
0012
      SC_V203_CLS_REQ := 0;
0013
0014
     SC_V204_OPN_REQ := 0;
0015
      SC_V204_CLS_REQ := 0;
0016
0017
      SC_TP201_ON_REQ := 0;
0018
      SC_TP201_OFF_REQ := 0;
0019
      SC_TP201_VENT_ENABLE_REQ := 0;
0020
      SC_TP201_VENT_DISABLE_REQ := 0;
0021
0022
      SC SLOTV211 OPN REO := 0;
0023 SC_SLOTV211_CLS_REQ := 0;
ES_SM (ST)
0001
     (* ES211 Pump/Vent State Machine *)
0002
      (* Always test for PV_ERROR first *)
0003
0004
      IF NOT (LL_PE211_PIY_OK AND LL_ES_CONFIG_OK) THEN
0005
          ES_STATE := PV_ERROR;
0006
      END_IF
0007
0008
      CASE ES_STATE OF
0009
          PV_ERROR:
0010
              V204_CLS_REQ_ES := TRUE;
0011
              LLV211_CLS_REQ_ES := TRUE;
0012
              RPV211_OPN_REQ_ES := FALSE;
0013
              RP211_ON_REQ_ES := FALSE;
0014
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0015
              VPV211_FAST_OPN_REQ_ES := FALSE;
0016
              TPV211_OPN_REQ_ES := FALSE;
0017
              TP211_ON_REQ_ES := FALSE;
0018
              IF LL_PE211_PIY_OK THEN
0019
0020
                  ES_STATE := PV_ISOLATING;
0021
              END_IF
0022
0023
          PV_ISOLATING:
0024
              V204 CLS REO ES := TRUE;
0025
              LLV211_CLS_REQ_ES := TRUE;
0026
              RPV211_OPN_REQ_ES := FALSE;
0027
              RP211_ON_REQ_ES := FALSE;
0028
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0029
              VPV211_FAST_OPN_REQ_ES := FALSE;
0030
              TPV211 OPN REO ES := FALSE;
0031
              TP211_ON_REQ_ES := FALSE;
```

```
0032
0033
              IF V204_CSD AND LLV211_CSD AND RPV211_CSD THEN
0034
                  ES_STATE := PV_ISOLATED;
0035
              END_IF
0036
0037
          PV_ISOLATED:
0038
              V204_CLS_REQ_ES := TRUE;
0039
              LLV211_CLS_REQ_ES := TRUE;
0040
              RPV211_OPN_REQ_ES := FALSE;
0041
              RP211_ON_REQ_ES := FALSE;
0042
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0043
              VPV211_FAST_OPN_REQ_ES := FALSE;
              TPV211_OPN_REQ_ES := FALSE;
0044
0045
              TP211_ON_REQ_ES := FALSE;
0046
0047
              IF (ES_REQUEST = PV_VENT_REQ) THEN
0048
                  ES_STATE := PV_SLOW_VENTING;
0049
              ELSIF (ES_REQUEST = PV_PUMP_REQ) AND PE211_PSL_MIDLO AND TP211_OK THEN
0050
                  ES_STATE := PV_TP_PUMPING;
0051
              ELSIF (ES_REQUEST = PV_PUMP_REQ) THEN
0052
                  ES_STATE := PV_RP_STARTING;
              END_IF
0053
0054
0055
          PV_SLOW_VENTING:
0056
              V204_CLS_REQ_ES := TRUE;
0057
              LLV211_CLS_REQ_ES := TRUE;
0058
              RPV211_OPN_REQ_ES := FALSE;
0059
              RP211_ON_REQ_ES := FALSE;
0060
              VPV211_SLOW_OPN_REQ_ES := TRUE;
0061
              VPV211_FAST_OPN_REQ_ES := FALSE;
0062
              TPV211_OPN_REQ_ES := FALSE;
0063
              TP211_ON_REQ_ES := FALSE;
0064
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0065
                  ES_STATE := PV_SLOW_VENTING;
0066
0067
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0068
                  ES_STATE := PV_ISOLATING;
0069
              ELSIF (PE211_PSH_MIDHI) THEN
0070
                  ES_STATE := PV_FAST_VENTING;
0071
              END_IF
0072
0073
          PV_FAST_VENTING:
              V204_CLS_REQ_ES := TRUE;
0074
              LLV211_CLS_REQ_ES := TRUE;
0075
0076
              RPV211_OPN_REQ_ES := FALSE;
0077
              RP211_ON_REQ_ES := FALSE;
0078
              VPV211_SLOW_OPN_REQ_ES := TRUE;
0079
              VPV211_FAST_OPN_REQ_ES := TRUE;
0080
              TPV211_OPN_REQ_ES := FALSE;
0081
              TP211_ON_REQ_ES := FALSE;
0082
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0083
                  ES_STATE := PV_FAST_VENTING;
0084
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0085
                  ES_STATE := PV_ISOLATING;
0086
0087
              ELSIF (PE211_PSH_HI) THEN
                  ES_STATE := PV_VENTED;
0088
0089
              END_IF
0090
0091
          PV_VENTED:
0092
              V204_CLS_REQ_ES := TRUE;
0093
              LLV211_CLS_REQ_ES := FALSE; (* LLV211 can be opened when both ES211 and LL211 are vented *)
0094
              RPV211_OPN_REQ_ES := FALSE;
0095
              RP211_ON_REQ_ES := FALSE;
0096
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0097
              VPV211_FAST_OPN_REQ_ES := FALSE;
0098
              TPV211_OPN_REQ_ES := FALSE;
0099
              TP211_ON_REQ_ES := FALSE;
0100
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0101
0102
                  ES_STATE := PV_VENTED;
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0103
                  ES_STATE := PV_ISOLATING;
0104
```

```
0105
              ELSIF (NOT PE211_PSH_HI) THEN
0106
                  ES_STATE := PV_FAST_VENTING;
0107
              END_IF
0108
0109
          PV_RP_STARTING:
0110
              V204_CLS_REQ_ES := TRUE;
0111
              LLV211_CLS_REQ_ES := TRUE;
0112
              RPV211_OPN_REQ_ES := FALSE;
0113
              RP211_ON_REQ_ES := TRUE;
0114
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0115
              VPV211_FAST_OPN_REQ_ES := FALSE;
              TPV211_OPN_REQ_ES := FALSE;
0116
0117
              TP211_ON_REQ_ES := FALSE;
0118
0119
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0120
                  ES_STATE := PV_RP_STARTING;
0121
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0122
                  ES_STATE := PV_ISOLATING;
0123
              ELSIF (RP211_ON) THEN
0124
                  (* ignore RP211_PSL *)
0125
                  ES_STATE := PV_RP_PUMPING;
0126
              END_IF
0127
0128
          PV_RP_PUMPING:
0129
              V204_CLS_REQ_ES := TRUE;
0130
              LLV211_CLS_REQ_ES := TRUE;
0131
              RPV211_OPN_REQ_ES := TRUE;
0132
              RP211_ON_REQ_ES := TRUE;
0133
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0134
              VPV211_FAST_OPN_REQ_ES := FALSE;
              TPV211_OPN_REQ_ES := FALSE;
0135
0136
              TP211_ON_REQ_ES := FALSE;
0137
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0138
0139
                  ES_STATE := PV_RP_PUMPING;
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0140
                  ES_STATE := PV_ISOLATING;
0141
              ELSIF (PE211_PSL_MIDLO) THEN
0142
0143
                  ES_STATE := PV_RP_PUMPED;
0144
              END_IF
0145
0146
          PV_RP_PUMPED:
              V204_CLS_REQ_ES := TRUE;
0147
              LLV211_CLS_REQ_ES := TRUE;
0148
0149
              RPV211_OPN_REQ_ES := TRUE;
0150
              RP211_ON_REQ_ES := TRUE;
0151
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0152
              VPV211_FAST_OPN_REQ_ES := FALSE;
0153
              TPV211_OPN_REQ_ES := FALSE;
0154
              TP211_ON_REQ_ES := FALSE;
0155
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0156
                  ES_STATE := PV_RP_PUMPED;
0157
0158
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
                  ES_STATE := PV_ISOLATING;
0159
0160
              ELSIF (NOT PE211_PSL_MIDLO) THEN
                  ES_STATE := PV_RP_PUMPING;
0161
0162
              ELSIF (TP211_OK) THEN
0163
                   (* First isolate, then go to TP_STARTING *)
0164
                  ES_STATE := PV_ISOLATING;
0165
              END_IF
0166
0167
          PV_TP_PUMPING:
0168
              V204_CLS_REQ_ES := TRUE;
0169
              LLV211_CLS_REQ_ES := TRUE;
0170
              RPV211_OPN_REQ_ES := FALSE;
0171
              RP211_ON_REQ_ES := TRUE; (* Leave on in case MIDLO false *)
0172
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0173
              VPV211_FAST_OPN_REQ_ES := FALSE;
              TPV211_OPN_REQ_ES := TRUE;
0174
0175
              TP211_ON_REQ_ES := TRUE;
0176
0177
              IF (ES_REQUEST = PV_NONE_REQ) THEN
```

```
0178
                  ES_STATE := PV_TP_PUMPING;
0179
              ELSIF NOT (ES REOUEST = PV PUMP REO) THEN
0180
                  ES_STATE := PV_ISOLATING;
0181
              ELSIF (NOT PE211_PSL_MIDLO) THEN
0182
                  ES_STATE := PV_RP_PUMPING;
0183
              ELSIF (PE211_PSL_LO) THEN
0184
                  ES_STATE := PV_PUMPED;
0185
              END_IF
0186
0187
          PV_PUMPED:
0188
              V204_CLS_REQ_ES := FALSE;
              LLV211_CLS_REQ_ES := FALSE; (* LLV211 can be opened when both ES211 and LL211 are pumped *)
0189
0190
              RPV211_OPN_REQ_ES := FALSE;
0191
              RP211_ON_REQ_ES := FALSE;
0192
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0193
              VPV211_FAST_OPN_REQ_ES := FALSE;
0194
              TPV211_OPN_REQ_ES := TRUE;
0195
              TP211_ON_REQ_ES := TRUE;
0196
0197
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0198
                  ES_STATE := PV_PUMPED;
0199
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0200
                 ES_STATE := PV_ISOLATING;
0201
              ELSIF (NOT PE211_PSL_MIDLO) THEN
0202
                  (* return to PV_RP_PUMPING via PV_ISOLATING *)
0203
                  ES_STATE := PV_ISOLATING;
0204
              ELSIF (PE211_PSL_LO) THEN
0205
                 ES_STATE := PV_PUMPED;
0206
              END_IF
0207
0208
          ELSE
0209
              (* Invalid State, should never get here *)
0210
              ES_STATE := PV_ERROR;
0211
0212 END_CASE
0213
Fault_Logic (ST)
0001 (* Latched interlocks *)
0003 LL_ACTUATOR_OK := ACTUATOR_OK AND (LL_ACTUATOR_OK OR RESET_REQ);
0004 LL_PE101_PSL_LO := PE101_PSL_LO AND (LL_PE101_PSL_LO OR RESET_REQ);
0005 LL_PE201_PSL_LO := PE201_PSL_LO AND (LL_PE201_PSL_LO OR RESET_REQ);
     LL_V202_OPN := V202_OPN AND (LL_V202_OPN OR RESET_REQ);
     LL_PE202_PSL_LO := PE202_PSL_LO AND (LL_PE202_PSL_LO OR RESET_REQ);
0008 LL_PE203_PSL_LO := PE203_PSL_LO AND (LL_PE203_PSL_LO OR RESET_REQ);
0009
0010 LL_ES_CONFIG_OK := ES_CONFIG_OK AND (LL_ES_CONFIG_OK OR RESET_REQ);
0011
     LL_LL_CONFIG_OK := LL_CONFIG_OK AND (LL_LL_CONFIG_OK OR RESET_REQ);
0012
0013
     LL_PE203_PIY_OK := PE203_PIY_OK AND (LL_PE203_PIY_OK OR RESET_REQ);
0014
     LL_PE211_PIY_OK := PE211_PIY_OK AND (LL_PE211_PIY_OK OR RESET_REQ);
0015
     LL_PE212_PIY_OK := PE212_PIY_OK AND (LL_PE212_PIY_OK OR RESET_REQ);
0016
0017
     LL_BP211_ON := BP211_ON AND (LL_BP211_ON OR RESET_REQ);
0018
0019
     LL_TP201_OK := TP201_OK AND (LL_TP201_OK OR RESET_REQ);
0020
     LL_TP211_OK := TP211_OK AND (LL_TP211_OK OR RESET_REQ);
0021
     LL_TP212_OK := TP212_OK AND (LL_TP212_OK OR RESET_REQ);
0022
0023
     Reset_Required :=
                          (ACTUATOR_OK AND NOT LL_ACTUATOR_OK) OR
0024
                           (PE101_PSL_LO AND NOT LL_PE101_PSL_LO) OR
0025
                           (PE201_PSL_LO AND NOT LL_PE201_PSL_LO) OR
0026
                           (V202_OPN AND NOT LL_V202_OPN) OR
0027
                           (PE202_PSL_LO AND NOT LL_PE202_PSL_LO) OR
0028
                           (PE203_PSL_LO AND NOT LL_PE203_PSL_LO) OR
0029
                           (ES_CONFIG_OK AND NOT LL_ES_CONFIG_OK) OR
0030
                           (LL_CONFIG_OK AND NOT LL_LL_CONFIG_OK) OR
0031
                           (PE203_PIY_OK AND NOT LL_PE203_PIY_OK) OR
0032
                           (PE211_PIY_OK AND NOT LL_PE211_PIY_OK) OR
0033
                           (PE212_PIY_OK AND NOT LL_PE212_PIY_OK) OR
                           (BP211_ON AND NOT LL_BP211_ON) OR
0034
0035
                          (TP201_OK AND NOT LL_TP201_OK) OR
0036
                          (TP211_OK AND NOT LL_TP211_OK) OR
```

```
0037
                           (TP212_OK AND NOT LL_TP212_OK);
0038
LL_SM (ST)
0001
      (* LL211 Pump/Vent State Machine *)
0002
0003
      (* Always test for PV_ERROR first *)
0004
      IF NOT (LL_PE212_PIY_OK AND LL_LL_CONFIG_OK) THEN
0005
          LL_STATE := PV_ERROR;
0006
     END_IF
0007
     CASE LL_STATE OF
8000
0009
0010
          PV_ERROR:
0011
              LLV211_CLS_REQ_LL := TRUE;
0012
              RPV212_OPN_REQ_LL := FALSE;
0013
              RP211_ON_REQ_LL := FALSE;
0014
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0015
              VPV212_FAST_OPN_REQ_LL := FALSE;
0016
              TPV212_OPN_REQ_LL := FALSE;
0017
              TP212_ON_REQ_LL := FALSE;
0018
0019
              IF LL_PE212_PIY_OK THEN
0020
                  LL_STATE := PV_ISOLATING;
0021
              END_IF
0022
0023
          PV_ISOLATING:
0024
              LLV211_CLS_REQ_LL := TRUE;
              RPV212_OPN_REQ_LL := FALSE;
0025
0026
              RP211_ON_REQ_LL := FALSE;
0027
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0028
              VPV212_FAST_OPN_REQ_LL := FALSE;
0029
              TPV212_OPN_REQ_LL := FALSE;
0030
              TP212_ON_REQ_LL := FALSE;
0031
0032
              IF LLV211 CSD AND RPV212 CSD
0033
                  LL_STATE := PV_ISOLATED;
0034
              END IF
0035
0036
          PV ISOLATED:
0037
              LLV211_CLS_REQ_LL := TRUE;
0038
              RPV212_OPN_REQ_LL := FALSE;
0039
              RP211_ON_REQ_LL := FALSE;
0040
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0041
              VPV212_FAST_OPN_REQ_LL := FALSE;
0042
              TPV212_OPN_REQ_LL := FALSE;
0043
              TP212_ON_REQ_LL := FALSE;
0044
0045
              IF (LL_REQUEST = PV_VENT_REQ) THEN
0046
                  LL_STATE := PV_SLOW_VENTING;
0047
              ELSIF (LL_REQUEST = PV_PUMP_REQ) AND PE212_PSL_MIDLO AND TP212_OK THEN
0048
                  LL_STATE := PV_TP_PUMPING;
0049
              ELSIF (LL_REQUEST = PV_PUMP_REQ) THEN
0050
                  LL_STATE := PV_RP_STARTING;
0051
              END_IF
0052
0053
          PV_SLOW_VENTING:
0054
              LLV211_CLS_REQ_LL := TRUE;
0055
              RPV212_OPN_REQ_LL := FALSE;
0056
              RP211_ON_REQ_LL := FALSE;
0057
              VPV212_SLOW_OPN_REQ_LL := TRUE;
0058
              VPV212_FAST_OPN_REQ_LL := FALSE;
0059
              TPV212_OPN_REQ_LL := FALSE;
0060
              TP212_ON_REQ_LL := FALSE;
0061
0062
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0063
                  LL_STATE := PV_SLOW_VENTING;
0064
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
0065
                  LL_STATE := PV_ISOLATING;
0066
              ELSIF (PE212_PSH_MIDHI) THEN
0067
                  LL_STATE := PV_FAST_VENTING;
0068
              END_IF
0069
0070
          PV_FAST_VENTING:
```

```
LLV211_CLS_REQ_LL := TRUE;
0072
              RPV212 OPN REO LL := FALSE;
0073
              RP211_ON_REQ_LL := FALSE;
0074
              VPV212_SLOW_OPN_REQ_LL := TRUE;
0075
              VPV212_FAST_OPN_REQ_LL := TRUE;
0076
              TPV212_OPN_REQ_LL := FALSE;
0077
              TP212_ON_REQ_LL := FALSE;
0078
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0079
0080
                  LL_STATE := PV_FAST_VENTING;
0081
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
                  LL_STATE := PV_ISOLATING;
0082
              ELSIF (PE212_PSH_HI) THEN
0083
0084
                  LL_STATE := PV_VENTED;
0085
              END_IF
0086
0087
          PV_VENTED:
0088
              LLV211_CLS_REQ_LL := FALSE; (* LLV211 can be opened when both ES211 and LL211 are vented *)
0089
              RPV212_OPN_REQ_LL := FALSE;
0090
              RP211_ON_REQ_LL := FALSE;
0091
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0092
              VPV212_FAST_OPN_REQ_LL := FALSE;
0093
              TPV212_OPN_REQ_LL := FALSE;
0094
              TP212_ON_REQ_LL := FALSE;
0095
0096
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0097
                  LL_STATE := PV_VENTED;
0098
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
0099
                  LL_STATE := PV_ISOLATING;
0100
              ELSIF (NOT PE212_PSH_HI) THEN
0101
                  LL_STATE := PV_FAST_VENTING;
0102
              END_IF
0103
0104
          PV_RP_STARTING:
0105
              LLV211_CLS_REQ_ES := TRUE;
0106
              RPV212_OPN_REQ_LL := FALSE;
0107
              RP211_ON_REQ_LL := TRUE;
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0108
              VPV212_FAST_OPN_REQ_LL := FALSE;
0109
0110
              TPV212_OPN_REQ_LL := FALSE;
0111
              TP212_ON_REQ_LL := FALSE;
0112
0113
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0114
                  LL_STATE := PV_RP_STARTING;
0115
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0116
                  LL_STATE := PV_ISOLATING;
0117
              ELSIF (RP211_ON) THEN
0118
                   (* ignore RP211_PSL *)
0119
                  LL_STATE := PV_RP_PUMPING;
0120
              END_IF
0121
0122
          PV_RP_PUMPING:
0123
              LLV211_CLS_REQ_LL := TRUE;
0124
              RPV212_OPN_REQ_LL := TRUE;
0125
              RP211_ON_REQ_LL := TRUE;
0126
              VPV212_SLOW_OPN_REQ_LL := FALSE;
              VPV212_FAST_OPN_REQ_LL := FALSE;
0127
              TPV212_OPN_REQ_LL := FALSE;
0128
0129
              TP212_ON_REQ_LL := FALSE;
0130
0131
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0132
                  LL_STATE := PV_RP_PUMPING;
0133
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0134
                  LL_STATE := PV_ISOLATING;
0135
              ELSIF (PE212_PSL_MIDLO) THEN
0136
                  LL_STATE := PV_RP_PUMPED;
0137
              END_IF
0138
0139
          PV_RP_PUMPED:
0140
              LLV211_CLS_REQ_LL := TRUE;
0141
              RPV212_OPN_REQ_LL := TRUE;
              RP211_ON_REQ_LL := TRUE;
0142
0143
              VPV212_SLOW_OPN_REQ_LL := FALSE;
```

```
0144
              VPV212_FAST_OPN_REQ_LL := FALSE;
0145
              TPV212 OPN REO LL := FALSE;
0146
              TP212_ON_REQ_LL := FALSE;
0147
0148
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0149
                  LL_STATE := PV_RP_PUMPED;
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0150
0151
                  LL_STATE := PV_ISOLATING;
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0152
0153
                  LL_STATE := PV_RP_PUMPING;
0154
              ELSIF (TP212_OK) THEN
0155
                   (* First isolate, then go to TP_STARTING *)
                  LL_STATE := PV_ISOLATING;
0156
0157
              END IF
0158
0159
          PV_TP_PUMPING:
0160
              LLV211_CLS_REQ_LL := TRUE;
0161
              RPV212_OPN_REQ_LL := FALSE;
0162
              RP211_ON_REQ_LL := TRUE; (* Leave on in case MIDLO false *)
0163
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0164
              VPV212_FAST_OPN_REQ_LL := FALSE;
0165
              TPV212_OPN_REQ_LL := TRUE;
0166
              TP212_ON_REQ_LL := TRUE;
0167
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0168
0169
                  LL_STATE := PV_TP_PUMPING;
0170
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0171
                  LL_STATE := PV_ISOLATING;
0172
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0173
                  LL_STATE := PV_RP_PUMPING;
0174
              ELSIF (PE212_PSL_LO) THEN
0175
                  LL_STATE := PV_PUMPED;
              END_IF
0176
0177
          PV_PUMPED:
0178
0179
              LLV211_CLS_REQ_LL := FALSE; (* LLV211 can be opened when both ES211 and LL211 are pumped *)
0180
              RPV212_OPN_REQ_LL := FALSE;
0181
              RP211_ON_REQ_LL := FALSE;
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0182
0183
              VPV212_FAST_OPN_REQ_LL := FALSE;
0184
              TPV212_OPN_REQ_LL := TRUE;
0185
              TP212_ON_REQ_LL := TRUE;
0186
0187
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0188
                  LL_STATE := PV_PUMPED;
0189
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0190
                  LL_STATE := PV_ISOLATING;
0191
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0192
                  (* return to PV_RP_PUMPING via PV_ISOLATING *)
0193
                  LL_STATE := PV_ISOLATING;
0194
              ELSIF (PE212_PSL_LO) THEN
0195
                  LL_STATE := PV_PUMPED;
0196
              END_IF
0197
0198
          FLSE
0199
              (* Invalid State, should never get here *)
              LL_STATE := PV_ERROR;
0200
0201
0202 END_CASE
Process_Inputs (ST)
0001
      (*=== Processed Inputs *)
0002
      (* DISCRETE IN *)
0003
      PE101_PSL_LO := DI_PE101_PSL_LO;
0004
      PE201_PSL_LO := DI_PE201_PSL_LO;
0005
      PE202_PSL_LO := DI_PE202_PSL_LO;
0006
0007
      RP211_ON := DI_RP2110_ON;
8000
      BP211_ON := DI_RP2111_ON;
0009
      RP211_PSL := DI_PE2110_PSL;
0010
      BP211_PSL := DI_PE2111_PSL;
0011
0012
      PE203_PIY_OK := DI_PE203_PIY_OK;
0013
      PE203_PSH_HI := DI_PE203_PIY_OK AND NOT DI_PE203_PSL_HI;
```

```
0014
     PE203_PSH_MIDHI := DI_PE203_PIY_OK AND NOT DI_PE203_PSL_MIDHI;
0015
     PE203_PSL_MIDLO := DI_PE203_PSL_MIDLO;
0016
     PE203_PSL_LO := DI_PE203_PSL_LO;
0017
0018 | PE211_PIY_OK := DI_PE211_PIY_OK;
0019 PE211_PSH_HI := DI_PE211_PIY_OK AND NOT DI_PE211_PSL_HI;
0020 PE211_PSH_MIDHI := DI_PE211_PIY_OK AND NOT DI_PE211_PSL_MIDHI;
0021
     PE211_PSL_MIDLO := DI_PE211_PSL_MIDLO;
0022 PE211_PSL_LO := DI_PE211_PSL_LO;
0023
0024 PE212_PIY_OK := DI_PE212_PIY_OK;
0025 PE212_PSH_HI := DI_PE212_PIY_OK AND NOT DI_PE212_PSL_HI;
0026 PE212_PSH_MIDHI := DI_PE212_PIY_OK AND NOT DI_PE212_PSL_MIDHI;
0027 PE212_PSL_MIDLO := DI_PE212_PSL_MIDLO;
0028 PE212_PSL_LO := DI_PE212_PSL_LO;
0029
0030
     V100_OPN := DI_V100_OPEN;
0031
     V100_CSD := DI_V100_CLOSED;
0032
0033
     V101_OPN := DI_V101_OPEN AND DO_V101_OPEN_CMD;
0034
     V101_CSD := DI_V101_CLOSED AND NOT DO_V101_OPEN_CMD;
0035
0036
     V201_OPN := DI_V201_OPEN AND DO_V201_OPEN_CMD;
0037
     V201_CSD := DI_V201_CLOSED AND NOT DO_V201_OPEN_CMD;
0038
0039
     V202_OPN := DI_V202_OPEN;
0040
     V202_CSD := DI_V202_CLOSED;
0041
0042
     V203_OPN := DI_V203_OPEN AND DO_V203_OPEN_CMD;
0043
     V203_CSD := DI_V203_CLOSED AND NOT DO_V203_OPEN_CMD;
0044
0045
      V204_OPN := DI_V204_OPEN AND DO_V204_OPEN_CMD;
0046
     V204_CSD := DI_V204_CLOSED AND NOT DO_V204_OPEN_CMD;
0047
0048
     TP201_OK := DI_TP201_TURBO_OK;
0049
     TP201_ON := TP201_OK AND DO_TP201_ON_CMD;
0050
     TP201_READY := TP201_ON AND DI_TP201_AT_SPEED;
0051
0052
      VPV211_OPN := DO_VENT211_SLOW_CMD OR DO_VENT211_FAST_CMD;
0053
     VPV211_CSD := NOT VPV211_OPN;
0054
0055
      RPV211_OPN := DI_RPV211_OPEN AND DO_RPV211_OPEN_CMD;
0056
     RPV211_CSD := DI_RPV211_CLOSED AND NOT DO_RPV211_OPEN_CMD;
0057
0058
     TPV211_OPN := DI_TPV211_OPEN AND DO_TPV211_OPEN_CMD;
0059
      TPV211_CSD := DI_TPV211_CLOSED AND NOT DO_TPV211_OPEN_CMD;
0060
0061_
      TP211_OK := DI_TP211_TURBO_OK;
0062
      TP211_READY := DI_TP211_AT_SPEED AND DO_TP211_ON_CMD;
0063
0064
     VPV212_OPN := DO_VENT212_SLOW_CMD OR DO_VENT212_FAST_CMD;
0065
      VPV212_CSD := NOT VPV212_OPN;
0066
0067
     RPV212_OPN := DI_RPV212_OPEN AND DO_RPV212_OPEN_CMD;
     RPV212_CSD := DI_RPV212_CLOSED AND NOT DO_RPV212_OPEN_CMD;
0068
0069
0070
     TPV212_OPN := DI_TPV212_OPEN AND DO_TPV212_OPEN_CMD;
      TPV212_CSD := DI_TPV212_CLOSED AND NOT DO_TPV212_OPEN_CMD;
0071
0072
0073
     TP212_OK := DI_TP212_TURBO_OK;
0074
     TP212_READY := DI_TP212_AT_SPEED AND DO_TP212_ON_CMD;
0075
0076
     LLV211_OPN := DI_SLOTV211_OPEN;
     LLV211_CSD := DI_SLOTV211_CLOSED;
0077
0078
0079
     LL211_LID_CLOSED := DI_LL211_LID_CLOSED;
0080 LL211_ARM_RETRACTED := DI_LL211_ARM_RETRACTED;
Process_Outputs (ST)
0001
     (* Process Outputs *)
0002
0003
      DO_RP2110_ON_CMD := RP211.on_cmd;
0004
      DO_RP2111_ON_CMD := BP211_ON_CMD;
0005
      DO_V101_OPEN_CMD := V101.open_cmd;
```

```
0006
      DO_V201_OPEN_CMD := V201.open_cmd;
0007
      DO V203 OPEN CMD := V203.open cmd;
8000
      DO_V204_OPEN_CMD := V204.open_cmd;
0009
      DO_TP201_ON_CMD := TP201.on_cmd;
0010
      DO_TP201_VENT_ENABLE_CMD := VPV201.open_cmd;
0011
0012
      DO_TP211_ON_CMD := TP211.on_cmd;
0013
      DO_TPV211_OPEN_CMD := TPV211.open_cmd;
      DO_RPV211_OPEN_CMD := RPV211.open_cmd;
0014
0015
      DO_VENT211_SLOW_CMD := VPV211_SLOW.open_cmd;
0016
      DO_VENT211_FAST_CMD := VPV211_FAST.open_cmd;
0017
0018
     DO_SLOTV211_OPEN_CMD := LLV211.open_cmd;
0019
     DO_SLOTV211_CLOSE_CMD := LLV211.close_cmd;
0020
0021
     DO_TP212_ON_CMD := TP212.on_cmd;
0022
     DO_TPV212_OPEN_CMD := TPV212.open_cmd;
0023
     DO_RPV212_OPEN_CMD := RPV212.open_cmd;
0024
     DO_VENT212_SLOW_CMD := VPV212_SLOW.open_cmd;
0025
     DO_VENT212_FAST_CMD := VPV212_FAST.open_cmd;
Pumps (ST)
0001
     (* Pump Control Logic *)
0002
0003
     (* BP211 *)
0004
     BP211_ON_CMD := TRUE; (* always on *)
0005
0006
     (* RP211 *)
0007
     RP211.on_ena := TRUE;
0008
     RP211.off_ena := RPV211_CSD AND RPV212_CSD;
0009
     RP211.on_req := RP211_ON_REQ_ES OR RP211_ON_REQ_LL;
0010
     RP211.off_req := NOT RP211.on_req;
0011
     RP211();
0012
0013
     (* TP201 *)
0014
     TP201.on_intlk := LL_PE203_PIY_OK;
0015
     TP201.on_ena := TRUE;
0016
     TP201.off_ena := V203_CSD AND V204_CSD;
0017
     TP201.on_req := TP201_ON_REQ_SC;
0018
     TP201.off_req := TP201_OFF_REQ_SC;
0019
     TP201();
0020
0021
     (* TP211 *)
0022 TP211.on_intlk := LL_BP211_ON;
0023 TP211.on_ena := TPV211_CSD;
0024 TP211.off_ena := TPV211_CSD;
0025 TP211.on_req := TP211_ON_REQ_ES;
0026 TP211.off_req := NOT TP211.on_req;
0027 |TP211();
0028
0029
     (* TP212 *)
0030 TP212.on_intlk := LL_BP211_ON;
0031
     TP212.on_ena := TPV212_CSD;
0032
     TP212.off_ena := TPV212_CSD;
0033
     TP212.on_req := TP212_ON_REQ_LL;
0034 TP212.off_req := NOT TP212.on_req;
0035 TP212();
SC_Inputs (ST)
0001
     (* Supervisory Control Inputs *)
0002
     RESET_REQ := SC_RESET_REQ;
0003
0004
      (* Level-Triggered signals *)
0005
0006
      (* Edge-Triggered signals *)
0007
     V101_OPN_REQ_SC := SC_V101_OPN_REQ;
0008
     V101_CLS_REQ_SC := SC_V101_CLS_REQ;
0009
      V201_OPN_REQ_SC := SC_V201_OPN_REQ;
0010
     V201_CLS_REQ_SC := SC_V201_CLS_REQ;
0011
      V203_OPN_REQ_SC := SC_V203_OPN_REQ;
0012
      V203_CLS_REQ_SC := SC_V203_CLS_REQ;
     V204_OPN_REQ_SC := SC_V204_OPN_REQ;
0013
0014
     V204_CLS_REQ_SC := SC_V204_CLS_REQ;
     TP201_ON_REQ_SC := SC_TP201_ON_REQ;
0015
```

```
0016
      TP201_OFF_REQ_SC := SC_TP201_OFF_REQ;
0017
      TP201_VENT_ENABLE_REQ_SC := SC_TP201_VENT_ENABLE_REQ;
      TP201_VENT_DISABLE_REQ_SC := SC_TP201_VENT_DISABLE_REQ;
0018
0019
      LLV211_OPN_REQ_SC := SC_SLOTV211_OPN_REQ;
0020
      LLV211_CLS_REQ_SC := SC_SLOTV211_CLS_REQ;
0021
0022
      (* BR_REQ *)
0023
      CASE SC_BR_CMD_REQ OF
0024
          0:
0025
              BR_REQUEST := BR_NONE_REQ;
0026
0027
              BR_REQUEST := BR_SINS1_REQ;
0028
0029
              BR_REQUEST := BR_SINS2_REQ;
0030
0031
              BR_REQUEST := BR_YAG_REQ;
0032
          ELSE
0033
              BR_REQUEST := BR_NONE_REQ;
0034
     END_CASE;
0035
0036
      (* ES_REQ *)
0037
      CASE SC_ES_CMD_REQ OF
0038
0039
              ES_REQUEST := PV_NONE_REQ;
0040
          1:
0041
              ES_REQUEST := PV_ISOLATE_REQ;
0042
          2:
0043
              ES_REQUEST := PV_PUMP_REQ;
0044
          3:
0045
              ES_REQUEST := PV_VENT_REQ;
0046
          ELSE
0047
              ES_REQUEST := PV_NONE_REQ;
0048
      END_CASE;
0049
0050
0051
      (* LL_REQ *)
0052
      CASE SC_LL_CMD_REQ OF
0053
          0:
0054
              LL_REQUEST := PV_NONE_REQ;
0055
          1 :
0056
              LL_REQUEST := PV_ISOLATE_REQ;
0057
          2:
0058
              LL_REQUEST := PV_PUMP_REQ;
0059
          3:
0060
              LL_REQUEST := PV_VENT_REQ;
0061
          ELSE
0062
              LL_REQUEST := PV_NONE_REQ;
0063
      END_CASE;
0064
0065
0066
0067
SC_Outputs (ST)
0001
     (* Supervisory Control Outputs *)
0002
      SC_RESET_REQUIRED := Reset_Required;
0003
      SC_ATB := TRUE;
0004
      SC_AFB := FALSE;
0005
0006
      (* Inputs *)
0007
      SC_PE101_PSL := PE101_PSL_LO;
8000
      SC_PE201_PSL := PE201_PSL_LO;
0009
      SC_PE202_PSL := PE202_PSL_LO;
0010
0011
      SC_RP2110_AT_SPEED := DI_RP2110_ON;
0012
      SC_RP2111_AT_SPEED := DI_RP2111_ON;
0013
      SC_PE2110_PSL := DI_PE2110_PSL;
0014
      SC_PE2111_PSL := DI_PE2111_PSL;
0015
0016
      SC_PE203_OK := DI_PE203_PIY_OK;
0017
      SC_PE203_PSL_HI := DI_PE203_PSL_HI;
0018
      SC_PE203_PSL_MIDHI := DI_PE203_PSL_MIDHI;
0019
      SC_PE203_PSL_MIDLO := DI_PE203_PSL_MIDLO;
0020
      SC_PE203_PSL_LO := DI_PE203_PSL_LO;
```

```
0021
0022
      SC_PE211_OK := DI_PE211_PIY_OK;
0023
      SC_PE211_PSL_HI := DI_PE211_PSL_HI;
0024
      SC_PE211_PSL_MIDHI := DI_PE211_PSL_MIDHI;
0025
      SC_PE211_PSL_MIDLO := DI_PE211_PSL_MIDLO;
0026
      SC_PE211_PSL_LO := DI_PE211_PSL_LO;
0027
0028
      SC_PE212_OK := DI_PE212_PIY_OK;
0029
      SC_PE212_PSL_HI := DI_PE212_PSL_HI;
0030
      SC_PE212_PSL_MIDHI := DI_PE212_PSL_MIDHI;
0031
      SC_PE212_PSL_MIDLO := DI_PE212_PSL_MIDLO;
0032
      SC_PE212_PSL_LO := DI_PE212_PSL_LO;
0033
      SC_LL211_LID_CLOSED := DI_LL211_LID_CLOSED;
0034
0035
      SC_LL211_ARM_RETRACTED := DI_LL211_ARM_RETRACTED;
0036
0037
      SC_V100_OPEN := V100_OPN;
0038
     SC_V100_CLOSED := V100_CSD;
0039
0040
     SC_V101_BEAM_PASS := (NOT V100_CSD) AND (NOT V101_CSD) AND (BR_STATE = BR_SINS1_READY);
0041
      SC_V101_OPEN := V101_OPN;
      SC_V101_CLOSED := V101_CSD;
0042
0043
      SC_V101_OPEN_PERMIT := V101.open_ena;
0044
      SC_V101_CLOSE_PERMIT := V101.close_ena;
0045
      SC_V101_OPEN_CMD := V101.open_cmd;
0046
      SC_V101_NOT_SYMBOL := V101.not_symbol;
0047
0048
     SC_V201_BEAM_PASS := (NOT V100_CSD) AND (NOT V201_CSD) AND (BR_STATE = BR_SINS2_READY);
0049
      SC_V201_OPEN := V201_OPN;
0050
      SC_V201_CLOSED := V201_CSD;
0051
      SC_V201_OPEN_PERMIT := V201.open_ena;
0052
      SC_V201_CLOSE_PERMIT := V201.close_ena;
0053
      SC_V201_OPEN_CMD := V201.open_cmd;
0054
      SC_V201_NOT_SYMBOL := V201.not_symbol;
0055
0056
      SC_V202_OPEN := V202_OPN;
0057
      SC_V202_CLOSED := V202_CSD;
0058
      SC_V202_BEAM_PASS := SC_V201_BEAM_PASS AND (NOT V202_CSD);
0059
0060
      SC_V203_BEAM_PASS := SC_V202_BEAM_PASS AND (NOT V203_CSD);
0061
      SC_V203_OPEN := V203_OPN;
0062
      SC_V203_CLOSED := V203_CSD;
0063
      SC_V203_OPEN_PERMIT := V203.open_ena;
0064
      SC_V203_CLOSE_PERMIT := V203.close_ena;
0065
      SC_V203_OPEN_CMD := V203.open_cmd;
0066
      SC_V203_NOT_SYMBOL := V203.not_symbol;
0067
0068
      SC_V204_BEAM_PASS := SC_V203_BEAM_PASS AND (NOT V204_CSD);
0069
      SC_V204_OPEN := V204_OPN;
0070
      SC_V204_CLOSED := V204_CSD;
0071
      SC_V204_OPEN_PERMIT := V204.open_ena;
      SC_V204_CLOSE_PERMIT := V204.close_ena;
0072
0073
      SC_V204_OPEN_CMD := V204.open_cmd;
0074
      SC_V204_NOT_SYMBOL := V204.not_symbol;
0075
0076
      SC_RPV211_OPEN := RPV211_OPN;
0077
      SC_RPV211_CLOSED := RPV211_CSD;
0078
      SC_RPV211_OPEN_CMD := RPV211.open_cmd;
0079
0080
      SC_VENT211_SLOW_CMD := VPV211_SLOW.open_cmd;
0081
      SC_VENT211_FAST_CMD := VPV211_FAST.open_cmd;
0082
0083
      SC_TPV211_OPEN := TPV211_OPN;
         _TPV211_CLOSED := TPV211_CSD;
0084
0085
      SC_TPV211_OPEN_CMD := TPV211.open_cmd;
0086
0087
      SC_SLOTV211_OPEN := LLV211_OPN;
8800
      SC_SLOTV211_CLOSED := LLV211_CSD;
0089
      SC_SLOTV211_OPEN_PERMIT := LLV211.open_ena;
0090
      SC_SLOTV211_CLOSE_PERMIT := LLV211.close_ena;
0091
      SC_SLOTV211_OPEN_CMD := LLV211.open_cmd;
      SC_SLOTV211_CLOSE_CMD := LLV211.close_cmd;
0092
      SC_SLOTV211_NOT_SYMBOL := LLV211.not_symbol;
0093
```

```
0094
0095
      SC_RPV212_OPEN := RPV212_OPN;
0096
      SC_RPV212_CLOSED := RPV212_CSD;
0097
      SC_RPV212_OPEN_CMD := RPV212.open_cmd;
0098
0099
      SC_VENT212_SLOW_CMD := VPV212_SLOW.open_cmd;
0100
      SC_VENT212_FAST_CMD := VPV212_FAST.open_cmd;
0101
0102
      SC_TPV212_OPEN := TPV212_OPN;
0103
      SC_TPV212_CLOSED := TPV212_CSD;
0104
      SC_TPV212_OPEN_CMD := TPV212.open_cmd;
0105
0106
      SC_RP2110_ON := RP211_ON;
0107
      SC_RP2110_ON_CMD := RP211.on_cmd;
0108
0109
      SC_RP2111_ON := BP211_ON;
0110
     SC_RP2111_ON_CMD := BP211_ON_CMD;
0111
0112
     SC_TP201_VENT_ENABLE_CMD := VPV201.open_cmd;
0113
     SC_TP201_VENT_NOT_SYMBOL := VPV201.not_symbol;
0114
0115 | SC_TP201_OK := TP201_OK;
0116
     SC_TP201_ON := TP201_ON;
0117
      SC_TP201_OFF := NOT TP201.on_cmd;
0118
      SC_TP201_ON_PERMIT := TP201.on_ena;
0119
      SC_TP201_OFF_PERMIT := TP201.off_ena;
0120
      SC_TP201_ON_CMD := TP201.on_cmd;
0121
      SC_TP201_NOT_SYMBOL := TP201.not_symbol;
0122
0123
     SC_TP211_OK := TP211_OK;
0124
     SC_TP211_ON := TP211_READY;
0125
      SC_TP211_OFF := NOT TP211.on_cmd;
0126
0127
      SC_TP212_OK := TP212_OK;
0128
     SC_TP212_ON := TP212_READY;
0129
      SC_TP212_OFF := NOT TP212.on_cmd;
0130
0131
0132
      (* INTERLOCKS *)
0133
      SC_LL_ACTUATOR_OK := LL_ACTUATOR_OK;
0134
     SC_LL_PE101_PSL := LL_PE101_PSL_LO;
0135
     SC_LL_PE201_PSL := LL_PE201_PSL_LO;
0136
      SC_LL_V202_OPN := LL_V202_OPN;
0137
      SC_LL_PE202_PSL := LL_PE202_PSL_LO;
0138
      SC_LL_PE203_OK := LL_PE203_PIY_OK;
0139
      SC_LL_PE203_PSL_LO := LL_PE203_PSL_LO;
0140
      SC_LL_TP201_OK := LL_TP201_OK;
0141
0142
      SC_LL_ES_CONFIG_OK := LL_ES_CONFIG_OK;
0143
      SC_LL_LL_CONFIG_OK := LL_LL_CONFIG_OK;
0144
      SC_LL_PE211_OK := LL_PE211_PIY_OK;
0145
      SC_LL_PE212_OK := LL_PE212_PIY_OK;
0146
      SC_LL_RP2111_ON := LL_BP211_ON;
0147
      SC_LL_PE2111_PSL := BP211_PSL; (* This is just in case LabView needs it *)
0148
      SC_LL_TP211_TURBO_OK := LL_TP211_OK;
0149
      SC_LL_TP212_TURBO_OK := LL_TP212_OK;
0150
0151
      (* PLC_OUT REGISTERS *)
0152
0153
0154
0155
      (* Version Numbers *)
0156
      SC_VERSION_MAJOR := cVERSION_MAJOR;
0157
      SC_VERSION_MINOR := cVERSION_MINOR;
0158
0159
      (* Analog vacuum pressure *)
0160
      SC_PE101_PIY := AI_PE101_PIY;
0161
      SC_PE201_PIY := AI_PE201_PIY;
0162
      SC_PE202_PIY := AI_PE202_PIY;
0163
      SC_PE203_HI_PIY := AI_PE203_HI_PIY;
0164
      SC_PE203_LO_PIY := AI_PE203_LO_PIY;
      SC_PE211_HI_PIY := AI_PE211_HI_PIY;
0165
     SC_PE211_LO_PIY := AI_PE211_LO_PIY;
0166
```

```
0167
      SC_PE212_HI_PIY := AI_PE212_HI_PIY;
0168
      SC_PE212_LO_PIY := AI_PE212_LO_PIY;
0169
0170
      (* Current BR_REQ *)
0171
      CASE BR_REQUEST OF
0172
          BR_NONE_REQ:
0173
              SC_BR_CMD_VAL := 0;
0174
          BR_SINS1_REQ:
0175
              SC_BR_CMD_VAL := 1;
0176
          BR_SINS2_REQ:
0177
              SC_BR_CMD_VAL := 2;
0178
          BR_YAG_REQ:
0179
              SC_BR_CMD_VAL := 3;
0180
0181
               (* should never get here *)
0182
              SC_BR_CMD_VAL := 0;
0183
      END_CASE;
0184
0185
      (* Current ES_REQ *)
0186
      CASE ES_REQUEST OF
0187
          PV_NONE_REQ:
              SC_ES_CMD_VAL := 0;
0188
0189
          PV_ISOLATE_REQ:
0190
              SC_ES_CMD_VAL := 1;
0191
          PV_PUMP_REQ:
0192
              SC_ES_CMD_VAL := 2;
0193
          PV_VENT_REQ:
0194
              SC_ES_CMD_VAL := 3;
0195
          ELSE
0196
               (* should never get here *)
0197
              SC\_ES\_CMD\_VAL := 0;
0198
      END_CASE;
0199
0200
      (* Current LL_REQ *)
0201
      CASE LL_REQUEST OF
0202
          PV_NONE_REQ:
0203
              SC_LL_CMD_VAL := 0;
0204
          PV_ISOLATE_REQ:
0205
              SC_LL_CMD_VAL := 1;
          PV_PUMP_REQ:
0206
0207
              SC_LL_CMD_VAL := 2;
0208
          PV_VENT_REQ:
0209
              SC_LL_CMD_VAL := 3;
0210
          ELSE
0211
               (* should never get here *)
0212
              SC_LL_CMD_VAL := 0;
0213
      END_CASE;
0214
0215
0216
      (* Current BR_STATE *)
0217
      CASE BR_STATE OF
0218
          BR_ERROR:
0219
              SC_BR_STATE := 0;
0220
          BR_SINS1_READY:
               (* SINS.1 *)
0221
0222
              SC_BR_STATE := 1;
          BR_SINS2_READY:
0223
0224
               (* SINS.2 *)
0225
              SC_BR_STATE := 2;
0226
          BR_YAG_READY:
               (* YAG *)
0228
              SC_BR_STATE := 3;
0229
          BR_SINS1_SELECTING, BR_SINS2_SELECTING, BR_YAG_SELECTING:
0230
               (* BUSY *)
0231
              SC_BR_STATE := 5;
0232
          ELSE
0233
               (* should never get here *)
0234
               SC_BR_STATE := 16#FFFF;
0235
      END_CASE;
0236
0237
      (* Current ES_STATE *)
0238
      CASE ES_STATE OF
0239
          PV_ERROR:
```

```
0240
              SC_ES_STATE := 0;
0241
          PV ISOLATING:
0242
              SC_ES_STATE := 1;
0243
          PV_ISOLATED:
0244
              SC_ES_STATE := 2;
0245
          PV_SLOW_VENTING:
0246
              SC_ES_STATE := 3;
0247
          PV_FAST_VENTING:
0248
              SC\_ES\_STATE := 4;
0249
          PV_VENTED:
0250
              SC\_ES\_STATE := 5;
0251
          PV_RP_STARTING:
0252
              SC\_ES\_STATE := 6;
0253
          PV_RP_PUMPING:
0254
              SC\_ES\_STATE := 7;
0255
          PV_RP_PUMPED:
0256
              SC_ES_STATE := 8;
0257
          PV_TP_PUMPING:
0258
              SC\_ES\_STATE := 9;
0259
          PV_PUMPED:
0260
              SC_ES_STATE := 10;
0261
          FLSE
0262
               (* should never get here *)
0263
              SC_ES_STATE := 16#FFFF;
0264
      END_CASE;
0265
0266
      (* Current LL_STATE *)
0267
      CASE LL_STATE OF
          PV_ERROR:
0268
0269
              SC_LL_STATE := 0;
0270
          PV_ISOLATING:
0271
              SC_LL_STATE := 1;
0272
          PV_ISOLATED:
0273
              SC_{LL}STATE := 2;
          PV_SLOW_VENTING:
0274
0275
              SC_{LL\_STATE} := 3;
          PV_FAST_VENTING:
0276
0277
              SC_{LL}STATE := 4;
0278
          PV_VENTED:
0279
              SC_{LL\_STATE} := 5;
0280
          PV_RP_STARTING:
0281
              SC_LL_STATE := 6;
0282
          PV_RP_PUMPING:
0283
              SC_{LL\_STATE} := 7;
0284
          PV_RP_PUMPED:
0285
              SC_LL_STATE := 8;
0286
          PV_TP_PUMPING:
0287
              SC_LL_STATE := 9;
0288
          PV_PUMPED:
0289
              SC_LL_STATE := 10;
0290
0291
               (* should never get here *)
0292
              SC_LL_STATE := 16#FFFF;
0293
     END_CASE;
Valves (ST)
0001 (* Valve Control Logic *)
0002
0003
      (* V101 *)
0004
      V101.open_intlk := LL_PE101_PSL_LO AND LL_PE201_PSL_LO;
0005
      V101.open_ena := TRUE;
0006
      V101.close_ena := TRUE;
0007
      V101.open_req := V101_OPN_REQ_SC;
8000
      V101.close_req := V101_CLS_REQ_SC;
0009
      V101();
0010
0011
      (* V201 *)
0012
      V201.open_intlk := LL_PE201_PSL_LO AND LL_V202_OPN AND LL_PE202_PSL_LO;
0013
      V201.open_ena := TRUE;
0014
      V201.close_ena := TRUE;
0015
      V201.open_req := V201_OPN_REQ_SC;
0016
      V201.close_req := V201_CLS_REQ_SC;
0017
      V201();
0018
```

```
0019 (* V203 *)
0020 V203.open_intlk := LL_PE202_PSL_LO AND LL_TP201_OK AND LL_PE203_PSL_LO;
0021 | V203.open_ena := TP201_READY;
0022 | V203.close_ena := TRUE;
0023 V203.open_req := V203_OPN_REQ_SC;
0024 V203.close_req := V203_CLS_REQ_SC;
0025 V203();
0026
0027 (* VPV201 *)
0028 VPV201.open_intlk := V203_CSD AND V204_CSD AND NOT TP201_ON;
0029 | VPV201.open_ena := NOT TP201.on_cmd;
0030 VPV201.close_ena := TRUE;
0031 VPV201.open_reg := TP201_VENT_ENABLE_REQ_SC;
0032 VPV201.close_req := TP201_VENT_DISABLE_REQ_SC;
0033 VPV201();
0034
0035 (* V204 *)
0036 V204.open_intlk := LL_PE203_PSL_LO AND LL_TP201_OK AND PE211_PSL_LO;
0037 V204.open_ena := (ES_STATE = PV_PUMPED) AND LLV211_CSD AND TP201_READY;
0038 | V204.close_ena := TRUE;
0039 | V204.open_req := V204_OPN_REQ_SC;
0040 V204.close_req := V204_CLS_REQ_SC OR V204_CLS_REQ_ES;
0041
     V204();
0042
0043 (* LLV211 *)
0044 LLV211.open_intlk := ((ES_STATE = PV_PUMPED) AND (LL_STATE = PV_PUMPED)) OR
                             ((ES_STATE = PV_VENTED) AND (LL_STATE = PV_VENTED));
0045
                        := V204_CSD;
0046 | LLV211.open_ena
0047 LLV211.close_intlk := LL211_ARM_RETRACTED OR LLV211_CSD;
0048 LLV211.close_ena:= LL211_ARM_RETRACTED;
0049 LLV211.open_req := LLV211_OPN_REQ_SC;
0050 LLV211.close_req:= LLV211_CLS_REQ_SC OR LLV211_CLS_REQ_ES OR LLV211_CLS_REQ_LL;
0051 |LLV211();
0052
0053 (* VPV211_SLOW *)
0054 VPV211_SLOW.open_intlk := V204_CSD AND LLV211_CSD AND TPV211_CSD AND RPV211_CSD;
0055 | VPV211_SLOW.open_ena:= TRUE;
0056 VPV211_SLOW.close_ena := TRUE;
0057 | VPV211_SLOW.open_req:= VPV211_SLOW_OPN_REQ_ES;
0058 VPV211_SLOW.close_req := NOT VPV211_SLOW_OPN_REQ_ES;
0059
     VPV211_SLOW();
0060
0061 (* VPV211_FAST *)
0062 VPV211_FAST.open_intlk := V204_CSD AND LLV211_CSD AND TPV211_CSD AND RPV211_CSD;
0063 VPV211_FAST.open_ena:= TRUE;
0064 VPV211_FAST.close_ena := TRUE;
0065 VPV211_FAST.open_req:= VPV211_FAST_OPN_REQ_ES;
0066 VPV211_FAST.close_req := NOT VPV211_FAST_OPN_REQ_ES;
0067
     VPV211_FAST();
0068_
0069
     (* RPV211 *)
0070 RPV211.open_intlk := RP211_ON AND V204_CSD AND LLV211_CSD AND VPV211_CSD;
0071 RPV211.open_ena
                         := NOT PE211_PSL_MIDLO AND RPV212_CSD;
0072
     RPV211.close_ena:= TRUE;
0073
     RPV211.open_req
                        := RPV211_OPN_REQ_ES;
0074
     RPV211.close_req:= NOT RPV211_OPN_REQ_ES;
0075
     RPV211();
0076
     (* TPV211 *)
0077 (* TPV211 *)
0078 TPV211.open_intlk := PE211_PSL_MIDLO AND LL_BP211_ON AND LL_PE211_PIY_OK AND TP211.on_cmd;
0079 TPV211.open_ena := 1NCL,

0080 TPV211.close_ena:= V204_CSD AND LLV211_CSD;

TPV211 OPN REO_ES;
     TPV211.open_req
                         := TPV211_OPN_REQ_ES;
0082
     TPV211.close_req:= NOT TPV211_OPN_REQ_ES;
     TPV211();
0083
0084
     (* VPV212_SLOW *)
0085
     VPV212_SLOW.open_intlk := LLV211_CSD AND TPV212_CSD AND RPV212_CSD;
0086
     VPV212_SLOW.open_ena:= TRUE;
0087
     VPV212_SLOW.close_ena := TRUE;
0088
0089 VPV212_SLOW.open_req:= VPV212_SLOW_OPN_REQ_LL;
0090 VPV212_SLOW.close_req := NOT VPV212_SLOW_OPN_REQ_LL;
0091 VPV212_SLOW();
```

```
0092
0093
      (* VPV212 FAST *)
0094
     VPV212_FAST.open_intlk := LLV211_CSD AND TPV212_CSD AND RPV212_CSD;
0095
     VPV212_FAST.open_ena:= TRUE;
0096
     VPV212_FAST.close_ena := TRUE;
     VPV212_FAST.open_req:= VPV212_FAST_OPN_REQ_LL;
0097
0098
     VPV212_FAST.close_req := NOT VPV212_FAST_OPN_REQ_LL;
0099
     VPV212_FAST();
0100
0101
     (* RPV212 *)
0102 RPV212.open_intlk := RP211_ON AND LLV211_CSD AND VPV212_CSD;
                       := NOT PE212_PSL_MIDLO AND RPV211_CSD;
0103
     RPV212.open_ena
0104 RPV212.close_ena:= TRUE;
     RPV212.open_req := RPV212_OPN_REQ_LL;
0105
     RPV212.close_req:= NOT RPV212_OPN_REQ_LL;
0106
0107
     RPV212();
0108
0109
     (* TPV212 *)
0110 TPV212.open_intlk := PE212_PSL_MIDLO AND LL_BP211_ON AND LL_PE212_PIY_OK AND TP212.on_cmd;
0111 TPV212.open_ena
                        := TRUE;
0112 TPV212.close_ena:= LLV211_CSD;
0113 TPV212.open_req
                        := TPV212_OPN_REQ_LL;
0114 TPV212.close_req:= NOT TPV212_OPN_REQ_LL;
0115
     TPV212();
0116
RP_FB (FB-ST)
0001 (* ROUGH PUMP CONTROL *)
0002 FUNCTION_BLOCK RP_FB
0003 VAR_INPUT
0004
         on_ena: BOOL;
0005
         off_ena: BOOL;
0006
0007
         on_req : BOOL;
0008
         off_req : BOOL;
0009 END_VAR
0010
     VAR OUTPUT
0011
         on_cmd: BOOL;
0012
         not_symbol: BOOL;
0013
     END_VAR
0014
     VAR
0015
     END_VAR
0001
     on_cmd :=
                  (NOT off_req OR NOT off_ena) AND
0002
                  ((on_ena AND on_req) OR on_cmd);
0003
0004 not_symbol := (on_cmd AND NOT off_ena) OR (NOT on_cmd AND NOT on_ena);
TP_FB (FB-ST)
0001
     FUNCTION_BLOCK TP_FB
0002
     VAR_INPUT
0003
         on_intlk : BOOL;
0004
         on_ena : BOOL;
0005
         off_ena : BOOL;
0006
0007
         on_req : BOOL;
0008
         off_req : BOOL;
0009
     END_VAR
0010
     VAR_OUTPUT
0011
         on_cmd : BOOL;
0012
         not_symbol : BOOL;
0013
     END_VAR
0014
     7var
0015
     END_VAR
0001
     on_cmd
                  := on_intlk AND
0002
                      (NOT (off_ena AND off_req)) AND
0003
                      ((on_ena AND on_req) OR on_cmd);
0004
0005
     not_symbol := (on_cmd AND NOT off_ena) OR
0006
                      (NOT on_cmd AND NOT (on_intlk AND on_ena));
VALVE_BI_FB (FB-ST)
0001 FUNCTION_BLOCK VALVE_BI_FB
0002
     VAR_INPUT
0003
         open_intlk
                       : BOOL; (* open command interlock *)
```

```
0004
          open_ena
                        : BOOL; (* open command enable *)
          close_intlk : BOOL; (* close command interlock *)
0005
                        : BOOL; (* close command enable *)
0006
          close_ena
0007
8000
                      : BOOL; (* open command request *)
          open_req
0009
          close_req
                        : BOOL; (* close command request *)
0010
     END_VAR
0011
     VAR_OUTPUT
0012
                        : BOOL; (* open command *)
          open cmd
0013
          close_cmd
                       : BOOL; (* close command *)
0014
          not_symbol
                     : BOOL; (* state change prohibited *)
0015
     END_VAR
0016
0017
     END_VAR
0001
0002
     open_cmd:= open_intlk AND
0003
                      (NOT (close_ena AND close_req)) AND
0004
                      ((open_ena AND open_req) OR open_cmd);
0005
0006
                  := close_intlk AND
     close_cmd
0007
                      (NOT (open_ena AND open_req)) AND
8000
                      ((close_ena AND close_req) OR close_cmd);
0009
                 := (open_cmd AND NOT (close_intlk AND close_ena)) OR
0010
     not_symbol
                      (close_cmd AND NOT (open_intlk AND open_ena));
0011
VALVE_FB (FB-ST)
0001 FUNCTION_BLOCK VALVE_FB
0002
     VAR_INPUT
0003
                        : BOOL; (* open command interlock *)
          open_intlk
                        : BOOL; (* open command enable *)
0004
          open_ena
                        : BOOL; (* close command enable *)
0005
          close_ena
0006
                        : BOOL; (* open command request *)
0007
          open_req
                        : BOOL; (* close command request *)
0008
          close_req
0009
     TEND_VAR
     VAR_OUTPUT
0010
0011
          open_cmd
                        : BOOL; (* open command *)
                        : BOOL; (* state change prohibited *)
0012
          not_symbol
0013
     TEND VAR
0014
     VAR
0015
     END_VAR
0001
     open_cmd:= open_intlk AND
0002
                      (NOT (close_ena AND close_req)) AND
0003
                      ((open_ena AND open_req) OR open_cmd);
0004
0005
     not_symbol := (open_cmd AND NOT close_ena) OR
0006
                      (NOT open_cmd AND NOT (open_intlk AND open_ena));
Actuator
0001 TYPE Actuator :
0002
0003
          awStatus: ARRAY [0..9] OF WORD; (* actuator status words, incomming*)
0004
          wCommand: WORD;
                                       (* actuator control command, outgoing *)
0005
          wTarget
                    : WORD;
                                               (* actuator target position, outgoing *)
0006
          oMBMaster : ETHERNET_MODBUSMASTER_TCP;
0007
8000
          tonConnect : TON;
                                               (* connection delay timer *)
0009
0010
          xConnect: BOOL;
                                           (* initiate TCP connection *)
0011
          xSend
                     : BOOL;
                                               (* Initiate MB transaction *)
0012
          xBusy
                      : BOOL;
                                               (* Transaction in progress *)
          xDataReady : BOOL;
0013
                                               (* Transaction data ready *)
0014
0015
                      : WORD := 10;
          wState
                                              (* sequencer state *)
0016
     END_STRUCT
     END_TYPE
0017
BR_REQ
0001 TYPE BR REQ :
0002
0003
          BR_NONE_REQ := 0,
0004
          BR_SINS1_REQ,
0005
          BR_SINS2_REQ,
```

```
0007
          BR_YAG_REQ
0008
          );
0009
      END_TYPE
BR_ST
0001
      TYPE BR_ST :
0002
0003
          BR\_ERROR := 0,
0004
          BR_SINS1_SELECTING,
0005
          BR_SINS1_READY,
0006
          BR_SINS2_SELECTING,
0007
          BR_SINS2_READY,
8000
          BR_YAG_SELECTING,
0009
          BR_YAG_READY
0010
0011
      END_TYPE
PV_REQ
0001
      TYPE PV_REQ :
0002
0003
          PV_NONE_REQ := 0,
0004
          PV_ISOLATE_REQ,
0005
          PV_PUMP_REQ,
0006
          PV_VENT_REQ
0007
          );
0008
      END_TYPE
PV_ST
0001
      TYPE PV_ST :
0002
          PV\_ERROR := 0,
0003
0004
          PV_ISOLATING,
0005
          PV_ISOLATED,
0006
          PV_SLOW_VENTING,
0007
          PV_FAST_VENTING,
0008
          PV_VENTED,
0009
          PV_RP_STARTING,
0010
          PV_RP_PUMPING,
0011
          PV_RP_PUMPED,
0012
          PV_TP_PUMPING,
          PV_PUMPED
0013
0014
          );
0015 END_TYPE
ACTUATOR_VISU
```

BR\_SINS3\_REQ,

0006

## **ACTUATORS**

 Request
 Readback
 Position
 Target

 BR\_SELECTOR
 SINS.1
 SINS.2
 YAG
 %d
 %d
 %d


AUTO\_VISU

## **AUTO STATE MACHINES**

		Request		<u>CMD</u>	EXT VAL	<u>INT VAL</u>
BR_SELECTOR	NONE SINS	.1 SINS.2	YAG	%d	%d	%s
ES_PUMPVENT	NONE	TE PUMP	VENT	%d	%d	%s
LL_PUMPVENT	NONE	TE PUMP	VENT	%d	%d	%s

INTLKS\_VISU

## **Interlocks**



0002

SOCKET\_INVALID:DINT:=-1;

## VALVES

	VAL	/ES	
<u>Requests</u>	Name PMT	OPN CSD	Commands
	V100		
Open Close	V101		Open Beam
Open Close	V201		Open Beam
	V202		Beam
Open Close	V203		Open Beam
Enable Disable	VENT201		Enabled
Open Close	V204		Open Beam
	VENT211		Slow Fast
	RPV211		Open
	TPV211		Open
Open Close	SLOTV211		Open Close
	VENT212		Slow Fast
	RPV212		Open
	TPV212		Open
Global_Variables  0001 VAR_GLOBAL  xActuatorRes wActuatorSts wActuatorPos wActuatorAls 0005 0006 END_VAR 0007 VAR_GLOBAL RETAL 0008 wActuatorTas	atus : WORD; sition : WORD; arm : WORD;	(* Current	t Status *) t Position *)
Variable_Configuration 0001 VAR_CONFIG 0002 END_VAR	ו		
Global Variables 0 0001 VAR_GLOBAL 0002 END_VAR			
Globale_Variablen  0001 VAR_GLOBAL  0002 END_VAR			
Version  0001 VAR_GLOBAL CONST  0002 rVersion:REA  0003 END_VAR			
Globale_Variablen  0001 VAR_GLOBAL CONST	TANT LID:DINT:=-1;		

```
0003
0004
          (* AddressFamily *)
                                              (* unspecified *)
0005
          SOCKET_AF_UNSPEC:INT:= 0;
0006
          SOCKET_AF_LOCAL:INT:= 1;
                                                  (* local to host (pipes, portals) *)
0007
          SOCKET_AF_UNIX:INT:=SOCKET_AF_LOCAL;
                                                  (* backward compatibility *)
0008
          SOCKET_AF_INET:INT:=2;
                                                   (* internetwork: UDP, TCP, etc. *)
0009
          SOCKET_AF_IMPLINK:INT:=3;
                                                   (* arpanet imp addresses *)
0010
          SOCKET_AF_PUP:INT:=4;
                                                  (* pup protocols: e.g. BSP *)
0011
          SOCKET_AF_CHAOS:INT:=5;
                                              (* mit CHAOS protocols *)
0012
          SOCKET_AF_NS:INT:=6;
                                               (* XEROX NS protocols *)
0013
          SOCKET_AF_ISO:INT:=7;
                                                   (* ISO protocols *)
0014
          SOCKET_AF_OSI:INT:=SOCKET_AF_ISO;
0015
          SOCKET_AF_ECMA:INT:=8;
                                               (* european computer manufacturers *)
0016
          SOCKET_AF_DATAKIT:INT:=9;
                                                  (* datakit protocols *)
0017
          SOCKET_AF_CCITT:INT:=10;
                                              (* CCITT protocols, X.25 etc *)
0018
          SOCKET_AF_SNA:INT:=11;
                                                  (* IBM SNA *)
0019
          SOCKET_AF_DECnet:INT:=12;
                                                   (* DECnet *)
0020
          SOCKET_AF_DLI:INT:=13;
                                                   (* DEC Direct data link interface *)
0021
          SOCKET_AF_LAT:INT:= 14;
                                                   (* LAT *)
0022
          SOCKET_AF_HYLINK:INT:=15;
                                                   (* NSC Hyperchannel *)
0023
          SOCKET_AF_APPLETALK:INT:=16;
                                           (* Apple Talk *)
          SOCKET_AF_ROUTE:INT:=17;
                                              (* Internal Routing Protocol *)
0024
0025
          SOCKET_AF_LINK:INT:=18;
                                               (* Link layer interface *)
0026
          SOCKET_pseudo_AF_XTP:INT:=19;
                                               (* eXpress Transfer Protocol (no AF) *)
0027
          SOCKET_AF_COIP:INT:=20;
                                               (* connection-oriented IP, aka ST II *)
0028
          SOCKET_AF_CNT:INT:=21;
                                               (* Computer Network Technology *)
0029
                                               (* Help Identify RTIP packets *)
          SOCKET_pseudo_AF_RTIP:INT:=22;
0030
          SOCKET_AF_IPX:INT:=23;
                                                  (* Novell Internet Protocol *)
0031
                                                   (* Simple Internet Protocol *)
          SOCKET_AF_SIP:INT:=24;
0032
                                              (* Help Identify PIP packets *)
          SOCKET_pseudo_AF_PIP:INT:=25;
0033
          SOCKET_AF_MAX:INT:=26;
0034
          SOCKET_AF_INET_BSD:INT:=100; (* BSD-specific INET af *)
          SOCKET_AF_INET_STREAMS:INT:=101; (* STREAMS-specific INET af *)
0035
0036
0037
          (* Level number for (get/set)sockopt() to apply to socket itself. *)
0038
          SOCKET_SOL:WORD:=16#ffff;
0039
0040
          (* Socket options *)
0041
          SOCKET_SO_DEBUG:DINT:=16#0001;
                                                   (* turn on debugging info recording *)
          SOCKET_SO_ACCEPTCONN:DINT:=16#0002; (* socket has had listen() *)
0042
0043
          SOCKET_SO_REUSEADDR:DINT:=16#0004; (* allow local address reuse *)
0044
          SOCKET_SO_KEEPALIVE:DINT:=16#0008;
                                                  (* keep connections alive *)
0045
          SOCKET\_SO\_DONTROUTE:DINT:=16\#0010; (* just use interface addresses *)
0046
          SOCKET_SO_BROADCAST:DINT:=16#0020; (* permit sending of broadcast msgs *)
0047
          SOCKET_SO_USELOOPBACK:DINT:=16#0040; (* bypass hardware when possible *)
0048
          SOCKET_SO_LINGER:DINT:=16#0080;
                                                  (* linger on close if data present *)
0049
          SOCKET_SO_OOBINLINE:DINT:=16#0100;
                                                  (* leave received OOB data in line *)
0050
          SOCKET_SO_REUSEPORT:DINT:=16#0200; (* allow local address & port reuse *)
                                             (* send buffer size *)
0051
          SOCKET_SO_SNDBUF:DINT:=16#1001;
0052
          SOCKET_SO_RCVBUF:DINT:= 16#1002;
                                              (* receive buffer size *)
                                             (* send low-water mark *)
0053
          SOCKET_SO_SNDLOWAT:DINT:=16#1003;
0054
          SOCKET_SO_RCVLOWAT:DINT:=16#1004;
                                              (* receive low-water mark *)
0055
          SOCKET_SO_SNDTIMEO:DINT:=16#1005;
                                              (* send timeout *)
                                             (* receive timeout *)
0056
          SOCKET_SO_RCVTIMEO:DINT:=16#1006;
0057
          SOCKET_SO_ERROR:DINT:=16#1007;
                                              (* get error status and clear *)
0058
          SOCKET_SO_TYPE:DINT:=16#1008;
                                                 (* get socket type *)
          SOCKET_SO_PROTOTYPE:DINT:=16#1009; (* get/set protocol type *)
0059
0060
          (* TCPIP socket options *)
          SOCKET_TCP_NODELAY:DINT:=16#01; (* don't delay send to coalesce packets *)
0061
          SOCKET_TCP_MAXSEG:DINT:=16#02; (* set maximum segment size *)
0062
0063
0064
          (* Socket types *)
0065
          SOCKET_STREAM:DINT:=1;
                                           (* stream socket *)
0066
          SOCKET_DGRAM:DINT:=2;
                                           (* datagram socket *)
0067
          SOCKET_RAW:DINT:=3;
                                          (* raw-protocol interface *)
                                          (* reliably-delivered message *)
0068
          SOCKET_RDM:DINT:=4;
                                          (* sequenced packet stream *)
0069
          SOCKET_SEQPACKET:DINT:=5;
0070
0071
          (* Inet address definitions *)
0072
          SOCKET_INADDR_ANY:UDINT:=16#0000000;
0073
          SOCKET_INADDR_LOOPBACK:UDINT:=16#7f000001;
0074
          SOCKET_INADDR_BROADCAST:UDINT:=16#ffffffff;
0075
          SOCKET_INADDR_NONE:UDINT:=16#ffffffff;
```

```
0077
          (* Protocols *)
0078
          SOCKET_IPPROTO_IP:DINT:=0;
                                             (* dummy for IP *)
          SOCKET_IPPROTO_ICMP:DINT:=1; (* control message protocol *)
0079
0080
          SOCKET_IPPROTO_IGMP:DINT:=2;
                                         (* group management protocol *)
                                         (* gateway^2 (deprecated) *)
0081
          SOCKET_IPPROTO_GGP:DINT:=3;
                                          (* tcp *)
0082
          SOCKET_IPPROTO_TCP:DINT:=6;
                                         (* pup *)
0083
          SOCKET_IPPROTO_PUP:DINT:=12;
                                         (* user datagram protocol *)
0084
          SOCKET_IPPROTO_UDP:DINT:=17;
0085
          SOCKET_IPPROTO_IDP:DINT:=22;
                                         (* xns idp *)
0086
          SOCKET_IPPROTO_ND:DINT:=77;
                                         (* UNOFFICIAL net disk proto *)
                                         (* raw IP packet *)
0087
          SOCKET_IPPROTO_RAW:DINT:=255;
0088
          SOCKET_IPPROTO_MAX:DINT:=256;
0089
0090
          (* Flags *)
0091
          SOCKET_MSG_OOB:DINT:=16#1;
                                              (* process out-of-band data *)
0092
          SOCKET_MSG_PEEK:DINT:=16#2;
                                             (* peek at incoming message *)
0093
          SOCKET_MSG_DONTROUTE:DINT:=16#4; (* send without using routing tables *)
0094
0095
          (* Ioctl commands *)
0096
          SOCKET_FIONREAD:DINT:=1;
                                              (* get num chars available to read *)
          SOCKET_FIONBIO:DINT:=2;
                                                  (* set to non-blocking *)
0097
0098
          (* For SysSockSelect() descriptors *)
0099
0100
          SOCKET_FD_SETSIZE :DINT := 64;
0101
          MAX_SOCKET_FD_SETSIZE : DINT := 63;
0102 END_VAR
Globale_Variablen
0001 VAR_GLOBAL
0002 END_VAR
Alarm configuration
     Alarm configuration
     Alarm classes
         System
PLC Configuration
*Hardware configuration (Id.: 2010000001)
  Node number: −1
  Input address: %IB0
  Output address: %QB0
  Diagnostic address: %MB0
  Download: 1
  AutoAdr: 1
  *K-Bus (* WAGO 750-881 PFC ETHERNET *) [FIX] (Id.: 11994)
    Node number: 0
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
    *0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
      Node number: 0
      Input address: %IB0
      Output address: %QB0
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        AI_PE101_PIY AT %IW0: WORD; (* SINS.1 Branchline UHV pressure *) [CHANNEL (I)]
        AI_PE201_PIY AT %IW1: WORD; (* M201 UHV range pressure *) [CHANNEL (I)]
        AI_PE202_PIY AT %IW2: WORD; (* M202 UHV range pressure *) [CHANNEL (I)]
        AI_SPARE04 AT %IW3: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
    *0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
      Node number: 1
      Input address: %IB1
```

```
Output address: %QB1
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
  Channels:
   AI_PE203_HI_PIY AT %IW4: WORD; (* FTR201 High range pressure *) [CHANNEL (I)]
    AI_PE203_LO_PIY AT %IW5: WORD; (* FTR201 Low range pressure *) [CHANNEL (I)]
    AI_PE211_HI_PIY AT %IW6: WORD; (* ES211 High range pressure *) [CHANNEL (I)]
    AI_PE211_LO_PIY AT %IW7: WORD; (* ES211 Low range pressure *) [CHANNEL (I)]
*0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
 Node number: 2
  Input address: %IB2
 Output address: %QB2
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   AI_PE212_HI_PIY AT %IW8: WORD; (* LL211 High range pressure *) [CHANNEL (I)]
   AI_PE212_LO_PIY AT %IW9: WORD; (* LL211 Low range pressure *) [CHANNEL (I)]
    AI_SPARE11 AT %IW10: WORD; (* Ch_3 Input word *) [CHANNEL (I)]
    AI_SPARE12 AT %IW11: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
*0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
 Node number: 3
  Input address: %IB3
  Output address: %QB3
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   AI_SPARE13 AT %IW12: WORD; (* Ch_1 Input word *) [CHANNEL (I)]
    AI_SPARE14 AT %IW13: WORD; (* Ch_2 Input word *) [CHANNEL (I)]
    AI_SPARE15 AT %IW14: WORD; (* Ch_3 Input word *) [CHANNEL (I)]
    AI_SPARE16 AT %IW15: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 4
 Input address: %IB4
 Output address: %QB4
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
    DO_RP2110_ON_CMD AT %QX0.0: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_RP2111_ON_CMD AT %QX0.1: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_V101_OPEN_CMD AT %QX0.2: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_V201_OPEN_CMD AT %QX0.3: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_V203_OPEN_CMD AT %QX0.4: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_V204_OPEN_CMD AT %QX0.5: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_TP201_ON_CMD AT %QX0.6: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_TP201_VENT_ENABLE_CMD AT %QX0.7: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
  Node number: 5
  Input address: %IB5
  Output address: %QB5
  Diagnostic address: %MB0
 Download: 1
  AutoAdr: 1
 Parameter:
   PAAssignment: PLC
  Channels:
    DO_TP211_ON_CMD AT %QX0.8: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_TPV211_OPEN_CMD AT %QX0.9: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
```

```
DO_RPV211_OPEN_CMD AT %QX0.10: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_VENT211_SLOW_CMD AT %QX0.11: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_VENT211_FAST_CMD AT %QX0.12: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_14 AT %QX0.13: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SLOTV211_OPEN_CMD AT %QX0.14: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SLOTV211_CLOSE_CMD AT %QX0.15: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 6
  Input address: %IB6
 Output address: %QB6
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
    DO_TP212_ON_CMD AT %QX1.0: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_TPV212_OPEN_CMD AT %QX1.1: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_RPV212_OPEN_CMD AT %QX1.2: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_VENT212_SLOW_CMD AT %QX1.3: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_VENT212_FAST_CMD AT %QX1.4: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_22 AT %QX1.5: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SPARE_23 AT %QX1.6: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SPARE_24 AT %QX1.7: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 7
 Input address: %IB7
 Output address: %QB7
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DO_SPARE_25 AT %QX1.8: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_SPARE_26 AT %QX1.9: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_SPARE_27 AT %QX1.10: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_SPARE_28 AT %QX1.11: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_SPARE_29 AT %QX1.12: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_30 AT %QX1.13: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SPARE_31 AT %QX1.14: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SPARE_32 AT %QX1.15: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 8
 Input address: %IB8
 Output address: %QB8
 Diagnostic address: %MB0
 Download: 1
  AutoAdr:
 Parameter:
   PAAssignment: PLC
 Channels:
    DI_PE101_PSL_LO AT %IX16.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE201_PSL_LO AT %IX16.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE202_PSL_LO AT %IX16.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_SPARE_04 AT %IX16.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_RP2110_ON AT %IX16.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_RP2111_ON AT %IX16.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE2110_PSL AT %IX16.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE2111_PSL AT %IX16.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 9
  Input address: %IB9
  Output address: %QB9
  Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
```

```
Channels:
    DI_PE203_PIY_OK AT %IX16.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE211_PIY_OK AT %IX16.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE212_PIY_OK AT %IX16.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_SPARE_12 AT %IX16.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_HI AT %IX16.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_MIDHI AT %IX16.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_MIDLO AT %IX16.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_LO AT %IX16.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 10
  Input address: %IB10
 Output address: %QB10
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DI_PE211_PSL_HI AT %IX17.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_MIDHI AT %IX17.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_MIDLO AT %IX17.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_LO AT %IX17.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_HI AT %IX17.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_MIDHI AT %IX17.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_MIDLO AT %IX17.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_LO AT %IX17.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 11
  Input address: %IB11
 Output address: %QB11
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
    DI_V100_OPEN AT %IX17.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_V100_CLOSED AT %IX17.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_V101_OPEN AT %IX17.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_V101_CLOSED AT %IX17.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_V201_OPEN AT %IX17.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_V201_CLOSED AT %IX17.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_V202_OPEN AT %IX17.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_V202_CLOSED AT %IX17.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 12
  Input address: %IB12
 Output address: %QB12
 Diagnostic address: %MB0
 Download: 1
 AutoAdr:
 Parameter:
   PAAssignment: PLC
 Channels:
    DI_V203_OPEN AT %IX18.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_V203_CLOSED AT %IX18.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_V204_OPEN AT %IX18.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_V204_CLOSED AT %IX18.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_TP201_TURBO_OK AT %IX18.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_TP201_AT_SPEED AT %IX18.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_RPV211_OPEN AT %IX18.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_RPV211_CLOSED AT %IX18.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 13
  Input address: %IB13
  Output address: %QB13
  Diagnostic address: %MB0
  Download: 1
```

```
AutoAdr:
      Parameter:
        PAAssignment: PLC
      Channels:
        DI_TPV211_OPEN AT %IX18.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
        DI_TPV211_CLOSED AT %IX18.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
        DI_RPV212_OPEN AT %IX18.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
        DI_RPV212_CLOSED AT %IX18.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
        DI_TPV212_OPEN AT %IX18.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
        DI_TPV212_CLOSED AT %IX18.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
        DI_TP211_AT_SPEED AT %IX18.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
        DI_TP211_TURBO_OK AT %IX18.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
    *0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
      Node number: 14
      Input address: %IB14
      Output address: %QB14
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        DI_TP212_AT_SPEED AT %IX19.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
        DI_TP212_TURBO_OK AT %IX19.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
        DI_SLOTV211_OPEN AT %IX19.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
        DI_SLOTV211_CLOSED AT %IX19.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
        DI_LL211_LID_CLOSED AT %IX19.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
        DI_LL211_ARM_RETRACTED AT %IX19.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
        DI_SPARE_55 AT %IX19.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
        DI_SPARE_56 AT %IX19.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
    *0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
      Node number: 15
      Input address: %IB15
      Output address: %QB15
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        DI_SPARE_57 AT %IX19.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
        DI_SPARE_58 AT %IX19.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
        DI_SPARE_59 AT %IX19.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
        DI_SPARE_60 AT %IX19.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
        DI_SPARE_61 AT %IX19.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
        DI_SPARE_62 AT %IX19.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
        DI_SPARE_63 AT %IX19.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
        DI_SPARE_64 AT %IX19.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
  *Fieldbus variables[FIX] (Id.: 2010310001)
    Node number: 1
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
  *Flag variables[FIX] (Id.: 2010320001)
    Node number: 2
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
Sampling Trace
 No trace loaded
Task configuration
       Task configuration
     System events
```

```
Main (PRIORITY := 1, INTERVAL := T#15ms
        PLC_PRG();
         IAI (PRIORITY := 3, INTERVAL := T#100ms
         Actuator_SM();
Watch- and Recipe Manager
Workspace
Parameter Manager
0001 Parameter-Manager
0002 =======
Cross Reference List
xDataReadv
     ACTUATOR SM (23)
                                           Local Read
     ACTUATOR_SM (50)
                                          Local Read
     ACTUATOR_SM (59)
                                          Local Read
     ACTUATOR_SM (67)
                                          Local Read
     ACTUATOR_SM (76)
                                          Local Read
     ACTUATOR_SM (85)
                                          Local Read
     ACTUATOR_SM (92)
                                          Local Read
     ACTUATOR_SM (105)
                                          Local Read
     ACTUATOR_SM (122)
                                          Local Read
     ACTUATOR_SM (130)
                                          Local Read
     ACTUATOR_SM.DRG1_W... (34)
                                         Local Write
     ACTUATOR_SM.DRG1_W... (38)
                                         Local Write
     ACTUATOR_SM.DRG1_W... (40)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (35)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (39)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (41)
                                         Local Write
     ACTUATOR_SM.STATUS... (34)
                                         Local Write
     ACTUATOR_SM.STATUS... (41)
                                         Local Write
     ACTUATOR_SM.STATUS... (43)
                                         Local Write
     ACTUATORinit (11)
                                          Local Write
xSend
     ACTUATOR_SM.CONNECT (9)
                                         Local Write
     ACTUATOR_SM.CONNECT (25)
                                         Local Read
     ACTUATOR_SM.DRG1_W... (7)
                                         Local Write
     ACTUATOR_SM.DRG1_W... (26)
                                         Local Read
     ACTUATOR_SM.DRG1_W... (36)
                                         Local Read
     ACTUATOR_SM.PCMD_W... (8)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                         Local Read
     ACTUATOR_SM.PCMD_W... (37)
                                         Local Read
     ACTUATOR_SM.STATUS... (7)
                                         Local Write
     ACTUATOR_SM.STATUS... (26)
                                         Local Read
     ACTUATOR_SM.STATUS... (36)
                                          Local Read
     ACTUATORinit (9)
                                           Local Write
xConnect
     ACTUATOR_SM (5)
                                           Local Write
                                         Local Write
     ACTUATOR_SM (10)
     ACTUATOR_SM (145)
                                         Local Write
                                         Local Read
     ACTUATOR_SM.CONNECT (6)
     ACTUATOR_SM.CONNECT (31)
                                         Local Write
     ACTUATOR_SM.DRG1_W... (32)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (33)
                                          Local Write
     ACTUATOR_SM.STATUS... (32)
                                           Local Write
     ACTUATORinit (8)
                                           Local Write
xActuatorReady
     ACTUATOR SM (4)
                                           Global Write
     ACTUATOR_SM (110)
                                           Global Write
     ACTUATOR_SM (115)
                                           Global Write
     PLC_PRG.ACTUATOR_I... (5)
                                           Global Read
     _global_init (1)
                                           Global Write
VPV212_SLOW
     PLC_PRG.PROCESS_OU... (24)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (99)
                                           Local Read
                                           Local Write
     PLC_PRG.VALVES (86)
                                           Local Write
     PLC_PRG.VALVES (87)
                                           Local Write
     PLC_PRG.VALVES (88)
     PLC_PRG.VALVES (89)
                                           Local Write
     PLC_PRG.VALVES (90)
                                           Local Write
     PLC_PRG.VALVES (91)
                                           Local Read
     _global_init (302)
                                           Local Read
```

xBusy

```
ACTUATOR_SM (17)
                                            Local Write
     ACTUATOR_SM.DRG1_W... (5)
                                           Local Read
     ACTUATOR_SM.DRG1_W... (6)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (33)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (37)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (5)
                                           Local Read
     ACTUATOR_SM.PCMD_W... (7)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (34)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (38)
                                           Local Write
     ACTUATOR_SM.STATUS... (5)
                                           Local Read
     ACTUATOR_SM.STATUS... (6)
                                           Local Write
     ACTUATOR_SM.STATUS... (33)
                                           Local Write
     ACTUATOR_SM.STATUS... (40)
                                           Local Write
     ACTUATORinit (10)
                                            Local Write
wActuatorStatus
     ACTUATOR_SM.STATUS... (39)
                                           Global Write
     PLC_PRG.ACTUATOR_I... (3)
                                            Global Read
                                            Global Write
     _global_init (2)
VPV212_OPN
     PLC_PRG.PROCESS_IN... (64)
                                           Local Write
     PLC_PRG.PROCESS_IN... (65)
                                            Local Read
                                            Local Write
     _global_init (209)
wTarget
     ACTUATOR_SM.PCMD_W... (6)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                            Local Read
     ACTUATORinit (5)
                                            Local Write
wActuatorPosition
     ACTUATOR_SM (107)
                                            Global Read
     ACTUATOR_SM.STATUS... (37)
                                            Global Write
     PLC_PRG.ACTUATOR_I... (7)
                                            Global Read
     _global_init (3)
                                            Global Write
VPV211_SLOW_OPN_REQ_ES
     PLC_PRG.ES_SM (14)
                                            Local Write
     PLC_PRG.ES_SM (28)
                                            Local Write
     PLC_PRG.ES_SM (42)
                                            Local Write
     PLC_PRG.ES_SM (60)
                                            Local Write
     PLC_PRG.ES_SM (78)
                                            Local Write
     PLC_PRG.ES_SM (96)
                                            Local Write
     PLC_PRG.ES_SM (114)
                                            Local Write
     PLC_PRG.ES_SM (133)
                                            Local Write
     PLC_PRG.ES_SM (151)
                                            Local Write
     PLC_PRG.ES_SM (172)
                                            Local Write
     PLC_PRG.ES_SM (192)
                                            Local Write
     PLC_PRG.VALVES (57)
                                            Local Read
     PLC_PRG.VALVES (58)
                                            Local Read
     _global_init (256)
                                            Local Write
V100_OPN
     PLC_PRG.PROCESS_IN... (30)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (37)
                                            Local Read
     _global_init (189)
                                            Local Write
wState
     ACTUATOR_SM (3)
                                            Local Read
     ACTUATOR_SM (7)
                                            Local Write
     ACTUATOR_SM (9)
                                            Local Read
     ACTUATOR_SM (12)
                                            Local Write
     ACTUATOR_SM (14)
                                            Local Read
     ACTUATOR_SM (18)
                                            Local Write
     ACTUATOR_SM (21)
                                            Local Read
     ACTUATOR_SM (27)
                                            Local Write
     ACTUATOR_SM (31)
                                            Local Write
     ACTUATOR_SM (35)
                                            Local Write
     ACTUATOR_SM (39)
                                            Local Write
     ACTUATOR_SM (42)
                                            Local Write
     ACTUATOR_SM (46)
                                            Local Read
     ACTUATOR_SM (52)
                                            Local Write
     ACTUATOR_SM (55)
                                            Local Read
     ACTUATOR_SM (61)
                                            Local Write
     ACTUATOR_SM (64)
                                            Local Read
     ACTUATOR_SM (69)
                                            Local Write
     ACTUATOR_SM (72)
                                            Local Read
     ACTUATOR_SM (78)
                                            Local Write
     ACTUATOR_SM (81)
                                            Local Read
     ACTUATOR_SM (87)
                                            Local Write
```

```
ACTUATOR_SM (90)
                                           Local Read
     ACTUATOR SM (96)
                                           Local Write
     ACTUATOR_SM (99)
                                           Local Write
     ACTUATOR_SM (103)
                                          Local Read
     ACTUATOR_SM (111)
                                          Local Write
     ACTUATOR_SM (116)
                                          Local Write
     ACTUATOR_SM (120)
                                          Local Read
     ACTUATOR_SM (125)
                                          Local Write
     ACTUATOR_SM (128)
                                          Local Read
     ACTUATOR_SM (136)
                                          Local Write
     ACTUATOR_SM (140)
                                          Local Write
     ACTUATOR_SM (146)
                                          Local Write
     ACTUATOR_SM.CONNECT (32)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (35)
                                         Local Write
     ACTUATOR_SM.PCMD_W... (36)
                                          Local Write
     ACTUATOR_SM.STATUS... (35)
                                          Local Write
     ACTUATORinit (12)
                                           Local Write
wActuatorTarget
     ACTUATOR_SM (107)
                                           Global Read
     ACTUATOR_SM.PCMD_W... (6)
                                          Global Read
     PLC_PRG.ACTUATOR_O... (4)
                                          Global Write
     _global_init (1)
                                           Global Write
wActuatorAlarm
    ACTUATOR_SM.STATUS... (38)
                                           Global Write
     _global_init (4)
                                           Global Write
VPV212_SLOW_OPN_REQ_LL
    PLC_PRG.LL_SM (14)
                                           Local Write
     PLC_PRG.LL_SM (27)
                                           Local Write
     PLC_PRG.LL_SM (40)
                                           Local Write
     PLC_PRG.LL_SM (57)
                                           Local Write
     PLC_PRG.LL_SM (74)
                                          Local Write
     PLC_PRG.LL_SM (91)
                                          Local Write
     PLC_PRG.LL_SM (108)
                                          Local Write
     PLC_PRG.LL_SM (126)
                                          Local Write
     PLC_PRG.LL_SM (143)
                                          Local Write
     PLC_PRG.LL_SM (163)
                                          Local Write
     PLC_PRG.LL_SM (182)
                                          Local Write
     PLC_PRG.VALVES (89)
                                          Local Read
     PLC_PRG.VALVES (90)
                                           Local Read
                                           Local Write
     _global_init (268)
VPV211_SLOW_CLS_REQ_ES
     _global_init (257)
                                           Local Write
V101_OPN
     PLC_PRG.PROCESS_IN... (33)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (41)
                                           Local Read
     _global_init (191)
                                           Local Write
V100_CSD
     PLC_PRG.PROCESS_IN... (31)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (38)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (40)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (48)
                                           Local Read
     _global_init (190)
                                           Local Write
SC_VENT212_SLOW_CMD%MX8.11
     PLC_PRG.SC_OUTPUTS (99)
                                           Local Write
     _global_init (88)
                                           Local Write
uiSuccessful
                                           Local Read
     ACTUATOR_SM (134)
     ACTUATOR_SM (134)
                                           Local Write
     _global_init (7)
                                           Local Write
SC_VENT211_SLOW_CMD%MX6.11
                                           Local Write
     PLC_PRG.SC_OUTPUTS (80)
     _global_init (73)
                                           Local Write
tTCP_Watchdog
     ACTUATOR_SM.CONNECT (25)
                                           Local Read
     ACTUATOR_SM.DRG1_W... (26)
                                           Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                           Local Read
     ACTUATOR_SM.STATUS... (26)
                                           Local Read
     _global_init (5)
                                           Local Write
SC_V204_BEAM_PASS%MX5.8
     PLC_PRG.SC_OUTPUTS (68)
                                           Local Write
     _global_init (63)
                                           Local Write
wPort
     ACTUATOR_SM.CONNECT (25)
                                           Local Read
```

```
ACTUATOR_SM.DRG1_W... (26)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Read
     ACTUATOR_SM.STATUS... (26)
                                         Local Read
     _global_init (2)
                                          Local Write
VPV212_SLOW_CLS_REQ_LL
     _global_init (269)
                                          Local Write
VPV212_FAST_CLS_REQ_LL
     _global_init (271)
                                          Local Write
VPV212_FAST
     PLC_PRG.PROCESS_OU... (25)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (100)
                                          Local Read
     PLC_PRG.VALVES (94)
                                          Local Write
     PLC_PRG.VALVES (95)
                                          Local Write
     PLC_PRG.VALVES (96)
                                         Local Write
     PLC_PRG.VALVES (97)
                                         Local Write
     PLC_PRG.VALVES (98)
                                          Local Write
     PLC_PRG.VALVES (99)
                                          Local Read
     _global_init (303)
                                          Local Read
VPV212_FAST_OPN_REQ_LL
     PLC_PRG.LL_SM (15)
                                         Local Write
     PLC_PRG.LL_SM (28)
                                          Local Write
     PLC_PRG.LL_SM (41)
                                          Local Write
     PLC_PRG.LL_SM (58)
                                          Local Write
     PLC_PRG.LL_SM (75)
                                          Local Write
     PLC_PRG.LL_SM (92)
                                         Local Write
     PLC_PRG.LL_SM (109)
                                         Local Write
     PLC_PRG.LL_SM (127)
                                         Local Write
     PLC_PRG.LL_SM (144)
                                         Local Write
     PLC_PRG.LL_SM (164)
                                         Local Write
     PLC_PRG.LL_SM (183)
                                         Local Write
     PLC_PRG.VALVES (97)
                                          Local Read
     PLC_PRG.VALVES (98)
                                           Local Read
                                           Local Write
     _global_init (270)
VPV212_CSD
                                         Local Write
     PLC_PRG.PROCESS_IN... (65)
     PLC_PRG.VALVES (102)
                                           Local Read
     _global_init (210)
                                           Local Write
VPV211_SLOW
     PLC_PRG.PROCESS_OU... (15)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (80)
                                         Local Read
     PLC_PRG.VALVES (54)
                                          Local Write
     PLC_PRG.VALVES (55)
                                          Local Write
     PLC_PRG.VALVES (56)
                                           Local Write
     PLC_PRG.VALVES (57)
                                           Local Write
     PLC_PRG.VALVES (58)
                                           Local Write
     PLC_PRG.VALVES (59)
                                           Local Read
     _global_init (297)
                                           Local Read
VPV211_FAST
     PLC_PRG.PROCESS_OU... (16)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (81)
                                           Local Read
     PLC_PRG.VALVES (62)
                                           Local Write
     PLC_PRG.VALVES (63)
                                           Local Write
     PLC_PRG.VALVES (64)
                                           Local Write
     PLC_PRG.VALVES (65)
                                           Local Write
     PLC_PRG.VALVES (66)
                                           Local Write
     PLC_PRG.VALVES (67)
                                           Local Read
     _global_init (298)
                                           Local Read
VPV211_FAST_OPN_REQ_ES
     PLC_PRG.ES_SM (15)
                                           Local Write
     PLC_PRG.ES_SM (29)
                                           Local Write
     PLC_PRG.ES_SM (43)
                                           Local Write
     PLC_PRG.ES_SM (61)
                                           Local Write
     PLC_PRG.ES_SM (79)
                                           Local Write
     PLC_PRG.ES_SM (97)
                                           Local Write
     PLC_PRG.ES_SM (115)
                                           Local Write
     PLC_PRG.ES_SM (134)
                                           Local Write
     PLC_PRG.ES_SM (152)
                                           Local Write
     PLC_PRG.ES_SM (173)
                                           Local Write
     PLC_PRG.ES_SM (193)
                                           Local Write
     PLC_PRG.VALVES (65)
                                           Local Read
     PLC_PRG.VALVES (66)
                                           Local Read
     _global_init (258)
                                           Local Write
VPV201
```

```
Local Read
     PLC_PRG.PROCESS_OU... (10)
     PLC_PRG.SC_OUTPUTS (112)
                                         Local Read
                                         Local Read
     PLC_PRG.SC_OUTPUTS (113)
     PLC_PRG.VALVES (28)
                                         Local Write
     PLC_PRG.VALVES (29)
                                          Local Write
     PLC_PRG.VALVES (30)
                                          Local Write
     PLC_PRG.VALVES (31)
                                          Local Write
     PLC_PRG.VALVES (32)
                                          Local Write
     PLC_PRG.VALVES (33)
                                          Local Read
     _global_init (296)
                                          Local Read
VPV211_CSD
                                        Local Write
     PLC_PRG.PROCESS_IN... (53)
                                          Local Read
     PLC_PRG.VALVES (70)
                                          Local Write
     _global_init (202)
V204_OPN_REQ_SC
                                         Local Write
     PLC_PRG.SC_INPUTS (13)
     PLC_PRG.VALVES (39)
                                          Local Read
     _global_init (253)
                                          Local Write
VPV211_OPN
                                         Local Write
     PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_IN... (53)
                                         Local Read
                                          Local Write
     _global_init (201)
VPV211_FAST_CLS_REQ_ES
     _global_init (259)
                                          Local Write
V204_CSD
     PLC_PRG.ES_SM (33)
                                          Local Read
     PLC_PRG.PROCESS_IN... (46)
                                          Local Write
     PLC_PRG.PUMPS (16)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (68)
                                         Local Read
                                         Local Read
     PLC_PRG.SC_OUTPUTS (70)
     PLC_PRG.VALVES (28)
                                         Local Read
     PLC_PRG.VALVES (46)
                                          Local Read
     PLC_PRG.VALVES (54)
                                          Local Read
     PLC_PRG.VALVES (62)
                                         Local Read
     PLC_PRG.VALVES (70)
                                          Local Read
     PLC_PRG.VALVES (80)
                                           Local Read
                                           Local Write
     _global_init (200)
V203_OPN_REQ_SC
     PLC_PRG.SC_INPUTS (11)
                                         Local Write
     PLC_PRG.VALVES (23)
                                           Local Read
     _global_init (251)
                                           Local Write
V204_OPN
     PLC_PRG.PROCESS_IN... (45)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (69)
                                           Local Read
     _global_init (199)
                                           Local Write
V204_CLS_REQ_ES
     PLC_PRG.ES_SM (10)
                                           Local Write
     PLC_PRG.ES_SM (24)
                                           Local Write
     PLC_PRG.ES_SM (38)
                                           Local Write
     PLC_PRG.ES_SM (56)
                                           Local Write
     PLC_PRG.ES_SM (74)
                                           Local Write
     PLC_PRG.ES_SM (92)
                                           Local Write
     PLC_PRG.ES_SM (110)
                                           Local Write
     PLC_PRG.ES_SM (129)
                                           Local Write
     PLC_PRG.ES_SM (147)
                                           Local Write
     PLC_PRG.ES_SM (168)
                                           Local Write
     PLC_PRG.ES_SM (188)
                                           Local Write
     PLC_PRG.VALVES (40)
                                           Local Read
     _global_init (255)
                                           Local Write
V204
     PLC_PRG.PROCESS_OU... (8)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (71)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (72)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (73)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (74)
                                           Local Read
     PLC_PRG.VALVES (36)
                                           Local Write
     PLC_PRG.VALVES (37)
                                           Local Write
     PLC_PRG.VALVES (38)
                                           Local Write
     PLC_PRG.VALVES (39)
                                           Local Write
     PLC_PRG.VALVES (40)
                                           Local Write
     PLC_PRG.VALVES (41)
                                           Local Read
                                           Local Read
     _global_init (295)
V204_CLS_REQ_SC
```

```
PLC_PRG.SC_INPUTS (14)
                                             Local Write
      PLC_PRG.VALVES (40)
                                             Local Read
      _global_init (254)
                                             Local Write
V203_CSD
     PLC_PRG.PROCESS_IN... (43) Local Write
      PLC_PRG.PUMPS (16)
                                             Local Read
                                      Local Read
Local Read
      PLC_PRG.SC_OUTPUTS (60)
      PLC_PRG.SC_OUTPUTS (62)
      PLC_PRG.VALVES (28)
                                            Local Read
      _global_init (198)
                                             Local Write
V203_OPN
     PLC_PRG.PROCESS_IN... (42)
                                         Local Write
Local Read
     PLC_PRG.SC_OUTPUTS (61)
     _global_init (197)
                                             Local Write
V203
                                         Local Read
     PLC_PRG.PROCESS_OU... (7)
      PLC_PRG.SC_OUTPUTS (63)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (64)

PLC_PRG.SC_OUTPUTS (65)

PLC_PRG.SC_OUTPUTS (66)

PLC_PRG.SC_OUTPUTS (66)

Local Read

PLC_PRG.VALVES (20)

Local Write
      PLC_PRG.VALVES (21)
                                            Local Write
      PLC_PRG.VALVES (22)
                                            Local Write
      PLC_PRG.VALVES (23)
                                            Local Write
      PLC_PRG.VALVES (24)
                                            Local Write
     PLC_PRG.VALVES (25)
                                             Local Read
      _global_init (294)
                                             Local Read
V203_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (12)
                                            Local Write
      PLC_PRG.VALVES (24)
                                            Local Read
      _global_init (252)
                                             Local Write
V202_OPN
     PLC_PRG.FAULT_LOGIC (6)
PLC_PRG.FAULT_LOGIC (37)
PLC_PRG.PROCESS_IN... (39)
                                           Local Read
Local Read
Local Write
Local Read
      PLC_PRG.SC_OUTPUTS (56)
                                             Local Write
      _global_init (195)
V202_CSD
     CSD
PLC_PRG.PROCESS_IN... (40)
PLC_PRG.SC_OUTPUTS (57)
                                           Local Write
Local Read
     PLC_PRG.SC_OUTPUTS (58)
                                             Local Read
      _global_init (196)
                                              Local Write
V201_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (10)
                                            Local Write
     PLC_PRG.VALVES (16)
                                              Local Read
      _global_init (250)
                                              Local Write
V201_OPN_REQ_SC
     PLC_PRG.SC_INPUTS (9)
                                            Local Write
     PLC_PRG.VALVES (15)
                                              Local Read
      _global_init (249)
                                              Local Write
V101_OPN_REQ_SC
      PLC_PRG.SC_INPUTS (7)
                                             Local Write
      PLC_PRG.VALVES (7)
                                              Local Read
      _global_init (247)
                                              Local Write
V201_OPN
     PLC_PRG.PROCESS_IN... (36)
                                            Local Write
      PLC_PRG.SC_OUTPUTS (49)
                                              Local Read
                                              Local Write
      _global_init (193)
TPV212_OPN
      PLC_PRG.PROCESS_IN... (70)
                                            Local Write
      PLC_PRG.SC_OUTPUTS (102)
                                              Local Read
      _global_init (213)
                                              Local Write
V201_CSD
      PLC_PRG.PROCESS_IN... (37)
PLC_PRG.SC_OUTPUTS (48)
                                           Local Write
                                              Local Read
      PLC_PRG.SC_OUTPUTS (50)
                                              Local Read
      _global_init (194)
                                              Local Write
V201
      PLC_PRG.PROCESS_OU... (6)
                                             Local Read
                                            Local Read
      PLC_PRG.SC_OUTPUTS (51)
      PLC_PRG.SC_OUTPUTS (52)
                                              Local Read
      PLC_PRG.SC_OUTPUTS (53)
                                              Local Read
                                              Local Read
      PLC_PRG.SC_OUTPUTS (54)
```

```
PLC_PRG.VALVES (12)
                                            Local Write
     PLC PRG. VALVES (13)
                                            Local Write
     PLC_PRG.VALVES (14)
                                           Local Write
     PLC_PRG.VALVES (15)
                                           Local Write
     PLC_PRG.VALVES (16)
                                           Local Write
     PLC_PRG.VALVES (17)
                                           Local Read
      _global_init (293)
                                            Local Read
V101_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (8)
                                           Local Write
     PLC_PRG.VALVES (8)
                                            Local Read
     _global_init (248)
                                            Local Write
                                          Local Read
     PLC_PRG.PROCESS_OU... (22)
     PLC_PRG.SC_OUTPUTS (104)
                                           Local Read
     PLC_PRG.VALVES (110)
                                           Local Write
     PLC_PRG.VALVES (111)
                                           Local Write
     PLC_PRG.VALVES (112)
                                           Local Write
     PLC_PRG.VALVES (113)
                                           Local Write
     PLC_PRG.VALVES (114)
                                           Local Write
     PLC_PRG.VALVES (115)
                                           Local Read
     _global_init (305)
                                           Local Read
     PLC_PRG.PROCESS_OU... (5)
PLC_PRG.SC_OUTPUTS (43)

DDC_SC_OUTPUTS (44)
V101
                                          Local Read
Local Read
                                          Local Read
Local Read
     PLC_PRG.SC_OUTPUTS (45)
     PLC_PRG.SC_OUTPUTS (46)
                                           Local Read
     PLC_PRG.VALVES (4)
                                           Local Write
     PLC_PRG.VALVES (5)
                                           Local Write
     PLC_PRG.VALVES (6)
                                           Local Write
     PLC_PRG.VALVES (7)
                                           Local Write
     PLC_PRG.VALVES (8)
                                           Local Write
     PLC_PRG.VALVES (9)
                                           Local Read
     _global_init (292)
                                            Local Read
TPV211_OPN_REQ_ES
     PLC_PRG.ES_SM (16)
                                           Local Write
     PLC_PRG.ES_SM (30)
                                           Local Write
     PLC_PRG.ES_SM (44)
                                           Local Write
     PLC_PRG.ES_SM (62)
                                           Local Write
     PLC_PRG.ES_SM (80)
                                           Local Write
     PLC_PRG.ES_SM (98)
                                           Local Write
     PLC_PRG.ES_SM (116)
                                           Local Write
                                           Local Write
     PLC_PRG.ES_SM (135)
                                           Local Write
     PLC_PRG.ES_SM (153)
     PLC_PRG.ES_SM (174)
                                           Local Write
     PLC_PRG.ES_SM (194)
                                            Local Write
     PLC_PRG.VALVES (81)
                                            Local Read
     PLC_PRG.VALVES (82)
                                            Local Read
     _global_init (262)
                                            Local Write
TPV212_CSD
     PLC_PRG.PROCESS_IN... (71)
                                            Local Write
     PLC_PRG.PUMPS (31)
                                            Local Read
     PLC_PRG.PUMPS (32)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (103)
                                            Local Read
     PLC_PRG.VALVES (86)
                                            Local Read
     PLC_PRG.VALVES (94)
                                            Local Read
     _global_init (214)
                                            Local Write
TPV211_OPN
     PLC_PRG.PROCESS_IN... (58)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (83)
                                            Local Read
     _global_init (205)
                                            Local Write
TPV211_CSD
     1_CSD
PLC_PRG.PROCESS_IN... (59)
PLC_PRG.PUMPS (23)
                                           Local Write
                                            Local Read
     PLC_PRG.PUMPS (24)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (84)
                                            Local Read
     PLC_PRG.VALVES (54)
                                            Local Read
     PLC_PRG.VALVES (62)
                                            Local Read
     _global_init (206)
                                            Local Write
TPV211
     PLC_PRG.PROCESS_OU... (13)
PLC_PRG.SC_OUTPUTS (85)
                                           Local Read
                                            Local Read
     PLC_PRG.VALVES (78)
                                            Local Write
```

```
PLC_PRG.VALVES (79)
                                            Local Write
     PLC PRG. VALVES (80)
                                           Local Write
     PLC_PRG.VALVES (81)
                                          Local Write
     PLC_PRG.VALVES (82)
                                           Local Write
     PLC_PRG.VALVES (83)
                                           Local Read
      _global_init (300)
                                           Local Read
TP212_ON_REQ_LL
     PLC_PRG.LL_SM (17)
                                          Local Write
     PLC_PRG.LL_SM (30)
                                           Local Write
     PLC_PRG.LL_SM (43)
                                           Local Write
     PLC_PRG.LL_SM (60)
                                          Local Write
     PLC_PRG.LL_SM (77)
                                          Local Write
     PLC_PRG.LL_SM (94)
                                          Local Write
     PLC_PRG.LL_SM (111)
                                          Local Write
     PLC_PRG.LL_SM (129)
                                          Local Write
     PLC_PRG.LL_SM (146)
                                          Local Write
     PLC_PRG.LL_SM (166)
                                          Local Write
     PLC_PRG.LL_SM (185)
                                          Local Write
     PLC_PRG.PUMPS (33)
                                          Local Read
     _global_init (284)
                                           Local Write
TP212
     PLC_PRG.PROCESS_OU... (21)
                                          Local Read
     PLC_PRG.PUMPS (30)
                                          Local Write
     PLC_PRG.PUMPS (31)
                                          Local Write
     PLC_PRG.PUMPS (32)
                                          Local Write
     PLC_PRG.PUMPS (33)
                                          Local Write
     PLC_PRG.PUMPS (34)
                                          Local Read
     PLC_PRG.PUMPS (34)
                                          Local Write
     PLC_PRG.PUMPS (35)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (129)
                                          Local Read
     PLC_PRG.VALVES (110)
                                           Local Read
                                           Local Read
     _global_init (310)
TP211
     PLC_PRG.PROCESS_OU... (12)
                                         Local Read
     PLC_PRG.PUMPS (22)
                                           Local Write
     PLC_PRG.PUMPS (23)
                                           Local Write
     PLC_PRG.PUMPS (24)
                                           Local Write
     PLC_PRG.PUMPS (25)
                                           Local Write
     PLC_PRG.PUMPS (26)
                                          Local Read
     PLC_PRG.PUMPS (26)
                                          Local Write
     PLC_PRG.PUMPS (27)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (125)
                                          Local Read
     PLC_PRG.VALVES (78)
                                           Local Read
                                           Local Read
     _global_init (309)
TPV211_CLS_REQ_ES
     _global_init (263)
                                           Local Write
TP201_OK
                                          Local Read
     PLC_PRG.FAULT_LOGIC (19)
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.PROCESS_IN... (48)
                                           Local Write
     PLC_PRG.PROCESS_IN... (49)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (115)
                                            Local Read
     _global_init (215)
                                            Local Write
V101_CSD
     PLC_PRG.PROCESS_IN... (34)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (40)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (42)
                                            Local Read
     _global_init (192)
                                            Local Write
TP201_READY
     PLC_PRG.PROCESS_IN... (50)
                                           Local Write
     PLC_PRG.VALVES (21)
                                            Local Read
     PLC_PRG.VALVES (37)
                                            Local Read
     _global_init (217)
                                            Local Write
TP201_ON
     PLC_PRG.PROCESS_IN... (49)
                                           Local Write
     PLC_PRG.PROCESS_IN... (50)
PLC_PRG.SC_OUTPUTS (116)
                                           Local Read
                                           Local Read
     PLC_PRG.VALVES (28)
                                           Local Read
     _global_init (216)
                                           Local Write
SOCKET_SO_USELOOPBACK
     _global_init (123)
                                            Global Write
SOCKET_SO_SNDTIMEO
     _global_init (131)
                                            Global Write
```

```
SOCKET_SO_DEBUG
                                           Global Write
     _global_init (117)
SOCKET_SOL
                                           Global Write
     _global_init (116)
SOCKET_SO_SNDBUF
     _global_init (127)
                                          Global Write
SOCKET_SO_PROTOTYPE
     _global_init (135)
                                          Global Write
SOCKET_SO_REUSEADDR
     _global_init (119)
                                          Global Write
SOCKET_MSG_PEEK
     _global_init (159)
                                          Global Write
SOCKET_SO_ACCEPTCONN
     _global_init (118)
                                          Global Write
SOCKET_IPPROTO_TCP
     CLIENT_OPENCLOSE (11)
                                           Global Read
                                           Global Write
     _global_init (151)
SOCKET_IPPROTO_ND
     _global_init (155)
                                           Global Write
SC_VERSION_MINOR%MW1281
    PLC_PRG.SC_OUTPUTS (157)
                                          Local Write
                                          Local Write
     _global_init (146)
SC_VERSION_MAJOR%MW1280
    PLC_PRG.SC_OUTPUTS (156)
                                          Local Write
     _global_init (145)
                                          Local Write
SC_VENT212_FAST_CMD%MX8.12
    PLC_PRG.SC_OUTPUTS (100)
                                          Local Write
     _global_init (89)
                                           Local Write
SC_V202_CLOSED%MX4.9
    PLC_PRG.SC_OUTPUTS (57)
                                           Local Write
     _global_init (54)
                                           Local Write
SC_V201_BEAM_PASS%MX4.0
                                         Local Write
     PLC_PRG.SC_OUTPUTS (48)
     PLC_PRG.SC_OUTPUTS (58)
                                         Local Read
     _global_init (46)
                                           Local Write
SC_V100_CLOSED%MX3.1
    PLC_PRG.SC_OUTPUTS (38)
                                          Local Write
     _global_init (38)
                                           Local Write
uiFailing
     ACTUATOR_SM.CONNECT (30)
                                         Local Read
     ACTUATOR_SM.CONNECT (30)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (31)
                                         Local Read
     ACTUATOR_SM.DRG1_W... (31)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (32)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (32)
                                          Local Write
                                          Local Read
     ACTUATOR_SM.STATUS... (31)
     ACTUATOR_SM.STATUS... (31)
                                           Local Write
     _global_init (8)
                                           Local Write
TPV212_OPN_REQ_LL
     PLC_PRG.LL_SM (16)
                                           Local Write
     PLC_PRG.LL_SM (29)
                                           Local Write
     PLC_PRG.LL_SM (42)
                                           Local Write
     PLC_PRG.LL_SM (59)
                                           Local Write
     PLC_PRG.LL_SM (76)
                                           Local Write
     PLC_PRG.LL_SM (93)
                                           Local Write
     PLC_PRG.LL_SM (110)
                                           Local Write
     PLC_PRG.LL_SM (128)
                                           Local Write
     PLC_PRG.LL_SM (145)
                                           Local Write
     PLC_PRG.LL_SM (165)
                                           Local Write
     PLC_PRG.LL_SM (184)
                                           Local Write
     PLC_PRG.VALVES (113)
                                           Local Read
     PLC_PRG.VALVES (114)
                                           Local Read
     _global_init (274)
                                           Local Write
TP212_OK
     PLC_PRG.FAULT_LOGIC (21)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.LL_SM (47)
                                           Local Read
     PLC_PRG.LL_SM (154)
                                           Local Read
     PLC_PRG.PROCESS_IN... (73)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (127)
                                           Local Read
                                           Local Write
     _global_init (220)
TP211_ON_REQ_ES
     PLC_PRG.ES_SM (17)
                                           Local Write
```

```
PLC_PRG.ES_SM (31)
                                               Local Write
      PLC PRG.ES SM (45)
                                               Local Write
      PLC_PRG.ES_SM (63)
                                              Local Write
      PLC_PRG.ES_SM (81)
                                              Local Write
      PLC_PRG.ES_SM (99)
                                              Local Write
      PLC_PRG.ES_SM (117)
                                              Local Write
      PLC_PRG.ES_SM (136)
                                              Local Write
      PLC_PRG.ES_SM (154)
                                              Local Write
      PLC_PRG.ES_SM (175)
                                              Local Write
      PLC_PRG.ES_SM (195)
                                              Local Write
      PLC_PRG.PUMPS (25)
                                              Local Read
      _global_init (282)
                                               Local Write
TP211 READY
      PLC_PRG.PROCESS_IN... (62)
                                            Local Write
Local Read
      PLC_PRG.SC_OUTPUTS (124)
      _global_init (219)
                                              Local Write
TP211_OK
                                             Local Read
      PLC_PRG.ES_SM (49)
      PLC_PRG.ES_SM (162)
                                              Local Read
     PLC_PRG.FAULT_LOGIC (20)

PLC_PRG.FAULT_LOGIC (37)

PLC_PRG.PROCESS_IN... (61)

PLC_PRG.SC_OUTPUTS (123)

Global init (219)

Local Read

Global init (219)
      _global_init (218)
                                              Local Write
SC_VENT211_FAST_CMD%MX6.12
                                           Local Write
     PLC_PRG.SC_OUTPUTS (81)
                                              Local Write
      _global_init (74)
SC_V203_OPN_REQ%MX641.6
     PLC_PRG.CLEAR_REQS (11)
                                             Local Write
Local Read
      PLC_PRG.SC_INPUTS (11)
      _global_init (135)
                                              Local Write
SC_V201_CLS_REQ%MX641.3
                                             Local Write
Local Read
     PLC_PRG.CLEAR_REQS (9)
     PLC_PRG.SC_INPUTS (10)
      _global_init (134)
                                              Local Write
SC_V101_OPEN_PERMIT%MX3.11
     PLC_PRG.SC_OUTPUTS (43)
                                              Local Write
                                               Local Write
      _global_init (42)
SC_PE212_OK%MX2.0
    PLC_PRG.SC_OUTPUTS (28)
                                              Local Write
      _global_init (30)
                                               Local Write
tTCP_Timeout
                                             Local Read
Local Read
     ACTUATOR_SM.CONNECT (25)
     ACTUATOR_SM.CONNECT (25)
ACTUATOR_SM.DRG1_W... (26)
ACTUATOR_SM.PCMD_W... (27)
ACTUATOR_SM.STATUS... (26)
                                              Local Read
                                               Local Read
      _global_init (4)
                                               Local Write
TP212_OFF_REQ_LL
      _global_init (285)
                                               Local Write
TPV212_CLS_REQ_LL
      _global_init (275)
                                               Local Write
TP201_VENT_ENABLE_REQ_SC
      PLC_PRG.SC_INPUTS (17)
                                               Local Write
      PLC_PRG.VALVES (31)
                                                Local Read
      _global_init (278)
                                                Local Write
TP212_READY
     PLC_PRG.PROCESS_IN... (74)
PLC_PRG.SC_OUTPUTS (128)
                                               Local Write
                                                Local Read
      _global_init (221)
                                                Local Write
TP211_OFF_REQ_ES
      _global_init (283)
                                               Local Write
TP201_VENT_DISABLE_REQ_SC
      PLC_PRG.SC_INPUTS (18)
                                              Local Write
      PLC_PRG.VALVES (32)
                                               Local Read
      _global_init (279)
                                               Local Write
TP201_ON_REQ_SC
      PLC_PRG.PUMPS (17)
                                              Local Read
      PLC_PRG.SC_INPUTS (15)
                                               Local Write
                                               Local Write
      _global_init (276)
TP201_OFF_REQ_SC
      PLC_PRG.PUMPS (18)
                                               Local Read
      PLC_PRG.SC_INPUTS (16)
                                               Local Write
                                                Local Write
      _global_init (277)
```

```
SOCKET_INVALID
     _global_init (84)
                                          Global Write
     PLC_PRG.PROCESS_OU... (9)
                                         Local Read
     PLC_PRG.PUMPS (14)
                                          Local Write
     PLC_PRG.PUMPS (15)
                                          Local Write
     PLC_PRG.PUMPS (16)
                                          Local Write
     PLC_PRG.PUMPS (17)
                                          Local Write
     PLC_PRG.PUMPS (18)
                                          Local Write
     PLC_PRG.PUMPS (19)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (117)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (118)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (119)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (120)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (121)
                                          Local Read
     PLC_PRG.VALVES (29)
                                          Local Read
     _global_init (306)
                                          Local Read
SOCKET_pseudo_AF_XTP
     _global_init (106)
                                           Global Write
SOCKET_pseudo_AF_RTIP
     _global_init (109)
                                           Global Write
SOCKET_pseudo_AF_PIP
     _global_init (112)
                                           Global Write
SOCKET_AF_SIP
     _global_init (111)
                                           Global Write
SOCKET_AF_ROUTE
     _global_init (104)
                                           Global Write
SOCKET_AF_SNA
     _global_init (98)
                                           Global Write
SC_VERSION_MINOR%MW1281
    PLC_PRG.SC_OUTPUTS (157)
                                         Local Write
     _global_init (146)
                                          Local Write
SC_V204_OPN_REQ%MX641.8
                                         Local Write
     PLC_PRG.CLEAR_REQS (14)
                                          Local Read
     PLC_PRG.SC_INPUTS (13)
                                           Local Write
     _global_init (137)
SC_V203_CLOSED%MX5.2
    PLC_PRG.SC_OUTPUTS (62)
                                         Local Write
     _global_init (58)
                                           Local Write
SC_PE211_PSL_HI%MX1.9
    PLC_PRG.SC_OUTPUTS (23)
                                         Local Write
     _global_init (26)
                                           Local Write
SC_PE203_PSL_MIDHI%MX1.2
    PLC_PRG.SC_OUTPUTS (18)
                                          Local Write
     _global_init (22)
                                           Local Write
tonConnect
                                         Local Write
     ACTUATOR_SM.CONNECT (6)
     ACTUATOR_SM.CONNECT (25)
                                         Local Read
     ACTUATOR_SM.DRG1_W... (26)
                                           Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                           Local Read
     ACTUATOR_SM.STATUS... (26)
                                           Local Read
     ACTUATORinit (7)
                                           Local Read
SOCKET_SO_OOBINLINE
     _global_init (125)
                                           Global Write
SOCKET_SO_LINGER
     _global_init (124)
                                           Global Write
SOCKET_SO_KEEPALIVE
     _global_init (120)
                                           Global Write
SOCKET_SO_BROADCAST
                                           Global Write
     _global_init (122)
SOCKET_SO_DONTROUTE
                                           Global Write
     _global_init (121)
SOCKET_AF_UNSPEC
     _global_init (85)
                                           Global Write
SOCKET_AF_UNIX
     _global_init (87)
                                           Global Write
SOCKET_AF_PUP
     _global_init (90)
                                           Global Write
SOCKET_AF_NS
     _global_init (92)
                                           Global Write
SC_V204_OPEN_PERMIT%MX5.11
                                           Local Write
     PLC_PRG.SC_OUTPUTS (71)
                                           Local Write
     _global_init (66)
```

SC_V100_OPEN%MX3.0	
PLC_PRG.SC_OUTPUTS (37)	Local Write
	Local Write
SC_PE201_PSL%MX0.9	Boodi Wilee
PLC_PRG.SC_OUTPUTS (8)	Local Write
_global_init (14)	Local Write
strAddress	
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.STATUS (26)	Local Read
	Local Write
SOCKET_SO_TYPE	20001 11100
	Global Write
_global_init (134)	Global Wille
SOCKET_SO_SNDLOWAT	
_global_init (129)	Global Write
SOCKET_SO_RCVLOWAT	
_global_init (130)	Global Write
SOCKET_SO_REUSEPORT	
_global_init (126)	Global Write
SOCKET_SO_RCVTIMEO	GIODGI WIICC
	Clobal Waits
_global_init (132)	Global Write
SOCKET_SO_ERROR	
_global_init (133)	Global Write
SOCKET_IPPROTO_UDP	
CLIENT_OPENCLOSE (43)	Global Read
ETHERNET_MODBUSMAS (9)	Global Read
_global_init (153)	Global Write
SOCKET_SO_RCVBUF	
_global_init (128)	Global Write
	Global Wille
SOCKET_IPPROTO_MAX	
_global_init (157)	Global Write
SOCKET_IPPROTO_IP	
_global_init (147)	Global Write
SOCKET_IPPROTO_IGMP	
_global_init (149)	Global Write
SOCKET_AF_OSI	
_global_init (94)	Global Write
	Global Wilce
SOCKET_AF_MAX	
_global_init (113)	Global Write
SOCKET_AF_LOCAL	
_global_init (86)	Global Write
SOCKET_AF_LINK	
_global_init (105)	Global Write
SOCKET AF LAT	
_global_init (101)	Global Write
	GIODAI WIICE
SOCKET_AF_ISO	
_global_init (93)	Global Write
SOCKET_AF_IPX	
_global_init (110)	Global Write
SOCKET_AF_INET_STREAMS	
	Global Write
SOCKET_AF_INET_BSD	
_global_init (114)	Global Write
	GIODGI WIICE
SOCKET_AF_INET	
CLIENT_OPENCLOSE (11)	Global Read
CLIENT_OPENCLOSE (27)	Global Read
CLIENT_OPENCLOSE (43)	Global Read
ETHERNET_MODBUSMAS (9)	Global Read
ETHERNET_MODBUSMAS (12)	Global Read
_global_init (88)	Global Write
SOCKET_AF_HYLINK	
	Global Write
SOCKET_AF_ECMA	
	Clobal Maita
_global_init (95)	Global Write
SOCKET_AF_CHAOS	
_global_init (91)	Global Write
SOCKET_AF_IMPLINK	
_global_init (89)	Global Write
SOCKET_AF_DLI	
_global_init (100)	Global Write
SOCKET_AF_DECnet	
	Clobal Waita
_global_init (99)	Global Write

COCKET AF COLD	
SOCKET_AF_COIP _global_init (107)	Global Write
SOCKET_AF_DATAKITqlobal_init (96)	Global Write
SOCKET_AF_CNT _global_init (108)	Global Write
SOCKET_AF_APPLETALK	
_global_init (103) SC_VENT212_FAST_CMD%MX8.12	Global Write
PLC_PRG.SC_OUTPUTS (100) _global_init (89)	Local Write Local Write
SC_VENT212_SLOW_CMD%MX8.11 PLC_PRG.SC_OUTPUTS (99)	Local Write
_global_init (88) SC_VENT211_SLOW_CMD%MX6.11	Local Write
PLC_PRG.SC_OUTPUTS (80) _global_init (73)	Local Write Local Write
SC_VENT211_FAST_CMD%MX6.12 PLC_PRG.SC_OUTPUTS (81)	Local Write
_global_init (74) SC_V204_OPN_REQ%MX641.8	Local Write
PLC_PRG.CLEAR_REQS (14)	Local Write
PLC_PRG.SC_INPUTS (13) _global_init (137)	Local Read Local Write
SOCKET_AF_CCITT _global_init (97)	Global Write
SC_VERSION_MAJOR%MW1280	
PLC_PRG.SC_OUTPUTS (156) _global_init (145)	Local Write Local Write
SC_V204_OPEN_PERMIT%MX5.11 PLC_PRG.SC_OUTPUTS (71)	Local Write
_global_init (66)	Local Write
SC_V204_OPEN_CMD%MX5.13 PLC_PRG.SC_OUTPUTS (73)	Local Write
_global_init (68) SC_V204_OPEN_CMD%MX5.13	Local Write
PLC_PRG.SC_OUTPUTS (73) _global_init (68)	Local Write
SC_V204_NOT_SYMBOL%MX5.14	Local Write
PLC_PRG.SC_OUTPUTS (74) _global_init (69)	Local Write Local Write
SC_V204_CLS_REQ%MX641.9 PLC_PRG.CLEAR_REQS (15)	Local Write
PLC_PRG.SC_INPUTS (14)	Local Read
_global_init (138) SC_V204_BEAM_PASS%MX5.8	Local Write
PLC_PRG.SC_OUTPUTS (68) global init (63)	Local Write Local Write
SC_V204_OPEN%MX5.9	
PLC_PRG.SC_OUTPUTS (69) _global_init (64)	Local Write Local Write
SC_V204_CLOSED%MX5.10 PLC PRG.SC OUTPUTS (70)	Local Write
_global_init (65)	Local Write
SC_V204_OPEN%MX5.9 PLC_PRG.SC_OUTPUTS (69)	Local Write
_global_init (64) SC_V204_CLS_REQ%MX641.9	Local Write
PLC_PRG.CLEAR_REQS (15)	Local Write Local Read
PLC_PRG.SC_INPUTS (14) _global_init (138)	Local Read Local Write
SC_V203_OPN_REQ%MX641.6 PLC_PRG.CLEAR_REQS (11)	Local Write
PLC_PRG.SC_INPUTS (11)	Local Read
_global_init (135) SC_V204_CLOSE_PERMIT%MX5.12	Local Write
PLC_PRG.SC_OUTPUTS (72) _global_init (67)	Local Write Local Write
SC_V203_OPEN_PERMIT%MX5.3	
PLC_PRG.SC_OUTPUTS (63) _global_init (59)	Local Write Local Write
SC_V203_OPEN_PERMIT%MX5.3 PLC_PRG.SC_OUTPUTS (63)	Local Write
123_110.133_0011010 (03)	

_global_init (59)	Ι	ocal V	Write
SC_V203_OPEN_CMD%MX5.5			
PLC_PRG.SC_OUTPUTS (	,	ocal V	
_global_init (61)	I	ocal V	Write
SC_V203_NOT_SYMBOL%MX5.6			
PLC_PRG.SC_OUTPUTS (		ocal V	
_global_init (62)	Ι	ocal V	Write
SC_V203_CLS_REQ%MX641.7			
PLC_PRG.CLEAR_REQS (	· · ·	ocal V	
PLC_PRG.SC_INPUTS (1		ocal E	
_global_init (136)	I	ocal V	Write
SC_V203_OPEN%MX5.1			
PLC_PRG.SC_OUTPUTS (		ocal D	
_global_init (57)	I	ocal V	Write
SC_V203_CLOSED%MX5.2		_	
PLC_PRG.SC_OUTPUTS (		ocal D	
_global_init (58)	I	ocal V	Write
SC_V203_OPEN%MX5.1			
PLC_PRG.SC_OUTPUTS (		ocal D	
_global_init (57)		ocal V	Write
SC_V203_CLOSE_PERMIT%MX5.4			
PLC_PRG.SC_OUTPUTS (		ocal I	
_global_init (60)		ocal V	write
SC_V203_CLOSE_PERMIT%MX5.4			
PLC_PRG.SC_OUTPUTS (		local V	
_global_init (60)	Ι	ocal V	MITCE
SC_V203_BEAM_PASS%MX5.0	(60)	ocal W	Write
PLC_PRG.SC_OUTPUTS (	•	ocal N Jocal I	
PLC_PRG.SC_OUTPUTS (	,	ocal N	
_global_init (56)	1	JOCAL V	wiice
SC_V203_BEAM_PASS%MX5.0	(60)	ocal V	White
PLC_PRG.SC_OUTPUTS ( PLC_PRG.SC_OUTPUTS (		local N	
_global_init (56)	,	ocal W	
SC_V202_BEAM_PASS%MX4.10	1	JUCAI V	MIICE
PLC_PRG.SC_OUTPUTS (	750)	ocal W	Write
PLC_PRG.SC_OUTPUTS (	· · ·	ocal E	
_global_init (55)		ocal V	
SC_V202_OPEN%MX4.8	-	iocai i	WIICO
PLC_PRG.SC_OUTPUTS (	'56) ī	ocal V	Write
_global_init (53)		ocal V	
SC_V202_OPEN%MX4.8			
PLC_PRG.SC_OUTPUTS (	(56) I	Local V	Write
		Local V	
SC_V202_BEAM_PASS%MX4.10			
PLC_PRG.SC_OUTPUTS (	(58) I	ocal V	Write
PLC_PRG.SC_OUTPUTS (		ocal E	Read
_global_init (55)	I	ocal V	Write
SC_V202_CLOSED%MX4.9			
PLC_PRG.SC_OUTPUTS (	(57) I	ocal V	Write
_global_init (54)	I	ocal V	Write
SC_V201_OPN_REQ%MX641.2			
PLC_PRG.CLEAR_REQS (		ocal V	
PLC_PRG.SC_INPUTS (9		ocal E	
_global_init (133)	I	ocal V	Write
SC_V201_OPN_REQ%MX641.2			
PLC_PRG.CLEAR_REQS (		ocal V	
PLC_PRG.SC_INPUTS (9		ocal E	
_global_init (133)	Ι	ocal V	Write
SC_V201_OPEN_CMD%MX4.5			
PLC_PRG.SC_OUTPUTS (		ocal D	
_global_init (51)	I	ocal V	Write
SC_V201_OPEN%MX4.1	(40)	-	
PLC_PRG.SC_OUTPUTS (		ocal N	
_global_init (47)	Ι	ocal V	write
SC_V201_OPEN_PERMIT%MX4.3	, F 1 \ =		
PLC_PRG.SC_OUTPUTS (		local V	
_global_init (49)	Ι	ocal V	MITCE
SC_V201_OPEN_PERMIT%MX4.3	/E1\	0001 -	Write
PLC_PRG.SC_OUTPUTS (		ocal V	
_global_init (49) SC_V201_OPEN_CMD%MX4.5	1	ocal V	MTTCE
PLC_PRG.SC_OUTPUTS (	′53) ī	ocal V	Write
110_110.50_001F015 (	,	JUCAL N	n1 1 0 0

_global_init (51)	Local Write	
SC_V201_NOT_SYMBOL%MX4.6		
PLC_PRG.SC_OUTPUTS (54)	Local Write	
_global_init (52)	Local Write	
SC_V201_NOT_SYMBOL%MX4.6		
PLC_PRG.SC_OUTPUTS (54)	Local Write	
_global_init (52)	Local Write	
SC_V201_OPEN%MX4.1		
PLC_PRG.SC_OUTPUTS (49)	Local Write	
_global_init (47)	Local Write	
SC_V201_CLS_REQ%MX641.3		
PLC_PRG.CLEAR_REQS (9)	Local Write	
PLC_PRG.SC_INPUTS (10)	Local Read	
_global_init (134)	Local Write	
SC_V201_CLOSED%MX4.2		
PLC_PRG.SC_OUTPUTS (50)	Local Write	
_global_init (48)	Local Write	
SC_V201_CLOSE_PERMIT%MX4.4		
PLC_PRG.SC_OUTPUTS (52)	Local Write	
_global_init (50)	Local Write	
SC_V201_CLOSE_PERMIT%MX4.4		
PLC_PRG.SC_OUTPUTS (52)	Local Write	
global_init (50)	Local Write	
SC_V101_OPN_REQ%MX641.0		
PLC_PRG.CLEAR_REQS (5)	Local Write	
PLC_PRG.SC_INPUTS (7)	Local Read	
_global_init (131)	Local Write	
SC_V201_BEAM_PASS%MX4.0		
PLC_PRG.SC_OUTPUTS (48)	Local Write	
PLC_PRG.SC_OUTPUTS (58)		
_global_init (46)	Local Write	
SC_V101_OPEN_PERMIT%MX3.11		
PLC_PRG.SC_OUTPUTS (43)	Local Write	
_global_init (42)	Local Write	
SC_V201_CLOSED%MX4.2	Doda' Hiloo	
PLC_PRG.SC_OUTPUTS (50)	Local Write	
_global_init (48)	Local Write	
SC_V101_OPEN%MX3.9	Doda' Hiloo	
PLC_PRG.SC_OUTPUTS (41)	Local Write	
_global_init (40)	Local Write	
SC_V101_OPEN_CMD%MX3.13		
PLC_PRG.SC_OUTPUTS (45)	Local Write	
_global_init (44)	Local Write	
SC_V101_OPEN_CMD%MX3.13		
PLC_PRG.SC_OUTPUTS (45)	Local Write	
_global_init (44)	Local Write	
SC V101 NOT SYMBOL%MX3.14		
PLC_PRG.SC_OUTPUTS (46)	Local Write	
_global_init (45)	Local Write	
SC_V101_NOT_SYMBOL%MX3.14		
PLC_PRG.SC_OUTPUTS (46)	Local Write	
_global_init (45)	Local Write	
SC V101 OPEN%MX3.9		
PLC_PRG.SC_OUTPUTS (41)	Local Write	
_global_init (40)	Local Write	
SC_V101_CLS_REQ%MX641.1		
PLC_PRG.CLEAR_REQS (6)	Local Write	
PLC_PRG.SC_INPUTS (8)	Local Read	
_global_init (132)	Local Write	
SC_V101_CLOSE_PERMIT%MX3.12	Doda' Hiloo	
PLC_PRG.SC_OUTPUTS (44)	Local Write	
_global_init (43)	Local Write	
SC_V101_CLOSED%MX3.10	LOCAL WITCO	
PLC_PRG.SC_OUTPUTS (42)	Local Write	
_global_init (41)	Local Write	
_global_Init (41) SC_V101_CLOSED%MX3.10	TOCAT MITCE	
PLC_PRG.SC_OUTPUTS (42)	Local Write	
_global_init (41)	Local Write	
SC_V101_CLOSE_PERMIT%MX3.12	TOCAT MITCE	
PLC_PRG.SC_OUTPUTS (44)	Local Write	
_global_init (43)	Local Write	
_	TOCAT MITCE	
SC_V101_BEAM_PASS%MX3.8 PLC_PRG.SC_OUTPUTS (40)	Local Write	
FLC_FRG.SC_OUTPUIS (40)	TOCAT MITCE	

_global_init (39)		Local	l Write
SC_TPV212_OPEN_CMD%MX9.5 PLC_PRG.SC_OUTPUTS		Local	l Write
_global_init (92)	(101)		l Write
SC_TPV212_OPEN_CMD%MX9.5			
PLC_PRG.SC_OUTPUTS	(104)		l Write
_global_init (92)		Local	l Write
SC_V101_BEAM_PASS%MX3.8 PLC_PRG.SC_OUTPUTS	(40)	Logal	l Write
_global_init (39)	(40)		l Write
SC_V100_OPEN%MX3.0			
PLC_PRG.SC_OUTPUTS	(37)		l Write
_global_init (37)		Local	l Write
SC_V100_CLOSED%MX3.1 PLC_PRG.SC_OUTPUTS	(38)	Local	l Write
_global_init (38)	(30)		l Write
SC_TPV212_CLOSED%MX9.2			
PLC_PRG.SC_OUTPUTS			l Write
_global_init (91)		Local	l Write
SC_TPV212_OPEN%MX9.1 PLC_PRG.SC_OUTPUTS	(102)	Local	l Write
_global_init (90)	(102)		l Write
SC_TPV211_OPEN%MX7.1			
PLC_PRG.SC_OUTPUTS	(83)		l Write
_global_init (75)		Local	l Write
SC_TP212_ON%MX11.9 PLC_PRG.SC_OUTPUTS	(128)	Local	l Write
_global_init (110)			l Write
SC_TP212_ON%MX11.9			
PLC_PRG.SC_OUTPUTS	(128)		l Write
_global_init (110)		Local	l Write
SC_TP211_ON%MX11.1 PLC_PRG.SC_OUTPUTS	(124)	Local	l Write
_global_init (107)	(124)		l Write
SC_TPV212_OPEN%MX9.1			
PLC_PRG.SC_OUTPUTS	(102)		l Write
_global_init (90)		Local	l Write
SC_TP211_OK%MX11.0 PLC_PRG.SC_OUTPUTS	(123)	Local	l Write
_global_init (106)	(123)		l Write
SC_TP211_OK%MX11.0			
PLC_PRG.SC_OUTPUTS	(123)		l Write
_global_init (106)		Local	l Write
SC_TPV212_CLOSED%MX9.2 PLC_PRG.SC_OUTPUTS	(103)	Local	l Write
_global_init (91)	(100)		l Write
SC_TPV211_OPEN_CMD%MX7.5			
PLC_PRG.SC_OUTPUTS	(85)		l Write
_global_init (77) SC_TPV211_CLOSED%MX7.2		Local	l Write
PLC_PRG.SC_OUTPUTS	(84)	Local	l Write
_global_init (76)	. ,		l Write
SC_TP212_OK%MX11.8			
PLC_PRG.SC_OUTPUTS	(127)		l Write
_global_init (109) SC_TP212_OFF%MX11.10		Local	l Write
PLC_PRG.SC_OUTPUTS	(129)	Local	l Write
_global_init (111)			l Write
SC_TP211_OFF%MX11.2			
PLC_PRG.SC_OUTPUTS	(125)		l Write
_global_init (108) SC_TP201_VENT_NOT_SYMBOL	%MX10 6	госат	l Write
PLC_PRG.SC_OUTPUTS		Local	l Write
_global_init (98)	•		l Write
SC_TP211_ON%MX11.1			
PLC_PRG.SC_OUTPUTS	(124)		l Write
_global_init (107) SC_TP201_VENT_ENABLE_REQ	%MX641 12	Local	l Write
PLC_PRG.CLEAR_REQS		Local	l Write
PLC_PRG.SC_INPUTS			l Read
_global_init (141)		Local	l Write
SC_TP201_VENT_ENABLE_REQ		I o c c l	1 Write
PLC_PRG.CLEAR_REQS	(19)	ьосаl	l Write

PLC_PRG.SC_INPUTS (17)	Local Read
_global_init (141)	Local Write
SC_TP201_VENT_DISABLE_REQ%MX641.13	
PLC_PRG.CLEAR_REQS (20)	Local Write
PLC_PRG.SC_INPUTS (18)	Local Read
_global_init (142)	Local Write
SC_TP201_VENT_DISABLE_REQ%MX641.13	
PLC_PRG.CLEAR_REQS (20)	Local Write
PLC_PRG.SC_INPUTS (18)	Local Read
_global_init (142)	Local Write
SC TP211 OFF%MX11.2	
PLC_PRG.SC_OUTPUTS (125)	Local Write
_global_init (108)	Local Write
SC_TP201_ON_REQ%MX641.10	
PLC_PRG.CLEAR_REQS (17)	Local Write
PLC_PRG.SC_INPUTS (15)	Local Read
_global_init (139)	Local Write
SC_TP201_ON_REQ%MX641.10	Boodi Wilco
PLC PRG.CLEAR REOS (17)	Local Write
PLC_PRG.SC_INPUTS (15)	Local Read
_global_init (139)	Local Write
_global_init (139)  SC_TP201_ON_PERMIT%MX10.11	TOCAT MITCE
PLC PRG.SC OUTPUTS (118)	Iogal Writa
	Local Write
_global_init (102)	Local Write
SC_TP201_VENT_NOT_SYMBOL%MX10.6	I and Marks
PLC_PRG.SC_OUTPUTS (113)	Local Write
_global_init (98)	Local Write
SC_TP201_ON_CMD%MX10.13	
PLC_PRG.SC_OUTPUTS (120)	Local Write
_global_init (104)	Local Write
SC_TP201_OFF_REQ%MX641.11	
PLC_PRG.CLEAR_REQS (18)	Local Write
PLC_PRG.SC_INPUTS (16)	Local Read
_global_init (140)	Local Write
SC_RP2111_AT_SPEED%MX0.13	
PLC_PRG.SC_OUTPUTS (12)	Local Write
_global_init (17)	Local Write
SC_RP2111_AT_SPEED%MX0.13	
PLC_PRG.SC_OUTPUTS (12)	Local Write
_global_init (17)	Local Write
SC_PE212_OK%MX2.0	
PLC_PRG.SC_OUTPUTS (28)	Local Write
_global_init (30)	Local Write
SC_RP2110_AT_SPEED%MX0.12	
PLC_PRG.SC_OUTPUTS (11)	Local Write
_global_init (16)	Local Write
SC PE212 PSL MIDHI%MX2.2	nocai wiite
PLC_PRG.SC_OUTPUTS (30)	Local Mrito
	Local Write
_global_init (32)	Local Write
SC_PE211_PSL_HI%MX1.9	I 1 Maike
PLC_PRG.SC_OUTPUTS (23)	Local Write
_global_init (26)	Local Write
SC_PE212_PSL_LO%MX2.4	7 7 77 11
PLC_PRG.SC_OUTPUTS (32)	Local Write
_global_init (34)	Local Write
SC_PE212_PSL_LO%MX2.4	
PLC_PRG.SC_OUTPUTS (32)	Local Write
_global_init (34)	Local Write
SC_PE2110_PSL%MX0.14	
PLC_PRG.SC_OUTPUTS (13)	Local Write
_global_init (18)	Local Write
SC_RP2110_AT_SPEED%MX0.12	
PLC_PRG.SC_OUTPUTS (11)	Local Write
_global_init (16)	Local Write
SC_ATB%MX0.2	
PLC_PRG.SC_OUTPUTS (3)	Local Write
_global_init (11)	Local Write
SC_RESET_REQUIRED%MX0.0	
PLC_PRG.SC_OUTPUTS (2)	Local Write
_global_init (10)	Local Write
_global_Init (10)  SC_RESET_REQUIRED%MX0.0	TOCAL WITCO
PLC_PRG.SC_OUTPUTS (2)	Local Write
_global_init (10)	Local Write
_grobar_init (i0)	DOCAT MITCE
I	

```
SC_PE212_PSL_MIDLO%MX2.3
     PLC_PRG.SC_OUTPUTS (31)
                                          Local Write
     _global_init (33)
                                          Local Write
SC_PE212_PSL_HI%MX2.1
    PLC_PRG.SC_OUTPUTS (29)
                                          Local Write
     _global_init (31)
                                          Local Write
SC_PE211_OK%MX1.8
    PLC_PRG.SC_OUTPUTS (22)
                                          Local Write
     _global_init (25)
                                          Local Write
SC_PE211_PSL_MIDLO%MX1.11
    PLC_PRG.SC_OUTPUTS (25)
                                         Local Write
     _global_init (28)
                                          Local Write
SC_PE211_PSL_MIDLO%MX1.11
    PLC_PRG.SC_OUTPUTS (25)
                                          Local Write
                                          Local Write
     _global_init (28)
SC_PE203_OK%MX1.0
    PLC_PRG.SC_OUTPUTS (16)
                                          Local Write
     _global_init (20)
                                          Local Write
SC_PE2111_PSL%MX0.15
    PLC_PRG.SC_OUTPUTS (14)
                                          Local Write
     _global_init (19)
                                           Local Write
SC_PE203_PSL_HI%MX1.1
    PLC_PRG.SC_OUTPUTS (17)
                                          Local Write
     _global_init (21)
                                          Local Write
open_req
     PLC_PRG.VALVES (7)
                                          Local Write
     PLC_PRG.VALVES (15)
                                          Local Write
     PLC_PRG.VALVES (23)
                                          Local Write
     PLC_PRG.VALVES (31)
                                          Local Write
     PLC_PRG.VALVES (39)
                                           Local Write
     PLC_PRG.VALVES (57)
                                           Local Write
     PLC_PRG.VALVES (65)
                                           Local Write
     PLC_PRG.VALVES (73)
                                           Local Write
     PLC_PRG.VALVES (81)
                                           Local Write
     PLC_PRG.VALVES (89)
                                           Local Write
     PLC_PRG.VALVES (97)
                                          Local Write
     PLC_PRG.VALVES (105)
                                           Local Write
     PLC_PRG.VALVES (113)
                                           Local Write
     VALVE_FB (3)
                                           Local Read
     VALVE_FBinit (4)
                                           Local Write
open_intlk
     PLC_PRG.VALVES (4)
                                           Local Write
     PLC_PRG.VALVES (12)
                                           Local Write
     PLC_PRG.VALVES (20)
                                           Local Write
     PLC_PRG.VALVES (28)
                                           Local Write
     PLC_PRG.VALVES (36)
                                           Local Write
     PLC_PRG.VALVES (54)
                                           Local Write
     PLC_PRG.VALVES (62)
                                           Local Write
     PLC_PRG.VALVES (70)
                                           Local Write
     PLC_PRG.VALVES (78)
                                           Local Write
     PLC_PRG.VALVES (86)
                                           Local Write
     PLC_PRG.VALVES (94)
                                           Local Write
     PLC_PRG.VALVES (102)
                                           Local Write
     PLC_PRG.VALVES (110)
                                           Local Write
     VALVE_FB (3)
                                           Local Read
     VALVE_FB (6)
                                           Local Read
                                           Local Write
     VALVE_FBinit (1)
open_intlk
     PLC_PRG.VALVES (45)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (11)
                                           Local Read
     VALVE_BI_FBinit (1)
                                           Local Write
wCommand
     ACTUATOR_SM (48)
                                           Local Write
     ACTUATOR_SM (57)
                                           Local Write
     ACTUATOR_SM (65)
                                           Local Write
     ACTUATOR_SM (74)
                                           Local Write
     ACTUATOR_SM (83)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (26)
                                           Local Read
     ACTUATORinit (4)
                                           Local Write
SOCKET_TCP_NODELAY
     CLIENT_OPENCLOSE (20)
                                          Global Read
     CLIENT_OPENCLOSE (71)
                                           Global Read
```

_global_init (136)	Global Write
SOCKET_TCP_MAXSEG	
_global_init (137)	Global Write
SOCKET_STREAM	GIODAI WIICE
	Cl 1 D 1
CLIENT_OPENCLOSE (11)	Global Read
_global_init (138)	Global Write
SOCKET_SEQPACKET	
_global_init (142)	Global Write
SOCKET_RDM	
_global_init (141)	Global Write
SOCKET_INADDR_NONE	
_global_init (146)	Global Write
SOCKET_INADDR_ANY	
_global_init (143)	Global Write
SOCKET_RAW	GIODAI WIICC
_global_init (140)	Global Write
	GIODAI WIICE
SOCKET_MSG_OOB	
_global_init (158)	Global Write
SOCKET_MSG_DONTROUTE	
_global_init (160)	Global Write
SOCKET_IPPROTO_RAW	
_global_init (156)	Global Write
SOCKET_IPPROTO_PUP	
_global_init (152)	Global Write
SOCKET_IPPROTO_IDP	
_global_init (154)	Global Write
SOCKET_IPPROTO_ICMP	
global_init (148)	Global Write
SOCKET_IPPROTO_GGP	
_global_init (150)	Global Write
SOCKET_INADDR_LOOPBACK	
_global_init (144)	Global Write
SOCKET_INADDR_BROADCAST	
_global_init (145)	Global Write
SOCKET_FIONBIO	
CLIENT_OPENCLOSE (25)	Global Read
CLIENT_OPENCLOSE (46)	Global Read
ETHERNET_MODBUSMAS (11)	Global Read
_global_init (162)	Global Write
SOCKET_FD_SETSIZE	
_global_init (163)	Global Write
SOCKET FIONREAD	
_global_init (161)	Global Write
SOCKET DGRAM	
CLIENT_OPENCLOSE (43)	Global Read
ETHERNET_MODBUSMAS (9)	Global Read
_global_init (139)	Global Write
SC_V204_NOT_SYMBOL%MX5.14	GIODAI WIICC
PLC_PRG.SC_OUTPUTS (74)	Local Write
_global_init (69)	Local Write
SC_V204_CLOSED%MX5.10	HOCAT WITCO
PLC PRG.SC OUTPUTS (70)	Local Write
_global_init (65)	Local Write
SC TDV211 ODEN CMD8MY7 5	
SC_TPV211_OPEN_CMD%MX7.5	Iocal Write
PLC_PRG.SC_OUTPUTS (85)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)	Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75) SC_TP201_ON_PERMIT%MX10.11	Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75) SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118)	Local Write Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75) SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)	Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75) SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102) SC_TP201_ON_CMD%MX10.13	Local Write Local Write Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77) SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75) SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102) SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120)	Local Write Local Write Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)	Local Write Local Write Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11	Local Write Local Write Local Write Local Write Local Write Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11 PLC_PRG.CLEAR_REQS (18)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11 PLC_PRG.CLEAR_REQS (18) PLC_PRG.SC_INPUTS (16)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11 PLC_PRG.CLEAR_REQS (18) PLC_PRG.SC_INPUTS (16) _global_init (140)	Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1 PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11 PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13 PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11 PLC_PRG.CLEAR_REQS (18) PLC_PRG.SC_INPUTS (16) _global_init (140)  SC_TP201_VENT_ENABLE_CMD%MX10.5	Local Write Local Read Local Write
PLC_PRG.SC_OUTPUTS (85)     _global_init (77)  SC_TPV211_OPEN%MX7.1     PLC_PRG.SC_OUTPUTS (83)     _global_init (75)  SC_TP201_ON_PERMIT%MX10.11     PLC_PRG.SC_OUTPUTS (118)     _global_init (102)  SC_TP201_ON_CMD%MX10.13     PLC_PRG.SC_OUTPUTS (120)     _global_init (104)  SC_TP201_OFF_REQ%MX641.11     PLC_PRG.CLEAR_REQS (18)     PLC_PRG.SC_INPUTS (16)     _global_init (140)  SC_TP201_VENT_ENABLE_CMD%MX10.5     PLC_PRG.SC_OUTPUTS (112)	Local Write Local Read Local Write
PLC_PRG.SC_OUTPUTS (85) _global_init (77)  SC_TPV211_OPEN%MX7.1  PLC_PRG.SC_OUTPUTS (83) _global_init (75)  SC_TP201_ON_PERMIT%MX10.11  PLC_PRG.SC_OUTPUTS (118) _global_init (102)  SC_TP201_ON_CMD%MX10.13  PLC_PRG.SC_OUTPUTS (120) _global_init (104)  SC_TP201_OFF_REQ%MX641.11  PLC_PRG.CLEAR_REQS (18)  PLC_PRG.SC_INPUTS (16) _global_init (140)  SC_TP201_VENT_ENABLE_CMD%MX10.5  PLC_PRG.SC_OUTPUTS (112) _global_init (97)	Local Write Local Read Local Write
PLC_PRG.SC_OUTPUTS (85)     _global_init (77)  SC_TPV211_OPEN%MX7.1     PLC_PRG.SC_OUTPUTS (83)     _global_init (75)  SC_TP201_ON_PERMIT%MX10.11     PLC_PRG.SC_OUTPUTS (118)     _global_init (102)  SC_TP201_ON_CMD%MX10.13     PLC_PRG.SC_OUTPUTS (120)     _global_init (104)  SC_TP201_OFF_REQ%MX641.11     PLC_PRG.CLEAR_REQS (18)     PLC_PRG.SC_INPUTS (16)     _global_init (140)  SC_TP201_VENT_ENABLE_CMD%MX10.5     PLC_PRG.SC_OUTPUTS (112)	Local Write Local Read Local Write

PLC_PRG.SC_OUTPUTS (89)	Local Write
_global_init (80)  SC_SLOTV211_OPEN_CMD%MX7.13	Local Write
PLC_PRG.SC_OUTPUTS (91)	Local Write
_global_init (82)	Local Write
SC_TPV211_CLOSED%MX7.2	
PLC_PRG.SC_OUTPUTS (84)	Local Write
_global_init (76)	Local Write
SC_TP201_VENT_ENABLE_CMD%MX10.5	
PLC_PRG.SC_OUTPUTS (112)	Local Write
_global_init (97)	Local Write
SC_TP201_ON%MX10.9 PLC_PRG.SC_OUTPUTS (116)	Local Write
_global_init (100)	Local Write
SC_TP201_ON%MX10.9	HOCAI WIICC
PLC_PRG.SC_OUTPUTS (116)	Local Write
_global_init (100)	Local Write
SC_SLOTV211_OPEN_PERMIT%MX7.11	
PLC_PRG.SC_OUTPUTS (89)	Local Write
_global_init (80)	Local Write
SC_SLOTV211_OPEN_CMD%MX7.13	T 1 TA-: 4-
PLC_PRG.SC_OUTPUTS (91)	Local Write Local Write
_global_init (82)  SC_SLOTV211_OPEN%MX7.9	LOCAL WIICE
PLC_PRG.SC_OUTPUTS (87)	Local Write
_global_init (78)	Local Write
SC_SLOTV211_OPEN%MX7.9	
PLC_PRG.SC_OUTPUTS (87)	Local Write
_global_init (78)	Local Write
SC_SLOTV211_NOT_SYMBOL%MX7.15	
PLC_PRG.SC_OUTPUTS (93)	Local Write
_global_init (84)   SC_SLOTV211_NOT_SYMBOL%MX7.15	Local Write
PLC_PRG.SC_OUTPUTS (93)	Local Write
_global_init (84)	Local Write
SC_V204_CLOSE_PERMIT%MX5.12	
PLC_PRG.SC_OUTPUTS (72)	Local Write
_global_init (67)	Local Write
SC_RPV211_OPEN_CMD%MX6.5	
PLC_PRG.SC_OUTPUTS (78)	Local Write
_global_init (72)	Local Write
SC_V203_OPEN_CMD%MX5.5 PLC_PRG.SC_OUTPUTS (65)	Local Write
_global_init (61)	Local Write
SC_TP201_OK%MX10.8	20002 112200
PLC_PRG.SC_OUTPUTS (115)	Local Write
_global_init (99)	Local Write
SC_RPV211_OPEN%MX6.1	
PLC_PRG.SC_OUTPUTS (76)	Local Write
_global_init (70)	Local Write
SC_V203_NOT_SYMBOL%MX5.6 PLC_PRG.SC_OUTPUTS (66)	Local Write
_global_init (62)	Local Write Local Write
SC_V203_CLS_REQ%MX641.7	20001 11100
PLC_PRG.CLEAR_REQS (12)	Local Write
PLC_PRG.SC_INPUTS (12)	Local Read
_global_init (136)	Local Write
SC_V101_OPN_REQ%MX641.0	
PLC_PRG.CLEAR_REQS (5)	Local Write
PLC_PRG.SC_INPUTS (7)	Local Read
_global_init (131)  SC_V101_CLS_REQ%MX641.1	Local Write
PLC_PRG.CLEAR_REQS (6)	Local Write
PLC_PRG.SC_INPUTS (8)	Local Read
_global_init (132)	Local Write
SC_TP212_OFF%MX11.10	
PLC_PRG.SC_OUTPUTS (129)	Local Write
_global_init (111)	Local Write
SC_TP212_OK%MX11.8	
PLC_PRG.SC_OUTPUTS (127)	Local Write
_global_init (109)  SC_TP201_OK%MX10.8	Local Write
PLC_PRG.SC_OUTPUTS (115)	Local Write
120_110.00_0011010 (110)	

_global_init (99)	Local Write
SC_TP201_OFF_PERMIT%MX10.12	
PLC_PRG.SC_OUTPUTS (119)	Local Write
_global_init (103)	Local Write
SC TP201 OFF PERMIT%MX10.12	
PLC_PRG.SC_OUTPUTS (119)	Local Write
_global_init (103)	Local Write
SC_TP201_OFF%MX10.10	
PLC_PRG.SC_OUTPUTS (117)	Local Write
_global_init (101)	Local Write
SC_TP201_OFF%MX10.10	
PLC_PRG.SC_OUTPUTS (117)	Local Write
_global_init (101)	Local Write
SC_SLOTV211_OPN_REQ%MX642.0	
PLC_PRG.CLEAR_REQS (22)	Local Write
PLC_PRG.SC_INPUTS (19)	Local Read
_global_init (143)	Local Write
SC_SLOTV211_CLS_REQ%MX642.1	
PLC_PRG.CLEAR_REQS (23)	Local Write
PLC_PRG.SC_INPUTS (20)	Local Read
_global_init (144)	Local Write
SC_TP201_NOT_SYMBOL%MX10.14	
PLC_PRG.SC_OUTPUTS (121)	Local Write
_global_init (105)	Local Write
	HOCAT MITCE
SC_TP201_NOT_SYMBOL%MX10.14	
PLC_PRG.SC_OUTPUTS (121)	Local Write
_global_init (105)	Local Write
SC_SLOTV211_OPN_REQ%MX642.0	
PLC_PRG.CLEAR_REQS (22)	Local Write
PLC_PRG.SC_INPUTS (19)	Local Read
_global_init (143)	Local Write
SC_SLOTV211_CLS_REQ%MX642.1	20042 112100
	I and I White
PLC_PRG.CLEAR_REQS (23)	Local Write
PLC_PRG.SC_INPUTS (20)	Local Read
_global_init (144)	Local Write
SC_SLOTV211_CLOSE_PERMIT%MX7.12	
PLC_PRG.SC_OUTPUTS (90)	Local Write
_global_init (81)	Local Write
SC_SLOTV211_CLOSED%MX7.10	
PLC_PRG.SC_OUTPUTS (88)	Local Write
_global_init (79)	Local Write
SC_SLOTV211_CLOSE_PERMIT%MX7.12	
PLC_PRG.SC_OUTPUTS (90)	Local Write
_global_init (81)	Local Write
SC_RPV212_OPEN_CMD%MX8.5	
PLC_PRG.SC_OUTPUTS (97)	Local Write
_global_init (87)	Local Write
SC SLOTV211 CLOSED%MX7.10	
	Local Write
PLC_PRG.SC_OUTPUTS (88)	Local Write
_global_init (79)	Local Write
SC_RPV212_OPEN%MX8.1	
PLC_PRG.SC_OUTPUTS (95)	Local Write
_global_init (85)	Local Write
SC_RPV212_CLOSED%MX8.2	
PLC_PRG.SC_OUTPUTS (96)	Local Write
_global_init (86)	Local Write
SC_SLOTV211_CLOSE_CMD%MX7.14	100al Hilo
	Local White
PLC_PRG.SC_OUTPUTS (92)	Local Write
_global_init (83)	Local Write
SC_RPV212_OPEN%MX8.1	
PLC_PRG.SC_OUTPUTS (95)	Local Write
_global_init (85)	Local Write
SC_RPV212_CLOSED%MX8.2	
PLC_PRG.SC_OUTPUTS (96)	Local Write
_global_init (86)	Local Write
SC_SLOTV211_CLOSE_CMD%MX7.14	LOCAL MILOC
	Local White
PLC_PRG.SC_OUTPUTS (92)	Local Write
_global_init (83)	Local Write
SC_RPV211_OPEN_CMD%MX6.5	
PLC_PRG.SC_OUTPUTS (78)	Local Write
_global_init (72)	Local Write
SC_RPV212_OPEN_CMD%MX8.5	
PLC_PRG.SC_OUTPUTS (97)	Local Write
120_110.50_0011015 (57)	LOCAL MILOC

_global_init (87) SC_RPV211_OPEN%MX6.1	Local Write	
PLC_PRG.SC_OUTPUTS (76)	Local Write	
_global_init (70)	Local Write	
SC_RP2111_ON_CMD%MX10.1	I a gal Maita	
PLC_PRG.SC_OUTPUTS (110) _global_init (96)	Local Write Local Write	
SC_RPV211_CLOSED%MX6.2		
PLC_PRG.SC_OUTPUTS (77)	Local Write	
_global_init (71) SC_RPV211_CLOSED%MX6.2	Local Write	
PLC_PRG.SC_OUTPUTS (77)	Local Write	
_global_init (71)	Local Write	
SC_RP2111_ON_CMD%MX10.1	Tarah Maika	
PLC_PRG.SC_OUTPUTS (110) _global_init (96)	Local Write Local Write	
SC_RP2111_ON%MX10.0		
PLC_PRG.SC_OUTPUTS (109)	Local Write	
_global_init (95) SC_RP2111_ON%MX10.0	Local Write	
PLC_PRG.SC_OUTPUTS (109)	Local Write	
_global_init (95)	Local Write	
SC_RP2110_ON_CMD%MX9.9 PLC_PRG.SC_OUTPUTS (107)	Local Write	
_global_init (94)	Local Write	
SC_RP2110_ON_CMD%MX9.9		
PLC_PRG.SC_OUTPUTS (107)	Local Write	
_global_init (94) SC_RP2110_ON%MX9.8	Local Write	
PLC_PRG.SC_OUTPUTS (106)	Local Write	
_global_init (93)	Local Write	
SC_RP2110_ON%MX9.8 PLC_PRG.SC_OUTPUTS (106)	Local Write	
_global_init (93)	Local Write	
SC_RESET_REQ%MX640.0		
PLC_PRG.CLEAR_REQS (3)	Local Write Local Read	
PLC_PRG.SC_INPUTS (2) _global_init (130)	Local Write	
SC_RESET_REQ%MX640.0		
PLC_PRG.CLEAR_REQS (3)	Local Write Local Read	
PLC_PRG.SC_INPUTS (2) _global_init (130)	Local Write	
SC_PE212_PSL_MIDLO%MX2.3		
PLC_PRG.SC_OUTPUTS (31)	Local Write	
_global_init (33) SC_PE212_PSL_MIDHI%MX2.2	Local Write	
PLC_PRG.SC_OUTPUTS (30)	Local Write	
_global_init (32)	Local Write	
SC_PE212_HI_PIY%MW1291 PLC_PRG.SC_OUTPUTS (167)	Local Write	
_global_init (154)	Local Write	
SC_PE212_PSL_HI%MX2.1		
PLC_PRG.SC_OUTPUTS (29) _global_init (31)	Local Write Local Write	
SC_PE212_HI_PIY%MW1291	Hocar write	
PLC_PRG.SC_OUTPUTS (167)	Local Write	
_global_init (154) SC_PE212_LO_PIY%MW1292	Local Write	
PLC_PRG.SC_OUTPUTS (168)	Local Write	
_global_init (155)	Local Write	
SC_PE212_LO_PIY%MW1292		
PLC_PRG.SC_OUTPUTS (168) _global_init (155)	Local Write Local Write	
SC_PE211_PSL_MIDHI%MX1.10	20001 11100	
PLC_PRG.SC_OUTPUTS (24)	Local Write	
_global_init (27) SC_PE211_LO_PIY%MW1290	Local Write	
PLC_PRG.SC_OUTPUTS (166)	Local Write	
_global_init (153)	Local Write	
SC_PE211_HI_PIY%MW1289 PLC_PRG.SC_OUTPUTS (165)	Local Write	
_global_init (152)	Local Write Local Write	
SC_PE211_HI_PIY%MW1289		

PLC_PRG.SC_OUTPUTS	(165)	Local Write
_global_init (152) SC_PE203_HI_PIY%MW1287		Local Write
	(163)	Local Write
_global_init (150)	(===)	Local Write
SC_PE203_HI_PIY%MW1287		
PLC_PRG.SC_OUTPUTS	(163)	Local Write
_global_init (150)		Local Write
SC_PE201_PSL%MX0.9	(0)	
PLC_PRG.SC_OUTPUTS	(8)	Local Write
_global_init (14) SC_PE201_PIY%MW1285		Local Write
PLC_PRG.SC_OUTPUTS	(161)	Local Write
_global_init (148)	(101)	Local Write
SC_PE211_PSL_LO%MX1.12		
PLC_PRG.SC_OUTPUTS	(26)	Local Write
_global_init (29)		Local Write
SC_PE101_PSL%MX0.8		
PLC_PRG.SC_OUTPUTS	(7)	Local Write
_global_init (13) SC_PE202_PIY%MW1286		Local Write
PLC_PRG.SC_OUTPUTS	(162)	Local Write
_global_init (149)	(102)	Local Write
SC_LL_TP211_TURBO_OK%MX1	3.6	
PLC_PRG.SC_OUTPUTS	(148)	Local Write
_global_init (126)		Local Write
SC_PE211_PSL_MIDHI%MX1.1		
	(24)	
_global_init (27) SC_PE211_PSL_LO%MX1.12		Local Write
PLC_PRG.SC_OUTPUTS	(26)	Local Write
_global_init (29)	( /	Local Write
SC_PE203_PSL_MIDHI%MX1.2		
PLC_PRG.SC_OUTPUTS	(18)	Local Write
_global_init (22)		Local Write
SC_PE203_PSL_LO%MX1.4	(0.0)	
PLC_PRG.SC_OUTPUTS	(20)	Local Write
_global_init (24) SC_PE211_LO_PIY%MW1290		Local Write
PLC_PRG.SC_OUTPUTS	(166)	Local Write
_global_init (153)		Local Write
SC_PE203_LO_PIY%MW1288		
PLC_PRG.SC_OUTPUTS		Local Write
_global_init (151)		Local Write
SC_PE203_LO_PIY%MW1288	(1.6.4.)	Total Maike
PLC_PRG.SC_OUTPUTS _global_init (151)	(164)	Local Write Local Write
grobatinit (131)  SC_PE202_PIY%MW1286		LOCAL WIILE
PLC_PRG.SC_OUTPUTS	(162)	Local Write
_global_init (149)		Local Write
SC_PE101_PIY%MW1284		
PLC_PRG.SC_OUTPUTS	(160)	Local Write
_global_init (147)		Local Write
SC_PE201_PIY%MW1285	(161)	Local Write
PLC_PRG.SC_OUTPUTS _global_init (148)	( ± U ± )	Local Write Local Write
SC_LL_RP2111_ON%MX13.4		20041 11100
PLC_PRG.SC_OUTPUTS	(146)	Local Write
_global_init (124)		Local Write
SC_LL_PE2111_PSL_LL%MX13	.9	
_global_init (129)		Local Write
SC_LL_PE2111_PSL%MX13.5	(147)	Local White
PLC_PRG.SC_OUTPUTS _global_init (125)	( 1 4 / )	Local Write Local Write
global_init (125)  SC_PE211_OK%MX1.8		TOCAL MITCE
PLC_PRG.SC_OUTPUTS	(22)	Local Write
_global_init (25)	•	Local Write
SC_PE2111_PSL%MX0.15		
PLC_PRG.SC_OUTPUTS	(14)	Local Write
_global_init (19)		Local Write
SC_PE203_OK%MX1.0	(16)	Local White
PLC_PRG.SC_OUTPUTS _global_init (20)	( + 0 )	Local Write Local Write
_910581_1111 (20)		BOOM! WIICE

SC_PE2110_PSL%MX0.14			
PLC_PRG.SC_OUTPUTS	(13)	Local	Write
_global_init (18)		Local	write
SC_PE202_PSL%MX0.10			
PLC_PRG.SC_OUTPUTS	(9)	Local	Write
_global_init (15)		Local	Write
SC_LL_TP211_TURBO_OK%MX13	3 6		
		T 1	Weite
	(148)		
_global_init (126)		Local	Write
SC_LL_RP2111_ON%MX13.4			
PLC_PRG.SC_OUTPUTS	(146)	Local	Write
_global_init (124)		Local	
_		посат	MIICE
SC_LL_V202_OPN%MX12.3			
PLC_PRG.SC_OUTPUTS	(136)	Local	Write
_global_init (115)		Local	Write
SC_LL_STATE%MW1306			
PLC_PRG.SC_OUTPUTS	(269)	Logal	Write
PLC_PRG.SC_OUTPUTS	,	Local	
PLC_PRG.SC_OUTPUTS	(273)	Local	Write
PLC_PRG.SC_OUTPUTS	(275)	Local	Write
PLC_PRG.SC_OUTPUTS	(277)	Local	Write
PLC_PRG.SC_OUTPUTS		Local	
PLC_PRG.SC_OUTPUTS		Local	
PLC_PRG.SC_OUTPUTS	(283)	Local	Write
PLC_PRG.SC_OUTPUTS	(285)	Local	Write
PLC_PRG.SC_OUTPUTS		Local	Write
PLC_PRG.SC_OUTPUTS		Local	
PLC_PRG.SC_OUTPUTS		Local	
_global_init (161)		Local	Write
SC_LL_PE203_PSL_LO%MX12.6	5		
PLC_PRG.SC_OUTPUTS	(139)	Local	Write
_global_init (118)		Local	
		посат	MIICE
SC_LL_PE203_OK%MX12.5			
PLC_PRG.SC_OUTPUTS	(138)	Local	Write
_global_init (117)		Local	Write
SC_PE203_PSL_LO%MX1.4			
PLC_PRG.SC_OUTPUTS	(20)	Local	Write
_global_init (24)		Local	write
SC_LL_TP212_TURBO_OK%MX13			
PLC_PRG.SC_OUTPUTS	(149)	Local	Write
_global_init (127)		Local	Write
SC_LL_PE211_OK%MX13.2			
	(144)	T a a a 1	Maika
PLC_PRG.SC_OUTPUTS	(144)		Write
_global_init (122)		Local	Write
SC_LL_PE203_PSL_LO%MX12.6	5		
PLC_PRG.SC_OUTPUTS	(139)	Local	Write
	,	Local	
_		посат	WITCO
SC_LL_PE211_OK%MX13.2	(1.4.4.)		
PLC_PRG.SC_OUTPUTS	(144)	Local	Write
_global_init (122)		Local	Write
SC_LL_PE202_PSL%MX12.4			
PLC_PRG.SC_OUTPUTS	(137)	Local	Write
_global_init (116)	(10.)	Local	
		посат	MIICO
SC_PE203_PSL_MIDLO%MX1.3			
PLC_PRG.SC_OUTPUTS	(19)	Local	Write
_global_init (23)		Local	Write
SC_PE203_PSL_MIDLO%MX1.3			
PLC_PRG.SC_OUTPUTS	(10)	Local	Write
	(19)		
_global_init (23)		Local	Write
SC_LL_PE201_PSL%MX12.2			
PLC_PRG.SC_OUTPUTS	(135)	Local	Write
_global_init (114)		Local	Write
SC_PE203_PSL_HI%MX1.1			
	(17)	I o o o o o	Write
PLC_PRG.SC_OUTPUTS	( ± / )	Local	
		Local	Write
_global_init (21)			
_global_init (21) SC_LL_TP201_OK%MX12.7			The state of the s
	(140)	Local	Write
SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS	(140)		
SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS _global_init (119)			Write Write
SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS _global_init (119) SC_LL_PE2111_PSL_LL%MX13.		Local	Write
SC_LL_TP201_OK%MX12.7  PLC_PRG.SC_OUTPUTS  _global_init (119)  SC_LL_PE2111_PSL_LL%MX13.  _global_init (129)			Write
SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS _global_init (119) SC_LL_PE2111_PSL_LL%MX13.		Local	Write
SC_LL_TP201_OK%MX12.7  PLC_PRG.SC_OUTPUTS  _global_init (119)  SC_LL_PE2111_PSL_LL%MX13.  _global_init (129)	.9	Local	Write Write
SC_LL_TP201_OK%MX12.7  PLC_PRG.SC_OUTPUTS  _global_init (119)  SC_LL_PE2111_PSL_LL%MX13.  _global_init (129)  SC_LL_PE101_PSL%MX12.1  PLC_PRG.SC_OUTPUTS	.9	Local Local	Write Write Write
SC_LL_TP201_OK%MX12.7  PLC_PRG.SC_OUTPUTS  _global_init (119)  SC_LL_PE2111_PSL_LL%MX13.  _global_init (129)  SC_LL_PE101_PSL%MX12.1	.9	Local Local	Write Write Write

SC_LL_LL_CONFIG_OK%MX13.1	1		
PLC_PRG.SC_OUTPUTS		ocal	Write
_global_init (121)			Write
_		JOCAI	MIICE
SC_LL_LL_CONFIG_OK%MX13.1		-	
PLC_PRG.SC_OUTPUTS			Write
_global_init (121)	I	ocal	Write
SC_LL_PE201_PSL%MX12.2			
PLC_PRG.SC_OUTPUTS	(135) I	ocal	Write
_global_init (114)	J	ocal	Write
SC_LL_ES_CONFIG_OK%MX13.0	)		
PLC_PRG.SC_OUTPUTS		ocal	Write
_global_init (120)			Write
1	-	local	MIICE
SC_LL_ACTUATOR_OK%MX12.0	(122)	-	
PLC_PRG.SC_OUTPUTS			Write
_global_init (112)	I	ocal	Write
SC_PE202_PSL%MX0.10			
PLC_PRG.SC_OUTPUTS	(9)	ocal	Write
_global_init (15)	J	ocal	Write
SC LL211 LID CLOSED%MX2.8	3		
PLC_PRG.SC_OUTPUTS	(34)	ocal	Write
_global_init (35)			Write
_		JOCAI	MIICE
SC_LL211_ARM_RETRACTED%MX			The St.
PLC_PRG.SC_OUTPUTS			Write
_global_init (36)	I	ocal	Write
SC_PE101_PSL%MX0.8			
PLC_PRG.SC_OUTPUTS	(7)	ocal	Write
_global_init (13)	J	ocal	Write
SC_PE101_PIY%MW1284			
PLC_PRG.SC_OUTPUTS	(160)	ocal	Write
_global_init (147)			Write
_	1	JUCAI	WIICE
SC_LL_V202_OPN%MX12.3	4.0.5		
	(136) I		
_global_init (115)	I	ocal	Write
SC_LL_TP212_TURBO_OK%MX13	3.7		
PLC_PRG.SC_OUTPUTS	(149) J	ocal	Write
_global_init (127)	J	ocal	Write
SC_LL_STATE%MW1306			
PLC_PRG.SC_OUTPUTS	(269)	.ocal	Write
PLC_PRG.SC_OUTPUTS			Write
PLC_PRG.SC_OUTPUTS			Write
PLC_PRG.SC_OUTPUTS	,		Write
PLC_PRG.SC_OUTPUTS	(277) I	ocal	Write
PLC_PRG.SC_OUTPUTS	(279)	ocal	Write
PLC_PRG.SC_OUTPUTS	(281) J	ocal	Write
PLC_PRG.SC_OUTPUTS	(283)	ocal	Write
PLC_PRG.SC_OUTPUTS			Write
PLC PRG.SC OUTPUTS			Write
PLC_PRG.SC_OUTPUTS	,		Write
PLC_PRG.SC_OUTPUTS			Write
_global_init (161)			
	1	ocal	Write
SC_LL_PE212_OK%MX13.3			
PLC_PRG.SC_OUTPUTS	(145) I	Local	Write
	(145) I	Local	
PLC_PRG.SC_OUTPUTS	(145) I	Local	Write
PLC_PRG.SC_OUTPUTS _global_init (123)	(145) I	ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS	(145) I (147) I	ocal ocal	Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)	(145) I (147) I	ocal ocal	Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298	(145) I (147) I	ocal local local	Write Write Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS	(145) I (147) I (203) I	ocal ocal ocal ocal	Write Write Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II	local local local local	Write Write Write Write Write Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II	ocal ocal ocal ocal ocal ocal	Write Write Write Write Write Write Write Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II	ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II	ocal ocal ocal ocal ocal ocal ocal	Write Write Write Write Write Write Write Write Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II (209) II (212) II	Jocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123) SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125) SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II (209) II (212) II	Jocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3	(145) II (147) II (203) II (205) II (207) II (209) II (212) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS	(145) II (147) II (203) II (205) II (207) II (209) II (145) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)	(145) II (147) II (203) II (205) II (207) II (209) II (145) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0	(145) II (147) II (203) II (205) II (207) II (209) II (145) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (133)	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS _global_init (112)	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (133)	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS _global_init (112) SC_LL_TP201_OK%MX12.7	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (133) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS _global_init (112)  SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (1440) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS _global_init (112) SC_LL_TP201_OK%MX12.7	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (1440) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write
PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_PE2111_PSL%MX13.5 PLC_PRG.SC_OUTPUTS _global_init (125)  SC_LL_CMD_VAL%MW1298 PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS PLC_PRG.SC_OUTPUTS _global_init (158)  SC_LL_PE212_OK%MX13.3 PLC_PRG.SC_OUTPUTS _global_init (123)  SC_LL_ACTUATOR_OK%MX12.0 PLC_PRG.SC_OUTPUTS _global_init (112)  SC_LL_TP201_OK%MX12.7 PLC_PRG.SC_OUTPUTS	(145) II  (147) II  (203) II  (205) II  (207) II  (209) II  (145) II  (145) II  (1440) II	ocal ocal ocal ocal ocal ocal ocal ocal	Write

PLC_PRG.SC_OUTPUTS (138)	Local Write	
global_init (117)	Local Write	
SC_LL_ES_CONFIG_OK%MX13.0	23342 11235	
	I acal Write	
PLC_PRG.SC_OUTPUTS (142)	Local Write	
_global_init (120)	Local Write	
SC_LL_PE202_PSL%MX12.4		
PLC_PRG.SC_OUTPUTS (137)	Local Write	
_global_init (116)	Local Write	
SC_LL_CMD_REQ%MW3714		
PLC_PRG.SC_INPUTS (53)	Local Read	
PLC_PRG.SC_INPUTS (55)	Local Read	
PLC_PRG.SC_INPUTS (57)	Local Read	
PLC_PRG.SC_INPUTS (59)	Local Read	
_global_init (164)	Local Write	
SC_LL211_LID_CLOSED%MX2.8		
PLC_PRG.SC_OUTPUTS (34)	Local Write	
global_init (35)	Local Write	
SC_LL211_ARM_RETRACTED%MX2.9	20042 11200	
PLC_PRG.SC_OUTPUTS (35)	Local Write	
_global_init (36)	Local Write	
SC_ES_STATE%MW1305		
PLC_PRG.SC_OUTPUTS (240)	Local Write	
PLC_PRG.SC_OUTPUTS (242)	Local Write	
PLC_PRG.SC_OUTPUTS (244)	Local Write	
PLC_PRG.SC_OUTPUTS (244)		
	Local Write	
PLC_PRG.SC_OUTPUTS (248)	Local Write	
PLC_PRG.SC_OUTPUTS (250)	Local Write	
PLC_PRG.SC_OUTPUTS (252)	Local Write	
PLC_PRG.SC_OUTPUTS (254)	Local Write	
PLC_PRG.SC_OUTPUTS (256)	Local Write	
PLC_PRG.SC_OUTPUTS (258)	Local Write	
PLC_PRG.SC_OUTPUTS (260)	Local Write	
PLC_PRG.SC_OUTPUTS (263)	Local Write	
_global_init (160)	Local Write	
SC_LL_CMD_REQ%MW3714		
PLC_PRG.SC_INPUTS (53)	Local Read	
PLC_PRG.SC_INPUTS (55)	Local Read	
PLC_PRG.SC_INPUTS (57)	Local Read	
PLC_PRG.SC_INPUTS (59)	Local Read	
_global_init (164)		
	Local Write	
SC_ES_CMD_VAL%MW1297		
PLC_PRG.SC_OUTPUTS (188)	Local Write	
PLC_PRG.SC_OUTPUTS (190)	Local Write	
PLC_PRG.SC_OUTPUTS (192)	Local Write	
PLC_PRG.SC_OUTPUTS (194)	Local Write	
PLC_PRG.SC_OUTPUTS (197)	Local Write	
_global_init (157)	Local Write	
	Local wille	
SC_AFB%MX0.3		
PLC_PRG.SC_OUTPUTS (4)	Local Write	
_global_init (12)	Local Write	
SC_LL_CMD_VAL%MW1298		
PLC_PRG.SC_OUTPUTS (203)	Local Write	
PLC_PRG.SC_OUTPUTS (205)	Local Write	
PLC_PRG.SC_OUTPUTS (207)	Local Write	
PLC_PRG.SC_OUTPUTS (209)	Local Write	
PLC_PRG.SC_OUTPUTS (212)	Local Write	
_global_init (158)	Local Write	
SC_BR_STATE%MW1304		
PLC_PRG.SC_OUTPUTS (219)	Local Write	
PLC_PRG.SC_OUTPUTS (222)	Local Write	
PLC_PRG.SC_OUTPUTS (225)	Local Write	
PLC_PRG.SC_OUTPUTS (228)		
	Local Write	
PLC_PRG.SC_OUTPUTS (231)	Local Write	
PLC_PRG.SC_OUTPUTS (234)	Local Write	
_global_init (159)	Local Write	
SC_BR_CMD_REQ%MW3712		
PLC_PRG.SC_INPUTS (24)	Local Read	
PLC_PRG.SC_INPUTS (26)	Local Read	
PLC_PRG.SC_INPUTS (28)	Local Read	
PLC_PRG.SC_INPUTS (30)	Local Read	
_global_init (162)	Local Write	
rVersion		
_global_init (165)	Global Write	
\ <del></del>		

```
RPV212_CSD
      Local Read
PLC_PRG.PROCESS_IN... (68)
Local Write
PLC_PRG.PUMPS (8)
      PLC_PRG.PUMPS (8)
PLC_PRG.SC_OUTPUTS (96)
                                                 Local Read
      PLC_PRG.VALVES (71)
                                                 Local Read
      PLC_PRG.VALVES (86)
                                                  Local Read
      PLC_PRG.VALVES (94)
                                                  Local Read
       _global_init (212)
                                                  Local Write
RPV212
                                              Local Read
      PLC_PRG.PROCESS_OU... (23)
PLC_PRG.SC_OUTPUTS (97)
PLC_PRG.VALVES (102)
                                                 Local Read
      PLC_PRG.VALVES (102)
                                                 Local Write
      PLC_PRG.VALVES (103)
                                                 Local Write
      PLC_PRG.VALVES (104)
                                                 Local Write
      PLC_PRG.VALVES (105)
                                                 Local Write
      PLC_PRG.VALVES (106)
                                                  Local Write
      PLC_PRG.VALVES (107)
                                                  Local Read
      _global_init (304)
                                                  Local Read
SC_ES_STATE%MW1305
                                            Local Write
      PLC_PRG.SC_OUTPUTS (240)
PLC_PRG.SC_OUTPUTS (242)
PLC_PRG.SC_OUTPUTS (244)
PLC_PRG.SC_OUTPUTS (246)
      PLC_PRG.SC_OUTPUTS (240)
      PLC_PRG.SC_OUTPUTS (246)
      PLC_PRG.SC_OUTPUTS (248)
      PLC_PRG.SC_OUTPUTS (250)
      PLC_PRG.SC_OUTPUTS (252)
      PLC_PRG.SC_OUTPUTS (254)
      PLC_PRG.SC_OUTPUTS (256)
      PLC_PRG.SC_OUTPUTS (258)
      PLC_PRG.SC_OUTPUTS (260)
PLC_PRG.SC_OUTPUTS (263)
_global init (160)
      _global_init (160)
                                                  Local Write
RPV211_CSD
                                                 Local Read
      PLC_PRG.ES_SM (33)
      PLC_PRG.PROCESS_IN... (56)
PLC_PRG.PUMPS (8)
                                                 Local Write
                                                  Local Read
      PLC_PRG.SC_OUTPUTS (77)
                                                 Local Read
      PLC_PRG.VALVES (54)
                                                 Local Read
      PLC_PRG.VALVES (62)
                                                 Local Read
      PLC_PRG.VALVES (103)
                                                   Local Read
      _global_init (204)
                                                   Local Write
RP211_ON
                                                 Local Read
      PLC_PRG.ES_SM (123)
      PLC_PRG.LL_SM (117)
                                                  Local Read
      PLC_PRG.PROCESS_IN... (7)
PLC_PRG.SC_OUTPUTS (106)
                                              Local Write
                                                  Local Read
      PLC_PRG.VALVES (70)
                                                   Local Read
      PLC_PRG.VALVES (102)
                                                   Local Read
      _global_init (222)
                                                   Local Write
PE212_PSL_MIDLO
                                                  Local Read
      PLC_PRG.LL_SM (47)
      PLC_PRG.LL_SM (135)
                                                   Local Read
      PLC_PRG.LL_SM (152)
                                                   Local Read
      PLC_PRG.LL_SM (172)
                                                   Local Read
      PLC_PRG.LL_SM (191)
                                                   Local Read
      PLC_PRG.PROCESS_IN... (27)
                                                   Local Write
      PLC_PRG.VALVES (103)
                                                   Local Read
      PLC_PRG.VALVES (110)
                                                   Local Read
      _global_init (185)
                                                   Local Write
PE212_PSL_LO
      PLC_PRG.LL_SM (174)
PLC_PRG.LL_SM (194)
PLC_PRG.PROCESS_IN... (28)
      PLC_PRG.LL_SM (174)
                                                  Local Read
                                                   Local Read
                                                   Local Write
      _global_init (186)
                                                   Local Write
SC_LL_PE2111_PSL_ES%MX13.8
      _global_init (128)
                                                   Local Write
SC_LL_PE2111_PSL_ES%MX13.8
      _global_init (128)
                                                   Local Write
PE212_PSH_MIDHI
      PLC_PRG.LL_SM (66)
                                                   Local Read
      PLC_PRG.PROCESS_IN... (26)
                                                   Local Write
                                                   Local Write
      _global_init (184)
```

```
SC_ES_CMD_VAL%MW1297
     PLC_PRG.SC_OUTPUTS (188)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (190)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (192)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (194)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (197)
                                          Local Write
     _global_init (157)
                                           Local Write
RPV212_OPN_REQ_LL
     PLC_PRG.LL_SM (12)
                                          Local Write
     PLC_PRG.LL_SM (25)
                                           Local Write
     PLC_PRG.LL_SM (38)
                                          Local Write
     PLC_PRG.LL_SM (55)
                                          Local Write
     PLC_PRG.LL_SM (72)
                                          Local Write
     PLC_PRG.LL_SM (89)
                                          Local Write
     PLC_PRG.LL_SM (106)
                                          Local Write
     PLC_PRG.LL_SM (124)
                                          Local Write
     PLC_PRG.LL_SM (141)
                                          Local Write
     PLC_PRG.LL_SM (161)
                                          Local Write
     PLC_PRG.LL_SM (180)
                                          Local Write
     PLC_PRG.VALVES (105)
                                          Local Read
     PLC_PRG.VALVES (106)
                                          Local Read
                                           Local Write
     _global_init (272)
RPV212_CLS_REQ_LL
     _global_init (273)
                                           Local Write
RPV211
     PLC_PRG.PROCESS_OU... (14)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (78)
                                          Local Read
     PLC_PRG.VALVES (70)
                                           Local Write
     PLC_PRG.VALVES (71)
                                          Local Write
     PLC_PRG.VALVES (72)
                                          Local Write
     PLC_PRG.VALVES (73)
                                          Local Write
     PLC_PRG.VALVES (74)
                                          Local Write
     PLC_PRG.VALVES (75)
                                           Local Read
     _global_init (299)
                                           Local Read
RPV212_OPN
     PLC_PRG.PROCESS_IN... (67)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (95)
                                           Local Read
     _global_init (211)
                                           Local Write
RP211_ON_REQ_LL
     PLC_PRG.LL_SM (13)
                                          Local Write
     PLC_PRG.LL_SM (26)
                                           Local Write
     PLC_PRG.LL_SM (39)
                                           Local Write
     PLC_PRG.LL_SM (56)
                                           Local Write
     PLC_PRG.LL_SM (73)
                                           Local Write
     PLC_PRG.LL_SM (90)
                                           Local Write
     PLC_PRG.LL_SM (107)
                                           Local Write
     PLC_PRG.LL_SM (125)
                                           Local Write
     PLC_PRG.LL_SM (142)
                                           Local Write
     PLC_PRG.LL_SM (162)
                                           Local Write
     PLC_PRG.LL_SM (181)
                                           Local Write
     PLC_PRG.PUMPS (9)
                                           Local Read
     _global_init (281)
                                           Local Write
PE212_PIY_OK
     PLC_PRG.FAULT_LOGIC (15)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.PROCESS_IN... (24)
                                           Local Write
     _global_init (182)
                                           Local Write
PE211_PSL_MIDLO
     PLC_PRG.ES_SM (49)
                                           Local Read
     PLC_PRG.ES_SM (142)
                                           Local Read
     PLC_PRG.ES_SM (160)
                                           Local Read
     PLC_PRG.ES_SM (181)
                                           Local Read
     PLC_PRG.ES_SM (201)
                                           Local Read
     PLC_PRG.PROCESS_IN... (21)
                                           Local Write
     PLC_PRG.VALVES (71)
                                           Local Read
     PLC_PRG.VALVES (78)
                                           Local Read
     _global_init (180)
                                           Local Write
PE211_PSL_LO
     PLC_PRG.ES_SM (183)
                                           Local Read
     PLC_PRG.ES_SM (204)
                                           Local Read
     PLC_PRG.PROCESS_IN... (22)
                                           Local Write
     PLC_PRG.VALVES (36)
                                           Local Read
     _global_init (181)
                                           Local Write
```

```
SC_ES_CMD_REQ%MW3713
     PLC PRG.SC INPUTS (38)
                                          Local Read
     PLC_PRG.SC_INPUTS (40)
                                          Local Read
     PLC_PRG.SC_INPUTS (42)
                                          Local Read
     PLC_PRG.SC_INPUTS (44)
                                          Local Read
     _global_init (163)
                                           Local Write
SC_ES_CMD_REQ%MW3713
     PLC_PRG.SC_INPUTS (38)
                                          Local Read
     PLC_PRG.SC_INPUTS (40)
                                          Local Read
     PLC_PRG.SC_INPUTS (42)
                                          Local Read
     PLC_PRG.SC_INPUTS (44)
                                          Local Read
     _global_init (163)
                                          Local Write
PE211_PSH_HI
     PLC_PRG.ES_SM (87)
                                          Local Read
     PLC_PRG.ES_SM (105)
                                          Local Read
     PLC_PRG.PROCESS_IN... (19)
                                          Local Write
                                          Local Write
     _global_init (178)
SC_BR_CMD_VAL%MW1296
     PLC_PRG.SC_OUTPUTS (173)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (175)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (177)
                                         Local Write
                                         Local Write
     PLC_PRG.SC_OUTPUTS (179)
     PLC_PRG.SC_OUTPUTS (182)
                                          Local Write
     _global_init (156)
                                          Local Write
SC_BR_CMD_VAL%MW1296
                                         Local Write
     PLC_PRG.SC_OUTPUTS (173)
     PLC_PRG.SC_OUTPUTS (175)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (177)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (179)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (182)
                                           Local Write
     _global_init (156)
                                           Local Write
RPV211_OPN_REQ_ES
     PLC_PRG.ES_SM (12)
                                          Local Write
     PLC_PRG.ES_SM (26)
                                          Local Write
     PLC_PRG.ES_SM (40)
                                          Local Write
     PLC_PRG.ES_SM (58)
                                          Local Write
     PLC_PRG.ES_SM (76)
                                          Local Write
     PLC_PRG.ES_SM (94)
                                          Local Write
     PLC_PRG.ES_SM (112)
                                          Local Write
     PLC_PRG.ES_SM (131)
                                          Local Write
     PLC_PRG.ES_SM (149)
                                          Local Write
     PLC_PRG.ES_SM (170)
                                           Local Write
     PLC_PRG.ES_SM (190)
                                           Local Write
     PLC_PRG.VALVES (73)
                                           Local Read
     PLC_PRG.VALVES (74)
                                           Local Read
     _global_init (260)
                                           Local Write
PE211_PIY_OK
                                         Local Read
     PLC_PRG.FAULT_LOGIC (14)
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.PROCESS_IN... (18)
                                           Local Write
     _global_init (177)
                                           Local Write
SC_LL_PE101_PSL%MX12.1
     PLC_PRG.SC_OUTPUTS (134)
                                           Local Write
     _global_init (113)
                                           Local Write
RP211_ON_REQ_ES
     PLC_PRG.ES_SM (13)
                                           Local Write
     PLC_PRG.ES_SM (27)
                                           Local Write
     PLC_PRG.ES_SM (41)
                                           Local Write
     PLC_PRG.ES_SM (59)
                                           Local Write
     PLC_PRG.ES_SM (77)
                                           Local Write
     PLC_PRG.ES_SM (95)
                                           Local Write
     PLC_PRG.ES_SM (113)
                                           Local Write
     PLC_PRG.ES_SM (132)
                                           Local Write
     PLC_PRG.ES_SM (150)
                                           Local Write
     PLC_PRG.ES_SM (171)
                                           Local Write
     PLC_PRG.ES_SM (191)
                                           Local Write
     PLC_PRG.PUMPS (9)
                                           Local Read
     _global_init (280)
                                           Local Write
RP211
     PLC_PRG.PROCESS_OU... (3)
                                           Local Read
     PLC_PRG.PUMPS (7)
                                           Local Write
     PLC_PRG.PUMPS (8)
                                           Local Write
     PLC_PRG.PUMPS (9)
                                           Local Write
```

```
PLC_PRG.PUMPS (10)
                                            Local Read
     PLC PRG.PUMPS (10)
                                           Local Write
     PLC_PRG.PUMPS (11)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (107)
                                           Local Read
                                           Local Read
      _global_init (307)
RPV211_OPN
     PLC_PRG.PROCESS_IN... (55)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (76)
                                           Local Read
      _global_init (203)
                                           Local Write
PE203_PSL_LO
     PLC_PRG.FAULT_LOGIC (8)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.PROCESS_IN... (16)
                                          Local Write
                                           Local Write
     _global_init (176)
PE203_PSH_MIDHI
     PLC_PRG.PROCESS_IN... (14)
                                           Local Write
                                           Local Write
     _global_init (174)
SC_BR_STATE%MW1304
                                         Local Write
Local Write
Local Write
Local Write
Local Write
     PLC_PRG.SC_OUTPUTS (219)
     PLC_PRG.SC_OUTPUTS (222)
     PLC_PRG.SC_OUTPUTS (225)
     PLC_PRG.SC_OUTPUTS (228)
     PLC_PRG.SC_OUTPUTS (231)
     PLC_PRG.SC_OUTPUTS (234)
                                           Local Write
     _global_init (159)
                                           Local Write
PE203_PSH_HI
     PLC_PRG.PROCESS_IN... (13)
                                           Local Write
     _global_init (173)
                                            Local Write
SC_BR_CMD_REQ%MW3712
                                          Local Read
     PLC_PRG.SC_INPUTS (24)
     PLC_PRG.SC_INPUTS (26)
                                           Local Read
     PLC_PRG.SC_INPUTS (28)
                                           Local Read
     PLC_PRG.SC_INPUTS (30)
                                           Local Read
     _global_init (162)
                                            Local Write
SC_ATB%MX0.2
    PLC_PRG.SC_OUTPUTS (3)
                                           Local Write
                                            Local Write
     _global_init (11)
PE203_PIY_OK
    PLC_PRG.FAULT_LOGIC (13)
PLC_PRG.FAULT_LOGIC (37)
PLC_PRG.PROCESS_IN... (12)
                                          Local Read
Local Read
                                           Local Write
     _global_init (172)
                                            Local Write
SC_AFB%MX0.3
     PLC_PRG.SC_OUTPUTS (4)
                                            Local Write
     _global_init (12)
                                            Local Write
RPV211_CLS_REQ_ES
     _global_init (261)
                                            Local Write
RP211_PSL
    PLC_PRG.PROCESS_IN... (9)
                                            Local Write
     _global_init (187)
                                            Local Write
Reset_Required
     PLC_PRG.FAULT_LOGIC (37)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (2)
                                            Local Read
     _global_init (243)
                                            Local Write
PE202_PSL_LO
     PLC_PRG.FAULT_LOGIC (7)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                            Local Read
     PLC_PRG.PROCESS_IN... (5)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (9)
                                            Local Read
     _global_init (171)
                                            Local Write
PE201_PSL_LO
     PLC_PRG.FAULT_LOGIC (5)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                            Local Read
     PLC_PRG.PROCESS_IN... (4)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (8)
                                            Local Read
     _global_init (170)
                                            Local Write
RESET_REQ
     PLC_PRG.FAULT_LOGIC (3)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (4)
                                            Local Read
     PLC_PRG.FAULT_LOGIC (5)
                                            Local Read
     PLC_PRG.FAULT_LOGIC (6)
                                            Local Read
     PLC_PRG.FAULT_LOGIC (7)
                                            Local Read
                                            Local Read
     PLC_PRG.FAULT_LOGIC (8)
```

```
PLC_PRG.FAULT_LOGIC (10)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (11)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (13)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (14)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (15)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (17)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (19)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (20)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (21)
                                         Local Read
     PLC_PRG.SC_INPUTS (2)
                                          Local Write
     _global_init (168)
                                          Local Write
PE212_PSH_HI
     PLC_PRG.LL_SM (83)
                                          Local Read
     PLC_PRG.LL_SM (100)
                                          Local Read
     PLC_PRG.PROCESS_IN... (25)
                                         Local Write
     _global_init (183)
                                          Local Write
PE211_PSH_MIDHI
     PLC_PRG.ES_SM (69)
                                         Local Read
     PLC_PRG.PROCESS_IN... (20)
                                         Local Write
     _global_init (179)
                                          Local Write
PE203_PSL_MIDLO
    PLC_PRG.PROCESS_IN... (15)
                                         Local Write
     _global_init (175)
                                          Local Write
PE101_PSL_LO
                                         Local Read
     PLC_PRG.FAULT_LOGIC (4)
     PLC_PRG.FAULT_LOGIC (37)
                                         Local Read
     PLC_PRG.PROCESS_IN... (3)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (7)
                                         Local Read
                                          Local Write
     _global_init (169)
open_req
     PLC_PRG.VALVES (49)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FBinit (5)
                                          Local Write
open_ena
                                         Local Read
     PLC_PRG.SC_OUTPUTS (43)
     PLC_PRG.SC_OUTPUTS (51)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (63)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (71)
                                         Local Read
     PLC_PRG.VALVES (5)
                                          Local Write
     PLC_PRG.VALVES (13)
                                          Local Write
     PLC_PRG.VALVES (21)
                                          Local Write
     PLC_PRG.VALVES (29)
                                          Local Write
     PLC_PRG.VALVES (37)
                                          Local Write
     PLC_PRG.VALVES (55)
                                          Local Write
     PLC_PRG.VALVES (63)
                                          Local Write
     PLC_PRG.VALVES (71)
                                          Local Write
     PLC_PRG.VALVES (79)
                                          Local Write
     PLC_PRG.VALVES (87)
                                          Local Write
     PLC_PRG.VALVES (95)
                                          Local Write
     PLC_PRG.VALVES (103)
                                           Local Write
     PLC_PRG.VALVES (111)
                                           Local Write
     VALVE_FB (3)
                                           Local Read
     VALVE_FB (6)
                                           Local Read
     VALVE_FBinit (2)
                                           Local Write
open ena
     PLC_PRG.SC_OUTPUTS (89)
                                           Local Read
     PLC_PRG.VALVES (46)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FB (11)
                                           Local Read
     VALVE_BI_FBinit (2)
                                           Local Write
open_cmd
     PLC_PRG.PROCESS_OU... (5)
                                          Local Read
     PLC_PRG.PROCESS_OU... (6)
                                          Local Read
     PLC_PRG.PROCESS_OU... (7)
                                          Local Read
     PLC_PRG.PROCESS_OU... (8)
                                          Local Read
     PLC_PRG.PROCESS_OU... (10)
                                          Local Read
     PLC_PRG.PROCESS_OU... (13)
                                          Local Read
     PLC_PRG.PROCESS_OU... (14)
                                          Local Read
     PLC_PRG.PROCESS_OU... (15)
                                          Local Read
     PLC_PRG.PROCESS_OU... (16)
                                          Local Read
     PLC_PRG.PROCESS_OU... (22)
                                           Local Read
```

```
PLC_PRG.PROCESS_OU... (23)
                                            Local Read
     PLC_PRG.PROCESS_OU... (24)
                                           Local Read
     PLC_PRG.PROCESS_OU... (25)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (45)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (53)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (65)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (73)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (78)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (80)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (81)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (85)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (97)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (99)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (100)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (104)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (112)
                                           Local Read
     VALVE_FB (3)
                                            Local Read
     VALVE_FB (3)
                                            Local Write
     VALVE_FB (6)
                                            Local Read
     VALVE_FBinit (6)
                                            Local Write
on_req
     PLC_PRG.PUMPS (17)
                                           Local Write
     PLC_PRG.PUMPS (25)
                                            Local Write
     PLC_PRG.PUMPS (26)
                                            Local Read
     PLC_PRG.PUMPS (33)
                                            Local Write
     PLC_PRG.PUMPS (34)
                                            Local Read
     TP_FB (3)
                                            Local Read
     TP_FBinit (4)
                                            Local Write
on_req
     PLC_PRG.PUMPS (9)
                                            Local Write
     PLC_PRG.PUMPS (10)
                                            Local Read
     RP_FB (2)
                                            Local Read
     RP_FBinit (3)
                                            Local Write
open_cmd
     PLC_PRG.PROCESS_OU... (18)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (91)
                                            Local Read
     VALVE_BI_FB (4)
                                            Local Read
     VALVE_BI_FB (4)
                                            Local Write
     VALVE_BI_FB (11)
                                            Local Read
     VALVE_BI_FBinit (7)
                                            Local Write
LLV211_OPN_REQ_SC
     PLC_PRG.SC_INPUTS (19)
                                           Local Write
     PLC_PRG.VALVES (49)
                                            Local Read
                                            Local Write
     _global_init (264)
LLV211_CLS_REQ_LL
     PLC_PRG.LL_SM (11)
                                            Local Write
     PLC_PRG.LL_SM (24)
                                            Local Write
     PLC_PRG.LL_SM (37)
                                            Local Write
     PLC_PRG.LL_SM (54)
                                            Local Write
     PLC_PRG.LL_SM (71)
                                            Local Write
     PLC_PRG.LL_SM (88)
                                            Local Write
     PLC_PRG.LL_SM (123)
                                            Local Write
     PLC_PRG.LL_SM (140)
                                            Local Write
     PLC_PRG.LL_SM (160)
                                            Local Write
     PLC_PRG.LL_SM (179)
                                            Local Write
     PLC_PRG.VALVES (50)
                                            Local Read
     _global_init (267)
                                            Local Write
LLV211_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (20)
                                            Local Write
     PLC_PRG.VALVES (50)
                                            Local Read
     _global_init (265)
                                            Local Write
LLV211_CLS_REQ_ES
     PLC_PRG.ES_SM (11)
                                            Local Write
     PLC_PRG.ES_SM (25)
                                            Local Write
     PLC_PRG.ES_SM (39)
                                            Local Write
     PLC_PRG.ES_SM (57)
                                            Local Write
     PLC_PRG.ES_SM (75)
                                            Local Write
     PLC_PRG.ES_SM (93)
                                            Local Write
     PLC_PRG.ES_SM (111)
                                            Local Write
     PLC_PRG.ES_SM (130)
                                            Local Write
     PLC_PRG.ES_SM (148)
                                            Local Write
     PLC_PRG.ES_SM (169)
                                            Local Write
     PLC_PRG.ES_SM (189)
                                            Local Write
```

```
PLC_PRG.LL_SM (105)
                                             Local Write
     PLC_PRG.VALVES (50)
                                            Local Read
                                            Local Write
      _global_init (266)
on_intlk
     PLC_PRG.PUMPS (14)
                                            Local Write
     PLC_PRG.PUMPS (22)
                                            Local Write
     PLC_PRG.PUMPS (30)
                                            Local Write
     TP_FB (3)
                                            Local Read
     TP_FB (6)
                                            Local Read
     TP_FBinit (1)
                                            Local Write
LL_TP212_OK
     PLC_PRG.FAULT_LOGIC (21)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (21)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (149)
                                           Local Read
     _global_init (242)
                                            Local Write
on_ena
     PLC_PRG.PUMPS (15)
                                            Local Write
     PLC_PRG.PUMPS (23)
                                            Local Write
     PLC_PRG.PUMPS (31)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (118)
                                            Local Read
     TP_FB (3)
                                            Local Read
     TP_FB (6)
                                            Local Read
     TP_FBinit (2)
                                            Local Write
MAX_SOCKET_FD_SETSIZE
     _global_init (164)
                                            Global Write
LL_STATE
     PLC_PRG.LL_SM (5)
                                            Local Write
     PLC_PRG.LL_SM (10)
                                            Local Read
     PLC_PRG.LL_SM (20)
                                            Local Write
     PLC_PRG.LL_SM (23)
                                            Local Read
     PLC_PRG.LL_SM (33)
                                            Local Write
     PLC_PRG.LL_SM (36)
                                            Local Read
     PLC_PRG.LL_SM (46)
                                            Local Write
     PLC_PRG.LL_SM (48)
                                            Local Write
     PLC_PRG.LL_SM (50)
                                            Local Write
     PLC_PRG.LL_SM (53)
                                            Local Read
     PLC_PRG.LL_SM (63)
                                            Local Write
     PLC_PRG.LL_SM (65)
                                            Local Write
     PLC_PRG.LL_SM (67)
                                            Local Write
     PLC_PRG.LL_SM (70)
                                            Local Read
     PLC_PRG.LL_SM (80)
                                            Local Write
     PLC_PRG.LL_SM (82)
                                            Local Write
     PLC_PRG.LL_SM (84)
                                            Local Write
     PLC_PRG.LL_SM (87)
                                            Local Read
     PLC_PRG.LL_SM (97)
                                            Local Write
     PLC_PRG.LL_SM (99)
                                            Local Write
     PLC_PRG.LL_SM (101)
                                            Local Write
     PLC_PRG.LL_SM (104)
                                            Local Read
     PLC_PRG.LL_SM (114)
                                            Local Write
     PLC_PRG.LL_SM (116)
                                            Local Write
     PLC_PRG.LL_SM (119)
                                            Local Write
     PLC_PRG.LL_SM (122)
                                            Local Read
     PLC_PRG.LL_SM (132)
                                            Local Write
     PLC_PRG.LL_SM (134)
                                            Local Write
     PLC_PRG.LL_SM (136)
                                            Local Write
     PLC_PRG.LL_SM (139)
                                            Local Read
     PLC_PRG.LL_SM (149)
                                            Local Write
     PLC_PRG.LL_SM (151)
                                            Local Write
     PLC_PRG.LL_SM (153)
                                            Local Write
     PLC_PRG.LL_SM (156)
                                            Local Write
     PLC_PRG.LL_SM (159)
                                            Local Read
     PLC_PRG.LL_SM (169)
                                            Local Write
     PLC_PRG.LL_SM (171)
                                            Local Write
     PLC_PRG.LL_SM (173)
                                            Local Write
     PLC_PRG.LL_SM (175)
                                            Local Write
     PLC_PRG.LL_SM (178)
                                            Local Read
     PLC_PRG.LL_SM (188)
                                            Local Write
     PLC_PRG.LL_SM (190)
                                            Local Write
     PLC_PRG.LL_SM (193)
                                            Local Write
     PLC_PRG.LL_SM (195)
                                            Local Write
     PLC_PRG.LL_SM (200)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (268)
                                            Local Read
```

```
PLC_PRG.SC_OUTPUTS (270)
                                            Local Read
      PLC_PRG.SC_OUTPUTS (272)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (274)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (276)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (278)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (280)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (282)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (284)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (286)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (288)
                                           Local Read
      PLC_PRG.VALVES (45)
                                           Local Read
      _global_init (290)
                                            Local Write
LL_TP201_OK
                                          Local Read
     PLC_PRG.FAULT_LOGIC (19)
      PLC_PRG.FAULT_LOGIC (19)
                                           Local Write
      PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.FAULI_LOGIC (37)
PLC_PRG.SC_OUTPUTS (140)
                                           Local Read
     PLC_PRG.VALVES (20)
                                           Local Read
     PLC_PRG.VALVES (36)
                                           Local Read
      _global_init (235)
                                           Local Write
LL_PE211_PIY_OK
                                           Local Read
     PLC_PRG.ES_SM (4)
     PLC_PRG.ES_SM (19)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (14)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (14)
                                           Local Write
      PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (144)
                                           Local Read
     PLC_PRG.VALVES (78)
                                            Local Read
     _global_init (238)
                                             Local Write
on_ena
     PLC_PRG.PUMPS (7)
                                             Local Write
     RP_FB (2)
                                             Local Read
     RP_FB (4)
                                             Local Read
     RP_FBinit (1)
                                             Local Write
LL_PE203_PSL_LO
                                          Local Read
Local Write
     PLC_PRG.FAULT_LOGIC (8)
     PLC_PRG.FAULT_LOGIC (8)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
     PLC_PRG.SC_OUTPUTS (139)
                                           Local Read
      PLC_PRG.VALVES (20)
                                           Local Read
     PLC_PRG.VALVES (36)
                                            Local Read
     _global_init (234)
                                             Local Write
on_cmd
                                           Local Read
     PLC_PRG.PROCESS_OU... (9)
     PLC_PRG.PROCESS_OU... (9)
PLC_PRG.PROCESS_OU... (12)
PLC_PRG.PROCESS_OU... (21)
PLC_PRG.SC_OUTPUTS (117)
                                           Local Read
                                           Local Read
                                           Local Read
     PLC_PRG.SC_OUTPUTS (117)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (120)
                                           Local Read
      PLC_PRG.SC_OUTPUTS (125)
     PLC_PRG.SC_OUTPUTS (129)
                                            Local Read
      PLC_PRG.VALVES (29)
                                            Local Read
      PLC_PRG.VALVES (78)
                                             Local Read
      PLC_PRG.VALVES (110)
                                             Local Read
      TP_FB (3)
                                             Local Read
     TP_FB (3)
                                             Local Write
     TP_FB (6)
                                             Local Read
     TP_FBinit (6)
                                             Local Write
LL_TP211_OK
     PLC_PRG.FAULT_LOGIC (20)
                                           Local Read
      PLC_PRG.FAULT_LOGIC (20)
                                             Local Write
      PLC_PRG.FAULT_LOGIC (37)
                                             Local Read
      PLC_PRG.SC_OUTPUTS (148)
                                             Local Read
      _global_init (241)
                                             Local Write
LL_PE203_PIY_OK
     PLC_PRG.FAULT_LOGIC (13)
                                           Local Read
      PLC_PRG.FAULT_LOGIC (13)
                                            Local Write
      PLC_PRG.FAULT_LOGIC (37)
                                            Local Read
      PLC_PRG.PUMPS (14)
                                            Local Read
      PLC_PRG.SC_OUTPUTS (138)
                                             Local Read
      _global_init (233)
                                             Local Write
LL_PE202_PSL_LO
     PLC_PRG.FAULT_LOGIC (7)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (7)
                                             Local Write
```

```
PLC_PRG.FAULT_LOGIC (37)
                                                  Local Read
      PLC_PRG.SC_OUTPUTS (137)
                                                 Local Read
      PLC_PRG.VALVES (12)
                                                 Local Read
      PLC_PRG.VALVES (20)
                                                 Local Read
      _global_init (232)
                                                  Local Write
DO_VENT212_SLOW_CMD%QX1.3
                                                Global Read
Global Write
      PLC_PRG.PROCESS_IN... (64)
      PLC_PRG.PROCESS_OU... (24)
      _global_init (24)
                                                  Global Write
DO_VENT212_FAST_CMD%QX1.4
                                                Global Read
Global Write
      PLC_PRG.PROCESS_IN... (64)
      PLC_PRG.PROCESS_OU... (25)
                                                 Global Write
      _global_init (25)
DO_VENT211_SLOW_CMD%QX0.11
                                                Global Read
Global Write
      PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (15)
      _global_init (16)
                                                  Global Write
DO_VENT211_FAST_CMD%QX0.12
      PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (16)
                                                Global Read
Global Write
      _global_init (17)
                                                  Global Write
LL_LL_CONFIG_OK
                                                Local Read
Local Write
Local Read
      PLC_PRG.FAULT_LOGIC (11)
      PLC_PRG.FAULT_LOGIC (11)
      PLC_PRG.FAULT_LOGIC (37)
      PLC_PRG.LL_SM (4)
                                                 Local Read
      PLC_PRG.SC_OUTPUTS (143)
                                                  Local Read
      _global_init (237)
                                                  Local Write
DO_V204_OPEN_CMD%QX0.5
      PLC_PRG.PROCESS_IN... (45)
PLC_PRG.PROCESS_IN... (46)
                                              Global Read
Global Read
      PLC_PRG.PROCESS_OU... (8)
                                                Global Write
                                                  Global Write
      _global_init (10)
DO_V203_OPEN_CMD%QX0.4
      PLC_PRG.PROCESS_IN... (42)
PLC_PRG.PROCESS_IN... (43)
PLC_PRG.PROCESS_OU... (7)
                                               Global Read
Global Read
Global Write
                                                  Global Write
      _global_init (9)
DO_TPV212_OPEN_CMD%QX1.1
      PLC_PRG.PROCESS_IN... (70) Global Read PLC_PRG.PROCESS_IN... (71) Global Read PLC_PRG.PROCESS_OU... (22) Global Write
                                                 Global Write
      _global_init (22)
                                                   Global Write
LL_ES_CONFIG_OK
                                                 Local Read
     PLC_PRG.ES_SM (4)
                                                Local Read
      PLC_PRG.FAULT_LOGIC (10)
                                                 Local Write
      PLC_PRG.FAULT_LOGIC (10)
                                                  Local Read
      PLC_PRG.FAULT_LOGIC (37)
      PLC_PRG.SC_OUTPUTS (142)
                                                   Local Read
      _global_init (236)
                                                   Local Write
DO_TPV211_OPEN_CMD%QX0.9
      V211_OPEN_CMD&QAO.3

PLC_PRG.PROCESS_IN... (58)

PLC_PRG.PROCESS_IN... (59)

PLC_PRG.PROCESS_OU... (13)
                                                Global Read
                                                  Global Read
                                                   Global Write
      _global_init (14)
                                                   Global Write
                                                Global Read
DO_TP211_ON_CMD%QX0.8
      PLC_PRG.PROCESS_IN... (62)
                                                   Global Write
      PLC_PRG.PROCESS_OU... (12)
                                                   Global Write
      _global_init (13)
DO_SPARE_32%QX1.15
      _global_init (36)
                                                   Global Write
DO_SPARE_30%QX1.13
      _global_init (34)
                                                   Global Write
DO_V201_OPEN_CMD%QX0.3
                                                Global Read
Global Read
      PLC_PRG.PROCESS_IN... (36)
PLC_PRG.PROCESS_IN... (37)
PLC_PRG.PROCESS_OU... (6)
                                                   Global Write
      _global_init (8)
                                                   Global Write
DO_SPARE_29%QX1.12
      _global_init (33)
                                                   Global Write
DO_SPARE_28%QX1.11
      _global_init (32)
                                                   Global Write
DO_TP212_ON_CMD%QX1.0
```

PLC_PRG.PROCESS_IN (74)	Global Read
PLC_PRG.PROCESS_OU (21)	Global Write
_global_init (21)	Global Write
DO_SPARE_26%QX1.9	Global Write
_global_init (30) DO_SPARE_25%QX1.8	Global Wille
_global_init (29)	Global Write
DO_TP201_VENT_ENABLE_CMD%QX0.7	
PLC_PRG.PROCESS_OU (10)	Global Write
_global_init (12)	Global Write
DO_SPARE_24%QX1.7	
_global_init (28)	Global Write
DO_SPARE_22%QX1.5	
_global_init (26)	Global Write
DO_SPARE_14%QX0.13 _global_init (18)	Global Write
_grobar_init (18) DO_SLOTV211_CLOSE_CMD%QX0.15	GIODAI WIICE
PLC_PRG.PROCESS_OU (19)	Global Write
_global_init (20)	Global Write
DO_RP2111_ON_CMD%QX0.1	
PLC_PRG.PROCESS_OU (4)	Global Write
_global_init (6)	Global Write
LL_BP211_ON	
PLC_PRG.FAULT_LOGIC (17)	Local Read
PLC_PRG.FAULT_LOGIC (17)	Local Write
PLC_PRG.FAULT_LOGIC (37) PLC_PRG.PUMPS (22)	Local Read Local Read
PLC_PRG.PUMPS (30)	Local Read
PLC_PRG.SC_OUTPUTS (146)	Local Read
PLC_PRG.VALVES (78)	Local Read
PLC_PRG.VALVES (110)	Local Read
_global_init (240)	Local Write
DI_V204_OPEN%IX18.2	
PLC_PRG.PROCESS_IN (45) DI_V204_OPEN%IX18.2	Global Read
PLC_PRG.PROCESS_IN (45)	Global Read
DI_V204_CLOSED%IX18.3	
PLC_PRG.PROCESS_IN (46)	Global Read
DI_V204_CLOSED%IX18.3	
PLC_PRG.PROCESS_IN (46)	Global Read
DO_VENT212_SLOW_CMD%QX1.3	
PLC_PRG.PROCESS_IN (64)	Global Read
PLC_PRG.PROCESS_OU (24) _global_init (24)	Global Write Global Write
global_init (24) DI_V203_OPEN%IX18.0	GIODAI WIICE
PLC_PRG.PROCESS_IN (42)	Global Read
DI_V203_CLOSED%IX18.1	
PLC_PRG.PROCESS_IN (43)	Global Read
DI_V202_CLOSED%IX17.15	
PLC_PRG.PROCESS_IN (40)	Global Read
DI_V203_OPEN%IX18.0	Clobal Boad
PLC_PRG.PROCESS_IN (42) DI_V201_OPEN%IX17.12	Global Read
PLC_PRG.PROCESS_IN (36)	Global Read
DI_V201_CLOSED%IX17.13	
PLC_PRG.PROCESS_IN (37)	Global Read
DO_VENT212_FAST_CMD%QX1.4	
PLC_PRG.PROCESS_IN (64)	Global Read
PLC_PRG.PROCESS_OU (25)	Global Write
_global_init (25) DI_V101_OPEN%IX17.10	Global Write
PLC_PRG.PROCESS_IN (33)	Global Read
DI_V101_CLOSED%IX17.11	
PLC_PRG.PROCESS_IN (34)	Global Read
DI_V202_OPEN%IX17.14	
PLC_PRG.PROCESS_IN (39)	Global Read
DI_V202_OPEN%IX17.14	
PLC_PRG.PROCESS_IN (39)	Global Read
DI_V100_OPEN%IX17.8	Clobal Poad
PLC_PRG.PROCESS_IN (30) DI_TPV211_OPEN%IX18.8	Global Read
PLC_PRG.PROCESS_IN (58)	Global Read
DI_TPV211_CLOSED%IX18.9	

PLC_PRG.PROCESS_IN DI_TP212_TURBO_OK%IX19.1	(59)	Global Read
PLC_PRG.PROCESS_IN	(73)	Global Read
DI_V100_CLOSED%IX17.9	(21)	
PLC_PRG.PROCESS_IN DI_TP212_AT_SPEED%IX19.0	(31)	Global Read
PLC_PRG.PROCESS_IN	(74)	Global Read
DI_TP201_TURBO_OK%IX18.4 PLC_PRG.PROCESS_IN	(48)	Global Read
DI_TP201_AT_SPEED%IX18.5	(40)	Gibbai Read
PLC_PRG.PROCESS_IN	(50)	Global Read
DI_TPV212_OPEN%IX18.12 PLC_PRG.PROCESS_IN	(70)	Global Read
DI_TPV212_OPEN%IX18.12		
PLC_PRG.PROCESS_IN DI_TPV212_CLOSED%IX18.13	(70)	Global Read
PLC_PRG.PROCESS_IN	(71)	Global Read
DI_TP212_AT_SPEED%IX19.0 PLC_PRG.PROCESS_IN	(74)	Global Read
DI_TP211_TURBO_OK%IX18.15		
PLC_PRG.PROCESS_IN	(61)	Global Read
DI_V202_CLOSED%IX17.15 PLC_PRG.PROCESS_IN	(40)	Global Read
DI_TP211_TURBO_OK%IX18.15	(61)	
PLC_PRG.PROCESS_IN DI_TPV211_OPEN%IX18.8	(61)	Global Read
PLC_PRG.PROCESS_IN	(58)	Global Read
DI_TP211_AT_SPEED%IX18.14 PLC_PRG.PROCESS_IN	(62)	Global Read
DI_TP211_AT_SPEED%IX18.14		CIONAL NOR
PLC_PRG.PROCESS_IN DI_SLOTV211_OPEN%IX19.2	(62)	Global Read
PLC_PRG.PROCESS_IN	(76)	Global Read
DI_SLOTV211_CLOSED%IX19.3 PLC_PRG.PROCESS_IN	(77)	Clabal Dand
DI_RPV212_OPEN%IX18.10	(77)	Global Read
PLC_PRG.PROCESS_IN	(67)	Global Read
DI_RPV212_CLOSED%IX18.11 PLC_PRG.PROCESS_IN	(68)	Global Read
DI_TP201_TURBO_OK%IX18.4	(40)	
PLC_PRG.PROCESS_IN DI_RPV211_OPEN%IX18.6	(48)	Global Read
PLC_PRG.PROCESS_IN	(55)	Global Read
DI_RPV211_CLOSED%IX18.7 PLC_PRG.PROCESS_IN	(56)	Global Read
DI_LL211_LID_CLOSED%IX19.4		
PLC_PRG.PROCESS_IN PLC_PRG.SC_OUTPUTS (34		Global Read Global Read
on_cmd	- /	CIDBUI NOU
PLC_PRG.PROCESS_OU		Local Read
PLC_PRG.SC_OUTPUTS (10	07)	Local Read
RP_FB (2) RP_FB (2)		Local Read Local Write
RP_FB (2) RP_FB (4)		Local Read
RP_FBinit (5)		Local Write
bID (3)		nocal wiles
ACTUATOR_SM.CONNECT (2	25)	Local Read
ACTUATOR_SM.DRG1_W		Local Read
ACTUATOR_SM.PCMD_W		Local Read
ACTUATOR_SM.STATUS		Local Read
_global_init (3)		Local Write
oMBMaster		
ACTUATOR_SM (16)		Local Read
ACTUATOR_SM.CONNECT (2		Local Write
ACTUATOR_SM.CONNECT (2		Local Read
ACTUATOR_SM.DRG1_W		Local Write
ACTUATOR_SM.DRG1_W		Local Read
ACTUATOR_SM.PCMD_W		Local Boad
ACTUATOR_SM.PCMD_W ACTUATOR_SM.STATUS		Local Read Local Write
ACTUATOR_SM.STATUS  ACTUATOR_SM.STATUS		Local Write Local Read
ACTUATOR_SM.STATUS  ACTUATORinit (6)	( 4 7 )	Local Read
off_req		20042 1.044

```
PLC_PRG.PUMPS (18)
                                           Local Write
     PLC_PRG.PUMPS (26)
                                          Local Write
     PLC_PRG.PUMPS (34)
                                          Local Write
     TP_FB (3)
                                           Local Read
     TP_FBinit (5)
                                           Local Write
off_req
     PLC_PRG.PUMPS (10)
                                          Local Write
     RP_FB (2)
                                           Local Read
     RP_FBinit (4)
                                           Local Write
off_ena
     PLC_PRG.PUMPS (16)
                                          Local Write
                                          Local Write
     PLC_PRG.PUMPS (24)
     PLC_PRG.PUMPS (32)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (119)
                                          Local Read
     TP_FB (3)
                                          Local Read
     TP_FB (6)
                                           Local Read
     TP_FBinit (3)
                                           Local Write
not_symbol
                                         Local Read
     PLC_PRG.SC_OUTPUTS (46)
     PLC_PRG.SC_OUTPUTS (54)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (66)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (74)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (113)
                                          Local Read
     VALVE_FB (6)
                                           Local Write
     VALVE_FBinit (7)
                                           Local Write
LL_REQUEST
     PLC_PRG.LL_SM (45)
                                           Local Read
     PLC_PRG.LL_SM (47)
                                           Local Read
     PLC_PRG.LL_SM (49)
                                           Local Read
     PLC_PRG.LL_SM (62)
                                          Local Read
     PLC_PRG.LL_SM (64)
                                          Local Read
     PLC_PRG.LL_SM (79)
                                          Local Read
     PLC_PRG.LL_SM (81)
                                          Local Read
     PLC_PRG.LL_SM (96)
                                          Local Read
     PLC_PRG.LL_SM (98)
                                          Local Read
     PLC_PRG.LL_SM (113)
                                          Local Read
     PLC_PRG.LL_SM (115)
                                          Local Read
     PLC_PRG.LL_SM (131)
                                          Local Read
     PLC_PRG.LL_SM (133)
                                          Local Read
     PLC_PRG.LL_SM (148)
                                          Local Read
     PLC_PRG.LL_SM (150)
                                          Local Read
     PLC_PRG.LL_SM (168)
                                          Local Read
     PLC_PRG.LL_SM (170)
                                          Local Read
     PLC_PRG.LL_SM (187)
                                          Local Read
                                          Local Read
     PLC_PRG.LL_SM (189)
                                         Local Write
     PLC_PRG.SC_INPUTS (54)
                                         Local Write
     PLC_PRG.SC_INPUTS (56)
     PLC_PRG.SC_INPUTS (58)
                                           Local Write
     PLC_PRG.SC_INPUTS (60)
                                           Local Write
     PLC_PRG.SC_INPUTS (62)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (202)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (204)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (206)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (208)
                                           Local Read
     _global_init (291)
                                           Local Write
LL_PE201_PSL_LO
     PLC_PRG.FAULT_LOGIC (5)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (5)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (135)
                                           Local Read
     PLC_PRG.VALVES (4)
                                           Local Read
     PLC_PRG.VALVES (12)
                                           Local Read
     _global_init (230)
                                           Local Write
LL_PE101_PSL_LO
     PLC_PRG.FAULT_LOGIC (4)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (4)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (134)
                                           Local Read
     PLC_PRG.VALVES (4)
                                           Local Read
     _global_init (229)
                                           Local Write
ES_REQUEST
                                           Local Read
     PLC_PRG.ES_SM (47)
     PLC_PRG.ES_SM (49)
                                           Local Read
```

```
PLC_PRG.ES_SM (51)
                                            Local Read
     PLC PRG.ES SM (65)
                                            Local Read
     PLC_PRG.ES_SM (67)
                                           Local Read
     PLC_PRG.ES_SM (83)
                                           Local Read
     PLC_PRG.ES_SM (85)
                                           Local Read
     PLC_PRG.ES_SM (101)
                                           Local Read
     PLC_PRG.ES_SM (103)
                                           Local Read
     PLC_PRG.ES_SM (119)
                                           Local Read
     PLC_PRG.ES_SM (121)
                                           Local Read
     PLC_PRG.ES_SM (138)
                                           Local Read
     PLC_PRG.ES_SM (140)
                                           Local Read
     PLC_PRG.ES_SM (156)
                                           Local Read
     PLC_PRG.ES_SM (158)
                                           Local Read
                                           Local Read
     PLC_PRG.ES_SM (177)
     PLC_PRG.ES_SM (179)
                                           Local Read
     PLC_PRG.ES_SM (197)
                                           Local Read
     PLC_PRG.ES_SM (199)
                                           Local Read
     PLC_PRG.SC_INPUTS (39)
                                          Local Write
     PLC_PRG.SC_INPUTS (41)
                                          Local Write
     PLC_PRG.SC_INPUTS (43)
                                          Local Write
     PLC_PRG.SC_INPUTS (45)
                                          Local Write
     PLC_PRG.SC_INPUTS (47)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (187)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (189)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (191)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (193)
                                            Local Read
     _global_init (289)
                                            Local Write
off_ena
     PLC_PRG.PUMPS (8)
                                            Local Write
     RP_FB (2)
                                            Local Read
     RP_FB (4)
                                            Local Read
     RP_FBinit (2)
                                            Local Write
close_req
     PLC_PRG.VALVES (8)
                                          Local Write
     PLC_PRG.VALVES (16)
                                            Local Write
     PLC_PRG.VALVES (24)
                                            Local Write
     PLC_PRG.VALVES (32)
                                            Local Write
     PLC_PRG.VALVES (40)
                                            Local Write
     PLC_PRG.VALVES (58)
                                            Local Write
     PLC_PRG.VALVES (66)
                                            Local Write
     PLC_PRG.VALVES (74)
                                            Local Write
     PLC_PRG.VALVES (82)
                                            Local Write
     PLC_PRG.VALVES (90)
                                            Local Write
     PLC_PRG.VALVES (98)
                                            Local Write
     PLC_PRG.VALVES (106)
                                            Local Write
     PLC_PRG.VALVES (114)
                                            Local Write
     VALVE_FB (3)
                                            Local Read
     VALVE_FBinit (5)
                                            Local Write
oActuator
     ACTUATOR_SM (3)
                                            Local Read
     ACTUATOR_SM (5)
                                            Local Write
     ACTUATOR_SM (7)
                                            Local Write
     ACTUATOR_SM (9)
                                            Local Read
     ACTUATOR_SM (10)
                                            Local Write
     ACTUATOR_SM (12)
                                            Local Write
     ACTUATOR_SM (14)
                                            Local Read
     ACTUATOR_SM (16)
                                            Local Read
     ACTUATOR_SM (17)
                                            Local Write
     ACTUATOR_SM (18)
                                            Local Write
     ACTUATOR_SM (21)
                                            Local Read
     ACTUATOR_SM (23)
                                            Local Read
     ACTUATOR_SM (25)
                                            Local Read
     ACTUATOR_SM (27)
                                            Local Write
     ACTUATOR_SM (29)
                                            Local Read
     ACTUATOR_SM (31)
                                            Local Write
     ACTUATOR_SM (33)
                                            Local Read
     ACTUATOR_SM (35)
                                            Local Write
     ACTUATOR_SM (37)
                                            Local Read
     ACTUATOR_SM (39)
                                            Local Write
     ACTUATOR_SM (42)
                                            Local Write
     ACTUATOR_SM (46)
                                            Local Read
     ACTUATOR_SM (48)
                                            Local Write
     ACTUATOR_SM (50)
                                            Local Read
```

ACTUATOR_SM (52)	Local Write
_ : :	
ACTUATOR_SM (55)	Local Read
ACTUATOR_SM (57)	Local Write
ACTUATOR_SM (59)	Local Read
ACTUATOR SM (61)	Local Write
= , ,	
ACTUATOR_SM (64)	Local Read
ACTUATOR_SM (65)	Local Write
ACTUATOR_SM (67)	Local Read
ACTUATOR_SM (69)	Local Write
ACTUATOR_SM (72)	Local Read
ACTUATOR_SM (74)	Local Write
_ : :	
ACTUATOR_SM (76)	Local Read
ACTUATOR_SM (78)	Local Write
ACTUATOR_SM (81)	Local Read
ACTUATOR_SM (83)	Local Write
ACTUATOR_SM (85)	Local Read
ACTUATOR_SM (87)	Local Write
ACTUATOR_SM (90)	Local Read
ACTUATOR_SM (92)	Local Read
ACTUATOR_SM (94)	Local Read
ACTUATOR_SM (96)	Local Write
ACTUATOR_SM (99)	Local Write
ACTUATOR_SM (103)	Local Read
ACTUATOR_SM (105)	Local Read
ACTUATOR_SM (111)	Local Write
ACTUATOR SM (116)	Local Write
= , ,	
ACTUATOR_SM (120)	Local Read
ACTUATOR_SM (122)	Local Read
ACTUATOR_SM (125)	Local Write
ACTUATOR_SM (128)	Local Read
_ : :	
ACTUATOR_SM (130)	Local Read
ACTUATOR_SM (132)	Local Read
ACTUATOR_SM (136)	Local Write
ACTUATOR_SM (140)	Local Write
ACTUATOR_SM (145)	Local Write
_ :	
ACTUATOR_SM (146)	Local Write
ACTUATOR_SM.CONNECT (6)	Local Read
ACTUATOR_SM.CONNECT (6)	Local Write
ACTUATOR_SM.CONNECT (9)	Local Write
	Local Write
ACTUATOR_SM.CONNECT (25)	
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (28)	Local Read
ACTUATOR_SM.CONNECT (31)	Local Write
ACTUATOR_SM.CONNECT (32)	Local Write
ACTUATOR_SM.DRG1_W (5)	Local Read
ACTUATOR SM.DRG1 W (6)	Local Write
ACTUATOR_SM.DRG1_W (7)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (29)	Local Read
ACTUATOR_SM.DRG1_W (32)	Local Write
ACTUATOR_SM.DRG1_W (33)	Local Write
ACTUATOR_SM.DRG1_W (34)	Local Write
ACTUATOR_SM.DRG1_W (35)	Local Write
ACTUATOR_SM.DRG1_W (36)	Local Read
ACTUATOR_SM.DRG1_W (37)	Local Write
ACTUATOR_SM.DRG1_W (38)	Local Write
ACTUATOR_SM.DRG1_W (40)	Local Write
ACTUATOR_SM.PCMD_W (5)	Local Read
ACTUATOR_SM.PCMD_W (6)	Local Write
ACTUATOR_SM.PCMD_W (7)	Local Write
ACTUATOR_SM.PCMD_W (8)	Local Write
ACTUATOR_SM.PCMD_W (27)	Local Write
	LOUGE METUC

```
ACTUATOR_SM.PCMD_W... (27)
                                           Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (30)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (33)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (34)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (35)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (36)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (37)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (38)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (39)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (41)
                                          Local Write
     ACTUATOR_SM.STATUS... (5)
                                          Local Read
     ACTUATOR_SM.STATUS... (6)
                                          Local Write
     ACTUATOR_SM.STATUS... (7)
                                          Local Write
     ACTUATOR_SM.STATUS... (26)
                                          Local Write
     ACTUATOR_SM.STATUS... (26)
                                          Local Read
     ACTUATOR_SM.STATUS... (26)
                                          Local Write
     ACTUATOR_SM.STATUS... (26)
                                          Local Read
     ACTUATOR_SM.STATUS... (26)
                                          Local Write
     ACTUATOR_SM.STATUS... (26)
                                          Local Read
     ACTUATOR_SM.STATUS... (26)
                                          Local Write
     ACTUATOR_SM.STATUS... (29)
                                          Local Read
     ACTUATOR_SM.STATUS... (32)
                                          Local Write
     ACTUATOR_SM.STATUS... (33)
                                          Local Write
     ACTUATOR_SM.STATUS... (34)
                                          Local Write
     ACTUATOR_SM.STATUS... (35)
                                          Local Write
     ACTUATOR_SM.STATUS... (36)
                                          Local Read
     ACTUATOR_SM.STATUS... (37)
                                          Local Read
     ACTUATOR_SM.STATUS... (38)
                                          Local Read
     ACTUATOR_SM.STATUS... (39)
                                          Local Read
     ACTUATOR_SM.STATUS... (40)
                                          Local Write
     ACTUATOR_SM.STATUS... (41)
                                          Local Write
     ACTUATOR_SM.STATUS... (43)
                                           Local Write
     _global_init (6)
                                           Local Read
not_symbol
     PLC_PRG.SC_OUTPUTS (93)
                                           Local Read
     VALVE_BI_FB (11)
                                           Local Write
     VALVE_BI_FBinit (9)
                                           Local Write
LLV211
                                          Local Read
     PLC_PRG.PROCESS_OU... (18)
     PLC_PRG.PROCESS_OU... (19)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (89)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (90)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (91)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (92)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (93)
                                           Local Read
     PLC_PRG.VALVES (45)
                                           Local Write
     PLC_PRG.VALVES (46)
                                           Local Write
     PLC_PRG.VALVES (47)
                                           Local Write
     PLC_PRG.VALVES (48)
                                           Local Write
     PLC_PRG.VALVES (49)
                                           Local Write
     PLC_PRG.VALVES (50)
                                           Local Write
     PLC_PRG.VALVES (51)
                                           Local Read
     _global_init (301)
                                           Local Read
LLV211_OPN
     PLC_PRG.PROCESS_IN... (76)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (87)
                                           Local Read
                                           Local Write
     _global_init (207)
LL_V202_OPN
     PLC_PRG.FAULT_LOGIC (6)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (6)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (136)
                                           Local Read
     PLC_PRG.VALVES (12)
                                           Local Read
     _global_init (231)
                                           Local Write
LLV211_CSD
     PLC_PRG.ES_SM (33)
                                           Local Read
     PLC_PRG.LL_SM (32)
                                           Local Read
                                           Local Write
     PLC_PRG.PROCESS_IN... (77)
```

```
PLC_PRG.SC_OUTPUTS (88)
                                            Local Read
     PLC PRG. VALVES (37)
                                           Local Read
     PLC_PRG.VALVES (47)
                                           Local Read
     PLC_PRG.VALVES (54)
                                           Local Read
     PLC_PRG.VALVES (62)
                                           Local Read
     PLC_PRG.VALVES (70)
                                           Local Read
     PLC_PRG.VALVES (80)
                                           Local Read
     PLC_PRG.VALVES (86)
                                           Local Read
     PLC_PRG.VALVES (94)
                                           Local Read
     PLC_PRG.VALVES (102)
                                           Local Read
     PLC_PRG.VALVES (112)
                                           Local Read
     _global_init (208)
                                           Local Write
LL_CONFIG_OK
     PLC_PRG.BYPASSES (5)
                                           Local Write
                                           Local Read
     PLC_PRG.FAULT_LOGIC (11)
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     _global_init (227)
                                           Local Write
LL_ACTUATOR_OK
     PLC_PRG.BR_SM (4)
                                           Local Read
     PLC_PRG.BR_SM (13)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (3)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (3)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (133)
                                           Local Read
     _global_init (228)
                                           Local Write
not_symbol
     PLC_PRG.SC_OUTPUTS (121)
                                            Local Read
     TP_FB (6)
                                            Local Write
                                            Local Write
     TP_FBinit (7)
LL_PE212_PIY_OK
                                          Local Read
Local Write
     PLC_PRG.FAULT_LOGIC (15)
     PLC_PRG.FAULT_LOGIC (15)
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.LL_SM (4)
                                           Local Read
     PLC_PRG.LL_SM (19)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (145)
                                          Local Read
     PLC_PRG.VALVES (110)
                                            Local Read
                                            Local Write
     _global_init (239)
DO_V204_OPEN_CMD%QX0.5
     PLC_PRG.PROCESS_IN... (45)
PLC_PRG.PROCESS_IN... (46)
                                          Global Read
Global Read
                                          Global Write
     PLC_PRG.PROCESS_OU... (8)
     _global_init (10)
                                            Global Write
LL211_LID_CLOSED
                                          Local Write
     PLC_PRG.PROCESS_IN... (79)
     _global_init (224)
                                            Local Write
DO_VENT211_SLOW_CMD%QX0.11
                                          Global Read
     PLC_PRG.PROCESS_IN... (52)
     PLC_PRG.PROCESS_OU... (15)
                                            Global Write
     _global_init (16)
                                            Global Write
DO_VENT211_FAST_CMD%QX0.12
                                          Global Read
     PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (16)
     PLC_PRG.PROCESS_IN... (52)
                                            Global Write
     _global_init (17)
                                            Global Write
DO_SPARE_32%QX1.15
     _global_init (36)
                                            Global Write
DO_V203_OPEN_CMD%QX0.4
     PLC_PRG.PROCESS_IN... (42)
PLC_PRG.PROCESS_IN... (43)
                                           Global Read
                                            Global Read
     PLC_PRG.PROCESS_OU... (7)
                                            Global Write
     _global_init (9)
                                            Global Write
                                          Global Read
DO_V101_OPEN_CMD%QX0.2
     PLC_PRG.PROCESS_IN... (33)
     PLC_PRG.PROCESS_IN... (34)
     PLC_PRG.PROCESS_OU... (5)
                                            Global Write
     _global_init (7)
                                            Global Write
DO_SPARE_31%QX1.14
     _global_init (35)
                                            Global Write
LL211_ARM_RETRACTED
     PLC_PRG.PROCESS_IN... (80)
                                           Local Write
     PLC_PRG.VALVES (47)
                                            Local Read
                                            Local Read
     PLC_PRG.VALVES (48)
                                            Local Write
     _global_init (225)
```

```
DO_SPARE_30%QX1.13
     _global_init (34)
                                            Global Write
DO_V201_OPEN_CMD%QX0.3
     PLC_PRG.PROCESS_IN... (36)
                                          Global Read
     PLC_PRG.PROCESS_IN... (37)
                                           Global Read
     PLC_PRG.PROCESS_OU... (6)
                                           Global Write
     _global_init (8)
                                           Global Write
DO_SPARE_31%QX1.14
     _global_init (35)
                                            Global Write
DO_SPARE_29%QX1.12
     _global_init (33)
                                            Global Write
DO_TPV212_OPEN_CMD%QX1.1
     PLC_PRG.PROCESS_IN... (70)
                                          Global Read
     PLC_PRG.PROCESS_IN... (71)
                                          Global Read
                                          Global Write
     PLC_PRG.PROCESS_OU... (22)
     _global_init (22)
                                           Global Write
DO_SPARE_28%QX1.11
                                            Global Write
     _global_init (32)
DO_TP211_ON_CMD%QX0.8
     PLC_PRG.PROCESS_IN... (62)
                                          Global Read
     PLC_PRG.PROCESS_OU... (12)
                                          Global Write
                                           Global Write
     _global_init (13)
DO_TP201_ON_CMD%QX0.6
     PLC_PRG.PROCESS_IN... (49)
                                          Global Read
     PLC_PRG.PROCESS_OU... (9)
                                          Global Write
     _global_init (11)
                                           Global Write
DO_SPARE_27%QX1.10
     _global_init (31)
                                            Global Write
DO_SPARE_27%QX1.10
     _global_init (31)
                                            Global Write
DO_V101_OPEN_CMD%QX0.2
     PLC_PRG.PROCESS_IN... (33)
PLC_PRG.PROCESS_IN... (34)
                                          Global Read
                                          Global Read
                                           Global Write
     PLC_PRG.PROCESS_OU... (5)
                                           Global Write
     _global_init (7)
DO_SPARE_25%QX1.8
     _global_init (29)
                                            Global Write
DO_TPV211_OPEN_CMD%QX0.9
                                          Global Read
     PLC_PRG.PROCESS_IN... (58)
     PLC_PRG.PROCESS_IN... (59)
                                          Global Read
     PLC_PRG.PROCESS_OU... (13)
                                           Global Write
                                            Global Write
     _global_init (14)
DO_SPARE_24%QX1.7
     _global_init (28)
                                            Global Write
DO_SPARE_23%QX1.6
     _global_init (27)
                                            Global Write
DO_SPARE_23%QX1.6
                                            Global Write
     _global_init (27)
DO_TP212_ON_CMD%QX1.0
     PLC_PRG.PROCESS_IN... (74)
                                           Global Read
     PLC_PRG.PROCESS_OU... (21)
                                            Global Write
     _global_init (21)
                                            Global Write
DO_SPARE_22%QX1.5
     _global_init (26)
                                           Global Write
DO_TP201_VENT_ENABLE_CMD%QX0.7
     PLC_PRG.PROCESS_OU... (10)
                                            Global Write
     _global_init (12)
                                            Global Write
DO_SPARE_26%QX1.9
                                            Global Write
     _global_init (30)
DO_SPARE_14%QX0.13
     _global_init (18)
                                            Global Write
DO_SLOTV211_OPEN_CMD%QX0.14
     PLC_PRG.PROCESS_OU... (18)
                                            Global Write
     _global_init (19)
                                            Global Write
DO_SLOTV211_CLOSE_CMD%QX0.15
     PLC_PRG.PROCESS_OU... (19)
                                           Global Write
     _global_init (20)
                                            Global Write
DO_TP201_ON_CMD%QX0.6
     PLC_PRG.PROCESS_IN... (49)
                                          Global Read
     PLC_PRG.PROCESS_OU... (9)
                                           Global Write
     _global_init (11)
                                           Global Write
DO_RPV211_OPEN_CMD%QX0.10
     PLC_PRG.PROCESS_IN... (55)
                                            Global Read
```

```
PLC_PRG.PROCESS_IN... (56)
                                           Global Read
     PLC_PRG.PROCESS_OU... (14)
                                          Global Write
     _global_init (15)
                                          Global Write
DO_RP2110_ON_CMD%QX0.0
     PLC_PRG.PROCESS_OU... (3)
                                          Global Write
     _global_init (5)
                                           Global Write
ES_STATE
     PLC_PRG.ES_SM (5)
                                          Local Write
     PLC_PRG.ES_SM (9)
                                           Local Read
     PLC_PRG.ES_SM (20)
                                          Local Write
     PLC_PRG.ES_SM (23)
                                          Local Read
     PLC_PRG.ES_SM (34)
                                          Local Write
     PLC_PRG.ES_SM (37)
                                          Local Read
     PLC_PRG.ES_SM (48)
                                          Local Write
     PLC_PRG.ES_SM (50)
                                          Local Write
     PLC_PRG.ES_SM (52)
                                          Local Write
     PLC_PRG.ES_SM (55)
                                          Local Read
     PLC_PRG.ES_SM (66)
                                          Local Write
     PLC_PRG.ES_SM (68)
                                          Local Write
     PLC_PRG.ES_SM (70)
                                          Local Write
     PLC_PRG.ES_SM (73)
                                          Local Read
     PLC_PRG.ES_SM (84)
                                          Local Write
     PLC_PRG.ES_SM (86)
                                          Local Write
     PLC_PRG.ES_SM (88)
                                          Local Write
     PLC_PRG.ES_SM (91)
                                          Local Read
     PLC_PRG.ES_SM (102)
                                          Local Write
     PLC_PRG.ES_SM (104)
                                          Local Write
     PLC_PRG.ES_SM (106)
                                          Local Write
     PLC_PRG.ES_SM (109)
                                          Local Read
     PLC_PRG.ES_SM (120)
                                          Local Write
     PLC_PRG.ES_SM (122)
                                          Local Write
     PLC_PRG.ES_SM (125)
                                          Local Write
     PLC_PRG.ES_SM (128)
                                          Local Read
     PLC_PRG.ES_SM (139)
                                          Local Write
     PLC_PRG.ES_SM (141)
                                          Local Write
     PLC_PRG.ES_SM (143)
                                          Local Write
     PLC_PRG.ES_SM (146)
                                          Local Read
     PLC_PRG.ES_SM (157)
                                          Local Write
     PLC_PRG.ES_SM (159)
                                          Local Write
     PLC_PRG.ES_SM (161)
                                          Local Write
     PLC_PRG.ES_SM (164)
                                          Local Write
     PLC_PRG.ES_SM (167)
                                          Local Read
     PLC_PRG.ES_SM (178)
                                           Local Write
     PLC_PRG.ES_SM (180)
                                           Local Write
     PLC_PRG.ES_SM (182)
                                           Local Write
     PLC_PRG.ES_SM (184)
                                           Local Write
     PLC_PRG.ES_SM (187)
                                           Local Read
     PLC_PRG.ES_SM (198)
                                           Local Write
     PLC_PRG.ES_SM (200)
                                           Local Write
     PLC_PRG.ES_SM (203)
                                           Local Write
     PLC_PRG.ES_SM (205)
                                           Local Write
     PLC_PRG.ES_SM (210)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (239)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (241)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (243)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (245)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (247)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (249)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (251)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (253)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (255)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (257)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (259)
                                           Local Read
     PLC_PRG.VALVES (37)
                                           Local Read
     PLC_PRG.VALVES (45)
                                           Local Read
     _global_init (288)
                                           Local Write
DO_SLOTV211_OPEN_CMD%QX0.14
     PLC_PRG.PROCESS_OU... (18)
                                           Global Write
     _global_init (19)
                                           Global Write
DO_RPV212_OPEN_CMD%QX1.2
     PLC_PRG.PROCESS_IN... (67)
                                          Global Read
     PLC_PRG.PROCESS_IN... (68)
                                           Global Read
     PLC_PRG.PROCESS_OU... (23)
                                           Global Write
```

_global_init (23)	Global Write
	GIODAI WIICC
DO_RPV211_OPEN_CMD%QX0.10	
PLC_PRG.PROCESS_IN (55)	Global Read
PLC_PRG.PROCESS_IN (56)	Global Read
PLC_PRG.PROCESS_OU (14)	Global Write
_global_init (15)	Global Write
DI_V201_OPEN%IX17.12	
	Global Read
PLC_PRG.PROCESS_IN (36)	GIODAI KEAU
DI_V201_CLOSED%IX17.13	
PLC_PRG.PROCESS_IN (37)	Global Read
DI_V101_OPEN%IX17.10	
PLC_PRG.PROCESS_IN (33)	Global Read
DI_V101_CLOSED%IX17.11	
PLC_PRG.PROCESS_IN (34)	Global Read
DO_RP2110_ON_CMD%QX0.0	
	Clabal Waita
PLC_PRG.PROCESS_OU (3)	Global Write
_global_init (5)	Global Write
DI_V100_OPEN%IX17.8	
PLC_PRG.PROCESS_IN (30)	Global Read
ES_CONFIG_OK	
PLC_PRG.BYPASSES (4)	Local Write
PLC_PRG.FAULT_LOGIC (10)	Local Read
PLC_PRG.FAULT_LOGIC (37)	Local Read
_global_init (226)	Local Write
DI_TPV212_CLOSED%IX18.13	
PLC_PRG.PROCESS_IN (71)	Global Read
DI_V203_CLOSED%IX18.1	
PLC_PRG.PROCESS_IN (43)	Global Read
DI_TP201_AT_SPEED%IX18.5	
PLC_PRG.PROCESS_IN (50)	Global Read
DI_V100_CLOSED%IX17.9	
PLC_PRG.PROCESS_IN (31)	Global Read
DI_TP212_TURBO_OK%IX19.1	GIODAI NCAG
	Clabal Dard
PLC_PRG.PROCESS_IN (73)	Global Read
DI_TPV211_CLOSED%IX18.9	
PLC_PRG.PROCESS_IN (59)	Global Read
DI_SLOTV211_OPEN%IX19.2	
PLC_PRG.PROCESS_IN (76)	Global Read
DI_SLOTV211_CLOSED%IX19.3	
PLC_PRG.PROCESS_IN (77)	Global Read
DI_RPV212_OPEN%IX18.10	
PLC_PRG.PROCESS_IN (67)	Global Read
DI_RPV212_CLOSED%IX18.11	
PLC_PRG.PROCESS_IN (68)	Global Read
DI_RPV211_OPEN%IX18.6	GIODAI NCAG
	Clabal Dara
PLC_PRG.PROCESS_IN (55)	Global Read
DI_RPV211_CLOSED%IX18.7	
PLC_PRG.PROCESS_IN (56)	Global Read
DI_RP2111_ON%IX16.5	
PLC_PRG.PROCESS_IN (8)	Global Read
PLC_PRG.SC_OUTPUTS (12)	Global Read
DI_PE212_PSL_MIDLO%IX17.6	
PLC_PRG.PROCESS_IN (27)	Global Read
PLC_PRG.SC_OUTPUTS (31)	Global Read
DI_RP2111_ON%IX16.5	
PLC_PRG.PROCESS_IN (8)	Global Read
PLC_PRG.SC_OUTPUTS (12)	Global Read
DI_RP2110_ON%IX16.4	
PLC_PRG.PROCESS_IN (7)	Global Read
PLC_PRG.SC_OUTPUTS (11)	Global Read
DI_PE212_PSL_MIDLO%IX17.6	
PLC_PRG.PROCESS_IN (27)	Global Read
PLC_PRG.SC_OUTPUTS (31)	Global Read
DI_PE212_PSL_MIDHI%IX17.5	
PLC_PRG.PROCESS_IN (26)	Global Read
PLC_PRG.SC_OUTPUTS (30)	Global Read
DI_PE212_PSL_MIDHI%IX17.5	
PLC_PRG.PROCESS_IN (26)	Global Read
PLC_PRG.SC_OUTPUTS (30)	Global Read
DI_PE212_PSL_LO%IX17.7	01-1 1 5 1
PLC_PRG.PROCESS_IN (28)	Global Read
PLC_PRG.SC_OUTPUTS (32)	Global Read
DI_PE212_PSL_LO%IX17.7	

PLC_PRG.PROCESS_IN (28)	Global Read
PLC_PRG.SC_OUTPUTS (32)	Global Read
DI_PE212_PSL_HI%IX17.4	
PLC_PRG.PROCESS_IN (25)	Global Read
PLC_PRG.SC_OUTPUTS (29)	Global Read
DI_PE212_PSL_HI%IX17.4	
PLC_PRG.PROCESS_IN (25)	Global Read
PLC_PRG.SC_OUTPUTS (29)	Global Read
DI_PE212_PIY_OK%IX16.10	
PLC_PRG.PROCESS_IN (24)	Global Read
PLC_PRG.PROCESS_IN (25) PLC_PRG.PROCESS_IN (26)	Global Read Global Read
PLC_PRG.SC_OUTPUTS (28)	Global Read
DI_PE211_PSL_MIDLO%IX17.2	Global Kead
PLC_PRG.PROCESS_IN (21)	Global Read
PLC_PRG.SC_OUTPUTS (25)	Global Read
DI_PE212_PIY_OK%IX16.10	Global Kead
PLC_PRG.PROCESS_IN (24)	Global Read
PLC_PRG.PROCESS_IN (25)	Global Read
PLC_PRG.PROCESS_IN (26)	Global Read
PLC_PRG.SC_OUTPUTS (28)	Global Read
DI_PE211_PSL_MIDLO%IX17.2	SISSAI NOUL
PLC_PRG.PROCESS_IN (21)	Global Read
PLC_PRG.SC_OUTPUTS (25)	Global Read
DI_PE211_PSL_MIDHI%IX17.1	SISSAI NOUL
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (24)	Global Read
DI_PE211_PSL_LO%IX17.3	Global Read
PLC_PRG.PROCESS_IN (22)	Global Read
PLC_PRG.SC_OUTPUTS (26)	Global Read
DI_PE211_PSL_HI%IX17.0	Global Road
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.SC_OUTPUTS (23)	Global Read
DI_PE211_PIY_OK%IX16.9	Global Nead
PLC_PRG.PROCESS_IN (18)	Global Read
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (22)	Global Read
DI_PE2111_PSL%IX16.7	010301 1000
PLC_PRG.PROCESS_IN (10)	Global Read
PLC_PRG.SC_OUTPUTS (14)	Global Read
DI_PE2111_PSL%IX16.7	ologal Noda
PLC_PRG.PROCESS_IN (10)	Global Read
PLC_PRG.SC_OUTPUTS (14)	Global Read
DI_PE203_PSL_MIDLO%IX16.14	
PLC_PRG.PROCESS_IN (15)	Global Read
PLC_PRG.SC_OUTPUTS (19)	Global Read
DI_RP2110_ON%IX16.4	
PLC_PRG.PROCESS_IN (7)	Global Read
PLC_PRG.SC_OUTPUTS (11)	Global Read
DI_PE211_PSL_HI%IX17.0	
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.SC_OUTPUTS (23)	Global Read
DI_PE203_PSL_MIDHI%IX16.13	
PLC_PRG.PROCESS_IN (14)	Global Read
PLC_PRG.SC_OUTPUTS (18)	Global Read
DI_PE203_PSL_MIDHI%IX16.13	
PLC_PRG.PROCESS_IN (14)	Global Read
PLC_PRG.SC_OUTPUTS (18)	Global Read
DI_PE203_PSL_LO%IX16.15	
PLC_PRG.PROCESS_IN (16)	Global Read
PLC_PRG.SC_OUTPUTS (20)	Global Read
DI_PE203_PSL_LO%IX16.15	
PLC_PRG.PROCESS_IN (16)	Global Read
PLC_PRG.SC_OUTPUTS (20)	Global Read
DI_PE211_PIY_OK%IX16.9	
PLC_PRG.PROCESS_IN (18)	Global Read
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (22)	Global Read
DI_PE203_PSL_HI%IX16.12	
PLC_PRG.PROCESS_IN (13)	Global Read
PLC_PRG.SC_OUTPUTS (17)	Global Read

```
DI_PE203_PSL_HI%IX16.12
     PLC_PRG.PROCESS_IN... (13) Global Read
     PLC_PRG.SC_OUTPUTS (17)
                                         Global Read
DI_PE2110_PSL%IX16.6
                                       Global Read
     PLC_PRG.PROCESS_IN... (9)
     PLC_PRG.SC_OUTPUTS (13)
                                         Global Read
DI_PE203_PIY_OK%IX16.8
                                        Global Read
     PLC_PRG.PROCESS_IN... (12)
     PLC_PRG.PROCESS_IN... (13)
                                         Global Read
     PLC_PRG.PROCESS_IN... (14)
                                         Global Read
     PLC_PRG.SC_OUTPUTS (16)
                                         Global Read
DI_PE203_PIY_OK%IX16.8
     PLC_PRG.PROCESS_IN... (12)
                                        Global Read
Global Read
     PLC_PRG.PROCESS_IN... (13)
     PLC_PRG.PROCESS_IN... (14)
                                        Global Read
     PLC_PRG.SC_OUTPUTS (16)
                                         Global Read
DO_RPV212_OPEN_CMD%QX1.2
                                        Global Read
     PLC_PRG.PROCESS_IN... (67)
     PLC_PRG.PROCESS_IN... (68)
                                         Global Read
     PLC_PRG.PROCESS_OU... (23)
                                         Global Write
     _global_init (23)
                                         Global Write
DI_PE202_PSL_LO%IX16.2
     PLC_PRG.PROCESS_IN... (5)
                                         Global Read
DO_RP2111_ON_CMD%QX0.1
                                      Global Write
    PLC_PRG.PROCESS_OU... (4)
     _global_init (6)
                                         Global Write
DI_PE211_PSL_MIDHI%IX17.1
                                       Global Read
     PLC_PRG.PROCESS_IN... (20)
     PLC_PRG.SC_OUTPUTS (24)
                                         Global Read
DI_PE211_PSL_LO%IX17.3
                                       Global Read
     PLC_PRG.PROCESS_IN... (22)
     PLC_PRG.SC_OUTPUTS (26)
                                         Global Read
DI_PE203_PSL_MIDLO%IX16.14
                                        Global Read
     PLC_PRG.PROCESS_IN... (15)
     PLC_PRG.SC_OUTPUTS (19)
                                         Global Read
DI_PE2110_PSL%IX16.6
                                        Global Read
     PLC_PRG.PROCESS_IN... (9)
                                         Global Read
     PLC_PRG.SC_OUTPUTS (13)
DI_PE202_PSL_LO%IX16.2
     PLC_PRG.PROCESS_IN... (5)
                                         Global Read
DI_PE201_PSL_LO%IX16.1
     PLC_PRG.PROCESS_IN... (4)
                                         Global Read
DI_PE201_PSL_LO%IX16.1
    PLC_PRG.PROCESS_IN... (4)
                                         Global Read
DI_LL211_ARM_RETRACTED%IX19.5
     PLC_PRG.PROCESS_IN... (80)
                                        Global Read
     PLC_PRG.SC_OUTPUTS (35)
                                          Global Read
DI_PE101_PSL_LO%IX16.0
    PLC_PRG.PROCESS_IN... (3)
                                         Global Read
DI_PE101_PSL_LO%IX16.0
    PLC_PRG.PROCESS_IN... (3)
                                          Global Read
cYAG
     PLC_PRG.BR_SM (80)
                                          Local Read
     PLC_PRG.BR_SM (96)
                                          Local Read
                                          Local Write
     _global_init (5)
cSINS02
     PLC_PRG.BR_SM (49)
                                          Local Read
     PLC_PRG.BR_SM (65)
                                          Local Read
     _global_init (4)
                                          Local Write
cVERSION_MINOR
     PLC_PRG.SC_OUTPUTS (157)
                                         Local Read
     _global_init (2)
                                          Local Write
close_intlk
     PLC_PRG.VALVES (47)
                                          Local Write
     VALVE_BI_FB (8)
                                          Local Read
     VALVE_BI_FB (11)
                                          Local Read
                                          Local Write
     VALVE_BI_FBinit (3)
not_symbol
     RP_FB (4)
                                          Local Write
     RP_FBinit (6)
                                          Local Write
DI_LL211_LID_CLOSED%IX19.4
     PLC_PRG.PROCESS_IN... (79)
                                         Global Read
     PLC_PRG.SC_OUTPUTS (34)
                                          Global Read
```

```
DI_LL211_ARM_RETRACTED%IX19.5
     PLC_PRG.PROCESS_IN... (80)
                                          Global Read
     PLC_PRG.SC_OUTPUTS (35)
                                            Global Read
cVERSION_MAJOR
     PLC_PRG.SC_OUTPUTS (156)
                                          Local Read
     _global_init (1)
                                           Local Write
cSINS01
     PLC_PRG.BR_SM (19)
                                          Local Read
     PLC_PRG.BR_SM (34)
                                           Local Read
     _global_init (3)
                                           Local Write
count 2
     PLC_PRG.ACTUATOR_I... (6)
                                          Local Write
     PLC_PRG.ACTUATOR_I... (6)
                                          Local Read
     PLC_PRG.ACTUATOR_I... (7)
                                          Local Read
     PLC_PRG.ACTUATOR_I... (8)
                                          Local Read
     PLC_PRG.ACTUATOR_I... (11)
                                          Local Read
     PLC_PRG.ACTUATOR_I... (11)
                                          Local Write
     _global_init (166)
                                           Local Write
count
     _global_init (165)
                                           Local Write
close_req
     PLC_PRG.VALVES (50)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FBinit (6)
                                           Local Write
close_ena
     PLC_PRG.SC_OUTPUTS (44)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (52)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (64)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (72)
                                          Local Read
     PLC_PRG.VALVES (6)
                                          Local Write
     PLC_PRG.VALVES (14)
                                           Local Write
     PLC_PRG.VALVES (22)
                                           Local Write
     PLC_PRG.VALVES (30)
                                          Local Write
     PLC_PRG.VALVES (38)
                                          Local Write
     PLC_PRG.VALVES (56)
                                          Local Write
     PLC_PRG.VALVES (64)
                                          Local Write
     PLC_PRG.VALVES (72)
                                          Local Write
     PLC_PRG.VALVES (80)
                                           Local Write
     PLC_PRG.VALVES (88)
                                           Local Write
     PLC_PRG.VALVES (96)
                                           Local Write
     PLC_PRG.VALVES (104)
                                           Local Write
                                           Local Write
     PLC_PRG.VALVES (112)
     VALVE_FB (3)
                                            Local Read
     VALVE_FB (6)
                                            Local Read
     VALVE_FBinit (3)
                                            Local Write
close_ena
     PLC_PRG.SC_OUTPUTS (90)
                                           Local Read
     PLC_PRG.VALVES (48)
                                           Local Write
     VALVE_BI_FB (4)
                                            Local Read
     VALVE_BI_FB (8)
                                            Local Read
     VALVE_BI_FB (11)
                                            Local Read
     VALVE_BI_FBinit (4)
                                            Local Write
cBR_SELECTOR_UL
     _global_init (6)
                                            Local Write
cACTUATOR_TARGET
     PLC_PRG.ACTUATOR_I... (7)
                                           Local Read
     PLC_PRG.ACTUATOR_O... (4)
                                            Local Read
     _global_init (7)
                                            Local Write
     _global_init (8)
                                            Local Write
     _global_init (9)
                                            Local Write
close_cmd
     PLC_PRG.PROCESS_OU... (19)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (92)
                                           Local Read
     VALVE_BI_FB (8)
                                            Local Read
     VALVE_BI_FB (8)
                                            Local Write
     VALVE_BI_FB (11)
                                            Local Read
     VALVE_BI_FBinit (8)
                                            Local Write
BR_STATE
     PLC_PRG.BR_SM (5)
                                           Local Write
     PLC_PRG.BR_SM (9)
                                           Local Read
     PLC_PRG.BR_SM (14)
                                            Local Write
                                            Local Read
     PLC_PRG.BR_SM (17)
```

```
PLC_PRG.BR_SM (23)
                                            Local Write
     PLC_PRG.BR_SM (25)
                                           Local Write
     PLC_PRG.BR_SM (27)
                                           Local Write
     PLC_PRG.BR_SM (29)
                                           Local Write
     PLC_PRG.BR_SM (32)
                                           Local Read
     PLC_PRG.BR_SM (38)
                                           Local Write
     PLC_PRG.BR_SM (40)
                                           Local Write
     PLC_PRG.BR_SM (42)
                                           Local Write
     PLC_PRG.BR_SM (44)
                                           Local Write
     PLC_PRG.BR_SM (47)
                                           Local Read
     PLC_PRG.BR_SM (53)
                                           Local Write
     PLC_PRG.BR_SM (56)
                                           Local Write
     PLC_PRG.BR_SM (58)
                                          Local Write
     PLC_PRG.BR_SM (60)
                                           Local Write
     PLC_PRG.BR_SM (63)
                                           Local Read
     PLC_PRG.BR_SM (69)
                                           Local Write
     PLC_PRG.BR_SM (71)
                                           Local Write
     PLC_PRG.BR_SM (73)
                                           Local Write
     PLC_PRG.BR_SM (75)
                                           Local Write
     PLC_PRG.BR_SM (78)
                                           Local Read
     PLC_PRG.BR_SM (84)
                                           Local Write
     PLC_PRG.BR_SM (87)
                                           Local Write
     PLC_PRG.BR_SM (89)
                                          Local Write
     PLC_PRG.BR_SM (91)
                                          Local Write
     PLC_PRG.BR_SM (94)
                                          Local Read
     PLC_PRG.BR_SM (100)
                                          Local Write
     PLC_PRG.BR_SM (102)
                                          Local Write
     PLC_PRG.BR_SM (104)
                                          Local Write
     PLC_PRG.BR_SM (106)
                                          Local Write
     PLC_PRG.BR_SM (110)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (40)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (48)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (218)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (220)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (223)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (226)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (229)
                                           Local Read
     _global_init (286)
                                           Local Write
AI_PE212_LO_PIY%IW9
     PLC_PRG.SC_OUTPUTS (168)
                                            Global Read
BP211_ON_CMD
     PLC_PRG.PROCESS_OU... (4)
                                           Local Read
     PLC_PRG.PUMPS (4)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (110)
                                           Local Read
                                           Local Write
     _global_init (308)
AI_PE212_LO_PIY%IW9
    PLC_PRG.SC_OUTPUTS (168)
                                            Global Read
AI_PE212_HI_PIY%IW8
    PLC_PRG.SC_OUTPUTS (167)
                                            Global Read
AI_PE212_HI_PIY%IW8
    PLC_PRG.SC_OUTPUTS (167)
                                            Global Read
AI_PE211_LO_PIY%IW7
     PLC_PRG.SC_OUTPUTS (166)
                                            Global Read
AI_PE211_LO_PIY%IW7
     PLC_PRG.SC_OUTPUTS (166)
                                            Global Read
BR_REQUEST
     PLC_PRG.BR_SM (24)
                                            Local Read
     PLC_PRG.BR_SM (26)
                                            Local Read
     PLC_PRG.BR_SM (28)
                                            Local Read
     PLC_PRG.BR_SM (37)
                                            Local Read
     PLC_PRG.BR_SM (39)
                                            Local Read
     PLC_PRG.BR_SM (41)
                                            Local Read
     PLC_PRG.BR_SM (43)
                                            Local Read
     PLC_PRG.BR_SM (55)
                                            Local Read
     PLC_PRG.BR_SM (57)
                                           Local Read
     PLC_PRG.BR_SM (59)
                                           Local Read
     PLC_PRG.BR_SM (68)
                                           Local Read
     PLC_PRG.BR_SM (70)
                                           Local Read
     PLC_PRG.BR_SM (72)
                                           Local Read
     PLC_PRG.BR_SM (74)
                                            Local Read
     PLC_PRG.BR_SM (86)
                                            Local Read
     PLC_PRG.BR_SM (88)
                                            Local Read
     PLC_PRG.BR_SM (90)
                                            Local Read
```

```
PLC_PRG.BR_SM (99)
                                           Local Read
     PLC PRG.BR SM (101)
                                          Local Read
     PLC_PRG.BR_SM (103)
                                          Local Read
     PLC_PRG.BR_SM (105)
                                          Local Read
     PLC_PRG.SC_INPUTS (25)
                                          Local Write
     PLC_PRG.SC_INPUTS (27)
                                          Local Write
     PLC_PRG.SC_INPUTS (29)
                                          Local Write
     PLC_PRG.SC_INPUTS (31)
                                          Local Write
     PLC_PRG.SC_INPUTS (33)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (172)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (174)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (176)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (178)
                                          Local Read
     _global_init (287)
                                          Local Write
AI_PE211_HI_PIY%IW6
     PLC_PRG.SC_OUTPUTS (165)
                                          Global Read
BP211_ON
     PLC_PRG.FAULT_LOGIC (17)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (8)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (109)
                                          Local Read
     _global_init (223)
                                          Local Write
AI_PE211_HI_PIY%IW6
     PLC_PRG.SC_OUTPUTS (165)
                                          Global Read
AI_PE203_LO_PIY%IW5
     PLC_PRG.SC_OUTPUTS (164)
                                          Global Read
AI_PE203_LO_PIY%IW5
     PLC_PRG.SC_OUTPUTS (164)
                                          Global Read
AI_PE203_HI_PIY%IW4
     PLC_PRG.SC_OUTPUTS (163)
                                          Global Read
AI_PE203_HI_PIY%IW4
     PLC_PRG.SC_OUTPUTS (163)
                                          Global Read
AI_PE202_PIY%IW2
     PLC_PRG.SC_OUTPUTS (162)
                                          Global Read
AI_PE202_PIY%IW2
     PLC_PRG.SC_OUTPUTS (162)
                                          Global Read
AI_PE201_PIY%IW1
     PLC_PRG.SC_OUTPUTS (161)
                                          Global Read
AI_PE101_PIY%IW0
    PLC_PRG.SC_OUTPUTS (160)
                                           Global Read
BP211_PSL
     PLC_PRG.PROCESS_IN... (10)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (147)
                                           Local Read
                                           Local Write
     _global_init (188)
ACTUATOR OK
                                         Local Write
     PLC_PRG.ACTUATOR_I... (3)
     PLC_PRG.BYPASSES (3)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (3)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     _global_init (246)
                                           Local Write
awStatus
     ACTUATOR_SM (25)
                                           Local Read
     ACTUATOR_SM (29)
                                           Local Read
     ACTUATOR_SM (33)
                                           Local Read
     ACTUATOR_SM (37)
                                           Local Read
     ACTUATOR_SM (94)
                                           Local Read
     ACTUATOR_SM (132)
                                           Local Read
     ACTUATOR_SM.CONNECT (25)
                                           Local Read
     ACTUATOR_SM.STATUS... (26)
                                           Local Read
     ACTUATOR_SM.STATUS... (37)
                                           Local Read
     ACTUATOR_SM.STATUS... (38)
                                           Local Read
     ACTUATOR_SM.STATUS... (39)
                                           Local Read
     ACTUATORinit (2)
                                           Local Write
AI_PE201_PIY%IW1
     PLC_PRG.SC_OUTPUTS (161)
                                           Global Read
AI_PE101_PIY%IW0
     PLC_PRG.SC_OUTPUTS (160)
                                           Global Read
ACTUATOR_CMD
     PLC_PRG.ACTUATOR_O... (3)
                                          Local Read
     PLC_PRG.ACTUATOR_O... (4)
                                           Local Read
     PLC_PRG.BR_SM (11)
                                           Local Write
                                           Local Write
     PLC_PRG.BR_SM (19)
     PLC_PRG.BR_SM (22)
                                           Local Read
```

```
PLC_PRG.BR_SM (34)
                                            Local Write
     PLC_PRG.BR_SM (49)
                                            Local Write
     PLC_PRG.BR_SM (52)
                                            Local Read
                                            Local Write
     PLC_PRG.BR_SM (65)
     PLC_PRG.BR_SM (80)
                                            Local Write
     PLC_PRG.BR_SM (83)
                                            Local Read
     PLC_PRG.BR_SM (96)
                                            Local Write
      _global_init (245)
                                           Local Write
ACTUATOR_AT_TARGET
     PLC_PRG.ACTUATOR_I... (8)
                                           Local Write
     PLC_PRG.ACTUATOR_I... (13)
                                           Local Write
     PLC_PRG.BR_SM (22)
                                           Local Read
     PLC_PRG.BR_SM (52)
                                           Local Read
     PLC_PRG.BR_SM (83)
                                           Local Read
     _global_init (244)
                                            Local Write
a_num
     _global_init (167)
                                           Local Write
Call Tree of PLC_PRG (PRG-ST)
PLC_PRG
             PLC_PRG.PROCESS_INPUTS
             PLC_PRG.SC_INPUTS
             PLC_PRG.ACTUATOR_INPUTS
             PLC_PRG.BYPASSES
             PLC_PRG.FAULT_LOGIC
             PLC_PRG.BR_SM
             PLC_PRG.ES_SM
             PLC_PRG.LL_SM
             PLC_PRG.PUMPS
                               RP_FB
                                TP_FB
             PLC_PRG.VALVES
                                VALVE_FB
                                VALVE_BI_FB
             PLC_PRG.ACTUATOR_OUTPUTS
             PLC_PRG.SC_OUTPUTS
```

PLC\_PRG.PROCESS\_OUTPUTS

PLC\_PRG.CLEAR\_REQS

	Page
	rage
Project information	А
Actuator_SM (PRG-ST)	1
CONNECT (ST)	4
DRG1_WRITE (ST)	5
PCMD_WRITE (ST)	6
STATUS_READ (ST)	6
PLC_PRG (PRG-ST)	7
Actuator_Inputs (ST)	14
Actuator_Outputs (ST)	14
BR_SM (ST)	14
Bypasses (ST)	15
Clear_Reqs (ST)	16
ES_SM (ST)	16
Fault_Logic (ST)	19
LL_SM (ST)	20
Process_Inputs (ST)	22
Process_Outputs (ST)	23
Pumps (ST)	24
SC_Inputs (ST)	24
SC_Outputs (ST)	25
Valves (ST)	29
RP_FB (FB-ST)	31
TP_FB (FB-ST)	31
VALVE_BI_FB (FB-ST)	31
VALVE_FB (FB-ST)	32
Actuator	32
BR_REQ	32
BR_ST	33
PV_REQ	33
PV_ST	33
ACTUATOR_VISU	33
AUTO_VISU	33
INTLKS_VISU	33
PUMPS_VISU	34
SIGNALS_VISU	34
VALVES_VISU	35
Global_Variables	35
Variable_Configuration	35
Global Variables 0	35
Globale_Variablen	35
Version	35
Globale_Variablen	35
Globale_Variablen	37
Alarm configuration	37
PLC Configuration	37
Sampling Trace	41
Task configuration	41
Watch- and Recipe Manager	42
Workspace	42
Parameter Manager	42
Cross Reference List	42
Call Tree of PLC_PRG (PRG-ST)	92