Filename: SINS2.pro

Title: SSLS SINS.2 Reflectometer Branchline


Author: Carl Cork

Version: Description:

```
0001
     PROGRAM Actuator_SM
0002
0003 VAR CONSTANT
                          : STRING := '192.168.1.11';
0004
          strAddress
0005
                          : WORD := 502;
          wPort
0006
                          : BYTE := 1;
          bTD
0007
          tTCP_Timeout: TIME := t#100ms;
0008
          tTCP_Watchdog : TIME := t#10s;
0009 END_VAR
0010 VAR
0011
                          : Actuator; (* Actuator control and status object *)
          oActuator
0012
0013
                          : UINT; (* total numbers of successful Transfers *)
          uiSuccessful
0014
          uiFailing
                                     (* total numbers of failing Transfers
                          : UINT;
0015 END_VAR
     (* Actuator State Machine *)
0001
0002
     CASE oActuator.wState OF
          10: (* RESET: reset connection *)
0003
0004
              xActuatorReady := FALSE;
0005
              oActuator.xConnect := FALSE;
0006
              CONNECT();
0007
              oActuator.wState := 15;
8000
0009
          15: (* INIT: Initialize connection *)
0010
              oActuator.xConnect := TRUE;
0011
              CONNECT();
0012
              oActuator.wState := 20;
0013
          20: (* CONNECTING: wait for TCP connection*)
0014
0015
              CONNECT();
0016
              IF oActuator.oMBMaster.xIS_CONNECTED THEN
0017
                  oActuator.xBusy := FALSE;
0018
                  oActuator.wState := 30;
0019
              END_IF
0020
0021
          30: (* INITIALIZING: wait for servo on *)
0022
              STATUS READ():
0023
              IF oActuator.xDataReadv THEN
0024
                  (* test for EMGS ON or PWR OFF *)
0025
                  IF (oActuator.awStatus[5].15 OR NOT oActuator.awStatus[5].13 ) THEN
0026
                      (* Wait for this condition to be satisfied *)
0027
                      oActuator.wState := 30;
0028
                  (* test for ALMH alarm *)
0029
                  ELSIF oActuator.awStatus[5].10 THEN
0030
                      (* try to reset alarm *)
0031
                      oActuator.wState := 31;
                  (* test for SV servo OFF or PEND OFF *)
0032
0033
                  ELSIF (NOT oActuator.awStatus[5].12) OR (NOT oActuator.awStatus[5].3) THEN
0034
                      (* try to turn on servo *)
0035
                      oActuator.wState := 33;
0036
                  (* test for HEND homing complete *)
0037
                  ELSIF NOT oActuator.awStatus[5].4 THEN
0038
                      (* try to HOME motor *)
0039
                      oActuator.wState := 35;
0040
                  ELSE
0041
                      (* ready to receive position commands *)
0042
                      oActuator.wState := 40;
0043
                  END_IF
0044
              END_IF
0045
0046
          31: (* ALRS ON: reset alarm *)
0047
              (* first assert ALRS *)
0048
              oActuator.wCommand := 16#0100;
0049
              DRG1_WRITE();
0050
              IF oActuator.xDataReady THEN
0051
                  (* next step is to clear ALRS flag *)
0052
                  oActuator.wState := 32;
0053
              END_IF
0054
          32: (* ALRS OFF: clear flag *)
0055
              (* clear ALRS flag *)
0056
0057
              oActuator.wCommand := 16#0000;
```

```
0058
              DRG1_WRITE();
0059
              IF oActuator.xDataReady THEN
0060
                   (* finish initialization *)
0061
                  oActuator.wState := 30;
0062
              END_IF
0063
0064
          33: (* SON: turn on servo *)
0065
              oActuator.wCommand := 16#1000;
0066
              DRG1_WRITE();
0067
              IF oActuator.xDataReady THEN
0068
                   (* finish initialization *)
0069
                  oActuator.wState := 30;
              END_IF
0070
0071
0072
          35: (* HOME OFF: reset HOME flag *)
0073
               (* leave SON ON *)
0074
              oActuator.wCommand := 16#1000;
0075
              DRG1_WRITE();
0076
              IF oActuator.xDataReady THEN
0077
                   (* now set the flag *)
0078
                  oActuator.wState := 36;
              END_IF
0079
0080
          36: (* HOME ON: set HOME flag *)
0081
0082
               (* SON | HOME *)
0083
              oActuator.wCommand := 16#1010;
0084
              DRG1_WRITE();
0085
              IF oActuator.xDataReady THEN
0086
                  (* wait for HEND *)
0087
                  oActuator.wState := 37;
0088
              END_IF
0089
          37: (* HEND: wait for home to finish *)
0090
              STATUS_READ();
0091
0092
              IF oActuator.xDataReady THEN
0093
                   (* test for HEND *)
0094
                   IF NOT oActuator.awStatus[5].4 THEN
0095
                       (* not home yet *)
0096
                       oActuator.wState := 37;
0097
                  ELSE
0098
                       (* ready to receive position commands *)
0099
                       oActuator.wState := 40;
0100
                  END IF
0101
              END_IF
0102
0103
          40: (* IDLING: wait for new destination *)
0104
              STATUS_READ();
0105
               IF oActuator.xDataReady THEN
0106
                   (* New target? *)
0107
                   IF wActuatorTarget <> wActuatorPosition THEN
0108
                       (* update target *)
0109
                       PCMD_WRITE();
0110
                       xActuatorReady := FALSE;
0111
                       oActuator.wState := 50;
0112
                  ELSE
0113
                       (* continue idling *)
0114
                       STATUS_READ();
0115
                       xActuatorReady := TRUE;
0116
                       oActuator.wState := 40;
0117
                  END_IF
0118
              END_IF
0119
0120
          50: (* STARTING: set new target position*)
0121
              PCMD_WRITE();
0122
              IF oActuator.xDataReady THEN
0123
                   (* started, now test for motion complete *)
0124
                   STATUS_READ();
0125
                   oActuator.wState := 60;
0126
              END_IF
0127
0128
          60: (* MOVING: wait until move is completed*)
0129
              STATUS_READ();
0130
              IF oActuator.xDataReady THEN
```

```
0131
                  (* wStatus & PEND ? *)
0132
                  IF oActuator.awStatus[5].3 THEN
0133
                     (* Move complete, goto IDLING *)
0134
                      uiSuccessful := uiSuccessful + 1;
0135
                      STATUS_READ();
0136
                     oActuator.wState := 40;
                  ELSE
0137
0138
                      (* Still moving, test again *)
0139
                      STATUS_READ();
0140
                     oActuator.wState := 60;
0141
                  END_IF
0142
              END_IF
0143
0144
          ELSE (* Should never get here *)
0145
             oActuator.xConnect := FALSE;
0146
              oActuator.wState := 10;
0147 END_CASE
CONNECT (ST)
0001 (* CONNECT *)
0002
      (* initiate TCP connection *)
0003
0004 (* Delay before initiating connection *)
     (*BEGDEBUG oActuator.tonConnect(IN := oActuator.xConnect, PT := DWORD_TO_TIME((BYTE_TO_DWORD(bID) * 100)));
0005
0006
     oActuator.tonConnect(IN := oActuator.xConnect, PT := t#100ms);
0007
0008 (* Connect *)
0009 oActuator.xSend := FALSE;
0010 oActuator.oMBMaster(
0011
          xCONNECT
                        := oActuator.tonConnect.O,
0012
          strIP_ADDRESS
                             := strAddress,
0013
          wPORT
                             := wPort,
0014
          bUNIT_ID
                         := bID,
0015
            bFUNCTION_CODE := 16#03,
                                              (*ReadHoldingCoils*)
0016
            wREAD_ADDRESS:= 16#9000,
0017
            wread_Quantity := 10,
            ptREAD_DATA
0018
                             := ADR(oActuator.awStatus[0]),
0019
          wWRITE_ADDRESS
                             := 0,
0020
          wWRITE OUANTITY
                             := 0,
0021
          ptSEND_DATA
                             := 0,
0022
          tTIME_OUT
                             := tTCP_Timeout,
0023
          tCON_WATCHDOG
                             := tTCP_Watchdog,
0024
          xSEND
                             := oActuator.xSend
0025
          );
0026
0027 (* Test for connection error *)
0028 IF oActuator.oMBMaster.wError <> 0 THEN
0029
          (* error, return to RESET *)
0030
          uiFailing := uiFailing + 1;
0031
          oActuator.xConnect := FALSE;
0032
          oActuator.wState := 10;
0033 END_IF
```



```
DRG1_WRITE (ST)
0001 (* DRG1_WRITE*)
0002 (* Write to DRG1 command register *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
        oActuator.xBusy := TRUE;
0007
        oActuator.xSend := TRUE;
0008 END_IF
0009
0010 (* set DRG1 command register *)
0011 oActuator.oMBMaster(
0012
        xCONNECT := oActuator.tonConnect.Q,
0013
         strIP_ADDRESS := strAddress,
0014
         wPORT
                           := wPort,
0015
         bUNIT_ID := bID,
0016
          bFUNCTION_CODE := 16#06,
                                          (*WriteSingleRegister*)
0017
           wread_address:= 0,
0018
           wread_Quantity := 0,
           ptREAD_DATA := 0,
IRITE ADDRESS := 16
0019
0020
                          := 16#0D00,
         wWRITE_ADDRESS
```

```
0021
         wWRITE OUANTITY
0022
         ptSEND DATA
                            := ADR(oActuator.wCommand),
0023
         tTIME_OUT
                            := tTCP_Timeout,
0024
         tCON_WATCHDOG
                           := tTCP_Watchdog,
0025
         xSEND
                             := oActuator.xSend
0026
         );
0027
0028 (* Test for transaction complete *)
0029 IF oActuator.oMBMaster.wError <> 0 THEN
0030
         (* error, return to INIT *)
0031
         uiFailing := uiFailing + 1;
0032
        oActuator.xConnect := FALSE;
0033
        oActuator.xBusy := FALSE;
0034
        oActuator.xDataReady := FALSE;
0035
        oActuator.wState := 10;
0036 ELSIF NOT oActuator.xSend THEN
0037
        oActuator.xBusy := FALSE;
0038
         oActuator.xDataReady := TRUE;
0039 ELSE
0040
     oActuator.xDataReady := FALSE;
0041 END_IF
PCMD_WRITE (ST)
0001 (* PCMD_WRITE *)
0002
     (* Write to PCMD target position register *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
         oActuator.wTarget := wActuatorTarget;
0007
         oActuator.xBusy := TRUE;
0008
         oActuator.xSend := TRUE;
0009 END_IF
0010
     (* set PCMD target position *)
0011
0012 oActuator.oMBMaster(
0013
         xCONNECT
                        := oActuator.tonConnect.Q,
0014
         strIP ADDRESS
                            := strAddress,
0015
         wPORT
                             := wPort,
0016
         bUNIT ID
                        := bID,
0017
           bFUNCTION_CODE := 16#06,
                                            (*WriteSingleRegister*)
0018
            wREAD\_ADDRESS := 0,
0019
           wREAD_QUANTITY := 0,
0020
            ptREAD_DATA
                           := 0,
0021
         wWRITE_ADDRESS
                            := 16#9901,
0022
         wWRITE_QUANTITY
                            := 1,
0023
         ptSEND_DATA
                            := ADR(oActuator.wTarget),
0024
         tTIME_OUT
                            := tTCP_Timeout,
0025
         tCON_WATCHDOG
                           := tTCP_Watchdog,
0026
         xSEND
                            := oActuator.xSend
0027
0028
0029 (* Test for transaction complete *)
0030 | IF oActuator.oMBMaster.wError <> 0 THEN
0031
         (* error, return to RESET *)
0032
         uiFailing := uiFailing + 1;
0033
         oActuator.xConnect := FALSE;
0034
         oActuator.xBusy := FALSE;
0035
        oActuator.xDataReady := FALSE;
0036
        oActuator.wState := 10;
0037 ELSIF NOT oActuator.xSend THEN
0038
       oActuator.xBusy := FALSE;
0039
         oActuator.xDataReady := TRUE;
0040
     ELSE
0041
         oActuator.xDataReady := FALSE;
0042 | END_IF
STATUS_READ (ST)
0001 (* STATUS_READ *)
0002
     (* read status registers PNOW thru STAT *)
0003
0004 (* check for start condition *)
0005 IF NOT oActuator.xBusy THEN
0006
         oActuator.xBusy := TRUE;
0007
         oActuator.xSend := TRUE;
```

```
lend_if
0008
0009
0010
     (* Get actuator status words *)
0011 oActuator.oMBMaster(
0012
         xCONNECT
                         := oActuator.tonConnect.Q,
0013
         strIP_ADDRESS
                             := strAddress,
0014
                             := wPort,
0015
         bUNIT_ID
                        := bID,
0016
           bFUNCTION_CODE := 16#03,
                                             (*ReadHoldingCoils*)
0017
            wREAD_ADDRESS:= 16#9000,
0018
            wREAD_QUANTITY := 10,
0019
            ptREAD_DATA
                            := ADR(oActuator.awStatus[0]),
0020
         wWRITE_ADDRESS
                            := 0,
0021
         wWRITE_QUANTITY
                            := 0,
0022
         ptSEND_DATA
                             := 0,
0023
         tTIME_OUT
                             := tTCP_Timeout,
0024
         tCON_WATCHDOG
                            := tTCP_Watchdog,
0025
         xSEND
                             := oActuator.xSend
0026
0027
0028 (* Test for transaction complete *)
0029 IF oActuator.oMBMaster.wError <> 0 THEN
0030
         (* error, return to RESET *)
0031
         uiFailing := uiFailing + 1;
0032
         oActuator.xConnect := FALSE;
0033
         oActuator.xBusy := FALSE;
0034
         oActuator.xDataReady := FALSE;
0035
         oActuator.wState := 10;
0036 ELSIF NOT oActuator.xSend THEN
0037
        wActuatorPosition := oActuator.awStatus[1];
0038
         wActuatorAlarm := oActuator.awStatus[2];
0039
         wActuatorStatus := oActuator.awStatus[5];
0040
         oActuator.xBusy := FALSE;
0041
         oActuator.xDataReady := TRUE;
0042 ELSE
0043
       oActuator.xDataReady := FALSE;
0044 | END_IF
PLC_PRG (PRG-ST)
0001 PROGRAM PLC_PRG
0002 VAR CONSTANT
0003
         (* Version control *)
0004
         cversion_major : word := 0;
                                         (* Version major index *)
0005
         cVERSION_MINOR : WORD := 1;
                                         (* Version minor index *)
0006
0007
         (* BR_SELECTOR indexes *)
0008
         cSINS01 : WORD := 1;
                                         (* SINS.1 branchline *)
0009
         cSINS02
                         : WORD := 2;
                                         (* SINS.2 branchline *)
0010
         cSINS03
                        : WORD := 3;
                                       (* SINS.3 branchline *)
0011
         cYAG
                         : WORD := 4;
                                       (* YAG screen *)
0012
         (* Actuator Limits *)
0013
0014
         cBR_SELECTOR_UL : WORD := 10000;
         cACTUATOR_TARGET: ARRAY [1..4] OF WORD := 0,9566,2500,7225;
0015
0016 END_VAR
0017
0018
     VAR
     (* ******* Supervisory Control ******* *)
0019
     (* PFC_OUT DISCRETES *)
0020
0021
     (* %MX0.0 .. %MX639.15
0022
         SC_RESET_REQUIRED AT %MX0.0:BOOL;
0023
          (* 1 SPARE *)
0024
         SC_ATB AT %MX0.2: BOOL := TRUE;
0025
         SC_AFB AT %MX0.3: BOOL := FALSE;
0026
          (* 4 SPARE *)
0027
0028
         SC_PE101_PSL AT %MX0.8:BOOL;
0029
         SC_PE201_PSL AT %MX0.9:BOOL;
0030
          SC_PE202_PSL AT %MX0.10:BOOL;
0031
          (* 1 SPARE *)
0032
0033
         SC_RP2110_AT_SPEED AT %MX0.12:BOOL;
0034
         SC_RP2111_AT_SPEED AT %MX0.13:BOOL;
0035
          SC_PE2110_PSL AT %MX0.14:BOOL;
```

```
0036
          SC_PE2111_PSL AT %MX0.15:BOOL;
0037
0038
          SC_PE203_OK AT %MX1.0:BOOL;
0039
          SC_PE203_PSL_HI AT %MX1.1:BOOL;
0040
          SC_PE203_PSL_MIDHI AT %MX1.2:BOOL;
0041
          SC_PE203_PSL_MIDLO AT %MX1.3:BOOL;
0042
          SC_PE203_PSL_LO AT %MX1.4:BOOL;
0043
          (* 3 SPARE *)
0044
0045
          SC_PE211_OK AT %MX1.8:BOOL;
0046
          SC_PE211_PSL_HI AT %MX1.9:BOOL;
0047
          SC_PE211_PSL_MIDHI AT %MX1.10:BOOL;
          SC_PE211_PSL_MIDLO AT %MX1.11:BOOL;
0048
          SC_PE211_PSL_LO AT %MX1.12:BOOL;
0049
0050
          (* 3 SPARE *)
0051
0052
          SC_PE212_OK AT %MX2.0:BOOL;
0053
          SC_PE212_PSL_HI AT %MX2.1:BOOL;
0054
          SC_PE212_PSL_MIDHI AT %MX2.2:BOOL;
0055
          SC_PE212_PSL_MIDLO AT %MX2.3:BOOL;
0056
          SC_PE212_PSL_LO AT %MX2.4:BOOL;
0057
          (* 3 SPARE *)
0058
0059
          SC_LL211_LID_CLOSED AT %MX2.8:BOOL;
0060
          SC_LL211_ARM_RETRACTED AT %MX2.9:BOOL;
0061
          (* 6 SPARE *)
0062
          SC_V100_OPEN AT %MX3.0:BOOL;
0063
          SC_V100_CLOSED AT %MX3.1:BOOL;
0064
          (* 6 SPARE *)
0065
0066
          SC_V101_BEAM_PASS AT %MX3.8:BOOL;
0067
          SC_V101_OPEN AT %MX3.9:BOOL;
0068
0069
          SC_V101_CLOSED AT %MX3.10:BOOL;
          SC_V101_OPEN_PERMIT AT %MX3.11:BOOL;
0070
0071
          SC_V101_CLOSE_PERMIT AT %MX3.12:BOOL;
          SC_V101_OPEN_CMD AT %MX3.13:BOOL;
0072
0073
          SC_V101_NOT_SYMBOL AT %MX3.14:BOOL;
0074
          (* 1 SPARE *)
0075
0076
          SC_V201_BEAM_PASS AT %MX4.0 : BOOL;
          SC_V201_OPEN AT %MX4.1 : BOOL;
0077
0078
          SC_V201_CLOSED AT %MX4.2 : BOOL;
0079
          SC_V201_OPEN_PERMIT AT %MX4.3 : BOOL;
0800
          SC_V201_CLOSE_PERMIT AT %MX4.4 : BOOL;
0081
          SC_V201_OPEN_CMD AT %MX4.5 : BOOL;
0082
          SC_V201_NOT_SYMBOL AT %MX4.6:BOOL;
0083
          (* 1 SPARE *)
0084
0085
          SC_V202_OPEN AT %MX4.8 : BOOL;
0086
          SC_V202_CLOSED AT %MX4.9 : BOOL;
0087
          SC_V202_BEAM_PASS AT %MX4.10 : BOOL;
0088
          (* 5 SPARE *)
0089
0090
          SC_V203_BEAM_PASS AT %MX5.0 : BOOL;
0091
          SC_V203_OPEN AT %MX5.1 : BOOL;
          SC_V203_CLOSED AT %MX5.2 : BOOL;
0092
          SC_V203_OPEN_PERMIT AT %MX5.3 : BOOL;
0093
          SC_V203_CLOSE_PERMIT AT %MX5.4 : BOOL;
0094
          SC_V203_OPEN_CMD AT %MX5.5 : BOOL;
0095
0096
          SC_V203_NOT_SYMBOL AT %MX5.6:BOOL;
0097
          (* 1 SPARE *)
0098
0099
          SC_V204_BEAM_PASS AT %MX5.8 : BOOL;
0100
          SC_V204_OPEN AT %MX5.9 : BOOL;
0101
          SC_V204_CLOSED AT %MX5.10 : BOOL;
0102
          SC_V204_OPEN_PERMIT AT %MX5.11 : BOOL;
0103
          SC_V204_CLOSE_PERMIT AT %MX5.12 : BOOL;
          SC_V204_OPEN_CMD AT %MX5.13 : BOOL;
0104
0105
          SC_V204_NOT_SYMBOL AT %MX5.14:BOOL;
0106
          (* 1 SPARE *)
0107
          (* 1 SPARE *)
0108
```

```
0109
          SC_RPV211_OPEN AT %MX6.1 : BOOL;
0110
          SC_RPV211_CLOSED AT %MX6.2 : BOOL;
0111
          (* 2 SPARE *)
0112
          SC_RPV211_OPEN_CMD AT %MX6.5 : BOOL;
0113
          (* 2 SPARE *)
0114
0115
          (* 3 SPARE *)
0116
          SC_VENT211_SLOW_CMD AT %MX6.11 : BOOL;
0117
          SC_VENT211_FAST_CMD AT %MX6.12 : BOOL;
0118
          (* 3 SPARE *)
0119
0120
          (* 1 SPARE *)
          SC_TPV211_OPEN AT %MX7.1 : BOOL;
0121
          SC_TPV211_CLOSED AT %MX7.2 : BOOL;
0122
0123
          (* 2 SPARE *)
0124
          SC_TPV211_OPEN_CMD AT %MX7.5 : BOOL;
0125
          (* 2 SPARE *)
0126
0127
          (* 1 SPARE *)
0128
          SC_SLOTV211_OPEN AT %MX7.9 : BOOL;
0129
          SC_SLOTV211_CLOSED AT %MX7.10 : BOOL;
0130
          SC_SLOTV211_OPEN_PERMIT AT %MX7.11 : BOOL;
0131
          SC_SLOTV211_CLOSE_PERMIT AT %MX7.12 : BOOL;
0132
          SC_SLOTV211_OPEN_CMD AT %MX7.13 : BOOL;
0133
          SC_SLOTV211_CLOSE_CMD AT %MX7.14 : BOOL;
0134
          SC_SLOTV211_NOT_SYMBOL AT %MX7.15:BOOL;
0135
0136
          (* 1 SPARE *)
0137
          SC_RPV212_OPEN AT %MX8.1 : BOOL;
0138
          SC_RPV212_CLOSED AT %MX8.2 : BOOL;
0139
          (* 2 SPARE *)
0140
          SC_RPV212_OPEN_CMD AT %MX8.5 : BOOL;
0141
          (* 2 SPARE *)
0142
          (* 3 SPARE *)
0143
0144
          SC_VENT212_SLOW_CMD AT %MX8.11 : BOOL;
          SC_VENT212_FAST_CMD AT %MX8.12 : BOOL;
0145
          (* 3 SPARE *)
0146
0147
0148
          (* 1 SPARE *)
0149
          SC_TPV212_OPEN AT %MX9.1 : BOOL;
          SC_TPV212_CLOSED AT %MX9.2 : BOOL;
0150
0151
          (* 2 SPARE *)
          SC_TPV212_OPEN_CMD AT %MX9.5 : BOOL;
0152
0153
          (* 2 SPARE *)
0154
0155
          SC_RP2110_ON AT %MX9.8 : BOOL;
0156
          SC_RP2110_ON_CMD AT %MX9.9 : BOOL;
0157
          (* 6 SPARE *)
0158
0159
          SC_RP2111_ON AT %MX10.0 : BOOL;
0160
          SC_RP2111_ON_CMD AT %MX10.1 : BOOL;
0161
          (* 3 SPARE *)
0162
          SC_TP201_VENT_ENABLE_CMD AT %MX10.5 : BOOL;
0163
          SC_TP201_VENT_NOT_SYMBOL AT %MX10.6 : BOOL;
0164
          (* 1 SPARE *)
0165
          SC_TP201_OK AT %MX10.8 : BOOL;
0166
          SC_TP201_ON AT %MX10.9 : BOOL;
0167
          SC_TP201_OFF AT %MX10.10 : BOOL;
0168
0169
          SC_TP201_ON_PERMIT AT %MX10.11 : BOOL;
          SC_TP201_OFF_PERMIT AT %MX10.12 : BOOL;
0170
          SC_TP201_ON_CMD AT %MX10.13 : BOOL;
0171
0172
          SC_TP201_NOT_SYMBOL AT %MX10.14:BOOL;
0173
          (* 1 SPARE *)
0174
0175
          SC_TP211_OK AT %MX11.0 : BOOL;
0176
          SC_TP211_ON AT %MX11.1 : BOOL;
          SC_TP211_OFF AT %MX11.2 : BOOL;
0177
0178
          (* 5 SPARE *)
0179
          SC_TP212_OK AT %MX11.8 : BOOL;
0180
          SC_TP212_ON AT %MX11.9 : BOOL;
0181
```

```
0182
          SC_TP212_OFF AT %MX11.10 : BOOL;
0183
          (* 5 SPARE *)
0184
0185
          SC_LL_ACTUATOR_OK AT %MX12.0 : BOOL;
0186
          SC_LL_PE101_PSL AT %MX12.1 : BOOL;
0187
          SC_LL_PE201_PSL AT %MX12.2 : BOOL;
0188
          SC_LL_V202_OPN AT %MX12.3 : BOOL;
0189
          SC_LL_PE202_PSL AT %MX12.4 : BOOL;
0190
          SC_LL_PE203_OK AT %MX12.5 : BOOL;
0191
          SC_LL_PE203_PSL_LO AT %MX12.6 : BOOL;
0192
          SC_LL_TP201_OK AT %MX12.7 : BOOL;
0193
          (* 8 SPARE *)
0194
          SC_LL_ES_CONFIG_OK AT %MX13.0 : BOOL;
0195
0196
          SC_LL_LL_CONFIG_OK AT %MX13.1 : BOOL;
0197
          SC_LL_PE211_OK AT %MX13.2 : BOOL;
0198
          SC_LL_PE212_OK AT %MX13.3 : BOOL;
0199
          SC_LL_RP2111_ON AT %MX13.4 : BOOL;
0200
          SC_LL_PE2111_PSL AT %MX13.5 : BOOL;
0201
          SC_LL_TP211_TURBO_OK AT %MX13.6 : BOOL;
0202
          SC_LL_TP212_TURBO_OK AT %MX13.7 : BOOL;
0203
          SC_LL_PE2111_PSL_ES AT %MX13.8 : BOOL;
0204
          SC_LL_PE2111_PSL_LL AT %MX13.9 : BOOL;
0205
          (* 6 SPARE *)
0206
0207
      (* PFC_IN DISCRETES
                                   *)
0208
      (* %MX640.0 .. %MX1279.15
                                   *)
          SC_RESET_REQ AT %MX640.0 : BOOL;
0209
          (* 15 SPARE *)
0210
0211
0212
          SC_V101_OPN_REQ AT %MX641.0 : BOOL;
          SC_V101_CLS_REQ AT %MX641.1 : BOOL;
0213
0214
          SC_V201_OPN_REQ AT %MX641.2 : BOOL;
0215
          SC_V201_CLS_REQ AT %MX641.3 : BOOL;
0216
          (* 2 RESERVED *)
          SC_V203_OPN_REQ AT %MX641.6 : BOOL;
0217
          SC_V203_CLS_REQ AT %MX641.7 : BOOL;
0218
          SC_V204_OPN_REQ AT %MX641.8 : BOOL;
0219
0220
          SC_V204_CLS_REQ AT %MX641.9 : BOOL;
0221
          SC_TP201_ON_REQ AT %MX641.10 : BOOL;
          SC_TP201_OFF_REQ AT %MX641.11 : BOOL;
0222
          SC_TP201_VENT_ENABLE_REQ AT %MX641.12 : BOOL;
0223
0224
          SC_TP201_VENT_DISABLE_REQ AT %MX641.13 : BOOL;
          (* 2 SPARE *)
0225
0226
0227
          SC_SLOTV211_OPN_REQ AT %MX642.0 : BOOL;
0228
          SC_SLOTV211_CLS_REQ AT %MX642.1 : BOOL;
0229
          (* 14 SPARE *)
0230
0231
      (* PFC_OUT WORDs
                           *)
0232
      (* %MW1280 .. %MW3711
                              *)
0233
          (* Version Numbers *)
0234
          SC_VERSION_MAJOR AT %MW1280 : WORD;
0235
          SC_VERSION_MINOR AT %MW1281 : WORD;
          (* 2 RESERVED *)
0236
0237
0238
          (* Analog vacuum pressure *)
          SC_PE101_PIY AT %MW1284 : WORD;
0239
          SC_PE201_PIY AT %MW1285 : WORD;
0240
          SC_PE202_PIY AT %MW1286 : WORD;
0241
0242
          SC_PE203_HI_PIY AT %MW1287 : WORD;
          SC_PE203_LO_PIY AT %MW1288 : WORD;
0243
0244
          SC_PE211_HI_PIY AT %MW1289 : WORD;
0245
          SC_PE211_LO_PIY AT %MW1290 : WORD;
0246
          SC_PE212_HI_PIY AT %MW1291 : WORD;
0247
          SC_PE212_LO_PIY AT %MW1292 : WORD;
0248
          (* 3 SPARE *)
0249
0250
          (* State Machine current command values *)
0251
          SC_BR_CMD_VAL AT %MW1296 : WORD;
0252
          SC_ES_CMD_VAL AT %MW1297 : WORD;
0253
          SC_LL_CMD_VAL AT %MW1298 : WORD;
0254
          (* 5 SPARE *)
```

```
0255
0256
          (* State Machine current values *)
0257
          SC_BR_STATE AT %MW1304 : WORD;
          SC_ES_STATE AT %MW1305 : WORD;
0258
0259
          SC_LL_STATE AT %MW1306 : WORD;
0260
          (* 5 SPARE *)
0261
0262
      (* PFC_IN WORDs
0263
0264
      (* %MW3712 .. %MW4927 *)
0265
          (* State Machine current command requests *)
          SC_BR_CMD_REQ AT %MW3712 : WORD;
0266
          SC_ES_CMD_REQ AT %MW3713 : WORD;
0267
          SC_LL_CMD_REQ AT %MW3714 : WORD;
0268
0269
          (* 5 SPARE *)
0270
0271
0272
0273
      (* ***** Internal Variables ***** *)
0274
          count : BYTE;
0275
          count2 : BYTE;
0276
          a_num : BYTE;
0277
0278
          (* Request to reset latched faults *)
0279
          RESET_REQ : BOOL;
0280
0281
          (* Vacuum Interlocks *)
0282
          PE101_PSL_LO: BOOL;
0283
          PE201_PSL_LO: BOOL;
0284
          PE202_PSL_LO: BOOL;
          PE203_PIY_OK: BOOL;
0285
0286
          PE203_PSH_HI: BOOL;
          PE203_PSH_MIDHI: BOOL;
0287
          PE203_PSL_MIDLO: BOOL;
0288
          PE203_PSL_LO: BOOL;
0289
0290
          PE211_PIY_OK: BOOL;
0291
          PE211_PSH_HI: BOOL;
0292
          PE211_PSH_MIDHI: BOOL;
0293
          PE211_PSL_MIDLO: BOOL;
          PE211_PSL_LO: BOOL;
0294
0295
          PE212_PIY_OK: BOOL;
0296
          PE212_PSH_HI: BOOL;
0297
          PE212_PSH_MIDHI: BOOL;
0298
          PE212_PSL_MIDLO: BOOL;
0299
          PE212_PSL_LO: BOOL;
0300
          RP211_PSL: BOOL;
0301
          BP211_PSL: BOOL;
0302
0303
          (* Valve Positions *)
0304
          V100_OPN: BOOL;
          V100_CSD: BOOL;
0305
0306
          V101_OPN: BOOL;
          V101_CSD: BOOL;
0307
0308
          V201_OPN: BOOL;
          V201_CSD: BOOL;
0309
0310
          V202_OPN: BOOL;
          V202_CSD: BOOL;
0311
0312
          V203_OPN: BOOL;
0313
          V203_CSD: BOOL;
0314
          V204_OPN: BOOL;
0315
          V204_CSD: BOOL;
0316
          VPV211_OPN: BOOL;
0317
          VPV211_CSD: BOOL;
0318
          RPV211_OPN: BOOL;
0319
          RPV211_CSD: BOOL;
0320
          TPV211_OPN: BOOL;
          TPV211_CSD: BOOL;
0321
          LLV211_OPN: BOOL;
0322
          LLV211_CSD: BOOL;
0323
          VPV212_OPN: BOOL;
0324
0325
          VPV212_CSD: BOOL;
0326
          RPV212_OPN: BOOL;
0327
          RPV212_CSD: BOOL;
```

```
0328
          TPV212_OPN: BOOL;
0329
          TPV212_CSD: BOOL;
0330
0331
          (* Pump Status *)
0332
          TP201_OK: BOOL;
0333
          TP201_ON: BOOL;
0334
          TP201_READY: BOOL;
0335
          TP211_OK: BOOL;
0336
          TP211_READY: BOOL;
0337
          TP212_OK: BOOL;
0338
          TP212_READY: BOOL;
          RP211_ON: BOOL;
0339
          BP211_ON: BOOL;
0340
0341
0342
          (* LoadLock Status *)
0343
          LL211_LID_CLOSED: BOOL;
0344
          LL211_ARM_RETRACTED: BOOL;
0345
0346
          (* Configuration Interlocks *)
0347
          ES_CONFIG_OK: BOOL;
0348
          LL_CONFIG_OK: BOOL;
0349
0350
          (* Latched Interlocks *)
0351
          LL_ACTUATOR_OK: BOOL;
          LL_PE101_PSL_LO: BOOL;
0352
0353
          LL_PE201_PSL_LO: BOOL;
0354
          LL_V202_OPN: BOOL;
0355
          LL_PE202_PSL_LO: BOOL;
0356
          LL_PE203_PIY_OK: BOOL;
0357
          LL_PE203_PSL_LO: BOOL;
0358
          LL_TP201_OK: BOOL;
0359
          LL_ES_CONFIG_OK: BOOL;
0360
          LL_LL_CONFIG_OK: BOOL;
          LL_PE211_PIY_OK: BOOL;
0361
          LL_PE212_PIY_OK: BOOL;
0362
0363
          LL_BP211_ON: BOOL;
          LL_TP211_OK: BOOL;
0364
0365
          LL_TP212_OK: BOOL;
0366
0367
          Reset_Required: BOOL;
0368
0369
          (* IAI Actuator Data and Commands *)
0370
          ACTUATOR_AT_TARGET: WORD;
0371
          ACTUATOR_CMD: WORD;
0372
          ACTUATOR_OK: BOOL;
0373
0374
          (* Valve and Pump requests *)
0375
          V101_OPN_REQ_SC: BOOL;
0376
          V101_CLS_REQ_SC: BOOL;
0377
          V201_OPN_REQ_SC: BOOL;
0378
          V201_CLS_REQ_SC: BOOL;
0379
          V203_OPN_REQ_SC: BOOL;
0380
          V203_CLS_REQ_SC: BOOL;
0381
          V204_OPN_REQ_SC: BOOL;
0382
          V204_CLS_REQ_SC: BOOL;
0383
          V204_CLS_REQ_ES: BOOL;
          VPV211_SLOW_OPN_REQ_ES: BOOL;
0384
          VPV211_SLOW_CLS_REQ_ES: BOOL;
0385
          VPV211_FAST_OPN_REQ_ES: BOOL;
0386
          VPV211_FAST_CLS_REQ_ES: BOOL;
0387
0388
          RPV211_OPN_REQ_ES: BOOL;
0389
          RPV211_CLS_REQ_ES: BOOL;
0390
          TPV211_OPN_REQ_ES: BOOL;
0391
          TPV211_CLS_REQ_ES: BOOL;
0392
          LLV211_OPN_REQ_SC: BOOL;
0393
          LLV211_CLS_REQ_SC: BOOL;
0394
          LLV211_CLS_REQ_ES: BOOL;
0395
          LLV211_CLS_REQ_LL: BOOL;
0396
          VPV212_SLOW_OPN_REQ_LL: BOOL;
0397
          VPV212_SLOW_CLS_REQ_LL: BOOL;
0398
          VPV212_FAST_OPN_REQ_LL: BOOL;
0399
          VPV212_FAST_CLS_REQ_LL: BOOL;
0400
          RPV212_OPN_REQ_LL: BOOL;
```

```
0401
          RPV212_CLS_REQ_LL: BOOL;
0402
          TPV212 OPN REO LL: BOOL:
0403
          TPV212_CLS_REQ_LL: BOOL;
0404
0405
          TP201_ON_REQ_SC: BOOL;
0406
          TP201_OFF_REQ_SC: BOOL;
0407
          TP201_VENT_ENABLE_REQ_SC: BOOL;
          TP201_VENT_DISABLE_REQ_SC: BOOL;
0408
0409
0410
          RP211_ON_REQ_ES: BOOL;
0411
          RP211_ON_REQ_LL: BOOL;
0412
          TP211_ON_REQ_ES: BOOL;
0413
          TP211_OFF_REQ_ES: BOOL;
0414
          TP212_ON_REQ_LL: BOOL;
0415
          TP212_OFF_REQ_LL: BOOL;
0416
0417
          (* State Machine States and Controls*)
0418
          BR_STATE: BR_ST := BR_ERROR;
0419
          BR_REQUEST: BR_REQ := BR_NONE_REQ;
0420
          ES_STATE: PV_ST := PV_ERROR;
0421
          ES_REQUEST: PV_REQ := PV_NONE_REQ;
          LL_STATE: PV_ST := PV_ERROR;
0422
0423
          LL_REQUEST: PV_REQ := PV_NONE_REQ;
0424
0425
          (* Valves *)
0426
          V101: VALVE_FB;
0427
          V201: VALVE_FB;
0428
          V203: VALVE_FB;
0429
          V204: VALVE_FB;
0430
0431
          VPV201: VALVE_FB;
0432
          VPV211_SLOW: VALVE_FB;
          VPV211_FAST: VALVE_FB;
0433
          RPV211: VALVE_FB;
0434
          TPV211: VALVE_FB;
0435
0436
0437
          LLV211: VALVE_BI_FB;
0438
0439
          VPV212_SLOW: VALVE_FB;
0440
          VPV212_FAST: VALVE_FB;
0441
          RPV212: VALVE_FB;
0442
          TPV212: VALVE_FB;
0443
0444
          (* Pumps *)
0445
          TP201: TP_FB;
0446
0447
          RP211: RP_FB;
0448
          BP211_ON_CMD: BOOL := TRUE; (* always on *)
0449
0450
          TP211: TP_FB;
0451
          TP212: TP_FB;
0452
      END_VAR
0453
0001
      (* Evaluate Inputs *)
0002
      Process_Inputs();
0003
     SC_Inputs();
0004
     Actuator_Inputs();
0005
0006
      (* Temporary interlock bypasses *)
0007
     Bypasses();
8000
0009
      (* Internal logic *)
0010
     Fault_Logic();
0011
0012
     BR_SM();
0013
      ES_SM();
0014
      LL_SM();
0015
0016
                  (* must go before Valves() *)
     Pumps();
0017
      Valves();
0018
0019
      (* Evaluate Outputs *)
0020 Actuator_Outputs();
```

```
0021
      SC_Outputs();
0022
      Process_Outputs();
0023
0024
      (* Clear rising edge requests *)
0025 Clear_Reqs();
Actuator_Inputs (ST)
0001 (* Process Actuator Inputs *)
0002
     ACTUATOR_OK := NOT (wActuatorStatus.10 OR wActuatorStatus.12);
0003
0004
0005
      IF (xActuatorReady) THEN
0006
          FOR count2:=1 TO 4 DO
0007
              IF (wActuatorPosition = cACTUATOR_TARGET[count2]) THEN
0008
                  ACTUATOR_AT_TARGET := count2;
0009
                  EXIT:
0010
              END_IF;
0011
          END_FOR;
0012
     ELSE
0013
          ACTUATOR_AT_TARGET := 0;
0014 END_IF;
Actuator_Outputs (ST)
0001
     (* IAI Actuator Outputs *)
0002
0003
      IF ACTUATOR_CMD <> 0 THEN
0004
          wActuatorTarget := cACTUATOR_TARGET[ACTUATOR_CMD] ;
0005
     END_IF
BR_SM (ST)
0001
      (* State Machine for BRanchline selection *)
0002
0003
      (* Always test for BR_ERROR first *)
0004
      IF NOT LL_ACTUATOR_OK THEN
0005
          BR_STATE := BR_ERROR;
0006
     END_IF
0007
0008
      CASE BR_STATE OF
0009
          BR_ERROR:
0010
              (* Leave in place *)
0011
              ACTUATOR_CMD := 0;
0012
0013
              IF LL_ACTUATOR_OK THEN
0014
                  BR_STATE := BR_SINS1_SELECTING;
0015
              END_IF
0016
0017
          BR_SINS1_SELECTING:
0018
              (* Move actuator to SINS.1 *)
0019
              ACTUATOR_CMD := cSINS01;
0020
0021
              (* Wait for motion to complete *)
0022
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0023
                  BR_STATE := BR_SINS1_READY;
0024
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0025
                  BR_STATE := BR_SINS1_SELECTING;
0026
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0027
                  BR_STATE := BR_SINS2_SELECTING;
0028
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0029
                  BR_STATE := BR_SINS3_SELECTING;
0030
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0031
                  BR_STATE := BR_YAG_SELECTING;
0032
              END_IF
0033
0034
          BR_SINS1_READY:
0035
              (* Keep at SINS.1 *)
0036
              ACTUATOR_CMD := cSINS01;
0037
0038
               (* Look for state change request *)
0039
              IF BR_REQUEST = BR_NONE_REQ THEN
0040
                  BR_STATE := BR_SINS1_READY;
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0041
0042
                  BR_STATE := BR_SINS1_READY;
0043
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0044
                  BR_STATE := BR_SINS2_SELECTING;
```

```
0045
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0046
                  BR STATE := BR SINS3 SELECTING:
0047
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0048
                  BR_STATE := BR_YAG_SELECTING;
0049
              END_IF
0050
0051
          BR_SINS2_SELECTING:
0052
              (* Move actuator to SINS.2 *)
              ACTUATOR_CMD := cSINS02;
0053
0054
0055
              (* Wait for motion to complete *)
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0056
0057
                  BR_STATE := BR_SINS2_READY;
0058
              (* Else look for state change request *)
0059
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0060
                  BR_STATE := BR_SINS1_SELECTING;
0061
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0062
                  BR_STATE := BR_SINS2_SELECTING;
0063
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0064
                  BR_STATE := BR_SINS3_SELECTING;
0065
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0066
                  BR_STATE := BR_YAG_SELECTING;
0067
              END_IF
0068
0069
          BR_SINS2_READY:
0070
              (* Keep at SINS.2 *)
0071
              ACTUATOR_CMD := cSINS02;
0072
0073
              (* Look for state change request *)
0074
              IF BR_REQUEST = BR_NONE_REQ THEN
                  BR_STATE := BR_SINS2_READY;
0075
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0076
                  BR_STATE := BR_SINS1_SELECTING;
0077
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0078
0079
                  BR_STATE := BR_SINS2_READY;
0080
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0081
                  BR_STATE := BR_SINS3_SELECTING;
0082
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0083
                  BR_STATE := BR_YAG_SELECTING;
0084
              END_IF
0085
0086
0087
          BR_SINS3_SELECTING:
0088
              (* Move actuator to SINS.3 *)
0089
              ACTUATOR_CMD := cSINS03;
0090
0091
              (* Wait for motion to complete *)
0092
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
0093
                  BR_STATE := BR_SINS3_READY;
0094
              (* Else look for state change request *)
0095
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
                  BR_STATE := BR_SINS1_SELECTING;
0096
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0097
0098
                  BR_STATE := BR_SINS2_SELECTING;
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0099
0100
                  BR_STATE := BR_SINS3_SELECTING;
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0101
0102
                  BR_STATE := BR_YAG_SELECTING;
0103
              END_IF
0104
0105
          BR_SINS3_READY:
0106
              (* Keep at SINS.3 *)
0107
              ACTUATOR_CMD := cSINS03;
0108
0109
              (* Look for state change request *)
0110
              IF BR_REQUEST = BR_NONE_REQ THEN
0111
                  BR_STATE := BR_SINS3_READY;
0112
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0113
                  BR_STATE := BR_SINS1_SELECTING;
0114
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0115
                  BR_STATE := BR_SINS2_SELECTING;
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0116
0117
                  BR_STATE := BR_SINS3_READY;
```

```
0118
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0119
                  BR_STATE := BR_YAG_SELECTING;
0120
              END_IF
0121
0122
0123
          BR_YAG_SELECTING:
0124
              (* Move actuator to YAG *)
              ACTUATOR_CMD := cYAG;
0125
0126
0127
              (* Wait for motion to complete *)
0128
              IF ACTUATOR_AT_TARGET = ACTUATOR_CMD THEN
                  BR_STATE := BR_YAG_READY;
0129
0130
              (* Else look for state change request *)
0131
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0132
                  BR_STATE := BR_SINS1_SELECTING;
0133
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
0134
                  BR_STATE := BR_SINS2_SELECTING;
0135
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0136
                  BR_STATE := BR_SINS3_SELECTING;
0137
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0138
                  BR_STATE := BR_YAG_SELECTING;
0139
              END_IF
0140
0141
          BR_YAG_READY:
0142
              (* Keep at YAG *)
0143
              ACTUATOR_CMD := cYAG;
0144
0145
              (* Look for state change request *)
0146
              IF BR_REQUEST = BR_NONE_REQ THEN
0147
                  BR_STATE := BR_YAG_READY;
0148
              ELSIF BR_REQUEST = BR_SINS1_REQ THEN
0149
                  BR_STATE := BR_SINS1_SELECTING;
0150
              ELSIF BR_REQUEST = BR_SINS2_REQ THEN
                  BR_STATE := BR_SINS2_SELECTING;
0151
0152
              ELSIF BR_REQUEST = BR_SINS3_REQ THEN
0153
                  BR_STATE := BR_SINS3_SELECTING;
0154
              ELSIF BR_REQUEST = BR_YAG_REQ THEN
0155
                  BR_STATE := BR_YAG_READY;
0156
              END_IF
0157
0158
          ELSE
0159
              BR_STATE := BR_ERROR;
0160 END_CASE;
Bypasses (ST)
0001 (* Temporary Bypass Logic *)
0002
          (* Will remove this after initial testing *)
0003
          ACTUATOR_OK := TRUE;
0004
          ES_CONFIG_OK := TRUE;
0005
          LL_CONFIG_OK := TRUE;
0006
0007
          (* For testing during DP repair *)
0008
          V100\_OPN := TRUE;
0009
          V100_CSD := FALSE;
0010
0011
          V101_OPN := TRUE;
0012
          V101_CSD := FALSE;
0013
0014
          V201_OPN := TRUE;
0015
          V201_CSD := FALSE;
0016
0017
          V202_OPN := FALSE;
0018
          V202_CSD := TRUE;
0019
0020
          V203\_OPN := FALSE;
          V203_CSD := TRUE;
0021
Clear_Regs (ST)
0001
      (* Clear all edge-triggered supervisory requests *)
0002
0003
      SC_RESET_REQ := 0;
0004
0005
     SC_V101_OPN_REQ := 0;
0006 | SC_V101_CLS_REQ := 0;
```

```
0007
0008
      SC_V201_OPN_REQ := 0;
0009
      SC_V201_CLS_REQ := 0;
0010
0011
      SC_V203_OPN_REQ := 0;
0012
      SC_V203_CLS_REQ := 0;
0013
0014
      SC_V204_OPN_REQ := 0;
0015
      SC_V204_CLS_REQ := 0;
0016
0017
      SC_TP201_ON_REQ := 0;
      SC_TP201_OFF_REQ := 0;
0018
0019
      SC_TP201_VENT_ENABLE_REQ := 0;
0020
      SC_TP201_VENT_DISABLE_REQ := 0;
0021
0022
      SC_SLOTV211_OPN_REQ := 0;
0023 | SC_SLOTV211_CLS_REQ := 0;
ES_SM (ST)
0001
      (* ES211 Pump/Vent State Machine *)
0002
      (* Always test for PV_ERROR first *)
0003
0004
      IF NOT (LL_PE211_PIY_OK AND LL_ES_CONFIG_OK) THEN
0005
          ES_STATE := PV_ERROR;
0006
      END_IF
0007
0008
      CASE ES_STATE OF
0009
          PV_ERROR:
0010
              V204_CLS_REQ_ES := TRUE;
0011
              LLV211_CLS_REQ_ES := TRUE;
              RPV211_OPN_REQ_ES := FALSE;
0012
0013
              RP211_ON_REQ_ES := FALSE;
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0014
0015
              VPV211_FAST_OPN_REQ_ES := FALSE;
0016
              TPV211_OPN_REQ_ES := FALSE;
0017
              TP211_ON_REQ_ES := FALSE;
0018
0019
              IF LL_PE211_PIY_OK THEN
0020
                  ES_STATE := PV_ISOLATING;
0021
              END_IF
0022
0023
          PV_ISOLATING:
0024
              V204_CLS_REQ_ES := TRUE;
0025
              LLV211_CLS_REQ_ES := TRUE;
0026
              RPV211_OPN_REQ_ES := FALSE;
0027
              RP211_ON_REQ_ES := FALSE;
0028
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0029
              VPV211_FAST_OPN_REQ_ES := FALSE;
0030
              TPV211_OPN_REQ_ES := FALSE;
0031
              TP211_ON_REQ_ES := FALSE;
0032
              IF V204_CSD AND LLV211_CSD AND RPV211_CSD THEN
0033
0034
                  ES_STATE := PV_ISOLATED;
0035
              END_IF
0036
0037
          PV_ISOLATED:
0038
              V204_CLS_REQ_ES := TRUE;
0039
              LLV211_CLS_REQ_ES := TRUE;
0040
              RPV211_OPN_REQ_ES := FALSE;
0041
              RP211_ON_REQ_ES := FALSE;
0042
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0043
              VPV211_FAST_OPN_REQ_ES := FALSE;
0044
              TPV211_OPN_REQ_ES := FALSE;
0045
              TP211_ON_REQ_ES := FALSE;
0046
0047
              IF (ES_REQUEST = PV_VENT_REQ) THEN
0048
                  ES_STATE := PV_SLOW_VENTING;
0049
              ELSIF (ES_REQUEST = PV_PUMP_REQ) AND PE211_PSL_MIDLO AND TP211_OK THEN
0050
                  ES_STATE := PV_TP_PUMPING;
0051
              ELSIF (ES_REQUEST = PV_PUMP_REQ) THEN
0052
                  ES_STATE := PV_RP_STARTING;
0053
              END_IF
0054
0055
          PV_SLOW_VENTING:
```

```
0056
              V204_CLS_REQ_ES := TRUE;
0057
              LLV211 CLS REO ES := TRUE;
0058
              RPV211_OPN_REQ_ES := FALSE;
0059
              RP211_ON_REQ_ES := FALSE;
0060
              VPV211_SLOW_OPN_REQ_ES := TRUE;
0061
              VPV211_FAST_OPN_REQ_ES := FALSE;
0062
              TPV211_OPN_REQ_ES := FALSE;
0063
              TP211_ON_REQ_ES := FALSE;
0064
0065
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0066
                  ES_STATE := PV_SLOW_VENTING;
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0067
                  ES_STATE := PV_ISOLATING;
0068
              ELSIF (PE211_PSH_MIDHI) THEN
0069
0070
                  ES_STATE := PV_FAST_VENTING;
0071
              END IF
0072
0073
          PV_FAST_VENTING:
0074
              V204_CLS_REQ_ES := TRUE;
0075
              LLV211_CLS_REQ_ES := TRUE;
0076
              RPV211_OPN_REQ_ES := FALSE;
              RP211_ON_REQ_ES := FALSE;
0077
0078
              VPV211_SLOW_OPN_REQ_ES := TRUE;
0079
              VPV211_FAST_OPN_REQ_ES := TRUE;
              TPV211_OPN_REQ_ES := FALSE;
0080
0081
              TP211_ON_REQ_ES := FALSE;
0082
0083
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0084
                  ES_STATE := PV_FAST_VENTING;
0085
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0086
                  ES_STATE := PV_ISOLATING;
0087
              ELSIF (PE211_PSH_HI) THEN
8800
                  ES_STATE := PV_VENTED;
0089
              END_IF
0090
0091
          PV_VENTED:
0092
              V204_CLS_REQ_ES := TRUE;
0093
              LLV211_CLS_REQ_ES := FALSE; (* LLV211 can be opened when both ES211 and LL211 are vented *)
              RPV211_OPN_REQ_ES := FALSE;
0094
0095
              RP211_ON_REQ_ES := FALSE;
0096
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0097
              VPV211_FAST_OPN_REQ_ES := FALSE;
0098
              TPV211_OPN_REQ_ES := FALSE;
0099
              TP211_ON_REQ_ES := FALSE;
0100
0101
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0102
                  ES_STATE := PV_VENTED;
0103
              ELSIF NOT (ES_REQUEST = PV_VENT_REQ) THEN
0104
                  ES_STATE := PV_ISOLATING;
0105
              ELSIF (NOT PE211_PSH_HI) THEN
0106
                  ES_STATE := PV_FAST_VENTING;
0107
              END_IF
0108
0109
          PV_RP_STARTING:
0110
              V204_CLS_REQ_ES := TRUE;
0111
              LLV211_CLS_REQ_ES := TRUE;
              RPV211_OPN_REQ_ES := FALSE;
0112
              RP211_ON_REQ_ES := TRUE;
0113
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0114
0115
              VPV211_FAST_OPN_REQ_ES := FALSE;
0116
              TPV211_OPN_REQ_ES := FALSE;
0117
              TP211_ON_REQ_ES := FALSE;
0118
0119
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0120
                  ES_STATE := PV_RP_STARTING;
0121
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0122
                  ES_STATE := PV_ISOLATING;
0123
              ELSIF (RP211_ON) THEN
0124
                   (* ignore RP211_PSL *)
0125
                  ES_STATE := PV_RP_PUMPING;
0126
              END_IF
0127
0128
          PV_RP_PUMPING:
```

```
0129
              V204_CLS_REQ_ES := TRUE;
0130
              LLV211 CLS REO ES := TRUE;
0131
              RPV211_OPN_REQ_ES := TRUE;
0132
              RP211_ON_REQ_ES := TRUE;
0133
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0134
              VPV211_FAST_OPN_REQ_ES := FALSE;
0135
              TPV211_OPN_REQ_ES := FALSE;
0136
              TP211_ON_REQ_ES := FALSE;
0137
0138
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0139
                  ES_STATE := PV_RP_PUMPING;
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0140
                  ES_STATE := PV_ISOLATING;
0141
0142
              ELSIF (PE211_PSL_MIDLO) THEN
0143
                  ES_STATE := PV_RP_PUMPED;
0144
              END IF
0145
0146
          PV_RP_PUMPED:
0147
              V204_CLS_REQ_ES := TRUE;
0148
              LLV211_CLS_REQ_ES := TRUE;
0149
              RPV211_OPN_REQ_ES := TRUE;
0150
              RP211_ON_REQ_ES := TRUE;
0151
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0152
              VPV211_FAST_OPN_REQ_ES := FALSE;
0153
              TPV211_OPN_REQ_ES := FALSE;
0154
              TP211_ON_REQ_ES := FALSE;
0155
0156
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0157
                  ES_STATE := PV_RP_PUMPED;
0158
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0159
                  ES_STATE := PV_ISOLATING;
0160
              ELSIF (NOT PE211_PSL_MIDLO) THEN
0161
                  ES_STATE := PV_RP_PUMPING;
              ELSIF (TP211_OK) THEN
0162
                  (* First isolate, then go to TP_STARTING *)
0163
0164
                  ES_STATE := PV_ISOLATING;
0165
              END_IF
0166
          PV_TP_PUMPING:
0167
0168
              V204_CLS_REQ_ES := TRUE;
              LLV211_CLS_REQ_ES := TRUE;
0169
              RPV211_OPN_REQ_ES := FALSE;
0170
0171
              RP211_ON_REQ_ES := TRUE; (* Leave on in case MIDLO false *)
0172
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0173
              VPV211_FAST_OPN_REQ_ES := FALSE;
0174
              TPV211_OPN_REQ_ES := TRUE;
0175
              TP211_ON_REQ_ES := TRUE;
0176
0177
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0178
                  ES_STATE := PV_TP_PUMPING;
0179
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
0180
                  ES_STATE := PV_ISOLATING;
0181
              ELSIF (NOT PE211_PSL_MIDLO) THEN
0182
                  ES_STATE := PV_RP_PUMPING;
0183
              ELSIF (PE211_PSL_LO) THEN
0184
                  ES_STATE := PV_PUMPED;
0185
              END_IF
0186
          PV_PUMPED:
0187
0188
              V204_CLS_REQ_ES := FALSE;
0189
              LLV211_CLS_REQ_ES := FALSE; (* LLV211 can be opened when both ES211 and LL211 are pumped *)
0190
              RPV211_OPN_REQ_ES := FALSE;
0191
              RP211_ON_REQ_ES := FALSE;
0192
              VPV211_SLOW_OPN_REQ_ES := FALSE;
0193
              VPV211_FAST_OPN_REQ_ES := FALSE;
0194
              TPV211_OPN_REQ_ES := TRUE;
0195
              TP211_ON_REQ_ES := TRUE;
0196
              IF (ES_REQUEST = PV_NONE_REQ) THEN
0197
0198
                  ES_STATE := PV_PUMPED;
0199
              ELSIF NOT (ES_REQUEST = PV_PUMP_REQ) THEN
                  ES_STATE := PV_ISOLATING;
0200
              ELSIF (NOT PE211_PSL_MIDLO) THEN
0201
```

```
0202
                  (* return to PV_RP_PUMPING via PV_ISOLATING *)
0203
                  ES STATE := PV ISOLATING:
0204
              ELSIF (PE211_PSL_LO) THEN
0205
                 ES_STATE := PV_PUMPED;
0206
              END_IF
0207
0208
          ELSE
0209
              (* Invalid State, should never get here *)
0210
              ES_STATE := PV_ERROR;
0211
0212 END_CASE
0213
Fault_Logic (ST)
0001 (* Latched interlocks *)
0002
0003
     LL_ACTUATOR_OK := ACTUATOR_OK AND (LL_ACTUATOR_OK OR RESET_REQ);
0004
     LL_PE101_PSL_LO := PE101_PSL_LO AND (LL_PE101_PSL_LO OR RESET_REQ);
0005
     LL_PE201_PSL_LO := PE201_PSL_LO AND (LL_PE201_PSL_LO OR RESET_REQ);
0006
     LL_V202_OPN := V202_OPN AND (LL_V202_OPN OR RESET_REQ);
0007
     LL_PE202_PSL_LO := PE202_PSL_LO AND (LL_PE202_PSL_LO OR RESET_REQ);
8000
     LL_PE203_PSL_LO := PE203_PSL_LO AND (LL_PE203_PSL_LO OR RESET_REQ);
0009
0010
     LL_ES_CONFIG_OK := ES_CONFIG_OK AND (LL_ES_CONFIG_OK OR RESET_REQ);
0011
     LL_LL_CONFIG_OK := LL_CONFIG_OK AND (LL_LL_CONFIG_OK OR RESET_REQ);
0012
0013
     LL_PE203_PIY_OK := PE203_PIY_OK AND (LL_PE203_PIY_OK OR RESET_REQ);
     LL_PE211_PIY_OK := PE211_PIY_OK AND (LL_PE211_PIY_OK OR RESET_REQ);
0014
     LL_PE212_PIY_OK := PE212_PIY_OK AND (LL_PE212_PIY_OK OR RESET_REQ);
0015
0016
0017
     LL_BP211_ON := BP211_ON AND (LL_BP211_ON OR RESET_REQ);
0018
0019
     LL_TP201_OK := TP201_OK AND (LL_TP201_OK OR RESET_REQ);
0020
     LL_TP211_OK := TP211_OK AND (LL_TP211_OK OR RESET_REQ);
0021
     LL_TP212_OK := TP212_OK AND (LL_TP212_OK OR RESET_REQ);
0022
     Reset_Required :=
0023
                          (ACTUATOR_OK AND NOT LL_ACTUATOR_OK) OR
0024
                           (PE101 PSL LO AND NOT LL PE101 PSL LO) OR
0025
                           (PE201 PSL LO AND NOT LL PE201 PSL LO) OR
0026
                           (V202 OPN AND NOT LL V202 OPN) OR
0027
                           (PE202_PSL_LO AND NOT LL_PE202_PSL_LO) OR
0028
                           (PE203_PSL_LO AND NOT LL_PE203_PSL_LO) OR
0029
                           (ES_CONFIG_OK AND NOT LL_ES_CONFIG_OK) OR
0030
                           (LL_CONFIG_OK AND NOT LL_LL_CONFIG_OK) OR
0031
                           (PE203_PIY_OK AND NOT LL_PE203_PIY_OK) OR
0032
                           (PE211_PIY_OK AND NOT LL_PE211_PIY_OK) OR
0033
                           (PE212_PIY_OK AND NOT LL_PE212_PIY_OK) OR
0034
                           (BP211_ON AND NOT LL_BP211_ON) OR
0035
                           (TP201_OK AND NOT LL_TP201_OK) OR
0036
                           (TP211_OK AND NOT LL_TP211_OK) OR
0037
                           (TP212_OK AND NOT LL_TP212_OK);
0038
LL_SM (ST)
0001
     (* LL211 Pump/Vent State Machine *)
0002
0003
      (* Always test for PV_ERROR first *)
0004
     IF NOT (LL_PE212_PIY_OK AND LL_LL_CONFIG_OK) THEN
0005
          LL_STATE := PV_ERROR;
0006
     END_IF
0007
0008
     CASE LL_STATE OF
0009
0010
          PV_ERROR:
0011
              LLV211_CLS_REQ_LL := TRUE;
0012
              RPV212_OPN_REQ_LL := FALSE;
0013
              RP211_ON_REQ_LL := FALSE;
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0014
0015
              VPV212_FAST_OPN_REQ_LL := FALSE;
0016
              TPV212_OPN_REQ_LL := FALSE;
0017
              TP212_ON_REQ_LL := FALSE;
0018
0019
              IF LL_PE212_PIY_OK THEN
0020
                  LL_STATE := PV_ISOLATING;
```

```
0021
              END_IF
0022
0023
          PV_ISOLATING:
0024
              LLV211_CLS_REQ_LL := TRUE;
0025
              RPV212_OPN_REQ_LL := FALSE;
0026
              RP211_ON_REQ_LL := FALSE;
0027
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0028
              VPV212_FAST_OPN_REQ_LL := FALSE;
0029
              TPV212_OPN_REQ_LL := FALSE;
0030
              TP212_ON_REQ_LL := FALSE;
0031
              IF LLV211_CSD AND RPV212_CSD THEN
0032
0033
                  LL_STATE := PV_ISOLATED;
0034
              END_IF
0035
0036
          PV_ISOLATED:
0037
              LLV211_CLS_REQ_LL := TRUE;
0038
              RPV212_OPN_REQ_LL := FALSE;
0039
              RP211_ON_REQ_LL := FALSE;
0040
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0041
              VPV212_FAST_OPN_REQ_LL := FALSE;
0042
              TPV212_OPN_REQ_LL := FALSE;
0043
              TP212_ON_REQ_LL := FALSE;
0044
0045
              IF (LL_REQUEST = PV_VENT_REQ) THEN
0046
                  LL_STATE := PV_SLOW_VENTING;
0047
              ELSIF (LL_REQUEST = PV_PUMP_REQ) AND PE212_PSL_MIDLO AND TP212_OK THEN
0048
                  LL_STATE := PV_TP_PUMPING;
0049
              ELSIF (LL_REQUEST = PV_PUMP_REQ) THEN
0050
                  LL_STATE := PV_RP_STARTING;
0051
              END_IF
0052
          PV_SLOW_VENTING:
0053
0054
              LLV211_CLS_REQ_LL := TRUE;
0055
              RPV212_OPN_REQ_LL := FALSE;
0056
              RP211_ON_REQ_LL := FALSE;
              VPV212_SLOW_OPN_REQ_LL := TRUE;
0057
              VPV212_FAST_OPN_REQ_LL := FALSE;
0058
0059
              TPV212_OPN_REQ_LL := FALSE;
0060
              TP212_ON_REQ_LL := FALSE;
0061
0062
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0063
                  LL_STATE := PV_SLOW_VENTING;
0064
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
0065
                  LL_STATE := PV_ISOLATING;
0066
              ELSIF (PE212_PSH_MIDHI) THEN
0067
                  LL_STATE := PV_FAST_VENTING;
0068
              END_IF
0069
0070
          PV_FAST_VENTING:
0071
              LLV211_CLS_REQ_LL := TRUE;
0072
              RPV212_OPN_REQ_LL := FALSE;
0073
              RP211_ON_REQ_LL := FALSE;
0074
              VPV212_SLOW_OPN_REQ_LL := TRUE;
              VPV212_FAST_OPN_REQ_LL := TRUE;
0075
0076
              TPV212_OPN_REQ_LL := FALSE;
              TP212_ON_REQ_LL := FALSE;
0077
0078
0079
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0080
                  LL_STATE := PV_FAST_VENTING;
0081
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
0082
                  LL_STATE := PV_ISOLATING;
0083
              ELSIF (PE212_PSH_HI) THEN
0084
                  LL_STATE := PV_VENTED;
0085
              END_IF
0086
0087
          PV_VENTED:
              LLV211_CLS_REQ_LL := FALSE; (* LLV211 can be opened when both ES211 and LL211 are vented *)
8800
0089
              RPV212_OPN_REQ_LL := FALSE;
              RP211_ON_REQ_LL := FALSE;
0090
0091
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0092
              VPV212_FAST_OPN_REQ_LL := FALSE;
0093
              TPV212_OPN_REQ_LL := FALSE;
```

```
TP212_ON_REQ_LL := FALSE;
0095
0096
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0097
                  LL_STATE := PV_VENTED;
0098
              ELSIF NOT (LL_REQUEST = PV_VENT_REQ) THEN
0099
                  LL_STATE := PV_ISOLATING;
0100
              ELSIF (NOT PE212_PSH_HI) THEN
0101
                  LL_STATE := PV_FAST_VENTING;
0102
              END_IF
0103
0104
          PV_RP_STARTING:
              LLV211_CLS_REQ_ES := TRUE;
0105
              RPV212_OPN_REQ_LL := FALSE;
0106
0107
              RP211_ON_REQ_LL := TRUE;
0108
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0109
              VPV212_FAST_OPN_REQ_LL := FALSE;
0110
              TPV212_OPN_REQ_LL := FALSE;
0111
              TP212_ON_REQ_LL := FALSE;
0112
0113
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0114
                  LL_STATE := PV_RP_STARTING;
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0115
0116
                  LL_STATE := PV_ISOLATING;
              ELSIF (RP211_ON) THEN
0117
0118
                  (* ignore RP211_PSL *)
0119
                  LL_STATE := PV_RP_PUMPING;
0120
              END_IF
0121
0122
          PV_RP_PUMPING:
0123
              LLV211_CLS_REQ_LL := TRUE;
              RPV212_OPN_REQ_LL := TRUE;
0124
0125
              RP211_ON_REQ_LL := TRUE;
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0126
              VPV212_FAST_OPN_REQ_LL := FALSE;
0127
0128
              TPV212_OPN_REQ_LL := FALSE;
              TP212_ON_REQ_LL := FALSE;
0129
0130
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0131
0132
                  LL_STATE := PV_RP_PUMPING;
0133
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0134
                  LL_STATE := PV_ISOLATING;
0135
              ELSIF (PE212_PSL_MIDLO) THEN
0136
                  LL_STATE := PV_RP_PUMPED;
0137
              END_IF
0138
0139
          PV RP PUMPED:
0140
              LLV211_CLS_REQ_LL := TRUE;
0141
              RPV212_OPN_REQ_LL := TRUE;
0142
              RP211_ON_REQ_LL := TRUE;
0143
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0144
              VPV212_FAST_OPN_REQ_LL := FALSE;
0145
              TPV212_OPN_REQ_LL := FALSE;
0146
              TP212_ON_REQ_LL := FALSE;
0147
0148
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0149
                  LL_STATE := PV_RP_PUMPED;
0150
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0151
                  LL_STATE := PV_ISOLATING;
0152
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0153
                  LL_STATE := PV_RP_PUMPING;
0154
              ELSIF (TP212_OK) THEN
0155
                   (* First isolate, then go to TP_STARTING *)
0156
                  LL_STATE := PV_ISOLATING;
0157
              END_IF
0158
0159
          PV_TP_PUMPING:
0160
              LLV211_CLS_REQ_LL := TRUE;
0161
              RPV212_OPN_REQ_LL := FALSE;
              RP211_ON_REQ_LL := TRUE; (* Leave on in case MIDLO false *)
0162
0163
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0164
              VPV212_FAST_OPN_REQ_LL := FALSE;
              TPV212_OPN_REQ_LL := TRUE;
0165
0166
              TP212_ON_REQ_LL := TRUE;
```

```
0167
0168
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0169
                  LL_STATE := PV_TP_PUMPING;
0170
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0171
                  LL_STATE := PV_ISOLATING;
0172
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0173
                  LL_STATE := PV_RP_PUMPING;
0174
              ELSIF (PE212_PSL_LO) THEN
0175
                  LL_STATE := PV_PUMPED;
0176
              END_IF
0177
0178
          PV PUMPED:
0179
              LLV211_CLS_REQ_LL := FALSE; (* LLV211 can be opened when both ES211 and LL211 are pumped *)
0180
              RPV212_OPN_REQ_LL := FALSE;
0181
              RP211_ON_REQ_LL := FALSE;
0182
              VPV212_SLOW_OPN_REQ_LL := FALSE;
0183
              VPV212_FAST_OPN_REQ_LL := FALSE;
0184
              TPV212_OPN_REQ_LL := TRUE;
0185
              TP212_ON_REQ_LL := TRUE;
0186
0187
              IF (LL_REQUEST = PV_NONE_REQ) THEN
0188
                  LL_STATE := PV_PUMPED;
0189
              ELSIF NOT (LL_REQUEST = PV_PUMP_REQ) THEN
0190
                 LL_STATE := PV_ISOLATING;
0191
              ELSIF (NOT PE212_PSL_MIDLO) THEN
0192
                  (* return to PV_RP_PUMPING via PV_ISOLATING *)
0193
                  LL_STATE := PV_ISOLATING;
0194
              ELSIF (PE212_PSL_LO) THEN
0195
                 LL_STATE := PV_PUMPED;
0196
              END_IF
0197
0198
          ELSE
0199
              (* Invalid State, should never get here *)
0200
              LL_STATE := PV_ERROR;
0201
0202 END_CASE
Process_Inputs (ST)
0001 (*=== Processed Inputs *)
0002
     (* DISCRETE IN *)
0003 PE101_PSL_LO := DI_PE101_PSL_LO;
0004 PE201_PSL_LO := DI_PE201_PSL_LO;
0005 | PE202_PSL_LO := DI_PE202_PSL_LO;
0006
0007 RP211_ON := DI_RP2110_ON;
0008 BP211_ON := DI_RP2111_ON;
0009
     RP211_PSL := DI_PE2110_PSL;
0010 BP211_PSL := DI_PE2111_PSL;
0011
0012 PE203_PIY_OK := DI_PE203_PIY_OK;
0013 PE203_PSH_HI := DI_PE203_PIY_OK AND NOT DI_PE203_PSL_HI;
0014 PE203_PSH_MIDHI := DI_PE203_PIY_OK AND NOT DI_PE203_PSL_MIDHI;
0015
     PE203_PSL_MIDLO := DI_PE203_PSL_MIDLO;
0016 PE203_PSL_LO := DI_PE203_PSL_LO;
0017
0018
     PE211_PIY_OK := DI_PE211_PIY_OK;
0019
     PE211_PSH_HI := DI_PE211_PIY_OK AND NOT DI_PE211_PSL_HI;
0020
     PE211_PSH_MIDHI := DI_PE211_PIY_OK AND NOT DI_PE211_PSL_MIDHI;
0021
      PE211_PSL_MIDLO := DI_PE211_PSL_MIDLO;
0022
     PE211_PSL_LO := DI_PE211_PSL_LO;
0023
0024
     PE212_PIY_OK := DI_PE212_PIY_OK;
0025
      PE212_PSH_HI := DI_PE212_PIY_OK AND NOT DI_PE212_PSL_HI;
0026
      PE212_PSH_MIDHI := DI_PE212_PIY_OK AND NOT DI_PE212_PSL_MIDHI;
0027
      PE212_PSL_MIDLO := DI_PE212_PSL_MIDLO;
0028
      PE212_PSL_LO := DI_PE212_PSL_LO;
0029
0030
      V100_OPN := DI_V100_OPEN;
0031
      V100_CSD := DI_V100_CLOSED;
0032
0033
      V101_OPN := DI_V101_OPEN AND DO_V101_OPEN_CMD;
0034
      V101_CSD := DI_V101_CLOSED AND NOT DO_V101_OPEN_CMD;
0035
0036
     V201_OPN := DI_V201_OPEN AND DO_V201_OPEN_CMD;
```

```
0037
      V201_CSD := DI_V201_CLOSED AND NOT DO_V201_OPEN_CMD;
0038
0039
      V202_OPN := DI_V202_OPEN;
0040
     V202_CSD := DI_V202_CLOSED;
0041
0042
      V203_OPN := DI_V203_OPEN AND DO_V203_OPEN_CMD;
0043
     V203_CSD := DI_V203_CLOSED AND NOT DO_V203_OPEN_CMD;
0044
0045
      V204_OPN := DI_V204_OPEN AND DO_V204_OPEN_CMD;
0046
     V204_CSD := DI_V204_CLOSED AND NOT DO_V204_OPEN_CMD;
0047
     TP201_OK := DI_TP201_TURBO_OK;
0048
     TP201_ON := TP201_OK AND DO_TP201_ON_CMD;
0049
     TP201_READY := TP201_ON AND DI_TP201_AT_SPEED;
0050
0051
0052
      VPV211_OPN := DO_VENT211_SLOW_CMD OR DO_VENT211_FAST_CMD;
0053
      VPV211_CSD := NOT VPV211_OPN;
0054
0055
      RPV211_OPN := DI_RPV211_OPEN AND DO_RPV211_OPEN_CMD;
0056
      RPV211_CSD := DI_RPV211_CLOSED AND NOT DO_RPV211_OPEN_CMD;
0057
0058
      TPV211_OPN := DI_TPV211_OPEN AND DO_TPV211_OPEN_CMD;
0059
      TPV211_CSD := DI_TPV211_CLOSED AND NOT DO_TPV211_OPEN_CMD;
0060
0061
     TP211_OK := DI_TP211_TURBO_OK;
0062
      TP211_READY := DI_TP211_AT_SPEED AND DO_TP211_ON_CMD;
0063
0064
      VPV212_OPN := DO_VENT212_SLOW_CMD OR DO_VENT212_FAST_CMD;
0065
      VPV212_CSD := NOT VPV212_OPN;
0066
0067
     RPV212_OPN := DI_RPV212_OPEN AND DO_RPV212_OPEN_CMD;
     RPV212_CSD := DI_RPV212_CLOSED AND NOT DO_RPV212_OPEN_CMD;
0068
0069
      TPV212_OPN := DI_TPV212_OPEN AND DO_TPV212_OPEN_CMD;
0070
      TPV212_CSD := DI_TPV212_CLOSED AND NOT DO_TPV212_OPEN_CMD;
0071
0072
0073
     TP212_OK := DI_TP212_TURBO_OK;
0074
     TP212_READY := DI_TP212_AT_SPEED AND DO_TP212_ON_CMD;
0075
0076
      LLV211_OPN := DI_SLOTV211_OPEN;
0077
      LLV211_CSD := DI_SLOTV211_CLOSED;
0078
0079 LL211_LID_CLOSED := DI_LL211_LID_CLOSED;
     LL211_ARM_RETRACTED := DI_LL211_ARM_RETRACTED;
0.080
Process_Outputs (ST)
0001 (* Process Outputs *)
0002
0003 DO_RP2110_ON_CMD := RP211.on_cmd;
0004 DO_RP2111_ON_CMD := BP211_ON_CMD;
0005
     DO_V101_OPEN_CMD := V101.open_cmd;
0006
     DO_V201_OPEN_CMD := V201.open_cmd;
0007
     DO_V203_OPEN_CMD := V203.open_cmd;
8000
     DO_V204_OPEN_CMD := V204.open_cmd;
0009
      DO_TP201_ON_CMD := TP201.on_cmd;
0010
      DO_TP201_VENT_ENABLE_CMD := VPV201.open_cmd;
0011
0012
      DO_TP211_ON_CMD := TP211.on_cmd;
0013
      DO_TPV211_OPEN_CMD := TPV211.open_cmd;
0014
      DO_RPV211_OPEN_CMD := RPV211.open_cmd;
0015
      DO_VENT211_SLOW_CMD := VPV211_SLOW.open_cmd;
0016
      DO_VENT211_FAST_CMD := VPV211_FAST.open_cmd;
0017
0018
      DO_SLOTV211_OPEN_CMD := LLV211.open_cmd;
0019
      DO_SLOTV211_CLOSE_CMD := LLV211.close_cmd;
0020
0021
      DO_TP212_ON_CMD := TP212.on_cmd;
0022
      DO_TPV212_OPEN_CMD := TPV212.open_cmd;
0023
      DO_RPV212_OPEN_CMD := RPV212.open_cmd;
0024
      DO_VENT212_SLOW_CMD := VPV212_SLOW.open_cmd;
     DO_VENT212_FAST_CMD := VPV212_FAST.open_cmd;
0025
Pumps (ST)
0001
     (* Pump Control Logic *)
```

```
0002
0003
      (* BP211 *)
0004
     BP211_ON_CMD := TRUE; (* always on *)
0005
0006
      (* RP211 *)
0007
     RP211.on_ena := TRUE;
0008
     RP211.off_ena := RPV211_CSD AND RPV212_CSD;
0009
     RP211.on_req := RP211_ON_REQ_ES OR RP211_ON_REQ_LL;
0010
     RP211.off_req := NOT RP211.on_req;
0011
     RP211();
0012
     (* TP201 *)
0013
0014 TP201.on_intlk := LL_PE203_PIY_OK;
0015 TP201.on_ena := TRUE;
     TP201.off_ena := V203_CSD AND V204_CSD;
0016
0017
     TP201.on_req := TP201_ON_REQ_SC;
0018 TP201.off_req := TP201_OFF_REQ_SC;
0019
0020
0021
     (* TP211 *)
0022
     TP211.on_intlk := LL_BP211_ON;
0023
     TP211.on_ena := TPV211_CSD;
0024
     TP211.off_ena := TPV211_CSD;
0025
     TP211.on_req := TP211_ON_REQ_ES;
0026
     TP211.off_req := NOT TP211.on_req;
0027
     TP211();
0028
0029
     (* TP212 *)
0030 | TP212.on_intlk := LL_BP211_ON;
0031 TP212.on_ena := TPV212_CSD;
0032 TP212.off_ena := TPV212_CSD;
0033
     TP212.on_req := TP212_ON_REQ_LL;
0034 TP212.off_req := NOT TP212.on_req;
0035 TP212();
SC_Inputs (ST)
0001
     (* Supervisory Control Inputs *)
0002
     RESET_REQ := SC_RESET_REQ;
0003
0004
     (* Level-Triggered signals *)
0005
0006
     (* Edge-Triggered signals *)
0007
     V101_OPN_REQ_SC := SC_V101_OPN_REQ;
0008 V101_CLS_REQ_SC := SC_V101_CLS_REQ;
0009 | V201_OPN_REQ_SC := SC_V201_OPN_REQ;
0010 | V201_CLS_REQ_SC := SC_V201_CLS_REQ;
0011 | V203_OPN_REQ_SC := SC_V203_OPN_REQ;
0012 | V203_CLS_REQ_SC := SC_V203_CLS_REQ;
0013 | V204_OPN_REQ_SC := SC_V204_OPN_REQ;
0014 | V204_CLS_REQ_SC := SC_V204_CLS_REQ;
0015
     TP201_ON_REQ_SC := SC_TP201_ON_REQ;
0016
     TP201_OFF_REQ_SC := SC_TP201_OFF_REQ;
0017
     TP201_VENT_ENABLE_REQ_SC := SC_TP201_VENT_ENABLE_REQ;
0018
     TP201_VENT_DISABLE_REQ_SC := SC_TP201_VENT_DISABLE_REQ;
0019
     LLV211_OPN_REQ_SC := SC_SLOTV211_OPN_REQ;
0020
     LLV211_CLS_REQ_SC := SC_SLOTV211_CLS_REQ;
0021
0022
     (* BR_REQ *)
0023
     CASE SC_BR_CMD_REQ OF
0024
0025
              BR_REQUEST := BR_NONE_REQ;
0026
          1:
0027
              BR_REQUEST := BR_SINS1_REQ;
0028
          2:
0029
              BR_REQUEST := BR_SINS2_REQ;
0030
          3:
0031
              BR_REQUEST := BR_SINS3_REQ;
0032
          4:
0033
              BR_REQUEST := BR_YAG_REQ;
0034
          ELSE
0035
              BR_REQUEST := BR_NONE_REQ;
0036
     END_CASE;
0037
0038
      (* ES_REQ *)
```

```
CASE SC_ES_CMD_REQ OF
0039
0040
0041
              ES_REQUEST := PV_NONE_REQ;
0042
0043
              ES_REQUEST := PV_ISOLATE_REQ;
0044
0045
              ES_REQUEST := PV_PUMP_REQ;
0046
0047
              ES_REQUEST := PV_VENT_REQ;
0048
0049
              ES_REQUEST := PV_NONE_REQ;
0050
     END_CASE;
0051
0052
0053
      (* LL_REQ *)
0054
     CASE SC_LL_CMD_REQ OF
0055
0056
              LL_REQUEST := PV_NONE_REQ;
0057
0058
              LL_REQUEST := PV_ISOLATE_REQ;
0059
          2:
              LL_REQUEST := PV_PUMP_REQ;
0060
0061
          3:
0062
              LL_REQUEST := PV_VENT_REQ;
0063
          ELSE
0064
              LL_REQUEST := PV_NONE_REQ;
0065
     END_CASE;
0066
0067
0068
0069
SC_Outputs (ST)
0001 (* Supervisory Control Outputs *)
0002
      SC_RESET_REQUIRED := Reset_Required;
0003
      SC_ATB := TRUE;
0004
     SC_AFB := FALSE;
0005
0006
      (* Inputs *)
0007
      SC_PE101_PSL := PE101_PSL_LO;
8000
      SC_PE201_PSL := PE201_PSL_LO;
0009
      SC_PE202_PSL := PE202_PSL_LO;
0010
0011
      SC_RP2110_AT_SPEED := DI_RP2110_ON;
0012
      SC_RP2111_AT_SPEED := DI_RP2111_ON;
0013
      SC_PE2110_PSL := DI_PE2110_PSL;
0014
      SC_PE2111_PSL := DI_PE2111_PSL;
0015
0016
      SC_PE203_OK := DI_PE203_PIY_OK;
0017
      SC_PE203_PSL_HI := DI_PE203_PSL_HI;
0018
      SC_PE203_PSL_MIDHI := DI_PE203_PSL_MIDHI;
0019
      SC_PE203_PSL_MIDLO := DI_PE203_PSL_MIDLO;
0020
      SC_PE203_PSL_LO := DI_PE203_PSL_LO;
0021
0022
      SC_PE211_OK := DI_PE211_PIY_OK;
0023
      SC_PE211_PSL_HI := DI_PE211_PSL_HI;
0024
      SC_PE211_PSL_MIDHI := DI_PE211_PSL_MIDHI;
0025
      SC_PE211_PSL_MIDLO := DI_PE211_PSL_MIDLO;
0026
      SC_PE211_PSL_LO := DI_PE211_PSL_LO;
0027
0028
      SC_PE212_OK := DI_PE212_PIY_OK;
0029
      SC_PE212_PSL_HI := DI_PE212_PSL_HI;
0030
      SC_PE212_PSL_MIDHI := DI_PE212_PSL_MIDHI;
0031
      SC_PE212_PSL_MIDLO := DI_PE212_PSL_MIDLO;
0032
      SC_PE212_PSL_LO := DI_PE212_PSL_LO;
0033
0034
      SC_LL211_LID_CLOSED := DI_LL211_LID_CLOSED;
0035
      SC_LL211_ARM_RETRACTED := DI_LL211_ARM_RETRACTED;
0036
0037
      SC_V100_OPEN := V100_OPN;
0038
      SC_V100_CLOSED := V100_CSD;
0039
0040
      SC_V101_BEAM_PASS := (NOT V100_CSD) AND (NOT V101_CSD) AND (BR_STATE = BR_SINS1_READY);
0041
      SC_V101_OPEN := V101_OPN;
```

```
0042
      SC_V101_CLOSED := V101_CSD;
      SC V101_OPEN_PERMIT := V101.open_ena;
0043
0044
      SC_V101_CLOSE_PERMIT := V101.close_ena;
      SC V101_OPEN_CMD := V101.open_cmd;
0045
0046
      SC_V101_NOT_SYMBOL := V101.not_symbol;
0047
0048
      SC_V201_BEAM_PASS := (NOT V100_CSD) AND (NOT V201_CSD) AND (BR_STATE = BR_SINS2_READY);
0049
      SC_V201_OPEN := V201_OPN;
      SC_V201_CLOSED := V201_CSD;
0050
0051
      SC_V201_OPEN_PERMIT := V201.open_ena;
0052
      SC_V201_CLOSE_PERMIT := V201.close_ena;
      SC_V201_OPEN_CMD := V201.open_cmd;
0053
0054
      SC_V201_NOT_SYMBOL := V201.not_symbol;
0055
0056
      SC_V202_OPEN := V202_OPN;
0057
      SC_V202_CLOSED := V202_CSD;
0058
      SC_V202_BEAM_PASS := SC_V201_BEAM_PASS AND (NOT V202_CSD);
0059
0060
      SC_V203_BEAM_PASS := SC_V202_BEAM_PASS AND (NOT V203_CSD);
0061
      SC_V203_OPEN := V203_OPN;
0062
      SC_V203_CLOSED := V203_CSD;
0063
      SC_V203_OPEN_PERMIT := V203.open_ena;
0064
      SC_V203_CLOSE_PERMIT := V203.close_ena;
0065
      SC_V203_OPEN_CMD := V203.open_cmd;
0066
      SC_V203_NOT_SYMBOL := V203.not_symbol;
0067
0068
     SC_V204_BEAM_PASS := SC_V203_BEAM_PASS AND (NOT V204_CSD);
0069
      SC_V204_OPEN := V204_OPN;
0070
      SC_V204_CLOSED := V204_CSD;
0071
      SC_V204_OPEN_PERMIT := V204.open_ena;
0072
      SC_V204_CLOSE_PERMIT := V204.close_ena;
0073
      SC_V204_OPEN_CMD := V204.open_cmd;
      SC_V204_NOT_SYMBOL := V204.not_symbol;
0074
0075
0076
      SC_RPV211_OPEN := RPV211_OPN;
0077
      SC_RPV211_CLOSED := RPV211_CSD;
0078
      SC_RPV211_OPEN_CMD := RPV211.open_cmd;
0079
0800
      SC_VENT211_SLOW_CMD := VPV211_SLOW.open_cmd;
0081
      SC_VENT211_FAST_CMD := VPV211_FAST.open_cmd;
0082
0083
      SC_TPV211_OPEN := TPV211_OPN;
0084
      SC_TPV211_CLOSED := TPV211_CSD;
0085
      SC_TPV211_OPEN_CMD := TPV211.open_cmd;
0086
0087
      SC_SLOTV211_OPEN := LLV211_OPN;
8800
      SC_SLOTV211_CLOSED := LLV211_CSD;
0089
      SC_SLOTV211_OPEN_PERMIT := LLV211.open_ena;
0090
      SC_SLOTV211_CLOSE_PERMIT := LLV211.close_ena;
0091
      SC_SLOTV211_OPEN_CMD := LLV211.open_cmd;
0092
      SC_SLOTV211_CLOSE_CMD := LLV211.close_cmd;
0093
      SC_SLOTV211_NOT_SYMBOL := LLV211.not_symbol;
0094
0095
      SC_RPV212_OPEN := RPV212_OPN;
0096
      SC_RPV212_CLOSED := RPV212_CSD;
0097
      SC_RPV212_OPEN_CMD := RPV212.open_cmd;
0098
0099
      SC_VENT212_SLOW_CMD := VPV212_SLOW.open_cmd;
      SC_VENT212_FAST_CMD := VPV212_FAST.open_cmd;
0100
0101
0102
      SC_TPV212_OPEN := TPV212_OPN;
         _TPV212_CLOSED := TPV212_CSD;
0103
0104
      SC_TPV212_OPEN_CMD := TPV212.open_cmd;
0105
0106
      SC_RP2110_ON := RP211_ON;
0107
      SC_RP2110_ON_CMD := RP211.on_cmd;
0108
0109
      SC_RP2111_ON := BP211_ON;
0110
      SC_RP2111_ON_CMD := BP211_ON_CMD;
0111
0112
      SC_TP201_VENT_ENABLE_CMD := VPV201.open_cmd;
      SC_TP201_VENT_NOT_SYMBOL := VPV201.not_symbol;
0113
0114
```

```
0115
      SC_TP201_OK := TP201_OK;
0116
      SC TP201 ON := TP201 ON;
0117
      SC_TP201_OFF := NOT TP201.on_cmd;
0118
      SC_TP201_ON_PERMIT := TP201.on_ena;
0119
      SC_TP201_OFF_PERMIT := TP201.off_ena;
0120
      SC_TP201_ON_CMD := TP201.on_cmd;
0121
      SC_TP201_NOT_SYMBOL := TP201.not_symbol;
0122
0123
      SC_TP211_OK := TP211_OK;
0124
      SC_TP211_ON := TP211_READY;
0125
      SC_TP211_OFF := NOT TP211.on_cmd;
0126
0127
      SC_TP212_OK := TP212_OK;
      SC_TP212_ON := TP212_READY;
0128
0129
      SC_TP212_OFF := NOT TP212.on_cmd;
0130
0131
0132
      (* INTERLOCKS *)
0133
      SC_LL_ACTUATOR_OK := LL_ACTUATOR_OK;
0134
      SC_LL_PE101_PSL := LL_PE101_PSL_LO;
0135
      SC_LL_PE201_PSL := LL_PE201_PSL_LO;
0136
      SC_LL_V202_OPN := LL_V202_OPN;
0137
      SC_LL_PE202_PSL := LL_PE202_PSL_LO;
0138
      SC_LL_PE203_OK := LL_PE203_PIY_OK;
0139
      SC_LL_PE203_PSL_LO := LL_PE203_PSL_LO;
0140
      SC_LL_TP201_OK := LL_TP201_OK;
0141
0142
      SC_LL_ES_CONFIG_OK := LL_ES_CONFIG_OK;
0143
      SC_LL_LL_CONFIG_OK := LL_LL_CONFIG_OK;
0144
      SC_LL_PE211_OK := LL_PE211_PIY_OK;
0145
      SC_LL_PE212_OK := LL_PE212_PIY_OK;
0146
      SC_LL_RP2111_ON := LL_BP211_ON;
      SC_LL_PE2111_PSL := BP211_PSL; (* This is just in case LabView needs it *)
0147
      SC_LL_TP211_TURBO_OK := LL_TP211_OK;
0148
0149
      SC_LL_TP212_TURBO_OK := LL_TP212_OK;
0150
0151
0152
      (* PLC_OUT REGISTERS *)
0153
0154
0155
      (* Version Numbers *)
0156
      SC_VERSION_MAJOR := cVERSION_MAJOR;
0157
      SC_VERSION_MINOR := cVERSION_MINOR;
0158
0159
      (* Analog vacuum pressure *)
0160
      SC_PE101_PIY := AI_PE101_PIY;
0161
      SC_PE201_PIY := AI_PE201_PIY;
0162
      SC_PE202_PIY := AI_PE202_PIY;
0163
      SC_PE203_HI_PIY := AI_PE203_HI_PIY;
0164
      SC_PE203_LO_PIY := AI_PE203_LO_PIY;
0165
      SC_PE211_HI_PIY := AI_PE211_HI_PIY;
0166
      SC_PE211_LO_PIY := AI_PE211_LO_PIY;
0167
      SC_PE212_HI_PIY := AI_PE212_HI_PIY;
0168
      SC_PE212_LO_PIY := AI_PE212_LO_PIY;
0169
0170
      (* Current BR_REQ *)
      CASE BR_REQUEST OF
0171
0172
          BR_NONE_REQ:
0173
              SC_BR_CMD_VAL := 0;
0174
          BR_SINS1_REQ:
0175
              SC_BR_CMD_VAL := 1;
0176
          BR_SINS2_REQ:
0177
              SC_BR_CMD_VAL := 2;
0178
          BR_SINS3_REQ:
0179
              SC_BR_CMD_VAL := 3;
0180
          BR_YAG_REQ:
0181
              SC_BR_CMD_VAL := 4;
0182
0183
              (* should never get here *)
0184
              SC_BR_CMD_VAL := 0;
0185
      END_CASE;
0186
0187
      (* Current ES_REQ *)
```

```
0188
      CASE ES_REQUEST OF
          PV_NONE_REQ:
0189
0190
              SC_ES_CMD_VAL := 0;
0191
          PV_ISOLATE_REQ:
0192
              SC_ES_CMD_VAL := 1;
0193
          PV_PUMP_REQ:
0194
              SC_ES_CMD_VAL := 2;
0195
          PV_VENT_REQ:
0196
              SC_ES_CMD_VAL := 3;
0197
0198
               (* should never get here *)
0199
              SC_ES_CMD_VAL := 0;
0200
      END_CASE;
0201
0202
      (* Current LL_REQ *)
0203
      CASE LL_REQUEST OF
0204
          PV_NONE_REQ:
0205
              SC_LL_CMD_VAL := 0;
0206
          PV_ISOLATE_REQ:
0207
              SC_LL_CMD_VAL := 1;
0208
          PV_PUMP_REQ:
0209
              SC_LL_CMD_VAL := 2;
0210
          PV_VENT_REQ:
0211
              SC_LL_CMD_VAL := 3;
0212
          ELSE
0213
               (* should never get here *)
0214
              SC_LL_CMD_VAL := 0;
0215
      END_CASE;
0216
0217
0218
      (* Current BR_STATE *)
0219
      CASE BR_STATE OF
0220
          BR_ERROR:
0221
              SC_BR_STATE := 0;
0222
          BR_SINS1_READY:
0223
               (* SINS.1 *)
              SC_BR_STATE := 1;
0224
0225
          BR_SINS2_READY:
0226
               (* SINS.2 *)
0227
              SC_BR_STATE := 2;
0228
          BR_SINS3_READY:
0229
               (* SINS.3 *)
0230
              SC_BR_STATE := 3;
0231
          BR_YAG_READY:
0232
               (* YAG *)
0233
              SC_BR_STATE := 4;
0234
          BR_SINS1_SELECTING, BR_SINS2_SELECTING, BR_SINS3_SELECTING, BR_YAG_SELECTING:
0235
               (* BUSY *)
0236
              SC_BR_STATE := 5;
0237
          ELSE
0238
               (* should never get here *)
0239
              SC_BR_STATE := 16#FFFF;
0240
      END_CASE;
0241
0242
      (* Current ES_STATE *)
0243
      CASE ES_STATE OF
          PV_ERROR:
0244
0245
              SC_ES_STATE := 0;
0246
          PV_ISOLATING:
0247
              SC\_ES\_STATE := 1;
0248
          PV_ISOLATED:
0249
              SC\_ES\_STATE := 2;
0250
          PV_SLOW_VENTING:
0251
              SC\_ES\_STATE := 3;
0252
          PV_FAST_VENTING:
0253
              SC\_ES\_STATE := 4;
0254
          PV_VENTED:
0255
              SC\_ES\_STATE := 5;
0256
          PV_RP_STARTING:
0257
              SC\_ES\_STATE := 6;
0258
          PV_RP_PUMPING:
0259
              SC\_ES\_STATE := 7;
0260
          PV_RP_PUMPED:
```


```
SC_ES_STATE := 8;
0261
0262
          PV TP PUMPING:
0263
              SC_ES_STATE := 9;
0264
          PV_PUMPED:
0265
              SC_ES_STATE := 10;
0266
0267
              (* should never get here *)
0268
              SC_ES_STATE := 16#FFFF;
0269
      END_CASE;
0270
0271
      (* Current LL_STATE *)
0272
      CASE LL_STATE OF
0273
          PV_ERROR:
0274
              SC_LL_STATE := 0;
0275
          PV_ISOLATING:
0276
              SC_LL_STATE := 1;
0277
          PV_ISOLATED:
0278
              SC_LL_STATE := 2;
0279
          PV_SLOW_VENTING:
0280
              SC_LL_STATE := 3;
0281
          PV_FAST_VENTING:
0282
              SC_{LL\_STATE} := 4;
0283
          PV_VENTED:
0284
              SC_{LL\_STATE} := 5;
0285
          PV_RP_STARTING:
0286
              SC_{LL}STATE := 6;
0287
          PV_RP_PUMPING:
0288
              SC_{LL\_STATE} := 7;
0289
          PV_RP_PUMPED:
0290
              SC_LL_STATE := 8;
0291
          PV_TP_PUMPING:
0292
              SC_LL_STATE := 9;
          PV_PUMPED:
0293
0294
              SC_{LL\_STATE} := 10;
0295
          ELSE
0296
              (* should never get here *)
              SC_LL_STATE := 16#FFFF;
0297
0298 END_CASE;
Valves (ST)
0001 (* Valve Control Logic *)
0002
0003
      (* V101 *)
0004 V101.open_intlk := LL_PE101_PSL_LO AND LL_PE201_PSL_LO;
0005 V101.open_ena := TRUE;
0006 V101.close_ena := TRUE;
0007 V101.open_req := V101_OPN_REQ_SC;
0008 V101.close_req := V101_CLS_REQ_SC;
0009 V101();
0010
0011
     (* V201 *)
0012 V201.open_intlk := LL_PE201_PSL_LO AND LL_V202_OPN AND LL_PE202_PSL_LO;
0013 | V201.open_ena := TRUE;
0014 | V201.close_ena := TRUE;
0015
     V201.open_req := V201_OPN_REQ_SC;
0016
     V201.close_req := V201_CLS_REQ_SC;
0017
     V201();
0018
0019
      (* V203 *)
0020
      V203.open_intlk := LL_PE202_PSL_LO AND LL_TP201_OK AND LL_PE203_PSL_LO;
0021
      V203.open_ena := TP201_READY;
0022
      V203.close_ena := TRUE;
0023
      V203.open_req := V203_OPN_REQ_SC;
0024
     V203.close_req := V203_CLS_REQ_SC;
0025
      V203();
0026
0027
      (* VPV201 *)
0028
      VPV201.open_intlk := V203_CSD AND V204_CSD AND NOT TP201_ON;
0029
      VPV201.open_ena := NOT TP201.on_cmd;
0030
      VPV201.close_ena := TRUE;
0031
      VPV201.open_req := TP201_VENT_ENABLE_REQ_SC;
0032
      VPV201.close_req := TP201_VENT_DISABLE_REQ_SC;
0033
      VPV201();
0034
```

```
0035 (* V204 *)
0036 V204.open_intlk := LL_PE203_PSL_LO AND LL_TP201_OK AND PE211_PSL_LO;
0037 V204.open_ena := (ES_STATE = PV_PUMPED) AND LLV211_CSD AND TP201_READY;
0038 V204.close_ena := TRUE;
0039 V204.open_req := V204_OPN_REQ_SC;
0040 V204.close_req := V204_CLS_REQ_SC OR V204_CLS_REQ_ES;
0041 V204();
0042
0043 (* LLV211 *)
0044 LLV211.open_intlk := ((ES_STATE = PV_PUMPED) AND (LL_STATE = PV_PUMPED)) OR
0045
                             ((ES_STATE = PV_VENTED) AND (LL_STATE = PV_VENTED));
0046 LLV211.open_ena := V204_CSD;
0047 LLV211.close_intlk := LL211_ARM_RETRACTED OR LLV211_CSD;
0048 LLV211.close_ena:= LL211_ARM_RETRACTED;
0049 LLV211.open_req := LLV211_OPN_REQ_SC;
0050 LLV211.close_req:= LLV211_CLS_REQ_SC OR LLV211_CLS_REQ_ES OR LLV211_CLS_REQ_LL;
0051 |LLV211();
0052
0053 (* VPV211_SLOW *)
0054 VPV211_SLOW.open_intlk := V204_CSD AND LLV211_CSD AND TPV211_CSD AND RPV211_CSD;
0055 VPV211_SLOW.open_ena:= TRUE;
0056 VPV211_SLOW.close_ena := TRUE;
0057 VPV211_SLOW.open_req:= VPV211_SLOW_OPN_REQ_ES;
0058 VPV211_SLOW.close_req := NOT VPV211_SLOW_OPN_REQ_ES;
0059 VPV211_SLOW();
0060
0061 (* VPV211_FAST *)
0062 | VPV211_FAST.open_intlk := V204_CSD AND LLV211_CSD AND TPV211_CSD AND RPV211_CSD;
0063 VPV211_FAST.open_ena:= TRUE;
0064 VPV211_FAST.close_ena := TRUE;
0065 VPV211_FAST.open_req:= VPV211_FAST_OPN_REQ_ES;
0066 VPV211_FAST.close_req := NOT VPV211_FAST_OPN_REQ_ES;
0067 VPV211_FAST();
0068
0069 (* RPV211 *)
0070 | RPV211.open_intlk := RP211_ON AND V204_CSD AND LLV211_CSD AND VPV211_CSD;
0071 | RPV211.open_ena := NOT PE211_PSL_MIDLO AND RPV212_CSD;
0072 RPV211.close_ena:= TRUE;
0073 | RPV211.open_req := RPV211_OPN_REQ_ES;
0074 RPV211.close_req:= NOT RPV211_OPN_REQ_ES;
0075 RPV211();
0076
0077 (* TPV211 *)
0078 TPV211.open_intlk := PE211_PSL_MIDLO AND LL_BP211_ON AND LL_PE211_PIY_OK AND TP211.on_cmd;
0079 TPV211.open_ena := TRUE;
O080 TPV211.close_ena:= V204_CSD AND LLV211_CSD;
0081 TPV211.open_req := TPV211_OPN_REQ_ES;
O082 TPV211.close_req:= NOT TPV211_OPN_REQ_ES;
0083
     TPV211();
0084
0085 (* VPV212_SLOW *)
O086 VPV212_SLOW.open_intlk := LLV211_CSD AND TPV212_CSD AND RPV212_CSD;
0087 VPV212_SLOW.open_ena:= TRUE;
0088 VPV212_SLOW.close_ena := TRUE;
0089
     VPV212_SLOW.open_req:= VPV212_SLOW_OPN_REQ_LL;
0090
     VPV212_SLOW.close_req := NOT VPV212_SLOW_OPN_REQ_LL;
     VPV212_SLOW();
0091
0092
     (* VPV212_FAST *)
0093 (* VPV212_FAST *)
0094 VPV212_FAST.open_intlk := LLV211_CSD AND TPV212_CSD AND RPV212_CSD;
0095 VPV212_FAST.open_ena. := TRUE;
0096 VPV212_FAST.close_ena := TRUE;
     VPV212_FAST.open_req:= VPV212_FAST_OPN_REQ_LL;
0098_
     VPV212_FAST.close_req := NOT VPV212_FAST_OPN_REQ_LL;
     VPV212_FAST();
0099
0100
     (* RPV212 *)
0101 (* RPV212 *)
0102 RPV212.open_intlk := RP211_ON AND LLV211_CSD AND VPV212_CSD;
0103 RPV212.open_ena
                         := NOT PE212_PSL_MIDLO AND RPV211_CSD;
0104 RPV212.close_ena:= TRUE;
0105 RPV212.open_req
                         := RPV212_OPN_REQ_LL;
0106 RPV212.close_req:= NOT RPV212_OPN_REQ_LL;
0107 RPV212();
```

```
0108
0109
      (* TPV212 *)
0110 TPV212.open_intlk := PE212_PSL_MIDLO AND LL_BP211_ON AND LL_PE212_PIY_OK AND TP212.on_cmd;
0111 TPV212.open_ena
                       := TRUE;
0112 | TPV212.close_ena:= LLV211_CSD;
0113 TPV212.open_req := TPV212_OPN_REQ_LL;
0114 TPV212.close_req:= NOT TPV212_OPN_REQ_LL;
0115 TPV212();
0116
RP_FB (FB-ST)
0001 (* ROUGH PUMP CONTROL *)
0002
     FUNCTION_BLOCK RP_FB
     VAR_INPUT
0003
0004
         on_ena: BOOL;
0005
         off_ena: BOOL;
0006
0007
         on_req : BOOL;
8000
          off_req : BOOL;
0009 END_VAR
0010
     VAR_OUTPUT
0011
          on_cmd: BOOL;
0012
          not_symbol: BOOL;
0013 END_VAR
0014
     VAR
0015
     END_VAR
0001
     on_cmd :=
                  (NOT off_req OR NOT off_ena) AND
0002
                  ((on_ena AND on_req) OR on_cmd);
0003
0004 not_symbol := (on_cmd AND NOT off_ena) OR (NOT on_cmd AND NOT on_ena);
TP_FB (FB-ST)
0001
     FUNCTION_BLOCK TP_FB
0002
      VAR_INPUT
0003
        on_intlk : BOOL;
0004
         on_ena : BOOL;
0005
         off_ena : BOOL;
0006
0007
         on_req : BOOL;
0008
         off_req : BOOL;
0009
     END_VAR
0010
     VAR_OUTPUT
0011
         on_cmd : BOOL;
0012
         not_symbol : BOOL;
0013
     END_VAR
0014
     VAR
0015
     END_VAR
0001
                     on_intlk AND
      on_cmd
0002
                      (NOT (off_ena AND off_req)) AND
0003
                      ((on_ena AND on_req) OR on_cmd);
0004
0005
     not_symbol := (on_cmd AND NOT off_ena) OR
0006
                      (NOT on_cmd AND NOT (on_intlk AND on_ena));
VALVE_BI_FB (FB-ST)
0001 FUNCTION_BLOCK VALVE_BI_FB
0002
     VAR_INPUT
0003
        open_intlk : BOOL; (* open command interlock *)
0004
         open_ena
                      : BOOL; (* open command enable *)
0005
         close_intlk : BOOL; (* close command interlock *)
0006
                       : BOOL; (* close command enable *)
         close_ena
0007
0008
                     : BOOL; (* open command request *)
         open_req
0009
                       : BOOL; (* close command request *)
         close_req
0010 END_VAR
0011
     VAR_OUTPUT
                    : BOOL; (* open command *)
0012
         open_cmd
0013
                      : BOOL; (* close command *)
         close_cmd
0014
         not_symbol
                     : BOOL; (* state change prohibited *)
0015
     END_VAR
0016
      VAR
     Tend_var
0017
0001
0002 | open_cmd:= open_intlk AND
```

```
0003
                       (NOT (close_ena AND close_req)) AND
0004
                       ((open_ena AND open_reg) OR open_cmd);
0005
0006
                  := close_intlk AND
     close_cmd
0007
                       (NOT (open_ena AND open_req)) AND
0008
                       ((close_ena AND close_req) OR close_cmd);
0009
                      (open_cmd AND NOT (close_intlk AND close_ena)) OR
0010 not_symbol
                       (close_cmd AND NOT (open_intlk AND open_ena));
0011
VALVE_FB (FB-ST)
0001 FUNCTION_BLOCK VALVE_FB
     VAR_INPUT
0002
0003
          open_intlk
                        : BOOL; (* open command interlock *)
                        : BOOL; (* open command enable *)
0004
          open_ena
                        : BOOL; (* close command enable *)
0005
          close_ena
0006
0007
                        : BOOL; (* open command request *)
          open_req
0008
                        : BOOL; (* close command request *)
          close_req
0009
     TEND_VAR
0010
     VAR_OUTPUT
                        : BOOL; (* open command *)
0011
          open_cmd
                        : BOOL; (* state change prohibited *)
0012
          not_symbol
0013
     TEND_VAR
0014
     lvar
0015
      END_VAR
0001
     open_cmd:= open_intlk AND
0002
                       (NOT (close_ena AND close_req)) AND
0003
                       ((open_ena AND open_req) OR open_cmd);
0004
0005
     not_symbol := (open_cmd AND NOT close_ena) OR
0006
                       (NOT open_cmd AND NOT (open_intlk AND open_ena));
Actuator
0001 TYPE Actuator :
0002
      STRUCT
0003
          awStatus: ARRAY [0..9] OF WORD; (* actuator status words, incomming*)
0004
          wCommand: WORD;
                                       (* actuator control command, outgoing *)
0005
          wTarget
                    : WORD;
                                               (* actuator target position, outgoing *)
0006
0007
                      : ETHERNET_MODBUSMASTER_TCP;
          oMBMaster
8000
          tonConnect : TON;
                                               (* connection delay timer *)
0009
0010
          xConnect: BOOL;
                                           (* initiate TCP connection *)
                     : BOOL;
0011
          xSend
                                               (* Initiate MB transaction *)
0012
                      : BOOL;
                                               (* Transaction in progress *)
          xBusy
0013
          xDataReady : BOOL;
                                               (* Transaction data ready *)
0014
0015
          wState
                      : WORD := 10;
                                               (* sequencer state *)
0016
     END_STRUCT
0017
     END_TYPE
BR_REQ
0001 TYPE BR_REQ :
0002
          BR_NONE_REQ := 0,
0003
0004
          BR_SINS1_REQ,
          BR_SINS2_REQ,
0005
0006
          BR_SINS3_REQ,
          BR_YAG_REQ
0007
0008
          );
0009
     END_TYPE
BR_ST
0001 TYPE BR_ST :
0002
         (
0003
          BR\_ERROR := 0,
0004
          BR_SINS1_SELECTING,
0005
          BR_SINS1_READY,
0006
          BR_SINS2_SELECTING,
0007
          BR_SINS2_READY,
0008
          BR_SINS3_SELECTING,
0009
          BR_SINS3_READY,
0010
          BR_YAG_SELECTING,
0011
          BR_YAG_READY
```

```
0012
          );
0013
      END_TYPE
PV_REQ
0001
     TYPE PV_REQ :
0002
0003
          PV_NONE_REQ := 0,
0004
          PV_ISOLATE_REQ,
0005
          PV_PUMP_REQ,
0006
          PV_VENT_REQ
0007
          );
8000
      END_TYPE
PV_ST
0001
      TYPE PV_ST :
0002
0003
          PV\_ERROR := 0,
0004
          PV_ISOLATING,
0005
          PV_ISOLATED,
0006
          PV_SLOW_VENTING,
0007
          PV_FAST_VENTING,
0008
          PV_VENTED,
0009
          PV_RP_STARTING,
0010
          PV_RP_PUMPING,
0011
          PV_RP_PUMPED,
0012
          PV_TP_PUMPING,
0013
          PV_PUMPED
0014
          );
0015 END_TYPE
ACTUATOR_VISU
                                                     ACTUATORS
                                 Request
                                                              Readback
                                                                           <u>Position</u>
                                                                                       Target
         BR SELECTOR SINS.1
                                 SINS.2
                                         SINS.3
                                                   YAG
                                                                %d
                                                                             %d
                                                                                         %d
AUTO_VISU
                                               AUTO STATE MACHINES
                                                                               EXT VAL
                                                                                           INT VAL
                                     Request
                                                                     <u>CMD</u>
    BR SELECTOR
                    NONE
                            SINS.1
                                     SINS.2
                                              SINS.3
                                                        YAG
                                                                     %d
                                                                                 %d
                                                                                         %s
    ES_PUMPVENT
                    NONE
                            ISOLATE
                                      PUMP
                                              VENT
                                                                     %d
                                                                                 %d
                                                                                         %s
    LL_PUMPVENT
                    NONE
                            ISOLATE
                                      PUMP
                                              VENT
                                                                     %d
                                                                                 %d
                                                                                         %s
INTLKS_VISU
                    Interlocks
                     EPS Reset
                        Reset
           Branchline
                                   Endstation
    ACTUATOR_OK
                           ES_CONFIG_OK
        PE101 PSL
                           LL_CONFIG_OK
        PE201 PSL
                                PE211_OK
         MOOD ODNI
                                DEG10 OV
```



```
VZUZ
                                                                  Deam
     Open
              Close
                       V203
                                                       Open
                                                                  Beam
             Disable
                       VENT201
     Enable
                                                       Enabled
     Open
              Close
                       V204
                                                       Open
                                                                  Beam
                       VENT211
                                                       Slow
                                                                  Fast
                       RPV211
                                                       Open
                       TPV211
                                                       Open
              Close
                       SLOTV211
     Open
                                                       Open
                                                                  Close
                       VENT212
                                                       Slow
                                                                  Fast
                       RPV212
                                                       Open
                       TPV212
                                                       Open
Global_Variables
0001 VAR_GLOBAL
0002
                              : BOOL; (* In Position *)
          xActuatorReady
                              : WORD; (* Current Status *)
0003
          wActuatorStatus
0004
          wActuatorPosition : WORD; (* Current Position *)
                              : WORD; (* Current Alarm *)
0005
          wActuatorAlarm
0006
     END_VAR
0007
      VAR_GLOBAL RETAIN
8000
          wActuatorTarget
                               : WORD; (* Target Position *)
0009
      END_VAR
Variable_Configuration
0001 VAR_CONFIG
0002 END_VAR
Global Variables 0
0001
     VAR_GLOBAL
0002 END_VAR
Globale_Variablen
0001 VAR_GLOBAL
0002 END_VAR
Version
0001 VAR_GLOBAL CONSTANT
0002
        rVersion:REAL:=1.001;
0003 END_VAR
Globale_Variablen
0001 VAR_GLOBAL CONSTANT
0002
          SOCKET_INVALID:DINT:=-1;
0003
0004
          (* AddressFamily *)
0005
          SOCKET_AF_UNSPEC:INT:= 0;
                                               (* unspecified *)
0006
                                                   (* local to host (pipes, portals) *)
          SOCKET_AF_LOCAL:INT:= 1;
0007
          SOCKET_AF_UNIX:INT:=SOCKET_AF_LOCAL;
                                                   (* backward compatibility *)
0008
                                                    (* internetwork: UDP, TCP, etc. *)
          SOCKET_AF_INET:INT:=2;
0009
                                                    (* arpanet imp addresses *)
          SOCKET_AF_IMPLINK:INT:=3;
                                                    (* pup protocols: e.g. BSP *)
0010
          SOCKET_AF_PUP:INT:=4;
                                                (* mit CHAOS protocols *)
0011
          SOCKET_AF_CHAOS:INT:=5;
0012
          SOCKET_AF_NS:INT:=6;
                                                (* XEROX NS protocols *)
          SOCKET_AF_ISO:INT:=7;
0013
                                                    (* ISO protocols *)
0014
          SOCKET_AF_OSI:INT:=SOCKET_AF_ISO;
0015
          SOCKET_AF_ECMA:INT:=8;
                                                (* european computer manufacturers *)
0016
          SOCKET_AF_DATAKIT:INT:=9;
                                                    (* datakit protocols *)
0017
          SOCKET_AF_CCITT:INT:=10;
                                                (* CCITT protocols, X.25 etc *)
```

```
0018
          SOCKET_AF_SNA:INT:=11;
                                                  (* IBM SNA *)
0019
          SOCKET AF DECnet:INT:=12;
                                                  (* DECnet *)
0020
          SOCKET_AF_DLI:INT:=13;
                                                  (* DEC Direct data link interface *)
0021
          SOCKET_AF_LAT:INT:= 14;
                                                  (* LAT *)
0022
          SOCKET_AF_HYLINK:INT:=15;
                                                  (* NSC Hyperchannel *)
0023
          SOCKET_AF_APPLETALK:INT:=16;
                                          (* Apple Talk *)
0024
          SOCKET_AF_ROUTE:INT:=17;
                                              (* Internal Routing Protocol *)
                                              (* Link layer interface *)
0025
          SOCKET_AF_LINK:INT:=18;
                                              (* eXpress Transfer Protocol (no AF) *)
0026
          SOCKET_pseudo_AF_XTP:INT:=19;
0027
          SOCKET_AF_COIP:INT:=20;
                                              (* connection-oriented IP, aka ST II *)
0028
          SOCKET_AF_CNT:INT:=21;
                                              (* Computer Network Technology *)
                                              (* Help Identify RTIP packets *)
0029
          SOCKET_pseudo_AF_RTIP:INT:=22;
                                                  (* Novell Internet Protocol *)
0030
          SOCKET_AF_IPX:INT:=23;
0031
          SOCKET_AF_SIP:INT:=24;
                                                  (* Simple Internet Protocol *)
0032
          SOCKET_pseudo_AF_PIP:INT:=25;
                                              (* Help Identify PIP packets *)
0033
          SOCKET_AF_MAX:INT:=26;
0034
          SOCKET_AF_INET_BSD:INT:=100; (* BSD-specific INET af *)
0035
          SOCKET_AF_INET_STREAMS:INT:=101; (* STREAMS-specific INET af *)
0036
0037
          (* Level number for (get/set)sockopt() to apply to socket itself. *)
0038
          SOCKET_SOL:WORD:=16#ffff;
0039
0040
          (* Socket options *)
0041
          SOCKET_SO_DEBUG:DINT:=16#0001;
                                                 (* turn on debugging info recording *)
0042
          SOCKET_SO_ACCEPTCONN:DINT:=16#0002; (* socket has had listen() *)
          SOCKET_SO_REUSEADDR:DINT:=16#0004; (* allow local address reuse *)
0043
0044
          SOCKET_SO_KEEPALIVE:DINT:=16#0008;
                                                 (* keep connections alive *)
          SOCKET_SO_DONTROUTE:DINT:=16#0010; (* just use interface addresses *)
0045
          SOCKET_SO_BROADCAST:DINT:=16#0020; (* permit sending of broadcast msgs *)
0046
0047
          SOCKET_SO_USELOOPBACK:DINT:=16#0040; (* bypass hardware when possible *)
0048
          SOCKET_SO_LINGER:DINT:=16#0080;
                                                 (* linger on close if data present *)
                                                 (* leave received OOB data in line *)
0049
          SOCKET_SO_OOBINLINE:DINT:=16#0100;
0050
          SOCKET_SO_REUSEPORT:DINT:=16#0200; (* allow local address & port reuse *)
          SOCKET_SO_SNDBUF:DINT:=16#1001;
                                             (* send buffer size *)
0051
0052
          SOCKET_SO_RCVBUF:DINT:= 16#1002;
                                             (* receive buffer size *)
0053
          SOCKET_SO_SNDLOWAT:DINT:=16#1003; (* send low-water mark *)
0054
          SOCKET_SO_RCVLOWAT:DINT:=16#1004; (* receive low-water mark *)
0055
          SOCKET_SO_SNDTIMEO:DINT:=16#1005;
                                             (* send timeout *)
0056
          SOCKET_SO_RCVTIMEO:DINT:=16#1006; (* receive timeout *)
0057
          SOCKET_SO_ERROR:DINT:=16#1007;
                                             (* get error status and clear *)
0058
          SOCKET_SO_TYPE:DINT:=16#1008;
                                                 (* get socket type *)
0059
          SOCKET_SO_PROTOTYPE:DINT:=16#1009; (* get/set protocol type *)
          (* TCPIP socket options *)
0060
0061
          SOCKET_TCP_NODELAY:DINT:=16#01; (* don't delay send to coalesce packets *)
0062
          SOCKET_TCP_MAXSEG:DINT:=16#02; (* set maximum segment size *)
0063
0064
          (* Socket types *)
0065
          SOCKET_STREAM:DINT:=1;
                                          (* stream socket *)
0066
          SOCKET_DGRAM:DINT:=2;
                                          (* datagram socket *)
0067
          SOCKET_RAW:DINT:=3;
                                          (* raw-protocol interface *)
0068
          SOCKET_RDM:DINT:=4;
                                          (* reliably-delivered message *)
0069
          SOCKET_SEQPACKET:DINT:=5;
                                          (* sequenced packet stream *)
0070
0071
          (* Inet address definitions *)
          SOCKET_INADDR_ANY:UDINT:=16#0000000;
0072
0073
          SOCKET_INADDR_LOOPBACK:UDINT:=16#7f000001;
          SOCKET_INADDR_BROADCAST:UDINT:=16#ffffffff;
0074
          SOCKET_INADDR_NONE:UDINT:=16#ffffffff;
0075
0076
          (* Protocols *)
0077
0078
          SOCKET_IPPROTO_IP:DINT:=0;
                                             (* dummy for IP *)
0079
          SOCKET_IPPROTO_ICMP:DINT:=1;
                                          (* control message protocol *)
0080
          SOCKET_IPPROTO_IGMP:DINT:=2;
                                          (* group management protocol *)
0081
          SOCKET_IPPROTO_GGP:DINT:=3;
                                          (* gateway^2 (deprecated) *)
0082
          SOCKET_IPPROTO_TCP:DINT:=6;
                                          (* tcp *)
0083
          SOCKET_IPPROTO_PUP:DINT:=12;
                                          (* pup *)
0084
          SOCKET_IPPROTO_UDP:DINT:=17;
                                          (* user datagram protocol *)
                                          (* xns idp *)
0085
          SOCKET_IPPROTO_IDP:DINT:=22;
                                          (* UNOFFICIAL net disk proto *)
0086
          SOCKET_IPPROTO_ND:DINT:=77;
                                          (* raw IP packet *)
0087
          SOCKET_IPPROTO_RAW:DINT:=255;
0088
          SOCKET_IPPROTO_MAX:DINT:=256;
0089
          (* Flags *)
0090
```

```
0091
          SOCKET_MSG_OOB:DINT:=16#1;
                                               (* process out-of-band data *)
          SOCKET MSG_PEEK:DINT:=16#2;
0092
                                              (* peek at incoming message *)
0093
          SOCKET_MSG_DONTROUTE:DINT:=16#4; (* send without using routing tables *)
0094
0095
          (* Ioctl commands *)
0096
          SOCKET_FIONREAD:DINT:=1;
                                              (* get num chars available to read *)
          SOCKET_FIONBIO:DINT:=2;
0097
                                                  (* set to non-blocking *)
0098
0099
          (* For SysSockSelect() descriptors *)
0100
          SOCKET_FD_SETSIZE :DINT := 64;
0101
          MAX_SOCKET_FD_SETSIZE : DINT := 63;
0102
      END_VAR
Globale_Variablen
0001 VAR_GLOBAL
0002 END_VAR
Alarm configuration
     Alarm configuration
     Alarm classes
         System
PLC Configuration
*Hardware configuration (Id.: 2010000001)
  Node number: -1
  Input address: %IB0
  Output address: %QB0
  Diagnostic address: %MB0
  Download: 1
  AutoAdr: 1
  *K-Bus (* WAGO 750-881 PFC ETHERNET *) [FIX] (Id.: 11994)
    Node number: 0
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
    *0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
      Node number: 0
      Input address: %IB0
      Output address: %QB0
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        AI_PE101_PIY AT %IWO: WORD; (* SINS.1 Branchline UHV pressure *) [CHANNEL (I)]
        AI_PE201_PIY AT %IW1: WORD; (* M201 UHV range pressure *) [CHANNEL (I)]
        AI_PE202_PIY AT %IW2: WORD; (* M202 UHV range pressure *) [CHANNEL (I)]
        AI_SPARE04 AT %IW3: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
    *0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
      Node number: 1
      Input address: %IB1
      Output address: %QB1
      Diagnostic address: %MB0
      Download:
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        AI_PE203_HI_PIY AT %IW4: WORD; (* FTR201 High range pressure *) [CHANNEL (I)]
        AI_PE203_LO_PIY AT %IW5: WORD; (* FTR201 Low range pressure *) [CHANNEL (I)]
        AI_PE211_HI_PIY AT %IW6: WORD; (* ES211 High range pressure *) [CHANNEL (I)]
        AI_PE211_LO_PIY AT %IW7: WORD; (* ES211 Low range pressure *) [CHANNEL (I)]
    *0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
      Node number: 2
```

Input address: %IB2

```
Output address: %QB2
  Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
  Channels:
   AI_PE212_HI_PIY AT %IW8: WORD; (* LL211 High range pressure *) [CHANNEL (I)]
    AI_PE212_LO_PIY AT %IW9: WORD; (* LL211 Low range pressure *) [CHANNEL (I)]
    AI_SPARE11 AT %IW10: WORD; (* Ch_3 Input word *) [CHANNEL (I)]
    AI_SPARE12 AT %IW11: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
*0750-0459 4 AI 0-10V DC s.e.[VAR] (Id.: 2000008004)
 Node number: 3
  Input address: %IB3
 Output address: %QB3
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   AI_SPARE13 AT %IW12: WORD; (* Ch_1 Input word *) [CHANNEL (I)]
   AI_SPARE14 AT %IW13: WORD; (* Ch_2 Input word *) [CHANNEL (I)]
    AI_SPARE15 AT %IW14: WORD; (* Ch_3 Input word *) [CHANNEL (I)]
    AI_SPARE16 AT %IW15: WORD; (* Ch_4 Input word *) [CHANNEL (I)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 4
  Input address: %IB4
  Output address: %QB4
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DO_RP2110_ON_CMD AT %QX0.0: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_RP2111_ON_CMD AT %QX0.1: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_V101_OPEN_CMD AT %QX0.2: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_V201_OPEN_CMD AT %QX0.3: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_V203_OPEN_CMD AT %QX0.4: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_V204_OPEN_CMD AT %QX0.5: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_TP201_ON_CMD AT %QX0.6: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_TP201_VENT_ENABLE_CMD AT %QX0.7: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 5
  Input address: %IB5
 Output address: %QB5
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
    DO_TP211_ON_CMD AT %QX0.8: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_TPV211_OPEN_CMD AT %QX0.9: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_RPV211_OPEN_CMD AT %QX0.10: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_VENT211_SLOW_CMD AT %QX0.11: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_VENT211_FAST_CMD AT %QX0.12: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_14 AT %QX0.13: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SLOTV211_OPEN_CMD AT %QX0.14: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SLOTV211_CLOSE_CMD AT %QX0.15: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 6
  Input address: %IB6
  Output address: %QB6
  Diagnostic address: %MB0
  Download: 1
  AutoAdr: 1
 Parameter:
```

```
PAAssignment: PLC
  Channels:
    DO_TP212_ON_CMD AT %QX1.0: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_TPV212_OPEN_CMD AT %QX1.1: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_RPV212_OPEN_CMD AT %QX1.2: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_VENT212_SLOW_CMD AT %QX1.3: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_VENT212_FAST_CMD AT %QX1.4: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_22 AT %QX1.5: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SPARE_23 AT %QX1.6: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SPARE_24 AT %QX1.7: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0530 8 DO 24 V DC 0.5A[VAR] (Id.: 2000010008)
 Node number: 7
  Input address: %IB7
 Output address: %QB7
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DO_SPARE_25 AT %QX1.8: BOOL; (* Ch_1 Digital output *) [CHANNEL (Q)]
    DO_SPARE_26 AT %QX1.9: BOOL; (* Ch_2 Digital output *) [CHANNEL (Q)]
    DO_SPARE_27 AT %QX1.10: BOOL; (* Ch_3 Digital output *) [CHANNEL (Q)]
    DO_SPARE_28 AT %QX1.11: BOOL; (* Ch_4 Digital output *) [CHANNEL (Q)]
    DO_SPARE_29 AT %QX1.12: BOOL; (* Ch_5 Digital output *) [CHANNEL (Q)]
    DO_SPARE_30 AT %QX1.13: BOOL; (* Ch_6 Digital output *) [CHANNEL (Q)]
    DO_SPARE_31 AT %QX1.14: BOOL; (* Ch_7 Digital output *) [CHANNEL (Q)]
    DO_SPARE_32 AT %QX1.15: BOOL; (* Ch_8 Digital output *) [CHANNEL (Q)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 8
 Input address: %IB8
 Output address: %QB8
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DI_PE101_PSL_LO AT %IX16.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE201_PSL_LO AT %IX16.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE202_PSL_LO AT %IX16.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_SPARE_04 AT %IX16.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_RP2110_ON AT %IX16.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_RP2111_ON AT %IX16.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE2110_PSL AT %IX16.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE2111_PSL AT %IX16.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 9
  Input address: %IB9
  Output address: %QB9
 Diagnostic address: %MB0
 Download:
 AutoAdr:
 Parameter:
   PAAssignment: PLC
 Channels:
    DI_PE203_PIY_OK AT %IX16.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE211_PIY_OK AT %IX16.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE212_PIY_OK AT %IX16.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_SPARE_12 AT %IX16.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_HI AT %IX16.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_MIDHI AT %IX16.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_MIDLO AT %IX16.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE203_PSL_LO AT %IX16.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 10
  Input address: %IB10
  Output address: %QB10
  Diagnostic address: %MB0
```

```
Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
  Channels:
    DI_PE211_PSL_HI AT %IX17.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_MIDHI AT %IX17.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_MIDLO AT %IX17.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_PE211_PSL_LO AT %IX17.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_HI AT %IX17.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_MIDHI AT %IX17.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_MIDLO AT %IX17.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_PE212_PSL_LO AT %IX17.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 11
 Input address: %IB11
 Output address: %QB11
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
   DI_V100_OPEN AT %IX17.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_V100_CLOSED AT %IX17.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_V101_OPEN AT %IX17.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_V101_CLOSED AT %IX17.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_V201_OPEN AT %IX17.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_V201_CLOSED AT %IX17.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_V202_OPEN AT %IX17.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_V202_CLOSED AT %IX17.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 12
 Input address: %IB12
 Output address: %QB12
 Diagnostic address: %MB0
 Download: 1
 AutoAdr: 1
 Parameter:
   PAAssignment: PLC
 Channels:
    DI_V203_OPEN AT %IX18.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_V203_CLOSED AT %IX18.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_V204_OPEN AT %IX18.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_V204_CLOSED AT %IX18.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_TP201_TURBO_OK AT %IX18.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_TP201_AT_SPEED AT %IX18.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_RPV211_OPEN AT %IX18.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_RPV211_CLOSED AT %IX18.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 13
  Input address: %IB13
 Output address: %QB13
 Diagnostic address: %MB0
 Download:
 AutoAdr: 1
 Parameter:
    PAAssignment: PLC
 Channels:
    DI_TPV211_OPEN AT %IX18.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
    DI_TPV211_CLOSED AT %IX18.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
    DI_RPV212_OPEN AT %IX18.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
    DI_RPV212_CLOSED AT %IX18.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
    DI_TPV212_OPEN AT %IX18.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
    DI_TPV212_CLOSED AT %IX18.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
    DI_TP211_AT_SPEED AT %IX18.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
    DI_TP211_TURBO_OK AT %IX18.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
*0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
 Node number: 14
```

```
Input address: %IB14
      Output address: %QB14
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        DI_TP212_AT_SPEED AT %IX19.0: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
        DI_TP212_TURBO_OK AT %IX19.1: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
        DI_SLOTV211_OPEN AT %IX19.2: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
        DI_SLOTV211_CLOSED AT %IX19.3: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
        DI_LL211_LID_CLOSED AT %IX19.4: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
        DI_LL211_ARM_RETRACTED AT %IX19.5: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
        DI_SPARE_55 AT %IX19.6: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
        DI_SPARE_56 AT %IX19.7: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
    *0750-0430 8 DI 24 V DC 3.0ms[VAR] (Id.: 2000001008)
      Node number: 15
      Input address: %IB15
      Output address: %QB15
      Diagnostic address: %MB0
      Download: 1
      AutoAdr: 1
      Parameter:
        PAAssignment: PLC
      Channels:
        DI_SPARE_57 AT %IX19.8: BOOL; (* Ch_1 Digital input *) [CHANNEL (I)]
        DI_SPARE_58 AT %IX19.9: BOOL; (* Ch_2 Digital input *) [CHANNEL (I)]
        DI_SPARE_59 AT %IX19.10: BOOL; (* Ch_3 Digital input *) [CHANNEL (I)]
        DI_SPARE_60 AT %IX19.11: BOOL; (* Ch_4 Digital input *) [CHANNEL (I)]
        DI_SPARE_61 AT %IX19.12: BOOL; (* Ch_5 Digital input *) [CHANNEL (I)]
        DI_SPARE_62 AT %IX19.13: BOOL; (* Ch_6 Digital input *) [CHANNEL (I)]
        DI_SPARE_63 AT %IX19.14: BOOL; (* Ch_7 Digital input *) [CHANNEL (I)]
        DI_SPARE_64 AT %IX19.15: BOOL; (* Ch_8 Digital input *) [CHANNEL (I)]
  *Fieldbus variables[FIX] (Id.: 2010310001)
    Node number: 1
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
  *Flag variables[FIX] (Id.: 2010320001)
    Node number: 2
    Input address: %IB0
    Output address: %QB0
    Diagnostic address: %MB0
    Download: 1
    AutoAdr: 1
Sampling Trace
 No trace loaded
Task configuration
     Task configuration
     System events
          Main (PRIORITY := 1, INTERVAL := T#15ms
         PLC_PRG();
          IAI (PRIORITY := 3, INTERVAL := T#100ms
              Actuator_SM();
Watch- and Recipe Manager
Workspace
Parameter Manager
0001 Parameter-Manager
0002
     |----
Cross Reference List
xDataReady
     ACTUATOR_SM (23)
                                            Local Read
```

```
ACTUATOR_SM (50)
                                            Local Read
     ACTUATOR SM (59)
                                           Local Read
     ACTUATOR_SM (67)
                                           Local Read
     ACTUATOR_SM (76)
                                           Local Read
     ACTUATOR_SM (85)
                                           Local Read
     ACTUATOR_SM (92)
                                           Local Read
     ACTUATOR_SM (105)
                                           Local Read
     ACTUATOR_SM (122)
                                           Local Read
     ACTUATOR_SM (130)
                                           Local Read
     ACTUATOR_SM.DRG1_W... (34)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (38)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (40)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (35)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (39)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (41)
                                          Local Write
     ACTUATOR_SM.STATUS... (34)
                                          Local Write
     ACTUATOR_SM.STATUS... (41)
                                          Local Write
     ACTUATOR_SM.STATUS... (43)
                                          Local Write
     ACTUATORinit (11)
                                           Local Write
xSend
     ACTUATOR_SM.CONNECT (9)
                                          Local Write
     ACTUATOR_SM.CONNECT (25)
                                          Local Read
     ACTUATOR_SM.DRG1_W... (7)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (26)
                                          Local Read
     ACTUATOR_SM.DRG1_W... (36)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (8)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Read
     ACTUATOR_SM.PCMD_W... (37)
                                          Local Read
     ACTUATOR_SM.STATUS... (7)
                                          Local Write
     ACTUATOR_SM.STATUS... (26)
                                           Local Read
     ACTUATOR_SM.STATUS... (36)
                                           Local Read
     ACTUATORinit (9)
                                           Local Write
xConnect
     ACTUATOR_SM (5)
                                           Local Write
     ACTUATOR_SM (10)
                                           Local Write
     ACTUATOR_SM (145)
                                          Local Write
     ACTUATOR_SM.CONNECT (6)
                                          Local Read
     ACTUATOR_SM.CONNECT (31)
                                          Local Write
     ACTUATOR_SM.DRG1_W... (32)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (33)
                                           Local Write
     ACTUATOR_SM.STATUS... (32)
                                           Local Write
     ACTUATORinit (8)
                                           Local Write
wActuatorTarget
     ACTUATOR_SM (107)
                                           Global Read
     ACTUATOR_SM.PCMD_W... (6)
                                           Global Read
     PLC_PRG.ACTUATOR_O... (4)
                                           Global Write
     _global_init (1)
                                           Global Write
xBusy
     ACTUATOR_SM (17)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (5)
                                           Local Read
     ACTUATOR_SM.DRG1_W... (6)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (33)
                                           Local Write
     ACTUATOR_SM.DRG1_W... (37)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (5)
                                           Local Read
     ACTUATOR_SM.PCMD_W... (7)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (34)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (38)
                                           Local Write
     ACTUATOR_SM.STATUS... (5)
                                           Local Read
     ACTUATOR_SM.STATUS... (6)
                                           Local Write
     ACTUATOR_SM.STATUS... (33)
                                           Local Write
     ACTUATOR_SM.STATUS... (40)
                                           Local Write
     ACTUATORinit (10)
                                            Local Write
wActuatorStatus
     ACTUATOR_SM.STATUS... (39)
                                           Global Write
     PLC_PRG.ACTUATOR_I... (3)
                                           Global Read
     _global_init (2)
                                           Global Write
xActuatorReady
     ACTUATOR_SM (4)
                                           Global Write
     ACTUATOR_SM (110)
                                           Global Write
     ACTUATOR_SM (115)
                                           Global Write
     PLC_PRG.ACTUATOR_I... (5)
                                           Global Read
     _global_init (1)
                                           Global Write
wActuatorPosition
```

```
ACTUATOR_SM (107)
                                            Global Read
     ACTUATOR_SM.STATUS... (37)
                                           Global Write
     PLC_PRG.ACTUATOR_I... (7)
                                           Global Read
                                            Global Write
     _global_init (3)
VPV212_OPN
     PLC_PRG.PROCESS_IN... (64)
                                           Local Write
     PLC_PRG.PROCESS_IN... (65)
                                           Local Read
     _global_init (211)
                                            Local Write
wTarget
     ACTUATOR_SM.PCMD_W... (6)
                                           Local Write
     ACTUATOR_SM.PCMD_W... (27)
                                           Local Read
     ACTUATORinit (5)
                                           Local Write
wActuatorAlarm
     ACTUATOR_SM.STATUS... (38)
                                           Global Write
     _global_init (4)
                                            Global Write
VPV211_SLOW_OPN_REQ_ES
     PLC_PRG.ES_SM (14)
                                           Local Write
     PLC_PRG.ES_SM (28)
                                           Local Write
     PLC_PRG.ES_SM (42)
                                           Local Write
     PLC_PRG.ES_SM (60)
                                           Local Write
     PLC_PRG.ES_SM (78)
                                           Local Write
                                           Local Write
     PLC_PRG.ES_SM (96)
     PLC_PRG.ES_SM (114)
                                           Local Write
     PLC_PRG.ES_SM (133)
                                           Local Write
     PLC_PRG.ES_SM (151)
                                           Local Write
     PLC_PRG.ES_SM (172)
                                           Local Write
     PLC_PRG.ES_SM (192)
                                           Local Write
     PLC_PRG.VALVES (57)
                                            Local Read
     PLC_PRG.VALVES (58)
                                            Local Read
     _global_init (258)
                                            Local Write
V100_OPN
     PLC_PRG.BYPASSES (8)
                                            Local Write
     PLC_PRG.PROCESS_IN... (30)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (37)
                                            Local Read
     _global_init (191)
                                            Local Write
wState
     ACTUATOR_SM (3)
                                            Local Read
     ACTUATOR_SM (7)
                                            Local Write
     ACTUATOR_SM (9)
                                            Local Read
     ACTUATOR_SM (12)
                                            Local Write
     ACTUATOR_SM (14)
                                            Local Read
     ACTUATOR_SM (18)
                                            Local Write
     ACTUATOR_SM (21)
                                            Local Read
     ACTUATOR_SM (27)
                                            Local Write
     ACTUATOR_SM (31)
                                            Local Write
     ACTUATOR_SM (35)
                                            Local Write
     ACTUATOR_SM (39)
                                            Local Write
     ACTUATOR_SM (42)
                                            Local Write
     ACTUATOR_SM (46)
                                            Local Read
     ACTUATOR_SM (52)
                                            Local Write
     ACTUATOR_SM (55)
                                            Local Read
     ACTUATOR_SM (61)
                                            Local Write
     ACTUATOR_SM (64)
                                            Local Read
     ACTUATOR_SM (69)
                                            Local Write
     ACTUATOR_SM (72)
                                            Local Read
     ACTUATOR_SM (78)
                                            Local Write
     ACTUATOR_SM (81)
                                            Local Read
     ACTUATOR_SM (87)
                                            Local Write
     ACTUATOR_SM (90)
                                            Local Read
     ACTUATOR_SM (96)
                                            Local Write
     ACTUATOR_SM (99)
                                            Local Write
     ACTUATOR_SM (103)
                                            Local Read
     ACTUATOR_SM (111)
                                            Local Write
     ACTUATOR_SM (116)
                                            Local Write
     ACTUATOR_SM (120)
                                            Local Read
     ACTUATOR_SM (125)
                                            Local Write
     ACTUATOR_SM (128)
                                            Local Read
     ACTUATOR_SM (136)
                                            Local Write
     ACTUATOR_SM (140)
                                            Local Write
     ACTUATOR_SM (146)
                                            Local Write
     ACTUATOR_SM.CONNECT (32)
                                            Local Write
     ACTUATOR_SM.DRG1_W... (35)
                                            Local Write
     ACTUATOR_SM.PCMD_W... (36)
                                            Local Write
```

```
ACTUATOR_SM.STATUS... (35)
                                              Local Write
     ACTUATORinit (12)
                                             Local Write
VPV212_SLOW_OPN_REQ_LL
     PLC_PRG.LL_SM (14)
                                            Local Write
     PLC_PRG.LL_SM (27)
                                             Local Write
     PLC_PRG.LL_SM (40)
                                             Local Write
      PLC_PRG.LL_SM (57)
                                             Local Write
      PLC_PRG.LL_SM (74)
                                             Local Write
      PLC_PRG.LL_SM (91)
                                             Local Write
      PLC_PRG.LL_SM (108)
                                            Local Write
      PLC_PRG.LL_SM (126)
                                            Local Write
      PLC_PRG.LL_SM (143)
                                            Local Write
     PLC_PRG.LL_SM (163)
                                            Local Write
      PLC_PRG.LL_SM (182)
                                            Local Write
      PLC_PRG.VALVES (89)
                                             Local Read
     PLC_PRG.VALVES (90)
                                             Local Read
      _global_init (270)
                                             Local Write
VPV212_SLOW_CLS_REQ_LL
     _global_init (271)
                                             Local Write
VPV212_SLOW
     PLC_PRG.PROCESS_OU... (24)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (99)
                                            Local Read
     PLC_PRG.VALVES (86)
                                            Local Write
     PLC_PRG.VALVES (87)
                                            Local Write
     PLC_PRG.VALVES (88)
                                            Local Write
     PLC_PRG.VALVES (89)
                                            Local Write
     PLC_PRG.VALVES (90)
                                            Local Write
     PLC_PRG.VALVES (91)
                                              Local Read
     _global_init (304)
                                              Local Read
VPV211_SLOW_CLS_REQ_ES
     _global_init (259)
                                              Local Write
SC_VERSION_MAJOR%MW1280
    PLC_PRG.SC_OUTPUTS (156)
                                            Local Write
     _global_init (147)
                                            Local Write
SC_VENT212_SLOW_CMD%MX8.11
    PLC_PRG.SC_OUTPUTS (99)
                                            Local Write
                                              Local Write
     _global_init (90)
uiSuccessful
     ACTUATOR_SM (134)
                                              Local Read
     ACTUATOR_SM (134)
                                              Local Write
      _global_init (7)
                                              Local Write
SC_VENT211_SLOW_CMD%MX6.11
    PLC_PRG.SC_OUTPUTS (80)
                                            Local Write
      _global_init (75)
                                              Local Write
SC_V203_OPN_REQ%MX641.6
                                            Local Write
     PLC_PRG.CLEAR_REQS (11)
     PLC_PRG.SC_INPUTS (11)
                                              Local Read
     _global_init (137)
                                              Local Write
tTCP_Watchdog
     ACTUATOR_SM.CONNECT (25)
                                            Local Read
     ACTUATOR_SM.CONNECT (25)
ACTUATOR_SM.DRG1_W... (26)
ACTUATOR_SM.PCMD_W... (27)
ACTUATOR_SM.STATUS... (26)
                                              Local Read
                                              Local Read
                                              Local Read
      _global_init (5)
                                              Local Write
SC_V203_OPEN_CMD%MX5.5
     PLC_PRG.SC_OUTPUTS (65)
                                              Local Write
     _global_init (63)
                                              Local Write
wPort
     ACTUATOR_SM.CONNECT (25)
                                              Local Read
     ACTUATOR_SM.DRG1_W... (26)
ACTUATOR_SM.PCMD_W... (27)
ACTUATOR_SM.STATUS... (26)
                                              Local Read
                                              Local Read
                                              Local Read
      _global_init (2)
                                              Local Write
VPV212_FAST_CLS_REQ_LL
      _global_init (273)
                                              Local Write
VPV212_FAST
     PLC_PRG.PROCESS_OU... (25)
PLC_PRG.SC_OUTPUTS (100)
                                            Local Read
                                              Local Read
                                              Local Write
      PLC_PRG.VALVES (94)
      PLC_PRG.VALVES (95)
                                              Local Write
      PLC_PRG.VALVES (96)
                                              Local Write
     PLC_PRG.VALVES (97)
                                              Local Write
                                              Local Write
      PLC_PRG.VALVES (98)
```

```
PLC_PRG.VALVES (99)
                                           Local Read
      _global_init (305)
                                           Local Read
VPV212_FAST_OPN_REQ_LL
     PLC_PRG.LL_SM (15)
                                          Local Write
     PLC_PRG.LL_SM (28)
                                          Local Write
     PLC_PRG.LL_SM (41)
                                          Local Write
     PLC_PRG.LL_SM (58)
                                          Local Write
     PLC_PRG.LL_SM (75)
                                          Local Write
     PLC_PRG.LL_SM (92)
                                          Local Write
     PLC_PRG.LL_SM (109)
                                          Local Write
     PLC_PRG.LL_SM (127)
                                          Local Write
     PLC_PRG.LL_SM (144)
                                          Local Write
     PLC_PRG.LL_SM (164)
                                          Local Write
                                          Local Write
     PLC_PRG.LL_SM (183)
     PLC_PRG.VALVES (97)
                                          Local Read
     PLC_PRG.VALVES (98)
                                          Local Read
     _global_init (272)
                                          Local Write
VPV212_CSD
                                         Local Write
     PLC_PRG.PROCESS_IN... (65)
     PLC_PRG.VALVES (102)
                                          Local Read
     _global_init (212)
                                          Local Write
VPV211_SLOW
                                         Local Read
     PLC_PRG.PROCESS_OU... (15)
     PLC_PRG.SC_OUTPUTS (80)
                                          Local Read
     PLC_PRG.VALVES (54)
                                          Local Write
     PLC_PRG.VALVES (55)
                                          Local Write
     PLC_PRG.VALVES (56)
                                          Local Write
     PLC_PRG.VALVES (57)
                                          Local Write
     PLC_PRG.VALVES (58)
                                          Local Write
     PLC_PRG.VALVES (59)
                                           Local Read
     _global_init (299)
                                           Local Read
VPV211_CSD
     PLC_PRG.PROCESS_IN... (53)
                                          Local Write
     PLC_PRG.VALVES (70)
                                           Local Read
     _global_init (204)
                                           Local Write
VPV211_OPN
     PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_IN... (53)
                                          Local Write
                                         Local Read
                                           Local Write
     _global_init (203)
VPV211_FAST_CLS_REQ_ES
     _global_init (261)
                                           Local Write
VPV211_FAST
     PLC_PRG.PROCESS_OU... (16)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (81)
                                           Local Read
     PLC_PRG.VALVES (62)
                                           Local Write
     PLC_PRG.VALVES (63)
                                           Local Write
     PLC_PRG.VALVES (64)
                                           Local Write
     PLC_PRG.VALVES (65)
                                           Local Write
     PLC_PRG.VALVES (66)
                                           Local Write
     PLC_PRG.VALVES (67)
                                           Local Read
     _global_init (300)
                                           Local Read
VPV211_FAST_OPN_REQ_ES
     PLC_PRG.ES_SM (15)
                                           Local Write
     PLC_PRG.ES_SM (29)
                                           Local Write
     PLC_PRG.ES_SM (43)
                                           Local Write
     PLC_PRG.ES_SM (61)
                                           Local Write
     PLC_PRG.ES_SM (79)
                                           Local Write
     PLC_PRG.ES_SM (97)
                                           Local Write
     PLC_PRG.ES_SM (115)
                                           Local Write
     PLC_PRG.ES_SM (134)
                                           Local Write
     PLC_PRG.ES_SM (152)
                                           Local Write
     PLC_PRG.ES_SM (173)
                                           Local Write
     PLC_PRG.ES_SM (193)
                                           Local Write
     PLC_PRG.VALVES (65)
                                           Local Read
     PLC_PRG.VALVES (66)
                                           Local Read
     _global_init (260)
                                           Local Write
VPV201
                                          Local Read
     PLC_PRG.PROCESS_OU... (10)
     PLC_PRG.SC_OUTPUTS (112)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (113)
                                           Local Read
     PLC_PRG.VALVES (28)
                                           Local Write
     PLC_PRG.VALVES (29)
                                           Local Write
     PLC_PRG.VALVES (30)
                                           Local Write
```

```
PLC_PRG.VALVES (31)
                                              Local Write
      PLC_PRG.VALVES (32)
                                             Local Write
      PLC_PRG.VALVES (33)
                                             Local Read
      _global_init (298)
                                             Local Read
V204_OPN_REQ_SC
      PLC_PRG.SC_INPUTS (13)
                                             Local Write
      PLC_PRG.VALVES (39)
                                             Local Read
      _global_init (255)
                                             Local Write
V204_CSD
     PLC_PRG.ES_SM (33)
                                             Local Read
     PLC_PRG.PROCESS_IN... (46)
                                            Local Write
     PLC_PRG.PUMPS (16)
PLC_PRG.SC_OUTPUTS (68)
PLC_PRG.SC_OUTPUTS (70)
                                             Local Read
                                           Local Read
Local Read
      PLC_PRG.VALVES (28)
                                            Local Read
      PLC_PRG.VALVES (46)
                                            Local Read
      PLC_PRG.VALVES (54)
                                             Local Read
      PLC_PRG.VALVES (62)
                                            Local Read
      PLC_PRG.VALVES (70)
                                             Local Read
      PLC_PRG.VALVES (80)
                                             Local Read
      _global_init (202)
                                             Local Write
V203_OPN_REQ_SC
     PLC_PRG.SC_INPUTS (11)
                                            Local Write
      PLC_PRG.VALVES (23)
                                             Local Read
      _global_init (253)
                                             Local Write
V204_OPN
     PLC_PRG.PROCESS_IN... (45)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (69)
                                             Local Read
                                              Local Write
      _global_init (201)
V204_CLS_REQ_ES
     PLC_PRG.ES_SM (10)
                                             Local Write
      PLC_PRG.ES_SM (24)
                                             Local Write
      PLC_PRG.ES_SM (38)
                                             Local Write
      PLC_PRG.ES_SM (56)
                                             Local Write
      PLC_PRG.ES_SM (74)
                                             Local Write
      PLC_PRG.ES_SM (92)
                                            Local Write
      PLC_PRG.ES_SM (110)
                                            Local Write
      PLC_PRG.ES_SM (129)
                                            Local Write
      PLC_PRG.ES_SM (147)
                                            Local Write
      PLC_PRG.ES_SM (168)
                                            Local Write
      PLC_PRG.ES_SM (188)
                                             Local Write
      PLC_PRG.VALVES (40)
                                              Local Read
     PLC_PRG.PROCESS_OU... (8)
PLC_PRG.SC_OUTPUTS (71)
PRG.SC_OUTPUTS (72)
PRG.SC_OUTPUTS (73)
      _global_init (257)
                                              Local Write
V204
                                           Local Read
Local Read
                                            Local Read
                                            Local Read
     PLC_PRG.SC_OUTPUTS (74)
                                              Local Read
      PLC_PRG.VALVES (36)
                                              Local Write
      PLC_PRG.VALVES (37)
                                              Local Write
      PLC_PRG.VALVES (38)
                                              Local Write
      PLC_PRG.VALVES (39)
                                              Local Write
      PLC_PRG.VALVES (40)
                                              Local Write
      PLC_PRG.VALVES (41)
                                              Local Read
      _global_init (297)
                                              Local Read
V204_CLS_REQ_SC
      PLC_PRG.SC_INPUTS (14)
                                              Local Write
      PLC_PRG.VALVES (40)
                                              Local Read
      _global_init (256)
                                              Local Write
V203_CSD
      PLC_PRG.BYPASSES (21)
                                             Local Write
      PLC_PRG.BYPASSES (21)
PLC_PRG.PROCESS_IN... (43)
                                              Local Write
      PLC_PRG.PUMPS (16)
                                              Local Read
     PLC_PRG.SC_OUTPUTS (62)
PLC_PRG.VALVES (22)
      PLC_PRG.SC_OUTPUTS (60)
                                              Local Read
                                              Local Read
                                              Local Read
      _global_init (200)
                                              Local Write
V203_OPN
      PLC_PRG.BYPASSES (20)
                                             Local Write
      PLC_PRG.BIPASSES (20)
PLC_PRG.PROCESS_IN... (42)
PLC_PRG.SC_OUTPUTS (61)
                                              Local Write
      PLC_PRG.SC_OUTPUTS (61)
                                              Local Read
                                              Local Write
      _global_init (199)
```

```
PLC_PRG.PROCESS_OU... (7) Local Read PLC_PRG.SC_OUTPUTS (63) Local Read
      PLC_PRG.SC_OUTPUTS (64)
                                              Local Read
      PLC_PRG.SC_OUTPUTS (65)
                                              Local Read
      PLC_PRG.SC_OUTPUTS (66)
                                              Local Read
      PLC_PRG.VALVES (20)
                                              Local Write
      PLC_PRG.VALVES (21)
                                              Local Write
      PLC_PRG.VALVES (22)
                                              Local Write
      PLC_PRG.VALVES (23)
                                              Local Write
      PLC_PRG.VALVES (24)
                                              Local Write
      PLC_PRG.VALVES (25)
                                               Local Read
      _global_init (296)
                                               Local Read
V203_CLS_REQ_SC
      PLC_PRG.SC_INPUTS (12)
                                              Local Write
      PLC_PRG.VALVES (24)
                                               Local Read
      _global_init (254)
                                               Local Write
V202_OPN
                                             Local Write
Local Read
Local Read
      PLC_PRG.BYPASSES (17)
     PLC_PRG.FAULT_LOGIC (6)
PLC_PRG.FAULT_LOGIC (37)
PLC_PRG.PROCESS_IN... (39)
      PLC_PRG.FAULT_LOGIC (6)
                                             Local Write
Local Read
      PLC_PRG.SC_OUTPUTS (56)
      _global_init (197)
                                               Local Write
V202_CSD
                                             Local Write
Local Write
     PLC_PRG.BYPASSES (18)
     PLC_PRG.BYPASSES (18)
PLC_PRG.PROCESS_IN... (40)
PLC_PRG.SC_OUTPUTS (57)
                                              Local Read
      PLC_PRG.SC_OUTPUTS (58)
                                              Local Read
                                               Local Write
      _global_init (198)
V201_OPN_REQ_SC
                                             Local Write
      PLC_PRG.SC_INPUTS (9)
      PLC_PRG.VALVES (15)
                                              Local Read
      _global_init (251)
                                               Local Write
V201_OPN
                                             Local Write
Local Write
     PLC_PRG.BYPASSES (14)
     PLC_PRG.BYPASSES (14)
PLC_PRG.PROCESS_IN... (36)
PLC_PRG.SC_OUTPUTS (49)
                                              Local Read
      _global_init (195)
                                               Local Write
V201_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (10)
                                              Local Write
     PLC_PRG.VALVES (16)
                                                Local Read
     PLC_PRG.PROCESS_OU... (6)

PLC_PRG.SC_OUTPUTS (51)

PRG.SC_OUTPUTS (52)
                                                Local Write
V201
                                             Local Read
Local Read
Local Read
                                              Local Read
      PLC_PRG.SC_OUTPUTS (53)
      PLC_PRG.SC_OUTPUTS (54)
                                              Local Read
      PLC_PRG.VALVES (12)
                                                Local Write
      PLC_PRG.VALVES (13)
                                                Local Write
      PLC_PRG.VALVES (14)
                                                Local Write
      PLC_PRG.VALVES (15)
                                                Local Write
      PLC_PRG.VALVES (16)
                                                Local Write
      PLC_PRG.VALVES (17)
                                                Local Read
      _global_init (295)
                                                Local Read
V201_CSD
      PLC_PRG.BYPASSES (15)
                                                Local Write
      PLC_PRG.PROCESS_IN... (37)
                                                Local Write
      PLC_PRG.SC_OUTPUTS (48)
                                                Local Read
      PLC_PRG.SC_OUTPUTS (50)
                                                Local Read
      _global_init (196)
                                                Local Write
V101_OPN_REQ_SC
      PLC_PRG.SC_INPUTS (7)
                                              Local Write
      PLC_PRG.VALVES (7)
                                                Local Read
      _global_init (249)
                                                Local Write
V101_OPN
      PLC_PRG.BYPASSES (11)
                                               Local Write
      PLC_PRG.PROCESS_IN... (33)
PLC_PRG.SC_OUTPUTS (41)
                                              Local Write
                                                Local Read
      _global_init (193)
                                                Local Write
V101_CSD
      PLC_PRG.BYPASSES (12)
                                                Local Write
```

```
PLC_PRG.PROCESS_IN... (34)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (40)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (42)
                                          Local Read
     _global_init (194)
                                          Local Write
V101
                                         Local Read
     PLC_PRG.PROCESS_OU... (5)
     PLC_PRG.SC_OUTPUTS (43)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (44)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (45)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (46)
                                          Local Read
     PLC_PRG.VALVES (4)
                                          Local Write
     PLC_PRG.VALVES (5)
                                          Local Write
     PLC_PRG.VALVES (6)
                                          Local Write
                                          Local Write
     PLC_PRG.VALVES (7)
     PLC_PRG.VALVES (8)
                                          Local Write
     PLC_PRG.VALVES (9)
                                          Local Read
     _global_init (294)
                                          Local Read
V101_CLS_REQ_SC
     PLC_PRG.SC_INPUTS (8)
                                          Local Write
     PLC_PRG.VALVES (8)
                                          Local Read
     _global_init (250)
                                           Local Write
V100_CSD
     PLC_PRG.BYPASSES (9)
                                          Local Write
     PLC_PRG.PROCESS_IN... (31)
PLC_PRG.SC_OUTPUTS (38)
                                         Local Write
                                          Local Read
     PLC_PRG.SC_OUTPUTS (40)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (48)
                                          Local Read
     _global_init (192)
                                           Local Write
TPV212_OPN_REQ_LL
     PLC_PRG.LL_SM (16)
                                          Local Write
     PLC_PRG.LL_SM (29)
                                           Local Write
     PLC_PRG.LL_SM (42)
                                          Local Write
     PLC_PRG.LL_SM (59)
                                          Local Write
     PLC_PRG.LL_SM (76)
                                          Local Write
     PLC_PRG.LL_SM (93)
                                          Local Write
     PLC_PRG.LL_SM (110)
                                          Local Write
     PLC_PRG.LL_SM (128)
                                          Local Write
     PLC_PRG.LL_SM (145)
                                          Local Write
     PLC_PRG.LL_SM (165)
                                          Local Write
     PLC_PRG.LL_SM (184)
                                          Local Write
     PLC_PRG.VALVES (113)
                                           Local Read
     PLC_PRG.VALVES (114)
                                           Local Read
     _global_init (276)
                                           Local Write
TPV212_OPN
     PLC_PRG.PROCESS_IN... (70)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (102)
                                           Local Read
     _global_init (215)
                                           Local Write
TPV212_CSD
     PLC_PRG.PROCESS_IN... (71)
                                           Local Write
     PLC_PRG.PUMPS (31)
                                           Local Read
     PLC_PRG.PUMPS (32)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (103)
                                           Local Read
     PLC_PRG.VALVES (86)
                                           Local Read
     PLC_PRG.VALVES (94)
                                           Local Read
     _global_init (216)
                                           Local Write
TPV212_CLS_REQ_LL
     _global_init (277)
                                           Local Write
TPV211_OPN_REQ_ES
     PLC_PRG.ES_SM (16)
                                           Local Write
     PLC_PRG.ES_SM (30)
                                           Local Write
     PLC_PRG.ES_SM (44)
                                           Local Write
     PLC_PRG.ES_SM (62)
                                           Local Write
     PLC_PRG.ES_SM (80)
                                           Local Write
     PLC_PRG.ES_SM (98)
                                           Local Write
     PLC_PRG.ES_SM (116)
                                           Local Write
     PLC_PRG.ES_SM (135)
                                           Local Write
     PLC_PRG.ES_SM (153)
                                           Local Write
     PLC_PRG.ES_SM (174)
                                           Local Write
     PLC_PRG.ES_SM (194)
                                           Local Write
     PLC_PRG.VALVES (81)
                                           Local Read
     PLC_PRG.VALVES (82)
                                           Local Read
     _global_init (264)
                                           Local Write
TP212_OFF_REQ_LL
```

```
_global_init (287)
                                            Local Write
TP212 READY
     PLC_PRG.PROCESS_IN... (74)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (128)
                                           Local Read
      _global_init (223)
                                           Local Write
TP201_VENT_ENABLE_REQ_SC
     PLC_PRG.SC_INPUTS (17)
                                          Local Write
     PLC_PRG.VALVES (31)
                                           Local Read
     _global_init (280)
                                           Local Write
TP201_ON_REQ_SC
     PLC_PRG.PUMPS (17)
                                          Local Read
     PLC_PRG.SC_INPUTS (15)
                                           Local Write
     _global_init (278)
                                           Local Write
TPV211_CSD
     PLC_PRG.PROCESS_IN... (59)
                                          Local Write
     PLC_PRG.PUMPS (23)
                                           Local Read
     PLC_PRG.PUMPS (24)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (84)
                                          Local Read
     PLC_PRG.VALVES (54)
                                          Local Read
     PLC_PRG.VALVES (62)
                                          Local Read
     _global_init (208)
                                           Local Write
TP201_OK
                                         Local Read
     PLC_PRG.FAULT_LOGIC (19)
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (48)
PLC_PRG.PROCESS_IN... (49)
                                          Local Write
                                          Local Read
     PLC_PRG.SC_OUTPUTS (115)
                                           Local Read
     _global_init (217)
                                           Local Write
TPV211_OPN
     PLC_PRG.PROCESS_IN... (58)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (83)
                                           Local Read
                                            Local Write
     _global_init (207)
TPV211_CLS_REQ_ES
     _global_init (265)
                                            Local Write
TP212_ON_REQ_LL
     PLC_PRG.LL_SM (17)
                                           Local Write
     PLC_PRG.LL_SM (30)
                                           Local Write
     PLC_PRG.LL_SM (43)
                                           Local Write
     PLC_PRG.LL_SM (60)
                                           Local Write
     PLC_PRG.LL_SM (77)
                                           Local Write
     PLC_PRG.LL_SM (94)
                                           Local Write
     PLC_PRG.LL_SM (111)
                                           Local Write
     PLC_PRG.LL_SM (129)
                                           Local Write
                                           Local Write
     PLC_PRG.LL_SM (146)
     PLC_PRG.LL_SM (166)
                                           Local Write
     PLC_PRG.LL_SM (185)
                                           Local Write
     PLC_PRG.PUMPS (33)
                                            Local Read
     _global_init (286)
                                            Local Write
TP211_ON_REQ_ES
     PLC_PRG.ES_SM (17)
                                           Local Write
     PLC_PRG.ES_SM (31)
                                            Local Write
     PLC_PRG.ES_SM (45)
                                            Local Write
     PLC_PRG.ES_SM (63)
                                            Local Write
     PLC_PRG.ES_SM (81)
                                            Local Write
     PLC_PRG.ES_SM (99)
                                            Local Write
     PLC_PRG.ES_SM (117)
                                            Local Write
     PLC_PRG.ES_SM (136)
                                            Local Write
     PLC_PRG.ES_SM (154)
                                            Local Write
     PLC_PRG.ES_SM (175)
                                            Local Write
     PLC_PRG.ES_SM (195)
                                            Local Write
     PLC_PRG.PUMPS (25)
                                            Local Read
      _global_init (284)
                                            Local Write
TP211_OFF_REQ_ES
     _global_init (285)
                                           Local Write
TP201_VENT_DISABLE_REQ_SC
     PLC_PRG.SC_INPUTS (18)
                                           Local Write
     PLC_PRG.VALVES (32)
                                            Local Read
     _global_init (281)
                                            Local Write
TP201_ON
     PLC_PRG.PROCESS_IN... (49)
                                           Local Write
     PLC_PRG.PROCESS_IN... (50)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (116)
                                            Local Read
                                            Local Read
     PLC_PRG.VALVES (28)
```

```
_global_init (218)
                                                Local Write
SOCKET SOL
     _global_init (116)
                                               Global Write
SOCKET_SO_TYPE
     _global_init (134)
                                              Global Write
SOCKET_SO_USELOOPBACK
     _global_init (123)
                                              Global Write
SOCKET_SO_SNDTIMEO
     _global_init (131)
                                              Global Write
SOCKET_SO_ACCEPTCONN
     _global_init (118)
                                              Global Write
TP201_OFF_REQ_SC
                                              Local Read
     PLC_PRG.PUMPS (18)
     PLC_PRG.SC_INPUTS (16)
                                              Local Write
     _global_init (279)
                                              Local Write
SC_VERSION_MAJOR%MW1280
     PLC_PRG.SC_OUTPUTS (156)
                                              Local Write
     _global_init (147)
                                              Local Write
SOCKET_SO_REUSEPORT
     _global_init (126)
                                              Global Write
SC_VENT212_FAST_CMD%MX8.12
     PLC_PRG.SC_OUTPUTS (100)
                                              Local Write
     _global_init (91)
                                              Local Write
SC_V202_OPEN%MX4.8
    PLC_PRG.SC_OUTPUTS (56)
                                              Local Write
      _global_init (55)
                                              Local Write
SC_V201_BEAM_PASS%MX4.0
                                             Local Write
     PLC_PRG.SC_OUTPUTS (48)
     PLC_PRG.SC_OUTPUTS (58)
                                              Local Read
                                              Local Write
     _global_init (48)
SC_V100_OPEN%MX3.0
     PLC_PRG.SC_OUTPUTS (37)
                                              Local Write
      _global_init (39)
                                              Local Write
uiFailing
    ACTUATOR_SM.CONNECT (30)
ACTUATOR_SM.CONNECT (30)
ACTUATOR_SM.DRG1_W... (31)
ACTUATOR_SM.DRG1_W... (31)
                                            Local Read
Local Write
Local Read
Local Write
Local Read
Local Write
     ACTUATOR_SM.PCMD_W... (32)
     ACTUATOR_SM.PCMD_W... (32)
ACTUATOR_SM.STATUS... (31)
ACTUATOR_SM.STATUS... (31)
                                             Local Read
                                           Local Write
     _global_init (8)
                                               Local Write
TP212_OK
     _OK
PLC_PRG.FAULT_LOGIC (21)
PLC_PRG.FAULT_LOGIC (37)
                                             Local Read
Local Read
                                              Local Read
      PLC_PRG.LL_SM (47)
                                               Local Read
      PLC_PRG.LL_SM (154)
     PLC_PRG.PROCESS_IN... (73)
                                              Local Write
      PLC_PRG.SC_OUTPUTS (127)
                                               Local Read
      _global_init (222)
                                               Local Write
TP211_READY
     PLC_PRG.PROCESS_IN... (62)
PLC_PRG.SC_OUTPUTS (124)
                                              Local Write
                                               Local Read
      _global_init (221)
                                               Local Write
TP211_OK
     PLC_PRG.ES_SM (49)
                                              Local Read
      PLC_PRG.ES_SM (162)
                                               Local Read
      PLC_PRG.FAULT_LOGIC (20)
                                               Local Read
      PLC_PRG.FAULT_LOGIC (37)
                                               Local Read
      PLC_PRG.PROCESS_IN... (61)
                                               Local Write
      PLC_PRG.SC_OUTPUTS (123)
                                               Local Read
      _global_init (220)
                                               Local Write
TP201_READY
     PLC_PRG.PROCESS_IN... (50)
PLC_PRG.VALVES (21)
                                              Local Write
                                               Local Read
      PLC_PRG.VALVES (37)
                                               Local Read
      _global_init (219)
                                               Local Write
SC_VENT211_FAST_CMD%MX6.12
     PLC_PRG.SC_OUTPUTS (81)
                                              Local Write
      _global_init (76)
                                               Local Write
SC_V201_OPN_REQ%MX641.2
     PLC_PRG.CLEAR_REQS (8)
                                               Local Write
```

```
PLC_PRG.SC_INPUTS (9)
                                          Local Read
     _global_init (135)
                                         Local Write
SC_V101_CLOSED%MX3.10
    PLC_PRG.SC_OUTPUTS (42)
                                         Local Write
                                          Local Write
     _global_init (43)
SC_PE211_PSL_LO%MX1.12
     PLC_PRG.SC_OUTPUTS (26)
                                         Local Write
                                         Local Write
     _global_init (31)
tTCP_Timeout
    ACTUATOR_SM.CONNECT (25)
                                        Local Read
     ACTUATOR_SM.DRG1_W... (26)
                                        Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                         Local Read
     ACTUATOR_SM.STATUS... (26)
                                        Local Read
     _global_init (4)
                                         Local Write
TPV212
                                       Local Read
     PLC_PRG.PROCESS_OU... (22)
     PLC_PRG.SC_OUTPUTS (104)
                                         Local Read
     PLC_PRG.VALVES (110)
                                         Local Write
     PLC_PRG.VALVES (111)
                                        Local Write
     PLC_PRG.VALVES (112)
                                        Local Write
     PLC_PRG.VALVES (113)
                                        Local Write
     PLC_PRG.VALVES (114)
                                        Local Write
     PLC_PRG.VALVES (115)
                                         Local Read
     _global_init (307)
                                         Local Read
TP211
     PLC_PRG.PROCESS_OU... (12)
                                        Local Read
     PLC_PRG.PUMPS (22)
                                         Local Write
     PLC_PRG.PUMPS (23)
                                         Local Write
     PLC_PRG.PUMPS (24)
                                         Local Write
     PLC_PRG.PUMPS (25)
                                         Local Write
     PLC_PRG.PUMPS (26)
                                         Local Read
     PLC_PRG.PUMPS (26)
                                         Local Write
     PLC_PRG.PUMPS (27)
                                        Local Read
     PLC_PRG.SC_OUTPUTS (125)
                                      Local Read
     PLC_PRG.VALVES (78)
                                         Local Read
     _global_init (311)
                                          Local Read
TPV211
     PLC_PRG.PROCESS_OU... (13)
                                        Local Read
     PLC_PRG.SC_OUTPUTS (85)
                                         Local Read
     PLC_PRG.VALVES (78)
                                         Local Write
     PLC_PRG.VALVES (79)
                                         Local Write
     PLC_PRG.VALVES (80)
                                         Local Write
                                         Local Write
     PLC_PRG.VALVES (81)
     PLC_PRG.VALVES (82)
                                          Local Write
     PLC_PRG.VALVES (83)
                                          Local Read
     _global_init (302)
                                          Local Read
TP212
     PLC_PRG.PROCESS_OU... (21)
                                         Local Read
     PLC_PRG.PUMPS (30)
                                          Local Write
     PLC_PRG.PUMPS (31)
                                          Local Write
     PLC_PRG.PUMPS (32)
                                          Local Write
     PLC_PRG.PUMPS (33)
                                          Local Write
     PLC_PRG.PUMPS (34)
                                          Local Read
     PLC_PRG.PUMPS (34)
                                          Local Write
     PLC_PRG.PUMPS (35)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (129)
                                          Local Read
     PLC_PRG.VALVES (110)
                                          Local Read
     _global_init (312)
                                          Local Read
SOCKET_SO_DEBUG
     _global_init (117)
                                          Global Write
SOCKET_INVALID
                                          Global Write
     _global_init (84)
SOCKET_AF_SNA
     _global_init (98)
                                          Global Write
TP201
     PLC_PRG.PROCESS_OU... (9)
                                          Local Read
     PLC_PRG.PUMPS (14)
                                          Local Write
     PLC_PRG.PUMPS (15)
                                          Local Write
     PLC_PRG.PUMPS (16)
                                          Local Write
     PLC_PRG.PUMPS (17)
                                          Local Write
     PLC_PRG.PUMPS (18)
                                          Local Write
     PLC_PRG.PUMPS (19)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (117)
                                          Local Read
```

PLC_PRG.SC_OUTPUTS (118)	Local Read
PLC_PRG.SC_OUTPUTS (119)	Local Read
PLC_PRG.SC_OUTPUTS (120)	Local Read
PLC_PRG.SC_OUTPUTS (121)	Local Read
PLC_PRG.VALVES (29)	Local Read
_global_init (308)	Local Read
SOCKET_TCP_NODELAY	
CLIENT_OPENCLOSE (20)	Global Read
CLIENT_OPENCLOSE (71)	Global Read
_global_init (136)	Global Write
SOCKET_SO_REUSEADDR	
_global_init (119)	Global Write
SOCKET_SO_OOBINLINE	
_global_init (125)	Global Write
SOCKET_SO_LINGER	
_global_init (124)	Global Write
SOCKET_SO_DONTROUTE	
_global_init (121)	Global Write
SOCKET_SO_BROADCAST	
_global_init (122)	Global Write
SOCKET_SO_KEEPALIVE	
 _global_init (120)	Global Write
SOCKET_pseudo_AF_XTP	
global_init (106)	Global Write
SOCKET_pseudo_AF_RTIP	
_global_init (109)	Global Write
SOCKET_pseudo_AF_PIP	010201 111100
_global_init (112)	Global Write
SOCKET_AF_SIP	GIODAI WIICC
_global_init (111)	Global Write
SOCKET_AF_ROUTE	GIODAI WIILE
_global_init (104)	Global Write
SOCKET_AF_PUP	GIODAI WIILE
_global_init (90)	Global Write
	Global Wille
SOCKET_AF_OSI global_init (94)	Global Write
	Global Wille
SC_VERSION_MINOR%MW1281	Logol Weite
PLC_PRG.SC_OUTPUTS (157)	Local Write
_global_init (148)	Local Write
SC_V204_OPN_REQ%MX641.8	
PLC_PRG.CLEAR_REQS (14)	Local Write
PLC_PRG.SC_INPUTS (13)	Local Read
_global_init (139)	Local Write
SC_V203_OPEN%MX5.1	7 77 11
PLC_PRG.SC_OUTPUTS (61)	Local Write
_global_init (59)	Local Write
SC_PE211_OK%MX1.8	
PLC_PRG.SC_OUTPUTS (22)	Local Write
_global_init (27)	Local Write
SC_PE203_PSL_HI%MX1.1	I and Maike
PLC_PRG.SC_OUTPUTS (17)	Local Write
_global_init (23)	Local Write
tonConnect	I and Maike
ACTUATOR_SM.CONNECT (6)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.STATUS (26)	Local Read
ACTUATORinit (7)	Local Read
SOCKET_AF_UNSPEC	
_global_init (85)	Global Write
SOCKET_AF_LOCAL	
_global_init (86)	Global Write
SC_V204_OPEN_PERMIT%MX5.11	
PLC_PRG.SC_OUTPUTS (71)	Local Write
_global_init (68)	Local Write
SC_V100_CLOSED%MX3.1	
PLC_PRG.SC_OUTPUTS (38)	Local Write
_global_init (40)	Local Write
SC_PE101_PSL%MX0.8	
PLC_PRG.SC_OUTPUTS (7)	Local Write
_global_init (15)	Local Write
strAddress	

ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.STATUS (26)	Local Read
_global_init (1)	Local Write
SOCKET_TCP_MAXSEG	
_global_init (137)	Global Write
SOCKET_STREAM	
CLIENT_OPENCLOSE (11)	Global Read
_global_init (138)	Global Write
SOCKET_SO_SNDLOWAT	
_global_init (129)	Global Write
SOCKET_SO_RCVTIMEO	
_global_init (132)	Global Write
SOCKET_SO_SNDBUF _global_init (127)	Global Write
_global_init (127) SOCKET_SO_RCVLOWAT	Global Wilce
_global_init (130)	Global Write
SOCKET_SO_ERROR	Global Wilce
_global_init (133)	Global Write
SOCKET_SO_RCVBUF	
_global_init (128)	Global Write
SOCKET_MSG_OOB	
_global_init (158)	Global Write
SOCKET_IPPROTO_TCP	
CLIENT_OPENCLOSE (11)	Global Read
_global_init (151)	Global Write
SOCKET_IPPROTO_PUP	
_global_init (152)	Global Write
SOCKET_IPPROTO_ND	
_global_init (155)	Global Write
SOCKET_SEQPACKET	
_global_init (142)	Global Write
SOCKET_DGRAM	
CLIENT_OPENCLOSE (43)	Global Read
ETHERNET_MODBUSMAS (9)	Global Read
_global_init (139)	Global Write
SOCKET_SO_PROTOTYPE	
_global_init (135)	Global Write
SOCKET_RAW _global_init (140)	Global Write
	Global Wilce
SOCKET_IPPROTO_RAW global_init (156)	Global Write
SOCKET_IPPROTO_UDP	Global Wilce
CLIENT_OPENCLOSE (43)	Global Read
ETHERNET_MODBUSMAS (9)	Global Read
_global_init (153)	Global Write
SOCKET_INADDR_NONE	
_global_init (146)	Global Write
SOCKET_AF_UNIX	
	Global Write
SOCKET_AF_MAX	
_global_init (113)	Global Write
SOCKET_AF_NS	
_global_init (92)	Global Write
SOCKET_AF_LINK	
_global_init (105)	Global Write
SOCKET_AF_LAT	
_global_init (101)	Global Write
SOCKET_AF_ISO	
_global_init (93)	Global Write
SOCKET_AF_IPX	Clabal Weita
_global_init (110)	Global Write
SOCKET_AF_INET_STREAMS	Global Write
_global_init (115) SOCKET_AF_INET_BSD	GIONGI MIICE
_global_init (114)	Global Write
_global_init (ii4) SOCKET_AF_INET	Clobal Wilco
CLIENT_OPENCLOSE (11)	Global Read
CLIENT OPENCLOSE (27)	Global Read

Global Read

Global Read

Global Read Global Read

CLIENT_OPENCLOSE (27)

CLIENT_OPENCLOSE (43)

ETHERNET_MODBUSMAS... (9)

ETHERNET_MODBUSMAS... (12)

_global_init (88)	Global Write
	Global Wilce
SOCKET_AF_COIP	
_global_init (107)	Global Write
SOCKET_AF_ECMA	
_global_init (95)	Global Write
SOCKET_AF_CHAOS	
_global_init (91)	Global Write
SOCKET_AF_IMPLINK	
_global_init (89)	Global Write
SOCKET_AF_HYLINK	
global_init (102)	Global Write
SOCKET_AF_DLI	Olobal Wilco
_global_init (100)	Global Write
	Global Wille
SOCKET_AF_DECnet	
_global_init (99)	Global Write
SOCKET_AF_DATAKIT	
_global_init (96)	Global Write
SC_VERSION_MINOR%MW1281	
PLC_PRG.SC_OUTPUTS (157)	Local Write
_global_init (148)	Local Write
SOCKET_AF_CNT	
_global_init (108)	Global Write
	Global Wilee
SC_VENT212_SLOW_CMD%MX8.11	Local Weite
PLC_PRG.SC_OUTPUTS (99)	Local Write
_global_init (90)	Local Write
SC_VENT212_FAST_CMD%MX8.12	
PLC_PRG.SC_OUTPUTS (100)	Local Write
_global_init (91)	Local Write
SOCKET_AF_APPLETALK	
global_init (103)	Global Write
SC_V204_OPEN_PERMIT%MX5.11	
PLC_PRG.SC_OUTPUTS (71)	Local Write
_global_init (68)	Local Write
SOCKET_AF_CCITT	
_global_init (97)	Global Write
SC_VENT211_FAST_CMD%MX6.12	
PLC_PRG.SC_OUTPUTS (81)	Local Write
_global_init (76)	Local Write
SC_VENT211_SLOW_CMD%MX6.11	
PLC_PRG.SC_OUTPUTS (80)	Local Write
_global_init (75)	Local Write
SC_V204_OPN_REQ%MX641.8	DOGGE HITTOO
	Local Write
PLC_PRG.CLEAR_REQS (14)	
PLC_PRG.SC_INPUTS (13)	Local Read
_global_init (139)	Local Write
SC_V204_OPEN%MX5.9	
PLC_PRG.SC_OUTPUTS (69)	Local Write
_global_init (66)	Local Write
SC_V204_OPEN_CMD%MX5.13	
PLC_PRG.SC_OUTPUTS (73)	Local Write
_global_init (70)	Local Write
SC_V204_OPEN_CMD%MX5.13	
PLC_PRG.SC_OUTPUTS (73)	Local Write
	Local Write
_global_init (70)	TOCAT MITCE
SC_V204_NOT_SYMBOL%MX5.14	
PLC_PRG.SC_OUTPUTS (74)	Local Write
_global_init (71)	Local Write
SC_V204_CLS_REQ%MX641.9	
PLC_PRG.CLEAR_REQS (15)	Local Write
PLC_PRG.SC_INPUTS (14)	Local Read
_global_init (140)	Local Write
SC_V204_CLS_REQ%MX641.9	
PLC_PRG.CLEAR_REQS (15)	Local Write
PLC_PRG.SC_INPUTS (14)	Local Read
_global_init (140)	Local Write
SC_V204_CLOSED%MX5.10	
PLC_PRG.SC_OUTPUTS (70)	Local Write
_global_init (67)	Local Write
SC_V204_CLOSE_PERMIT%MX5.12	
PLC_PRG.SC_OUTPUTS (72)	Local Write
_global_init (69)	Local Write
SC_V204_BEAM_PASS%MX5.8	nr00
	I agal Write
PLC_PRG.SC_OUTPUTS (68)	Local Write

_global_init (65)	Local Write
SC_V203_OPN_REQ%MX641.6	
PLC_PRG.CLEAR_REQS (11)	Local Write
PLC_PRG.SC_INPUTS (11)	Local Read
_global_init (137)	Local Write
SC_V204_BEAM_PASS%MX5.8	
PLC_PRG.SC_OUTPUTS (68)	Local Write
_global_init (65)	Local Write
SC_V203_OPEN_PERMIT%MX5.3	Local Wile
	Local Write
PLC_PRG.SC_OUTPUTS (63)	
_global_init (61)	Local Write
SC_V203_OPEN_PERMIT%MX5.3	
PLC_PRG.SC_OUTPUTS (63)	Local Write
_global_init (61)	Local Write
SC_V203_OPEN_CMD%MX5.5	
PLC_PRG.SC_OUTPUTS (65)	Local Write
_global_init (63)	Local Write
SC_V203_OPEN%MX5.1	
PLC_PRG.SC_OUTPUTS (61)	Local Write
_global_init (59)	Local Write
SC_V203_NOT_SYMBOL%MX5.6	
PLC_PRG.SC_OUTPUTS (66)	Local Write
_global_init (64)	Local Write
SC_V203_CLS_REQ%MX641.7	
	Local Write
PLC_PRG.SC_INPUTS (12)	Local Read
	Local Write
_global_init (138) SC_V203_CLOSED%MX5.2	nocal wiice
PLC_PRG.SC_OUTPUTS (62)	Local Write
_global_init (60)	Local Write
SC_V203_CLOSED%MX5.2	
PLC_PRG.SC_OUTPUTS (62)	Local Write
_global_init (60)	Local Write
SC_V203_CLOSE_PERMIT%MX5.4	
PLC_PRG.SC_OUTPUTS (64)	Local Write
_global_init (62)	Local Write
SC_V203_CLOSE_PERMIT%MX5.4	
PLC_PRG.SC_OUTPUTS (64)	Local Write
_global_init (62)	Local Write
SC_V203_BEAM_PASS%MX5.0	
PLC_PRG.SC_OUTPUTS (60)	Local Write
PLC_PRG.SC_OUTPUTS (68)	Local Read
_global_init (58)	Local Write
SC_V203_BEAM_PASS%MX5.0	
PLC_PRG.SC_OUTPUTS (60)	Local Write
PLC_PRG.SC_OUTPUTS (68)	Local Read
_global_init (58)	Local Write
SC V202 CLOSED%MX4.9	
PLC_PRG.SC_OUTPUTS (57)	Local Write
_global_init (56)	Local Write
SC_V202_OPEN%MX4.8	20001 11100
PLC_PRG.SC_OUTPUTS (56)	Local Write
	Local Write Local Write
_global_init (55)	TOCAT MITCE
SC_V202_BEAM_PASS%MX4.10	I I Weite
PLC_PRG.SC_OUTPUTS (58)	Local Write
PLC_PRG.SC_OUTPUTS (60)	Local Read
_global_init (57)	Local Write
SC_V201_OPN_REQ%MX641.2	
PLC_PRG.CLEAR_REQS (8)	Local Write
PLC_PRG.SC_INPUTS (9)	Local Read
_global_init (135)	Local Write
SC_V202_BEAM_PASS%MX4.10	
PLC_PRG.SC_OUTPUTS (58)	Local Write
PLC_PRG.SC_OUTPUTS (60)	Local Read
_global_init (57)	Local Write
SC_V201_OPEN_PERMIT%MX4.3	
PLC_PRG.SC_OUTPUTS (51)	Local Write
_global_init (51)	Local Write
SC_V202_CLOSED%MX4.9	
PLC_PRG.SC_OUTPUTS (57)	Local Write
_global_init (56)	Local Write
SC_V201_OPEN_CMD%MX4.5	20041 /11100
PLC_PRG.SC_OUTPUTS (53)	Local Write
I HC_I NG. SC_OUIF 013 (33)	DOCAL WIICE

1 1 1 1 1 (52)	
_global_init (53) SC_V201_OPEN%MX4.1	Local Write
PLC_PRG.SC_OUTPUTS (49)	Local Write
_global_init (49)	Local Write
SC_V201_OPEN_PERMIT%MX4.3	
	Local Write
_global_init (51)	Local Write
SC_V201_OPEN_CMD%MX4.5 PLC_PRG.SC_OUTPUTS (53)	Local Write
_global_init (53)	Local Write
SC_V201_NOT_SYMBOL%MX4.6	
PLC_PRG.SC_OUTPUTS (54)	Local Write
_global_init (54)	Local Write
SC_V201_NOT_SYMBOL%MX4.6	Taral Maika
PLC_PRG.SC_OUTPUTS (54) _global_init (54)	Local Write Local Write
SC_V201_OPEN%MX4.1	Book! Wiled
PLC_PRG.SC_OUTPUTS (49)	Local Write
_global_init (49)	Local Write
SC_V201_CLS_REQ%MX641.3	
PLC_PRG.CLEAR_REQS (9)	Local Write
PLC_PRG.SC_INPUTS (10) _global_init (136)	Local Read Local Write
SC_V201_CLOSED%MX4.2	
PLC_PRG.SC_OUTPUTS (50)	Local Write
_global_init (50)	Local Write
SC_V201_CLOSE_PERMIT%MX4.4	I and Maita
PLC_PRG.SC_OUTPUTS (52) _global_init (52)	Local Write Local Write
SC_V201_CLOSE_PERMIT%MX4.4	Book! Wiled
PLC_PRG.SC_OUTPUTS (52)	Local Write
_global_init (52)	Local Write
SC_V201_BEAM_PASS%MX4.0	
PLC_PRG.SC_OUTPUTS (48) PLC_PRG.SC_OUTPUTS (58)	Local Write Local Read
_global_init (48)	Local Write
SC_V201_CLOSED%MX4.2	
	Local Write
_global_init (50)	Local Write
SC_V101_OPN_REQ%MX641.0 PLC_PRG.CLEAR_REQS (5)	Local Write
PLC_PRG.SC_INPUTS (7)	Local Read
_global_init (133)	Local Write
SC_V101_OPEN_PERMIT%MX3.11	
PLC_PRG.SC_OUTPUTS (43)	Local Write
_global_init (44) SC_V101_OPEN_PERMIT%MX3.11	Local Write
PLC_PRG.SC_OUTPUTS (43)	Local Write
_global_init (44)	Local Write
SC_V101_OPEN_CMD%MX3.13	
PLC_PRG.SC_OUTPUTS (45)	Local Write
_global_init (46) SC_V101_OPEN_CMD%MX3.13	Local Write
PLC_PRG.SC_OUTPUTS (45)	Local Write
_global_init (46)	Local Write
SC_V101_CLOSE_PERMIT%MX3.12	
PLC_PRG.SC_OUTPUTS (44)	Local Write
_global_init (45) SC_V101_OPEN%MX3.9	Local Write
PLC_PRG.SC_OUTPUTS (41)	Local Write
_global_init (42)	Local Write
SC_V101_CLOSE_PERMIT%MX3.12	
PLC_PRG.SC_OUTPUTS (44)	Local Write
_global_init (45) SC_V101_OPEN%MX3.9	Local Write
PLC_PRG.SC_OUTPUTS (41)	Local Write
_global_init (42)	Local Write
SC_V101_NOT_SYMBOL%MX3.14	
PLC_PRG.SC_OUTPUTS (46)	Local Write
_global_init (47) SC_V101_CLS_REQ%MX641.1	Local Write
PLC_PRG.CLEAR_REQS (6)	Local Write
PLC_PRG.SC_INPUTS (8)	Local Read

_global_init (134)	Local Write
SC_V101_BEAM_PASS%MX3.8	
	Local Write
_global_init (41)	Local Write
SC_TP212_OK%MX11.8	
PLC_PRG.SC_OUTPUTS (127)	Local Write
_global_init (111)	Local Write
SC_TP211_ON%MX11.1	
PLC PRG.SC OUTPUTS (124)	Local Write
global init (109)	
	Local Write
SC_V101_NOT_SYMBOL%MX3.14	
PLC_PRG.SC_OUTPUTS (46)	Local Write
_global_init (47)	Local Write
SC_V101_CLOSED%MX3.10	
PLC_PRG.SC_OUTPUTS (42)	Local Write
_global_init (43)	Local Write
_	LOCAL WIICE
SC_V100_CLOSED%MX3.1	
PLC_PRG.SC_OUTPUTS (38)	Local Write
_global_init (40)	Local Write
SC_TPV212_OPEN%MX9.1	
PLC_PRG.SC_OUTPUTS (102)	Local Write
_global_init (92)	Local Write
	DOCAT WITCO
SC_TPV211_OPEN_CMD%MX7.5	
PLC_PRG.SC_OUTPUTS (85)	Local Write
_global_init (79)	Local Write
SC_V100_OPEN%MX3.0	
PLC_PRG.SC_OUTPUTS (37)	Local Write
_global_init (39)	Local Write
	HOCAI WIICC
SC_TPV212_OPEN_CMD%MX9.5	
PLC_PRG.SC_OUTPUTS (104)	
_global_init (94)	Local Write
SC_TPV212_CLOSED%MX9.2	
PLC_PRG.SC_OUTPUTS (103)	Local Write
_global_init (93)	Local Write
SC_TPV211_OPEN%MX7.1	HOOGI WIICO
	T 7 TT '
PLC_PRG.SC_OUTPUTS (83)	Local Write
_global_init (77)	Local Write
SC_TP201_VENT_ENABLE_REQ%MX641.12	
PLC_PRG.CLEAR_REQS (19)	Local Write
PLC_PRG.SC_INPUTS (17)	Local Read
global_init (143)	Local Write
SC_TP212_OK%MX11.8	
	I agal Waita
PLC_PRG.SC_OUTPUTS (127)	Local Write
_global_init (111)	Local Write
SC_TP201_VENT_ENABLE_CMD%MX10.5	
PLC_PRG.SC_OUTPUTS (112)	Local Write
_global_init (99)	Local Write
SC_TPV211_CLOSED%MX7.2	
PLC_PRG.SC_OUTPUTS (84)	Local Write
global init (78)	
	Local Write
SC_TP212_ON%MX11.9	
PLC_PRG.SC_OUTPUTS (128)	Local Write
_global_init (112)	Local Write
SC_TP212_OFF%MX11.10	
PLC_PRG.SC_OUTPUTS (129)	Local Write
_global_init (113)	Local Write
	DOCAT WITCE
SC_TP211_ON%MX11.1	
PLC_PRG.SC_OUTPUTS (124)	Local Write
_global_init (109)	Local Write
SC_TP211_OFF%MX11.2	
PLC_PRG.SC_OUTPUTS (125)	Local Write
_global_init (110)	Local Write
SC_TP211_OK%MX11.0	
	Iogal Write
PLC_PRG.SC_OUTPUTS (123)	Local Write
_global_init (108)	Local Write
SC_TP201_VENT_NOT_SYMBOL%MX10.6	
PLC_PRG.SC_OUTPUTS (113)	Local Write
_global_init (100)	Local Write
SC_TP201_VENT_DISABLE_REQ%MX641.13	
PLC_PRG.CLEAR_REQS (20)	Local Write
PLC_PRG.SC_INPUTS (18)	Local Read
_global_init (144)	Local Write
SC_TP201_ON_REQ%MX641.10	

PLC_PRG.CLEAR_REQS (17)	Local Write
PLC_PRG.SC_INPUTS (15)	Local Read
_global_init (141)	Local Write
SC_TP201_ON_PERMIT%MX10.11	
PLC_PRG.SC_OUTPUTS (118)	Local Write
_global_init (104)	Local Write
SC_TP201_ON_CMD%MX10.13	
PLC_PRG.SC_OUTPUTS (120)	Local Write
_global_init (106)	Local Write
SC_TP201_ON%MX10.9	
PLC_PRG.SC_OUTPUTS (116)	Local Write
_global_init (102)	Local Write
SC_TP201_OK%MX10.8	
PLC_PRG.SC_OUTPUTS (115)	Local Write
_global_init (101)	Local Write
SC_TP201_OK%MX10.8	
PLC_PRG.SC_OUTPUTS (115)	Local Write
_global_init (101)	Local Write
SC TP201 OFF PERMIT%MX10.12	20041 11100
PLC PRG.SC OUTPUTS (119)	Local Write
_global_init (105)	Local Write
SC_TP201_OFF%MX10.10	HOCAI WIICC
	Local Write
PLC_PRG.SC_OUTPUTS (117)	Local Write Local Write
_global_init (103)	POCAT MITCE
SC_TP201_NOT_SYMBOL%MX10.14	Local Mait-
	Local Write
_global_init (107)	Local Write
SC_SLOTV211_CLOSED%MX7.10	
PLC_PRG.SC_OUTPUTS (88)	Local Write
_global_init (81)	Local Write
SC_SLOTV211_CLOSE_PERMIT%MX7.12	
PLC_PRG.SC_OUTPUTS (90)	Local Write
_global_init (83)	Local Write
SC_SLOTV211_CLOSE_CMD%MX7.14	
PLC_PRG.SC_OUTPUTS (92)	Local Write
_global_init (85)	Local Write
SC_RPV212_OPEN%MX8.1	
PLC_PRG.SC_OUTPUTS (95)	Local Write
_global_init (87)	Local Write
SC_V101_BEAM_PASS%MX3.8	
PLC_PRG.SC_OUTPUTS (40)	Local Write
_global_init (41)	Local Write
SC_TPV212_OPEN_CMD%MX9.5	
PLC_PRG.SC_OUTPUTS (104)	Local Write
global_init (94)	Local Write
SC_RP2111_AT_SPEED%MX0.13	
PLC_PRG.SC_OUTPUTS (12)	Local Write
_global_init (19)	Local Write
SC_TP212_OFF%MX11.10	
PLC PRG.SC OUTPUTS (129)	Local Write
_global_init (113)	Local Write
SC_RP2110_AT_SPEED%MX0.12	DOCAT MITCE
PLC PRG.SC OUTPUTS (11)	Local Write
_global_init (18)	Local Write
_global_init (16) SC_RPV212_OPEN_CMD%MX8.5	nocar write
	Iogal Writa
PLC_PRG.SC_OUTPUTS (97)	Local Write
_global_init (89)	Local Write
SC_RESET_REQUIRED%MX0.0	7 7 7
PLC_PRG.SC_OUTPUTS (2)	Local Write
_global_init (12)	Local Write
SC_PE212_PSL_MIDLO%MX2.3	
PLC_PRG.SC_OUTPUTS (31)	Local Write
_global_init (35)	Local Write
SC_PE212_PSL_HI%MX2.1	
PLC_PRG.SC_OUTPUTS (29)	Local Write
_global_init (33)	Local Write
SC_RP2111_AT_SPEED%MX0.13	
PLC_PRG.SC_OUTPUTS (12)	Local Write
_global_init (19)	Local Write
SC_PE212_OK%MX2.0	
PLC_PRG.SC_OUTPUTS (28)	Local Write
_global_init (32)	Local Write
SC_PE212_PSL_MIDLO%MX2.3	

PLC_PRG.SC_OUTPUTS (31)	Local Write
_global_init (35)	Local Write
SC_PE211_PSL_MIDHI%MX1.10	
PLC_PRG.SC_OUTPUTS (24)	Local Write
	Local Write
_global_init (29)	Local wille
SC PE2110 PSL%MX0.14	
PLO DDG GG OHEDHEG (13)	Table Marks
PLC_PRG.SC_OUTPUTS (13)	Local Write
_global_init (20)	Local Write
_	
SC_RP2110_AT_SPEED%MX0.12	
PLC_PRG.SC_OUTPUTS (11)	Local Write
_global_init (18)	Local Write
SC ATB%MX0.2	
_	
PLC_PRG.SC_OUTPUTS (3)	Local Write
_global_init (13)	Local Write
_	Bodar write
SC_RESET_REQUIRED%MX0.0	
PLC_PRG.SC_OUTPUTS (2)	Local Write
_global_init (12)	Local Write
SC_PE211_PSL_MIDHI%MX1.10	
2C_FEZII_F2F_MIDUI@MVI.IO	
PLC_PRG.SC_OUTPUTS (24)	Local Write
	Local Write
_global_init (29)	Local Write
SC_PE203_OK%MX1.0	
	Logal Write
PLC_PRG.SC_OUTPUTS (16)	Local Write
_global_init (22)	Local Write
SC_PE2111_PSL%MX0.15	
PLC_PRG.SC_OUTPUTS (14)	Local Write
_global_init (21)	Local Write
SC_PE203_PSL_MIDHI%MX1.2	
	Tarada Maria
PLC_PRG.SC_OUTPUTS (18)	Local Write
_global_init (24)	Local Write
	20041 11100
open_req	
PLC_PRG.VALVES (7)	Local Write
PLC_PRG.VALVES (15)	Local Write
PLC_PRG.VALVES (23)	Local Write
PLC_PRG.VALVES (31)	Local Write
PLC_PRG.VALVES (39)	Local Write
PLC_PRG.VALVES (57)	Local Write
PLC_PRG.VALVES (65)	Local Write
PLC_PRG.VALVES (73)	Local Write
PLC_PRG.VALVES (81)	Local Write
PLC_PRG.VALVES (89)	Local Write
PLC_PRG.VALVES (97)	Local Write
	Table Marks
PLC_PRG.VALVES (105)	Local Write
PLC_PRG.VALVES (113)	Local Write
	Legal Dood
VALVE_FB (3)	Local Read
VALVE_FBinit (4)	Local Write
open_intlk	
PLC_PRG.VALVES (4)	Local Write
PLC_PRG.VALVES (12)	Local Write
PLC_PRG.VALVES (20)	Local Write
PLC_PRG.VALVES (28)	Local Write
PLC_PRG.VALVES (36)	Local Write
	Local Write
PLC_PRG.VALVES (54)	
PLC_PRG.VALVES (62)	Local Write
PLC_PRG.VALVES (70)	Local Write
PLC_PRG.VALVES (78)	Local Write
PLC_PRG.VALVES (86)	Local Write
PLC_PRG.VALVES (94)	Local Write
	Local Write
PLC_PRG.VALVES (102)	
PLC_PRG.VALVES (110)	Local Write
VALVE_FB (3)	Local Read
VALVE_FB (6)	Local Read
VALVE_FBinit (1)	Local Write
	HOCAL WITCE
open_intlk	
PLC_PRG.VALVES (45)	Local Write
VALVE_BI_FB (4)	Local Read
VALVE_BI_FB (11)	Local Read
VALVE_BI_FBinit (1)	Local Write
wCommand	
ACTUATOR_SM (48)	Local Write
ACTUATOR_SM (57)	Local Write
ACTUATOR_SM (65)	Local Write
	Local Write
ACTUATOR_SM (74)	Local Write
	Local Write Local Write

ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATORinit (4)	Local Write
SOCKET_RDM	
_global_init (141)	Global Write
SOCKET_MSG_PEEK	GIODGI WIICC
	Global Write
_global_init (159)	Global Wille
SOCKET_MSG_DONTROUTE	
_global_init (160)	Global Write
SOCKET_IPPROTO_MAX	
_global_init (157)	Global Write
SOCKET_IPPROTO_IP	
_global_init (147)	Global Write
SOCKET_IPPROTO_IGMP	
_global_init (149)	Global Write
SOCKET_IPPROTO_IDP	
_global_init (154)	Global Write
SOCKET_IPPROTO_ICMP	GIODGI WIICC
_global_init (148)	Global Write
_	Global Wille
SOCKET_IPPROTO_GGP	
_global_init (150)	Global Write
SOCKET_INADDR_LOOPBACK	
_global_init (144)	Global Write
SOCKET_INADDR_BROADCAST	
_global_init (145)	Global Write
SOCKET_FIONREAD	
global_init (161)	Global Write
SOCKET_FIONBIO	
CLIENT_OPENCLOSE (25)	Global Read
CLIENT_OPENCLOSE (46)	Global Read
ETHERNET_MODBUSMAS (11)	Global Read
_global_init (162)	Global Write
	Global Wille
SOCKET_INADDR_ANY	
_global_init (143)	Global Write
SOCKET_FD_SETSIZE	
_global_init (163)	Global Write
SC_V204_OPEN%MX5.9	
PLC_PRG.SC_OUTPUTS (69)	Local Write
_global_init (66)	Local Write
SC_V204_NOT_SYMBOL%MX5.14	
PLC_PRG.SC_OUTPUTS (74)	Local Write
_global_init (71)	Local Write
SC_TPV212_OPEN%MX9.1	
PLC_PRG.SC_OUTPUTS (102)	Local Write
_global_init (92)	Local Write
SC_TPV212_CLOSED%MX9.2	Eccai Wiicc
PLC_PRG.SC_OUTPUTS (103)	Local Write
_global_init (93)	Local Write
SC_V204_CLOSED%MX5.10	
PLC_PRG.SC_OUTPUTS (70)	Local Write
_global_init (67)	Local Write
SC_RPV211_OPEN_CMD%MX6.5	
PLC_PRG.SC_OUTPUTS (78)	Local Write
_global_init (74)	Local Write
SC_V204_CLOSE_PERMIT%MX5.12	
PLC_PRG.SC_OUTPUTS (72)	Local Write
_global_init (69)	Local Write
SC_TPV211_OPEN_CMD%MX7.5	
PLC_PRG.SC_OUTPUTS (85)	Local Write
global_init (79)	Local Write
SC_TP212_ON%MX11.9	
PLC_PRG.SC_OUTPUTS (128)	Local Write
_global_init (112)	Local Write
SC_TPV211_OPEN%MX7.1	
PLC_PRG.SC_OUTPUTS (83)	Local Write
_global_init (77)	Local Write
SC_TP201_OFF_REQ%MX641.11	
PLC_PRG.CLEAR_REQS (18)	Local Write
PLC_PRG.SC_INPUTS (16)	Local Read
_global_init (142)	Local Write
SC_TP201_VENT_ENABLE_CMD%MX10.5	
PLC_PRG.SC_OUTPUTS (112)	Local Write
_global_init (99)	Local Write
SC_SLOTV211_OPEN_PERMIT%MX7.11	

PLC_PRG.SC_OUTPUTS (89)	Local Write
_global_init (82)	Local Write
SC_SLOTV211_OPEN_CMD%MX7.13	20042 11-200
PLC_PRG.SC_OUTPUTS (91)	Local Write
_global_init (84)	Local Write
SC_TPV211_CLOSED%MX7.2	
PLC_PRG.SC_OUTPUTS (84)	Local Write
_global_init (78)	Local Write
	Local wille
SC_RPV211_OPEN%MX6.1	
PLC_PRG.SC_OUTPUTS (76)	Local Write
_global_init (72)	Local Write
SC_RPV211_CLOSED%MX6.2	
PLC_PRG.SC_OUTPUTS (77)	Local Write
_global_init (73)	Local Write
SC_V203_NOT_SYMBOL%MX5.6	
PLC_PRG.SC_OUTPUTS (66)	Local Write
_global_init (64)	Local Write
	Local wilte
SC_V203_CLS_REQ%MX641.7	
PLC_PRG.CLEAR_REQS (12)	Local Write
PLC_PRG.SC_INPUTS (12)	Local Read
_global_init (138)	Local Write
SC_V201_CLS_REQ%MX641.3	
	2 2 2 2
PLC_PRG.CLEAR_REQS (9)	Local Write
PLC_PRG.SC_INPUTS (10)	Local Read
_global_init (136)	Local Write
SC_V101_CLS_REQ%MX641.1	
	Local Write
PLC_PRG.CLEAR_REQS (6)	Local Write
PLC_PRG.SC_INPUTS (8)	Local Read
_global_init (134)	Local Write
SC_V101_OPN_REQ%MX641.0	
PLC_PRG.CLEAR_REQS (5)	Local Write
PLC_PRG.SC_INPUTS (7)	Local Read
_global_init (133)	Local Write
SC_TP211_OK%MX11.0	
PLC_PRG.SC_OUTPUTS (123)	Local Write
_global_init (108)	Local Write
	Booti Wilto
SC_TP201_VENT_ENABLE_REQ%MX641.12	
PLC_PRG.CLEAR_REQS (19)	Local Write
PLC_PRG.SC_INPUTS (17)	Local Read
_global_init (143)	Local Write
SC_TP211_OFF%MX11.2	
	Total Weike
PLC_PRG.SC_OUTPUTS (125)	Local Write
_global_init (110)	Local Write
SC_TP201_VENT_DISABLE_REQ%MX641.13	
PLC_PRG.CLEAR_REQS (20)	Local Write
PLC_PRG.SC_INPUTS (18)	Local Read
_global_init (144)	Local Write
SC_TP201_ON%MX10.9	
PLC_PRG.SC_OUTPUTS (116)	Local Write
_global_init (102)	Local Write
SC_TP201_VENT_NOT_SYMBOL%MX10.6	
PLC_PRG.SC_OUTPUTS (113)	Local Write
_global_init (100)	Local Write
SC_TP201_ON_REQ%MX641.10	
PLC_PRG.CLEAR_REQS (17)	Local Write
PLC_PRG.SC_INPUTS (15)	Local Read
_global_init (141)	Local Write
	HOCAT WITCE
SC_TP201_ON_PERMIT%MX10.11	
PLC_PRG.SC_OUTPUTS (118)	Local Write
_global_init (104)	Local Write
SC_TP201_OFF_REQ%MX641.11	
PLC_PRG.CLEAR_REQS (18)	Local Write
PLC_PRG.SC_INPUTS (16)	Local Read
_global_init (142)	Local Write
SC_TP201_OFF%MX10.10	
PLC_PRG.SC_OUTPUTS (117)	Local Write
_global_init (103)	Local Write
	TOCAT MITCE
SC_TP201_ON_CMD%MX10.13	
PLC_PRG.SC_OUTPUTS (120)	Local Write
_global_init (106)	Local Write
SC_TP201_OFF_PERMIT%MX10.12	
	Iocal Write
PLC_PRG.SC_OUTPUTS (119)	Local Write
_global_init (105)	Local Write

SC_TP201_NOT_SYMBOL%MX10.14	
PLC_PRG.SC_OUTPUTS (121) _global_init (107)	Local Write Local Write
_global_init (107) SC_SLOTV211_OPN_REQ%MX642.0	LOCAL WIILE
PLC_PRG.CLEAR_REQS (22)	Local Write
PLC_PRG.SC_INPUTS (19)	Local Read
_global_init (145)	Local Write
SC_SLOTV211_OPN_REQ%MX642.0	
PLC_PRG.CLEAR_REQS (22)	Local Write
PLC_PRG.SC_INPUTS (19)	Local Read
_global_init (145)	Local Write
SC_SLOTV211_OPEN_CMD%MX7.13	
PLC_PRG.SC_OUTPUTS (91)	Local Write
_global_init (84) SC_SLOTV211_OPEN_PERMIT%MX7.11	Local Write
PLC_PRG.SC_OUTPUTS (89)	Local Write
_global_init (82)	Local Write
SC_SLOTV211_NOT_SYMBOL%MX7.15	
PLC_PRG.SC_OUTPUTS (93)	Local Write
_global_init (86)	Local Write
SC_SLOTV211_NOT_SYMBOL%MX7.15	
PLC_PRG.SC_OUTPUTS (93)	Local Write
_global_init (86)	Local Write
SC_SLOTV211_CLS_REQ%MX642.1	T T T
~ ` '	Local Write Local Read
PLC_PRG.SC_INPUTS (20) _global_init (146)	Local Write
_global_init (146) SC_SLOTV211_CLS_REQ%MX642.1	DOCAL WITCO
PLC_PRG.CLEAR_REQS (23)	Local Write
PLC_PRG.SC_INPUTS (20)	Local Read
_global_init (146)	Local Write
SC_RPV211_OPEN_CMD%MX6.5	
	Local Write
_global_init (74)	Local Write
SC_SLOTV211_OPEN%MX7.9 PLC_PRG.SC_OUTPUTS (87)	Local Write
_global_init (80)	Local Write
SC_SLOTV211_OPEN%MX7.9	20041 11100
PLC_PRG.SC_OUTPUTS (87)	Local Write
_global_init (80)	Local Write
SC_SLOTV211_CLOSE_PERMIT%MX7.12	
PLC_PRG.SC_OUTPUTS (90)	Local Write
_global_init (83) SC_SLOTV211_CLOSED%MX7.10	Local Write
PLC_PRG.SC_OUTPUTS (88)	Local Write
_global_init (81)	Local Write
SC_SLOTV211_CLOSE_CMD%MX7.14	
PLC_PRG.SC_OUTPUTS (92)	Local Write
_global_init (85)	Local Write
SC_RPV212_OPEN_CMD%MX8.5	
PLC_PRG.SC_OUTPUTS (97)	Local Write
_global_init (89)	Local Write
SC_RPV212_CLOSED%MX8.2 PLC_PRG.SC_OUTPUTS (96)	Local Write
_qlobal_init (88)	Local Write
SC_RPV212_OPEN%MX8.1	LOCAL WITCO
PLC_PRG.SC_OUTPUTS (95)	Local Write
_global_init (87)	Local Write
SC_RP2111_ON%MX10.0	
PLC_PRG.SC_OUTPUTS (109)	Local Write
_global_init (97)	Local Write
SC_RPV212_CLOSED%MX8.2	Local Write
PLC_PRG.SC_OUTPUTS (96) _global_init (88)	Local Write Local Write
SC_RPV211_OPEN%MX6.1	LOCAL WITCO
PLC_PRG.SC_OUTPUTS (76)	Local Write
_global_init (72)	Local Write
SC_RPV211_CLOSED%MX6.2	
PLC_PRG.SC_OUTPUTS (77)	Local Write
_global_init (73)	Local Write
SC_RP2111_ON_CMD%MX10.1 PLC_PRG.SC_OUTPUTS (110)	Local Write
_global_init (98)	Local Write

SC_RP2111_ON_CMD%MX10.1	
PLC_PRG.SC_OUTPUTS (110)	Local Write
	Local Write
SC_RP2111_ON%MX10.0	Hotal Wiles
	I I FILL I I -
PLC_PRG.SC_OUTPUTS (109)	Local Write
_global_init (97)	Local Write
SC_RP2110_ON_CMD%MX9.9	
PLC_PRG.SC_OUTPUTS (107)	Local Write
_global_init (96)	Local Write
SC_RP2110_ON_CMD%MX9.9	
PLC_PRG.SC_OUTPUTS (107)	Local Write
_global_init (96)	Local Write
SC_RP2110_ON%MX9.8	
PLC_PRG.SC_OUTPUTS (106)	Local Write
_global_init (95)	Local Write
SC_RP2110_ON%MX9.8	
	Local Write
_global_init (95)	Local Write
SC_RESET_REQ%MX640.0	
PLC_PRG.CLEAR_REQS (3)	Local Write
PLC_PRG.SC_INPUTS (2)	Local Read
_global_init (132)	Local Write
SC RESET REO%MX640.0	20001
	T 1 T-7 ''
PLC_PRG.CLEAR_REQS (3)	Local Write
PLC_PRG.SC_INPUTS (2)	Local Read
_global_init (132)	Local Write
SC_PE212_PSL_LO%MX2.4	
PLC_PRG.SC_OUTPUTS (32)	Local Write
_global_init (36)	Local Write
SC_PE212_PSL_MIDHI%MX2.2	
PLC_PRG.SC_OUTPUTS (30)	Local Write
_global_init (34)	Local Write
SC_PE212_PSL_LO%MX2.4	
	Local Write
PLC_PRG.SC_OUTPUTS (32)	
_global_init (36)	Local Write
SC_PE212_PSL_MIDHI%MX2.2	
PLC_PRG.SC_OUTPUTS (30)	Local Write
_global_init (34)	Local Write
SC_PE212_PSL_HI%MX2.1	
	Table 1 March
PLC_PRG.SC_OUTPUTS (29)	Local Write
_global_init (33)	Local Write
SC_PE212_LO_PIY%MW1292	
PLC_PRG.SC_OUTPUTS (168)	Local Write
global init (157)	Local Write
SC_PE212_LO_PIY%MW1292	
	Incal Waite
PLC_PRG.SC_OUTPUTS (168)	Local Write
_global_init (157)	Local Write
SC_PE212_OK%MX2.0	
PLC_PRG.SC_OUTPUTS (28)	Local Write
_global_init (32)	Local Write
SC_PE212_HI_PIY%MW1291	
	Local Write
PLC_PRG.SC_OUTPUTS (167)	
_global_init (156)	Local Write
SC_PE212_HI_PIY%MW1291	
PLC_PRG.SC_OUTPUTS (167)	Local Write
_global_init (156)	Local Write
SC_PE211_PSL_MIDLO%MX1.11	
	Iogal Writa
PLC_PRG.SC_OUTPUTS (25)	Local Write
_global_init (30)	Local Write
SC_PE211_PSL_MIDLO%MX1.11	
PLC_PRG.SC_OUTPUTS (25)	Local Write
_global_init (30)	Local Write
SC_PE211_PSL_LO%MX1.12	
PLC_PRG.SC_OUTPUTS (26)	Local Write
_global_init (31)	Local Write
SC_PE211_OK%MX1.8	
PLC_PRG.SC_OUTPUTS (22)	Local Write
	Local Write
SC_PE211_LO_PIY%MW1290	
	Iogal Writa
PLC_PRG.SC_OUTPUTS (166)	Local Write
_global_init (155)	Local Write
SC_PE211_LO_PIY%MW1290	
PLC_PRG.SC_OUTPUTS (166)	Local Write
<u> </u>	

_global_init (155)		Local Write
SC_PE2111_PSL%MX0.15		
	(14)	
_global_init (21) SC_PE211_PSL_HI%MX1.9		Local Write
	(23)	Local Write
_global_init (28)	, ,	Local Write
SC_PE211_PSL_HI%MX1.9		local write
PLC_PRG.SC_OUTPUTS	(23)	Local Write
_global_init (28)		Local Write
SC_PE211_HI_PIY%MW1289		
PLC_PRG.SC_OUTPUTS	(165)	Local Write
_global_init (154)		Local Write
SC_PE203_PSL_MIDLO%MX1.3		
1	(19)	Local Write
_global_init (25)		Local Write
SC_PE2110_PSL%MX0.14		
I .	(13)	
_global_init (20)		Local Write
SC_PE203_PSL_HI%MX1.1 PLC_PRG.SC_OUTPUTS	(17)	Local Write
_global_init (23)	(± /)	Local Write
SC_PE211_HI_PIY%MW1289		
PLC_PRG.SC_OUTPUTS	(165)	Local Write
_global_init (154)	•	Local Write
SC_PE203_LO_PIY%MW1288		
PLC_PRG.SC_OUTPUTS	(164)	Local Write
_global_init (153)		Local Write
SC_PE203_PSL_MIDHI%MX1.2		
	(18)	
_global_init (24)		Local Write
SC_PE202_PSL%MX0.10	40)	
PLC_PRG.SC_OUTPUTS	(9)	Local Write
_global_init (17)		Local Write
SC_PE203_LO_PIY%MW1288 PLC_PRG.SC_OUTPUTS	(164)	Local Write
_global_init (153)		Local Write
SC_PE202_PIY%MW1286		HOOMI WIICC
PLC_PRG.SC_OUTPUTS	(162)	Local Write
global_init (151)		Local Write
SC_PE203_PSL_LO%MX1.4		
PLC_PRG.SC_OUTPUTS	(20)	Local Write
_global_init (26)		Local Write
SC_PE203_PSL_L0%MX1.4		
PLC_PRG.SC_OUTPUTS	(20)	Local Write
_global_init (26)		Local Write
SC_PE203_OK%MX1.0	(16)	
PLC_PRG.SC_OUTPUTS	(T Ø)	Local Write
_global_init (22) SC_PE202_PIY%MW1286		Local Write
PLC_PRG.SC_OUTPUTS	(162)	Local Write
_global_init (151)		Local Write
SC_PE203_HI_PIY%MW1287		
PLC_PRG.SC_OUTPUTS	(163)	Local Write
		Local Write
SC_PE203_HI_PIY%MW1287		
PLC_PRG.SC_OUTPUTS	(163)	Local Write
_global_init (152)		Local Write
SC_PE201_PIY%MW1285		
PLC_PRG.SC_OUTPUTS	(161)	Local Write
_global_init (150)		Local Write
SC_PE101_PSL%MX0.8 PLC_PRG.SC_OUTPUTS	(7)	Local Write
_global_init (15)	\ ' /	Local Write Local Write
_global_Init (13) SC_PE101_PIY%MW1284		20001 11100
PLC_PRG.SC_OUTPUTS	(160)	Local Write
_global_init (149)		Local Write
SC_LL_TP212_TURBO_OK%MX1		
PLC_PRG.SC_OUTPUTS	(149)	Local Write
_global_init (129)		Local Write
SC_LL_TP211_TURBO_OK%MX1		
PLC_PRG.SC_OUTPUTS		Local Write
_global_init (128)		Local Write

SC_PE203_PSL_MIDLO%MX1.3 PLC_PRG.SC_OUTPUTS (19)global_init (25)		
PLC_PRG.SC_OUTPUTS (19)		
	Local Write	
	Local Write	
	Hocar write	
SC_PE201_PSL%MX0.9		
PLC_PRG.SC_OUTPUTS (8)	Local Write	
_global_init (16)	Local Write	
SC_LL_V202_OPN%MX12.3		
PLC_PRG.SC_OUTPUTS (136)	Local Write	
_global_init (117)	Local Write	
SC LL TP212 TURBO OK%MX13.7	Booti Wile	
PLC_PRG.SC_OUTPUTS (149)	Local Write	
_global_init (129)	Local Write	
SC_LL_TP211_TURBO_OK%MX13.6		
PLC_PRG.SC_OUTPUTS (148)	Local Write	
_global_init (128)	Local Write	
SC_LL_TP201_OK%MX12.7		
PLC_PRG.SC_OUTPUTS (140)	Local White	
_global_init (121)	Local Write	
SC_LL_TP201_OK%MX12.7		
PLC_PRG.SC_OUTPUTS (140)	Local Write	
_global_init (121)	Local Write	
SC_LL_RP2111_ON%MX13.4		
	Local Write	
_global_init (126)	Local Write	
	HOCGT MITCE	
SC_PE202_PSL%MX0.10		
PLC_PRG.SC_OUTPUTS (9)	Local Write	
_global_init (17)	Local Write	
SC_LL_PE212_OK%MX13.3		
PLC_PRG.SC_OUTPUTS (145)	Local Write	
_global_init (125)	Local Write	
SC_LL_PE212_OK%MX13.3	20041 11200	
	Taral Maika	
PLC_PRG.SC_OUTPUTS (145)		
_global_init (125)	Local Write	
SC_LL_PE203_OK%MX12.5		
PLC_PRG.SC_OUTPUTS (138)	Local Write	
_global_init (119)	Local Write	
SC_LL_V202_OPN%MX12.3		
5 0 _ 2 2 _ 7 2 7 2 2 2 11 71 11 12 7 9		
DIC DDC CC OUTDUTC (136)	Iogal Write	
PLC_PRG.SC_OUTPUTS (136)	Local Write	
_global_init (117)	Local Write Local Write	
_global_init (117) SC_LL_STATE%MW1306	Local Write	
_global_init (117)		
_global_init (117) SC_LL_STATE%MW1306	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278)	Local Write Local Write Local Write Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280)	Local Write Local Write Local Write Local Write Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144)	Local Write Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124)	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9	Local Write	
global_init (117) SCLL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 global_init (131) SC_LL_PE2111_PSL_LL%MX13.9	Local Write	
global_init (117) SCLL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131)	Local Write	
global_init (117) SCLL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9	Local Write	
global_init (117) SCLL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130)	Local Write	
global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130)	Local Write	
global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8	Local Write	
_global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (286) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (294) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130)	Local Write	
global_init (117) SC_LL_STATE%MW1306 PLC_PRG.SC_OUTPUTS (274) PLC_PRG.SC_OUTPUTS (276) PLC_PRG.SC_OUTPUTS (278) PLC_PRG.SC_OUTPUTS (280) PLC_PRG.SC_OUTPUTS (282) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (284) PLC_PRG.SC_OUTPUTS (288) PLC_PRG.SC_OUTPUTS (290) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (292) PLC_PRG.SC_OUTPUTS (297) _global_init (163) SC_LL_RP2111_ON%MX13.4 PLC_PRG.SC_OUTPUTS (146) _global_init (126) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE211_OK%MX13.2 PLC_PRG.SC_OUTPUTS (144) _global_init (124) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.9 _global_init (131) SC_LL_PE2111_PSL_LL%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8 _global_init (130) SC_LL_PE2111_PSL_ES%MX13.8	Local Write	

SC_LL_PE2111_PSL%MX13.5		
PLC_PRG.SC_OUTPUTS (147)	l Write
_global_init (127)	Loca	l Write
SC_LL_PE202_PSL%MX12.4		
PLC_PRG.SC_OUTPUTS ([137] Local	l Write
_global_init (118)		l Write
	1000	WITCO
SC_LL_PE101_PSL%MX12.1		
PLC_PRG.SC_OUTPUTS (134) Local	L Write
_global_init (115)	Local	l Write
SC PE201 PSL%MX0.9		
	(0)	Unito
PLC_PRG.SC_OUTPUTS (
_global_init (16)	Local	L Write
SC_PE201_PIY%MW1285		
PLC PRG.SC OUTPUTS (161) Local	Write
_global_init (150)	Loca	l Write
SC_PE101_PIY%MW1284		
PLC_PRG.SC_OUTPUTS (160) Local	l Write
_global_init (149)	I.oca	l Write
	Боса	WITCO
SC_LL_STATE%MW1306		
PLC_PRG.SC_OUTPUTS (274) Local	L Write
PLC_PRG.SC_OUTPUTS ((276) Local	l Write
PLC_PRG.SC_OUTPUTS (l Write
PLC_PRG.SC_OUTPUTS (
PLC_PRG.SC_OUTPUTS (282) Local	l Write
PLC_PRG.SC_OUTPUTS (l Write
		L Write
PLC_PRG.SC_OUTPUTS (•	
PLC_PRG.SC_OUTPUTS (
PLC_PRG.SC_OUTPUTS (290) Local	l Write
PLC_PRG.SC_OUTPUTS (l Write
	•	
PLC_PRG.SC_OUTPUTS (l Write
PLC_PRG.SC_OUTPUTS ([297] Local	l Write
_global_init (163)	Loca	l Write
SC_LL_PE203_PSL_L0%MX12.6		
PLC_PRG.SC_OUTPUTS ([139] Local	L Write
_global_init (120)	Local	l Write
SC_LL_PE203_PSL_L0%MX12.6		
	120)	L Write
PLC_PRG.SC_OUTPUTS (
_global_init (120)	Local	l Write
SC_LL_PE203_OK%MX12.5		
PLC PRG.SC OUTPUTS (138) Local	Write
_global_init (119)		L Write
	LOCa	r write
SC_LL_PE202_PSL%MX12.4		
PLC_PRG.SC_OUTPUTS ([137] Local	l Write
_global_init (118)	Loca	l Write
SC_LL_PE101_PSL%MX12.1		
PLC_PRG.SC_OUTPUTS ([134] Local	l Write
_global_init (115)	Local	l Write
SC_LL_PE201_PSL%MX12.2		
	125)	Write
PLC_PRG.SC_OUTPUTS (L Write
_global_init (116)	Local	l Write
SC_LL_PE201_PSL%MX12.2		
PLC_PRG.SC_OUTPUTS (135)	l Write
_global_init (116)	Loca	l Write
SC_LL_LL_CONFIG_OK%MX13.1		
PLC_PRG.SC_OUTPUTS ([143] Local	l Write
_global_init (123)		L Write
	Боса	WITCO
SC_LL_LL_CONFIG_OK%MX13.1		
PLC_PRG.SC_OUTPUTS ([143] Local	l Write
_global_init (123)	Local	l Write
SC_LL_ES_CONFIG_OK%MX13.0		
	1140)	Weite
PLC_PRG.SC_OUTPUTS (L Write
_global_init (122)	Local	l Write
SC_LL_ES_CONFIG_OK%MX13.0		
PLC_PRG.SC_OUTPUTS (142)	l Write
_global_init (122)	Loca	l Write
SC_LL_CMD_VAL%MW1298		
PLC_PRG.SC_OUTPUTS (205) Local	l Write
PLC_PRG.SC_OUTPUTS (L Write
PLC_PRG.SC_OUTPUTS (l Write
PLC_PRG.SC_OUTPUTS (211) Local	l Write
PLC_PRG.SC_OUTPUTS ((214) Loca	l Write
_global_init (160)		L Write
	ьoca.	F WIICO
SC_LL_CMD_VAL%MW1298		

```
PLC_PRG.SC_OUTPUTS (205)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (207)
     PLC_PRG.SC_OUTPUTS (207)
PLC_PRG.SC_OUTPUTS (209)
                                            Local Write
                                           Local Write
      PLC_PRG.SC_OUTPUTS (211)
                                            Local Write
      PLC_PRG.SC_OUTPUTS (214)
                                            Local Write
      _global_init (160)
                                            Local Write
SC_LL_CMD_REQ%MW3714
     PLC_PRG.SC_INPUTS (55)
                                            Local Read
      PLC_PRG.SC_INPUTS (57)
                                            Local Read
     PLC_PRG.SC_INPUTS (59)
                                            Local Read
     PLC_PRG.SC_INPUTS (61)
                                            Local Read
     _global_init (166)
                                            Local Write
SC_LL_ACTUATOR_OK%MX12.0
     PLC_PRG.SC_OUTPUTS (133)
                                            Local Write
                                            Local Write
     _global_init (114)
SC_LL_CMD_REQ%MW3714
                                           Local Read
     PLC_PRG.SC_INPUTS (55)
     PLC_PRG.SC_INPUTS (57)
                                           Local Read
     PLC_PRG.SC_INPUTS (59)
                                           Local Read
     PLC_PRG.SC_INPUTS (61)
                                            Local Read
      _global_init (166)
                                            Local Write
SC_LL211_LID_CLOSED%MX2.8
     PLC_PRG.SC_OUTPUTS (34)
                                            Local Write
     _global_init (37)
                                             Local Write
SC_ES_STATE%MW1305
                                           Local Write
     PLC_PRG.SC_OUTPUTS (245)
     PLC_PRG.SC_OUTPUTS (247)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (249)
                                           Local Write
                                          Local Write
Local Write
Local Write
Local Write
Local Write
Local Write
Local Write
Local Write
Local Write
     PLC_PRG.SC_OUTPUTS (251)
     PLC_PRG.SC_OUTPUTS (253)
     PLC_PRG.SC_OUTPUTS (255)
     PLC_PRG.SC_OUTPUTS (257)
     PLC_PRG.SC_OUTPUTS (259)
     PLC_PRG.SC_OUTPUTS (261)
     PLC_PRG.SC_OUTPUTS (263)
      PLC_PRG.SC_OUTPUTS (265)
     PLC_PRG.SC_OUTPUTS (268)
                                            Local Write
     _global_init (162)
                                             Local Write
SC_ES_CMD_REQ%MW3713
                                           Local Read
     PLC_PRG.SC_INPUTS (40)
     PLC_PRG.SC_INPUTS (42)
                                            Local Read
     PLC_PRG.SC_INPUTS (44)
                                            Local Read
     PLC_PRG.SC_INPUTS (46)
                                             Local Read
     _global_init (165)
                                             Local Write
RPV212_OPN_REQ_LL
     PLC_PRG.LL_SM (12)
                                            Local Write
     PLC_PRG.LL_SM (25)
                                             Local Write
     PLC_PRG.LL_SM (38)
                                             Local Write
     PLC_PRG.LL_SM (55)
                                             Local Write
      PLC_PRG.LL_SM (72)
                                             Local Write
      PLC_PRG.LL_SM (89)
                                             Local Write
      PLC_PRG.LL_SM (106)
                                             Local Write
      PLC_PRG.LL_SM (124)
                                             Local Write
      PLC_PRG.LL_SM (141)
                                             Local Write
     PLC_PRG.LL_SM (161)
                                             Local Write
      PLC_PRG.LL_SM (180)
                                             Local Write
      PLC_PRG.VALVES (105)
                                             Local Read
      PLC_PRG.VALVES (106)
                                             Local Read
     _global_init (274)
                                             Local Write
RPV212_CSD
     PLC_PRG.LL_SM (32)
                                             Local Read
     PLC_PRG.PROCESS_IN... (68)
PLC_PRG.PUMPS (8)
                                             Local Write
                                             Local Read
      PLC_PRG.SC_OUTPUTS (96)
                                             Local Read
      PLC_PRG.VALVES (71)
                                             Local Read
      PLC_PRG.VALVES (86)
                                             Local Read
     PLC_PRG.VALVES (94)
                                             Local Read
      _global_init (214)
                                             Local Write
RPV212_CLS_REQ_LL
     _global_init (275)
                                            Local Write
SC_LL_ACTUATOR_OK%MX12.0
     PLC_PRG.SC_OUTPUTS (133)
                                             Local Write
     _global_init (114)
                                             Local Write
```

```
RPV211_CSD
     PLC_PRG.ES_SM (33)
                                             Local Read
      PLC_PRG.ES_SM (33)
PLC_PRG.PROCESS_IN... (56)
                                            Local Write
      PLC_PRG.PUMPS (8)
                                             Local Read
      PLC_PRG.SC_OUTPUTS (77)
                                             Local Read
      PLC_PRG.VALVES (54)
                                             Local Read
      PLC_PRG.VALVES (62)
                                             Local Read
      PLC_PRG.VALVES (103)
                                              Local Read
      _global_init (206)
                                              Local Write
SC_LL211_ARM_RETRACTED%MX2.9
     PLC_PRG.SC_OUTPUTS (35)
                                             Local Write
      _global_init (38)
                                              Local Write
SC_LL211_ARM_RETRACTED%MX2.9
     PLC_PRG.SC_OUTPUTS (35)
                                             Local Write
                                              Local Write
      _global_init (38)
SC_ES_CMD_VAL%MW1297
                                          Local Write
Local Write
Local Write
Local Write
Local Write
      PLC_PRG.SC_OUTPUTS (190)
      PLC_PRG.SC_OUTPUTS (192)
      PLC_PRG.SC_OUTPUTS (194)
      PLC_PRG.SC_OUTPUTS (196)
      PLC_PRG.SC_OUTPUTS (199)
      _global_init (159)
                                              Local Write
RP211_PSL
     PLC_PRG.PROCESS_IN... (9)
                                            Local Write
     _global_init (189)
                                              Local Write
Reset_Required
                                            Local Write
     PLC_PRG.FAULT_LOGIC (37)
     PLC_PRG.SC_OUTPUTS (2)
                                             Local Read
                                              Local Write
      _global_init (245)
SC_ES_STATE%MW1305
                                          Local Write
     PLC_PRG.SC_OUTPUTS (245)
      PLC_PRG.SC_OUTPUTS (247)
      PLC_PRG.SC_OUTPUTS (249)
      PLC_PRG.SC_OUTPUTS (251)
      PLC_PRG.SC_OUTPUTS (253)
      PLC_PRG.SC_OUTPUTS (255)
      PLC_PRG.SC_OUTPUTS (257)
      PLC_PRG.SC_OUTPUTS (259)
      PLC_PRG.SC_OUTPUTS (261)
      PLC_PRG.SC_OUTPUTS (263)
      PLC_PRG.SC_OUTPUTS (265)
      PLC_PRG.SC_OUTPUTS (268)
                                               Local Write
      _global_init (162)
rVersion
      _global_init (165)
                                               Global Write
RPV212
     PLC_PRG.PROCESS_OU... (23)
PLC_PRG.SC_OUTPUTS (97)
                                             Local Read
                                             Local Read
                                               Local Write
      PLC_PRG.VALVES (103)
                                               Local Write
      PLC_PRG.VALVES (104)
                                               Local Write
      PLC_PRG.VALVES (105)
                                               Local Write
      PLC_PRG.VALVES (106)
                                               Local Write
      PLC_PRG.VALVES (107)
                                               Local Read
      _global_init (306)
                                               Local Read
PE212_PSL_MIDLO
      PLC_PRG.LL_SM (47)
                                               Local Read
      PLC_PRG.LL_SM (135)
                                               Local Read
      PLC_PRG.LL_SM (152)
                                               Local Read
      PLC_PRG.LL_SM (172)
                                               Local Read
      PLC_PRG.LL_SM (191)
                                               Local Read
      PLC_PRG.PROCESS_IN... (27)
                                               Local Write
      PLC_PRG.VALVES (103)
                                               Local Read
      PLC_PRG.VALVES (110)
                                               Local Read
      _global_init (187)
                                               Local Write
SC_LL211_LID_CLOSED%MX2.8
     PLC_PRG.SC_OUTPUTS (34)
                                              Local Write
      _global_init (37)
                                               Local Write
PE212_PSH_MIDHI
      PLC_PRG.LL_SM (66)
                                              Local Read
      PLC_PRG.PROCESS_IN... (26)
                                               Local Write
                                               Local Write
      _global_init (186)
SC_ES_CMD_VAL%MW1297
```

```
PLC_PRG.SC_OUTPUTS (190)
                                             Local Write
                                         Local Write
Local Write
Local Write
      PLC_PRG.SC_OUTPUTS (192)
      PLC_PRG.SC_OUTPUTS (192)
PLC_PRG.SC_OUTPUTS (194)
      PLC_PRG.SC_OUTPUTS (196)
      PLC_PRG.SC_OUTPUTS (199)
                                            Local Write
      _global_init (159)
                                             Local Write
RPV212_OPN
                                           Local Write
     PLC_PRG.PROCESS_IN... (67)
     PLC_PRG.SC_OUTPUTS (95)
                                             Local Read
      _global_init (213)
                                             Local Write
RPV211_CLS_REQ_ES
     _global_init (263)
                                             Local Write
RPV211
     PLC_PRG.PROCESS_OU... (14)
PLC_PRG.SC_OUTPUTS (78)
                                           Local Read
                                            Local Read
      PLC_PRG.VALVES (70)
                                            Local Write
      PLC_PRG.VALVES (71)
                                            Local Write
      PLC_PRG.VALVES (72)
                                            Local Write
      PLC_PRG.VALVES (73)
                                            Local Write
      PLC_PRG.VALVES (74)
                                            Local Write
      PLC_PRG.VALVES (75)
                                            Local Read
     _global_init (301)
                                             Local Read
PE212_PSH_HI
     PLC_PRG.LL_SM (83)
                                            Local Read
      PLC_PRG.LL_SM (100)
                                             Local Read
                                           Local Write
     PLC_PRG.PROCESS_IN... (25)
      _global_init (185)
                                              Local Write
PE211_PSL_MIDLO
     PLC_PRG.ES_SM (49)
                                            Local Read
      PLC_PRG.ES_SM (142)
                                            Local Read
      PLC_PRG.ES_SM (160)
                                            Local Read
      PLC_PRG.ES_SM (181)
                                            Local Read
      PLC_PRG.ES_SM (201)
                                            Local Read
      PLC_PRG.PROCESS_IN... (21)
                                        Local Write
      PLC_PRG.VALVES (71)
                                            Local Read
     PLC_PRG.VALVES (78)
                                              Local Read
                                              Local Write
     _global_init (182)
PE211_PSL_LO
                                            Local Read
     PLC_PRG.ES_SM (183)
      PLC_PRG.ES_SM (204)
                                            Local Read
                                           Local Write
      PLC_PRG.PROCESS_IN... (22)
     PLC_PRG.VALVES (36)
                                              Local Read
     _global_init (183)
                                              Local Write
SC_ES_CMD_REQ%MW3713
                                           Local Read
Local Read
     PLC_PRG.SC_INPUTS (40)
     __INPUTS (42)
LC_PRG.SC_INPUTS (44)
PLC_PRG.SC_INPUTS (46)
_global_init (165)
_PSH_MIDHI
                                            Local Read
                                              Local Read
                                              Local Write
PE211_PSH_MIDHI
     PLC_PRG.ES_SM (69)
                                              Local Read
     PLC_PRG.PROCESS_IN... (20)
                                              Local Write
                                           Local Write
Local Write
      _global_init (181)
SC_BR_STATE%MW1304
     PLC_PRG.SC_OUTPUTS (221)
      PLC_PRG.SC_OUTPUTS (224)
      PLC_PRG.SC_OUTPUTS (227)
      PLC_PRG.SC_OUTPUTS (230)
                                              Local Write
      PLC_PRG.SC_OUTPUTS (233)
                                              Local Write
      PLC_PRG.SC_OUTPUTS (236)
                                              Local Write
      PLC_PRG.SC_OUTPUTS (239)
                                              Local Write
      _global_init (161)
                                              Local Write
                                           Local Write
SC_BR_STATE%MW1304
      PLC_PRG.SC_OUTPUTS (221)
      PLC_PRG.SC_OUTPUTS (224)
                                           Local Write
Local Write
Local Write
Local Write
Local Write
Local Write
      PLC_PRG.SC_OUTPUTS (227)
      PLC_PRG.SC_OUTPUTS (230)
      PLC_PRG.SC_OUTPUTS (233)
      PLC_PRG.SC_OUTPUTS (236)
      PLC_PRG.SC_OUTPUTS (239)
      _global_init (161)
                                              Local Write
SC_BR_CMD_VAL%MW1296
      PLC_PRG.SC_OUTPUTS (173)
                                              Local Write
```

```
PLC_PRG.SC_OUTPUTS (175)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (177)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (179)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (181)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (184)
                                           Local Write
     _global_init (158)
                                           Local Write
SC_BR_CMD_REQ%MW3712
     PLC_PRG.SC_INPUTS (24)
                                          Local Read
     PLC_PRG.SC_INPUTS (26)
                                           Local Read
     PLC_PRG.SC_INPUTS (28)
                                           Local Read
     PLC_PRG.SC_INPUTS (30)
                                          Local Read
     PLC_PRG.SC_INPUTS (32)
                                           Local Read
     _global_init (164)
                                           Local Write
SC_AFB%MX0.3
     PLC_PRG.SC_OUTPUTS (4)
                                            Local Write
     _global_init (14)
                                            Local Write
SC_ATB%MX0.2
     PLC_PRG.SC_OUTPUTS (3)
                                            Local Write
     _global_init (13)
                                            Local Write
RPV211_OPN_REQ_ES
     PLC_PRG.ES_SM (12)
                                           Local Write
                                           Local Write
     PLC_PRG.ES_SM (26)
     PLC_PRG.ES_SM (40)
                                           Local Write
     PLC_PRG.ES_SM (58)
                                           Local Write
     PLC_PRG.ES_SM (76)
                                           Local Write
     PLC_PRG.ES_SM (94)
                                           Local Write
     PLC_PRG.ES_SM (112)
                                           Local Write
     PLC_PRG.ES_SM (131)
                                           Local Write
     PLC_PRG.ES_SM (149)
                                           Local Write
     PLC_PRG.ES_SM (170)
                                           Local Write
     PLC_PRG.ES_SM (190)
                                           Local Write
     PLC_PRG.VALVES (73)
                                           Local Read
     PLC_PRG.VALVES (74)
                                           Local Read
     _global_init (262)
                                           Local Write
RP211_ON_REQ_LL
     PLC_PRG.LL_SM (13)
                                          Local Write
     PLC_PRG.LL_SM (26)
                                           Local Write
     PLC_PRG.LL_SM (39)
                                           Local Write
     PLC_PRG.LL_SM (56)
                                           Local Write
     PLC_PRG.LL_SM (73)
                                           Local Write
     PLC_PRG.LL_SM (90)
                                           Local Write
     PLC_PRG.LL_SM (107)
                                           Local Write
     PLC_PRG.LL_SM (125)
                                           Local Write
     PLC_PRG.LL_SM (142)
                                           Local Write
     PLC_PRG.LL_SM (162)
                                           Local Write
     PLC_PRG.LL_SM (181)
                                           Local Write
     PLC_PRG.PUMPS (9)
                                            Local Read
     _global_init (283)
                                            Local Write
RP211_ON
     PLC_PRG.ES_SM (123)
                                           Local Read
     PLC_PRG.LL_SM (117)
                                            Local Read
     PLC_PRG.PROCESS_IN... (7)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (106)
                                            Local Read
     PLC_PRG.VALVES (70)
                                            Local Read
     PLC_PRG.VALVES (102)
                                            Local Read
     _global_init (224)
                                            Local Write
RP211
     PLC_PRG.PROCESS_OU... (3)
                                            Local Read
     PLC_PRG.PUMPS (7)
                                            Local Write
     PLC_PRG.PUMPS (8)
                                            Local Write
     PLC_PRG.PUMPS (9)
                                            Local Write
     PLC_PRG.PUMPS (10)
                                            Local Read
     PLC_PRG.PUMPS (10)
                                            Local Write
     PLC_PRG.PUMPS (11)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (107)
                                            Local Read
     _global_init (309)
                                            Local Read
PE212_PSL_LO
     PLC_PRG.LL_SM (174)
                                           Local Read
     PLC_PRG.LL_SM (194)
                                           Local Read
     PLC_PRG.PROCESS_IN... (28)
                                            Local Write
      _global_init (188)
                                            Local Write
PE212_PIY_OK
     PLC_PRG.FAULT_LOGIC (15)
                                            Local Read
```

```
PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (24)
                                         Local Write
                                         Local Write
     _global_init (184)
PE211_PSH_HI
     PLC_PRG.ES_SM (87)
                                          Local Read
     PLC_PRG.ES_SM (105)
                                          Local Read
     PLC_PRG.PROCESS_IN... (19)
                                         Local Write
     _global_init (180)
                                          Local Write
PE211_PIY_OK
                                        Local Read
     PLC_PRG.FAULT_LOGIC (14)
     PLC_PRG.FAULT_LOGIC (37)
                                         Local Read
     PLC_PRG.PROCESS_IN... (18)
                                         Local Write
     _global_init (179)
                                          Local Write
PE203_PSL_MIDLO
     PLC_PRG.PROCESS_IN... (15)
                                         Local Write
     _global_init (177)
                                          Local Write
PE203_PSL_LO
                                        Local Read
     PLC_PRG.FAULT_LOGIC (8)
     PLC_PRG.FAULT_LOGIC (37)
                                         Local Read
     PLC_PRG.PROCESS_IN... (16)
                                         Local Write
     _global_init (178)
                                          Local Write
PE203_PSH_HI
    PLC_PRG.PROCESS_IN... (13)
                                         Local Write
     _global_init (175)
                                          Local Write
SC_BR_CMD_VAL%MW1296
                                        Local Write
Local Write
    PLC_PRG.SC_OUTPUTS (173)
     PLC_PRG.SC_OUTPUTS (175)
                                         Local Write
Local Write
     PLC_PRG.SC_OUTPUTS (177)
     PLC_PRG.SC_OUTPUTS (179)
     PLC_PRG.SC_OUTPUTS (181)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (184)
                                         Local Write
                                          Local Write
     _global_init (158)
PE203_PIY_OK
                                       Local Read
     PLC_PRG.FAULT_LOGIC (13)
     PLC_PRG.FAULT_LOGIC (37)
                                         Local Read
     PLC_PRG.PROCESS_IN... (12)
                                         Local Write
                                          Local Write
     _global_init (174)
SC_BR_CMD_REQ%MW3712
    PLC_PRG.SC_INPUTS (24)
                                         Local Read
                                         Local Read
     PLC_PRG.SC_INPUTS (26)
     PLC_PRG.SC_INPUTS (28)
                                         Local Read
     PLC_PRG.SC_INPUTS (30)
                                         Local Read
     PLC_PRG.SC_INPUTS (32)
                                          Local Read
     _global_init (164)
                                           Local Write
RPV211 OPN
     PLC_PRG.PROCESS_IN... (55)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (76)
                                           Local Read
     _global_init (205)
                                           Local Write
PE202_PSL_LO
     PLC_PRG.FAULT_LOGIC (7)
                                         Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (5)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (9)
                                           Local Read
     _global_init (173)
                                           Local Write
RESET_REQ
     PLC_PRG.FAULT_LOGIC (3)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (4)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (5)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (6)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (7)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (8)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (10)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (11)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (13)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (14)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (15)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (17)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (19)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (20)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (21)
                                          Local Read
     PLC_PRG.SC_INPUTS (2)
                                           Local Write
                                           Local Write
     _global_init (170)
PE201_PSL_LO
```

```
PLC_PRG.FAULT_LOGIC (5)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (4)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (8)
                                          Local Read
                                          Local Write
     _global_init (172)
PE101_PSL_LO
     PLC_PRG.FAULT_LOGIC (4)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.PROCESS_IN... (3)
                                         Local Write
     PLC_PRG.SC_OUTPUTS (7)
                                          Local Read
     _global_init (171)
                                          Local Write
SC_AFB%MX0.3
     PLC_PRG.SC_OUTPUTS (4)
                                           Local Write
     _global_init (14)
                                           Local Write
RP211_ON_REQ_ES
     PLC_PRG.ES_SM (13)
                                          Local Write
     PLC_PRG.ES_SM (27)
                                          Local Write
     PLC_PRG.ES_SM (41)
                                          Local Write
     PLC_PRG.ES_SM (59)
                                          Local Write
     PLC_PRG.ES_SM (77)
                                          Local Write
     PLC_PRG.ES_SM (95)
                                          Local Write
     PLC_PRG.ES_SM (113)
                                          Local Write
     PLC_PRG.ES_SM (132)
                                          Local Write
     PLC_PRG.ES_SM (150)
                                          Local Write
     PLC_PRG.ES_SM (171)
                                          Local Write
     PLC_PRG.ES_SM (191)
                                          Local Write
     PLC_PRG.PUMPS (9)
                                          Local Read
     _global_init (282)
                                           Local Write
PE203_PSH_MIDHI
     PLC_PRG.PROCESS_IN... (14)
                                          Local Write
     _global_init (176)
                                           Local Write
open_req
                                           Local Write
     PLC_PRG.VALVES (49)
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FBinit (5)
                                           Local Write
open_ena
                                         Local Read
     PLC_PRG.SC_OUTPUTS (43)
     PLC_PRG.SC_OUTPUTS (51)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (63)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (71)
                                          Local Read
     PLC_PRG.VALVES (5)
                                          Local Write
     PLC_PRG.VALVES (13)
                                           Local Write
     PLC_PRG.VALVES (21)
                                           Local Write
     PLC_PRG.VALVES (29)
                                           Local Write
     PLC_PRG.VALVES (37)
                                           Local Write
     PLC_PRG.VALVES (55)
                                           Local Write
     PLC_PRG.VALVES (63)
                                           Local Write
     PLC_PRG.VALVES (71)
                                           Local Write
     PLC_PRG.VALVES (79)
                                           Local Write
     PLC_PRG.VALVES (87)
                                           Local Write
     PLC_PRG.VALVES (95)
                                           Local Write
     PLC_PRG.VALVES (103)
                                           Local Write
     PLC_PRG.VALVES (111)
                                           Local Write
     VALVE_FB (3)
                                           Local Read
     VALVE_FB (6)
                                           Local Read
     VALVE_FBinit (2)
                                           Local Write
open_ena
     PLC_PRG.SC_OUTPUTS (89)
                                           Local Read
     PLC_PRG.VALVES (46)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FB (11)
                                           Local Read
     VALVE_BI_FBinit (2)
                                           Local Write
open_cmd
     PLC_PRG.PROCESS_OU... (5)
                                          Local Read
     PLC_PRG.PROCESS_OU... (6)
                                           Local Read
     PLC_PRG.PROCESS_OU... (7)
                                           Local Read
     PLC_PRG.PROCESS_OU... (8)
                                           Local Read
     PLC_PRG.PROCESS_OU... (10)
                                           Local Read
     PLC_PRG.PROCESS_OU... (13)
                                           Local Read
     PLC_PRG.PROCESS_OU... (14)
                                           Local Read
     PLC_PRG.PROCESS_OU... (15)
                                           Local Read
```

```
PLC_PRG.PROCESS_OU... (16)
                                           Local Read
     PLC_PRG.PROCESS_OU... (22)
                                          Local Read
     PLC_PRG.PROCESS_OU... (23)
                                          Local Read
     PLC_PRG.PROCESS_OU... (24)
                                          Local Read
     PLC_PRG.PROCESS_OU... (25)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (45)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (53)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (65)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (73)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (78)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (80)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (81)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (85)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (97)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (99)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (100)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (104)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (112)
                                          Local Read
     VALVE_FB (3)
                                           Local Read
     VALVE_FB (3)
                                           Local Write
     VALVE_FB (6)
                                           Local Read
     VALVE_FBinit (6)
                                           Local Write
on rea
     PLC_PRG.PUMPS (17)
                                          Local Write
     PLC_PRG.PUMPS (25)
                                           Local Write
     PLC_PRG.PUMPS (26)
                                           Local Read
     PLC_PRG.PUMPS (33)
                                           Local Write
     PLC_PRG.PUMPS (34)
                                           Local Read
     TP_FB (3)
                                           Local Read
     TP_FBinit (4)
                                           Local Write
on_req
     PLC_PRG.PUMPS (9)
                                           Local Write
     PLC_PRG.PUMPS (10)
                                           Local Read
     RP_FB (2)
                                           Local Read
     RP_FBinit (3)
                                           Local Write
open_cmd
     PLC_PRG.PROCESS_OU... (18)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (91)
                                          Local Read
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (4)
                                           Local Write
     VALVE_BI_FB (11)
                                           Local Read
     VALVE_BI_FBinit (7)
                                           Local Write
on_intlk
     PLC_PRG.PUMPS (14)
                                           Local Write
     PLC_PRG.PUMPS (22)
                                           Local Write
     PLC_PRG.PUMPS (30)
                                           Local Write
     TP_FB (3)
                                           Local Read
     TP_FB (6)
                                            Local Read
     TP_FBinit (1)
                                           Local Write
LL_TP201_OK
     PLC_PRG.FAULT_LOGIC (19)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (19)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (140)
                                           Local Read
     PLC_PRG.VALVES (20)
                                           Local Read
     PLC_PRG.VALVES (36)
                                           Local Read
     _global_init (237)
                                           Local Write
LL_PE212_PIY_OK
     PLC_PRG.FAULT_LOGIC (15)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (15)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.LL_SM (4)
                                           Local Read
     PLC_PRG.LL_SM (19)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (145)
                                           Local Read
     PLC_PRG.VALVES (110)
                                           Local Read
     _global_init (241)
                                           Local Write
on_ena
     PLC_PRG.PUMPS (15)
                                           Local Write
     PLC_PRG.PUMPS (23)
                                           Local Write
     PLC_PRG.PUMPS (31)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (118)
                                           Local Read
     TP_FB (3)
                                            Local Read
                                            Local Read
     TP_FB (6)
```

```
TP_FBinit (2)
                                             Local Write
LL_PE203_PSL_LO
     PLC_PRG.FAULT_LOGIC (8)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (8)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (139)
                                           Local Read
     PLC_PRG.VALVES (20)
                                           Local Read
     PLC_PRG.VALVES (36)
                                           Local Read
     _global_init (236)
                                            Local Write
on ena
     PLC_PRG.PUMPS (7)
                                            Local Write
     RP_FB (2)
                                            Local Read
     RP_FB (4)
                                            Local Read
     RP_FBinit (1)
                                            Local Write
LLV211_OPN_REQ_SC
     PLC_PRG.SC_INPUTS (19)
                                           Local Write
     PLC_PRG.VALVES (49)
                                           Local Read
     _global_init (266)
                                           Local Write
LLV211_CLS_REQ_LL
     PLC_PRG.LL_SM (11)
                                           Local Write
     PLC_PRG.LL_SM (24)
                                           Local Write
     PLC_PRG.LL_SM (37)
                                           Local Write
     PLC_PRG.LL_SM (54)
                                           Local Write
     PLC_PRG.LL_SM (71)
                                           Local Write
     PLC_PRG.LL_SM (88)
                                           Local Write
     PLC_PRG.LL_SM (123)
                                           Local Write
     PLC_PRG.LL_SM (140)
                                           Local Write
     PLC_PRG.LL_SM (160)
                                           Local Write
     PLC_PRG.LL_SM (179)
                                           Local Write
     PLC_PRG.VALVES (50)
                                            Local Read
     _global_init (269)
                                            Local Write
LLV211
     PLC_PRG.PROCESS_OU... (18)
PLC_PRG.PROCESS_OU... (19)
                                          Local Read
Local Read
Local Read
     PLC_PRG.SC_OUTPUTS (89)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (90)
     PLC_PRG.SC_OUTPUTS (91)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (92)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (93)
                                          Local Read
     PLC_PRG.VALVES (45)
                                           Local Write
     PLC_PRG.VALVES (46)
                                           Local Write
     PLC_PRG.VALVES (47)
                                           Local Write
     PLC_PRG.VALVES (48)
                                           Local Write
     PLC_PRG.VALVES (49)
                                            Local Write
     PLC_PRG.VALVES (50)
                                            Local Write
     PLC_PRG.VALVES (51)
                                            Local Read
     _global_init (303)
                                            Local Read
DO_VENT212_SLOW_CMD%QX1.3
     PLC_PRG.PROCESS_IN... (64)
                                           Global Read
     PLC_PRG.PROCESS_OU... (24)
                                            Global Write
      _global_init (24)
                                            Global Write
DO_VENT212_FAST_CMD%QX1.4
                                          Global Read
     PLC_PRG.PROCESS_IN... (64)
     PLC_PRG.PROCESS_OU... (25)
                                            Global Write
     _global_init (25)
                                            Global Write
LLV211_CLS_REQ_SC
                                            Local Write
     PLC_PRG.SC_INPUTS (20)
     PLC_PRG.VALVES (50)
                                            Local Read
                                            Local Write
     _global_init (267)
DO_V203_OPEN_CMD%QX0.4
     PLC_PRG.PROCESS_IN... (42)
                                            Global Read
     PLC_PRG.PROCESS_IN... (43)
                                            Global Read
     PLC_PRG.PROCESS_OU... (7)
                                            Global Write
     _global_init (9)
                                            Global Write
LL_STATE
     PLC_PRG.LL_SM (5)
                                            Local Write
     PLC_PRG.LL_SM (10)
                                            Local Read
     PLC_PRG.LL_SM (20)
                                            Local Write
     PLC_PRG.LL_SM (23)
                                            Local Read
     PLC_PRG.LL_SM (33)
                                            Local Write
     PLC_PRG.LL_SM (36)
                                            Local Read
     PLC_PRG.LL_SM (46)
                                            Local Write
     PLC_PRG.LL_SM (48)
                                            Local Write
```

```
PLC_PRG.LL_SM (50)
                                             Local Write
     PLC_PRG.LL_SM (53)
                                            Local Read
     PLC_PRG.LL_SM (63)
                                            Local Write
     PLC_PRG.LL_SM (65)
                                            Local Write
     PLC_PRG.LL_SM (67)
                                            Local Write
     PLC_PRG.LL_SM (70)
                                            Local Read
     PLC_PRG.LL_SM (80)
                                            Local Write
     PLC_PRG.LL_SM (82)
                                            Local Write
     PLC_PRG.LL_SM (84)
                                            Local Write
     PLC_PRG.LL_SM (87)
                                            Local Read
     PLC_PRG.LL_SM (97)
                                            Local Write
     PLC_PRG.LL_SM (99)
                                            Local Write
     PLC_PRG.LL_SM (101)
                                            Local Write
     PLC_PRG.LL_SM (104)
                                            Local Read
     PLC_PRG.LL_SM (114)
                                           Local Write
                                            Local Write
     PLC_PRG.LL_SM (116)
     PLC_PRG.LL_SM (119)
                                            Local Write
     PLC_PRG.LL_SM (122)
                                            Local Read
     PLC_PRG.LL_SM (132)
                                            Local Write
     PLC_PRG.LL_SM (134)
                                            Local Write
     PLC_PRG.LL_SM (136)
                                            Local Write
     PLC_PRG.LL_SM (139)
                                            Local Read
     PLC_PRG.LL_SM (149)
                                            Local Write
     PLC_PRG.LL_SM (151)
                                            Local Write
     PLC_PRG.LL_SM (153)
                                            Local Write
     PLC_PRG.LL_SM (156)
                                            Local Write
     PLC_PRG.LL_SM (159)
                                            Local Read
     PLC_PRG.LL_SM (169)
                                            Local Write
     PLC_PRG.LL_SM (171)
                                            Local Write
     PLC_PRG.LL_SM (173)
                                            Local Write
     PLC_PRG.LL_SM (175)
                                            Local Write
     PLC_PRG.LL_SM (178)
                                            Local Read
     PLC_PRG.LL_SM (188)
                                            Local Write
     PLC_PRG.LL_SM (190)
                                            Local Write
     PLC_PRG.LL_SM (193)
                                            Local Write
     PLC_PRG.LL_SM (195)
                                            Local Write
     PLC_PRG.LL_SM (200)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (273)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (275)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (277)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (279)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (281)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (283)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (285)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (287)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (289)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (291)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (293)
                                            Local Read
     PLC_PRG.VALVES (45)
                                            Local Read
     _global_init (292)
                                            Local Write
DO_V201_OPEN_CMD%QX0.3
     PLC_PRG.PROCESS_IN... (36)
                                            Global Read
     PLC_PRG.PROCESS_IN... (37)
                                            Global Read
     PLC_PRG.PROCESS_OU... (6)
                                            Global Write
     _global_init (8)
                                            Global Write
DO_SPARE_32%QX1.15
     _global_init (36)
                                            Global Write
LL_REQUEST
     PLC_PRG.LL_SM (45)
                                            Local Read
     PLC_PRG.LL_SM (47)
                                            Local Read
     PLC_PRG.LL_SM (49)
                                            Local Read
     PLC_PRG.LL_SM (62)
                                            Local Read
     PLC_PRG.LL_SM (64)
                                            Local Read
     PLC_PRG.LL_SM (79)
                                            Local Read
     PLC_PRG.LL_SM (81)
                                            Local Read
     PLC_PRG.LL_SM (96)
                                            Local Read
     PLC_PRG.LL_SM (98)
                                            Local Read
     PLC_PRG.LL_SM (113)
                                            Local Read
     PLC_PRG.LL_SM (115)
                                            Local Read
     PLC_PRG.LL_SM (131)
                                            Local Read
     PLC_PRG.LL_SM (133)
                                            Local Read
     PLC_PRG.LL_SM (148)
                                            Local Read
     PLC_PRG.LL_SM (150)
                                             Local Read
```

```
PLC_PRG.LL_SM (168)
                                             Local Read
     PLC PRG.LL SM (170)
                                            Local Read
     PLC_PRG.LL_SM (187)
                                            Local Read
     PLC_PRG.LL_SM (189)
                                            Local Read
     PLC_PRG.SC_INPUTS (56)
                                            Local Write
     PLC_PRG.SC_INPUTS (58)
                                           Local Write
     PLC_PRG.SC_INPUTS (60)
                                           Local Write
     PLC_PRG.SC_INPUTS (62)
                                           Local Write
     PLC_PRG.SC_INPUTS (64)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (204)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (206)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (208)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (210)
                                           Local Read
                                            Local Write
     _global_init (293)
DO_TP211_ON_CMD%QX0.8
     PLC_PRG.PROCESS_IN... (62)
                                           Global Read
     PLC_PRG.PROCESS_OU... (12)
                                           Global Write
     _global_init (13)
                                            Global Write
DO_SPARE_32%QX1.15
     _global_init (36)
                                             Global Write
DO_SPARE_31%QX1.14
     _global_init (35)
                                             Global Write
DO_SPARE_31%QX1.14
     _global_init (35)
                                             Global Write
LLV211_CLS_REQ_ES
     PLC_PRG.ES_SM (11)
                                            Local Write
     PLC_PRG.ES_SM (25)
                                            Local Write
     PLC_PRG.ES_SM (39)
                                            Local Write
     PLC_PRG.ES_SM (57)
                                           Local Write
     PLC_PRG.ES_SM (75)
                                           Local Write
     PLC_PRG.ES_SM (93)
                                           Local Write
     PLC_PRG.ES_SM (111)
                                           Local Write
     PLC_PRG.ES_SM (130)
                                           Local Write
     PLC_PRG.ES_SM (148)
                                           Local Write
     PLC_PRG.ES_SM (169)
                                           Local Write
     PLC_PRG.ES_SM (189)
                                           Local Write
     PLC_PRG.LL_SM (105)
                                           Local Write
     PLC_PRG.VALVES (50)
                                            Local Read
     _global_init (268)
                                            Local Write
DO_VENT211_FAST_CMD%QX0.12
     PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (16)
                                           Global Read
                                            Global Write
     _global_init (17)
                                             Global Write
DO_SPARE_30%QX1.13
     _global_init (34)
                                             Global Write
LL_PE203_PIY_OK
                                           Local Read
     PLC_PRG.FAULT_LOGIC (13)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (13)
     PLC_PRG.FAULT_LOGIC (37)
                                            Local Read
     PLC_PRG.PUMPS (14)
                                             Local Read
     PLC_PRG.SC_OUTPUTS (138)
                                             Local Read
     _global_init (235)
                                             Local Write
DO_TP212_ON_CMD%QX1.0
     PLC_PRG.PROCESS_IN... (74)
PLC_PRG.PROCESS_OU... (21)
                                           Global Read
                                             Global Write
                                             Global Write
      _global_init (21)
DO_SPARE_29%QX1.12
                                             Global Write
     _global_init (33)
LL_V202_OPN
     PLC_PRG.FAULT_LOGIC (6)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (6)
                                             Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                             Local Read
     PLC_PRG.SC_OUTPUTS (136)
                                             Local Read
     PLC_PRG.VALVES (12)
                                             Local Read
     _global_init (233)
                                             Local Write
DO_TPV212_OPEN_CMD%QX1.1
     PLC_PRG.PROCESS_IN... (70)
PLC_PRG.PROCESS_IN... (71)
PLC_PRG.PROCESS_OU... (22)
                                           Global Read
                                            Global Read
                                            Global Write
     _global_init (22)
                                             Global Write
DO_SPARE_29%QX1.12
                                             Global Write
     _global_init (33)
DO_SPARE_28%QX1.11
```

```
_global_init (32)
                                                Global Write
LL_PE202_PSL_LO
      PLC_PRG.FAULT_LOGIC (7)
                                             Local Read
      PLC_PRG.FAULT_LOGIC (7)
                                              Local Write
      PLC_PRG.FAULT_LOGIC (37)
                                              Local Read
      PLC_PRG.SC_OUTPUTS (137)
                                              Local Read
      PLC_PRG.VALVES (12)
                                              Local Read
      PLC_PRG.VALVES (20)
                                              Local Read
      _global_init (234)
                                              Local Write
DO_SPARE_27%QX1.10
      _global_init (31)
                                              Global Write
LL_PE101_PSL_LO
      PLC_PRG.FAULT_LOGIC (4)
                                            Local Read
Local Write
      PLC_PRG.FAULT_LOGIC (4)
                                             Local Read
      PLC_PRG.FAULT_LOGIC (37)
      PLC_PRG.SC_OUTPUTS (134)
                                              Local Read
      PLC_PRG.VALVES (4)
                                              Local Read
      _global_init (231)
                                              Local Write
DO_VENT211_SLOW_CMD%QX0.11
      PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (15)
                                            Global Read
Global Write
      _global_init (16)
                                               Global Write
DO_SPARE_26%QX1.9
      _global_init (30)
                                              Global Write
LL_LL_CONFIG_OK
                                            Local Read
Local Write
      PLC_PRG.FAULT_LOGIC (11)
      PLC_PRG.FAULT_LOGIC (11)
      PLC_PRG.FAULT_LOGIC (37)
                                             Local Read
                                              Local Read
      PLC_PRG.LL_SM (4)
      PLC_PRG.SC_OUTPUTS (143)
                                              Local Read
      _global_init (239)
                                              Local Write
DO_V204_OPEN_CMD%QX0.5
     PLC_PRG.PROCESS_IN... (45)
PLC_PRG.PROCESS_IN... (46)
PLC_PRG.PROCESS_OU... (8)
                                            Global Read
Global Read
Global Write
                                               Global Write
      _global_init (10)
DO_SPARE_28%QX1.11
      _global_init (32)
                                               Global Write
DO_SPARE_27%QX1.10
      _global_init (31)
                                               Global Write
DO_V101_OPEN_CMD%QX0.2
     PLC_PRG.PROCESS_IN... (33)
PLC_PRG.PROCESS_IN... (34)
PLC_PRG.PROCESS_OU... (5)
                                             Global Read
                                              Global Read
                                               Global Write
                                               Global Write
      _global_init (7)
DO_SPARE_25%QX1.8
      _global_init (29)
                                               Global Write
DO_SPARE_24%QX1.7
     _global_init (28)
                                               Global Write
DO_TPV211_OPEN_CMD%QX0.9
     PLC_PRG.PROCESS_IN... (58)
PLC_PRG.PROCESS_IN... (59)
PLC_PRG.PROCESS_OU... (13)
                                             Global Read
                                               Global Read
                                               Global Write
      _global_init (14)
                                               Global Write
DO_SPARE_23%QX1.6
      _global_init (27)
                                               Global Write
DO_SPARE_22%QX1.5
      _global_init (26)
                                               Global Write
DO_TP201_VENT_ENABLE_CMD%QX0.7
     PLC_PRG.PROCESS_OU... (10)
                                             Global Write
      _global_init (12)
                                               Global Write
DO_SLOTV211_OPEN_CMD%QX0.14
     PLC_PRG.PROCESS_OU... (18)
                                              Global Write
      _global_init (19)
                                               Global Write
DO_SLOTV211_CLOSE_CMD%QX0.15
                                            Global Write
      PLC_PRG.PROCESS_OU... (19)
      _global_init (20)
                                               Global Write
DI_V204_OPEN%IX18.2
      PLC_PRG.PROCESS_IN... (45)
                                              Global Read
DI_V204_OPEN%IX18.2
      PLC_PRG.PROCESS_IN... (45)
                                              Global Read
DI_V204_CLOSED%IX18.3
     PLC_PRG.PROCESS_IN... (46)
                                               Global Read
```

DT 1/204 GLOGED® TV10 2	
DI_V204_CLOSED%IX18.3	
PLC_PRG.PROCESS_IN (46)	Global Read
DI_V203_OPEN%IX18.0	
PLC_PRG.PROCESS_IN (42)	Global Read
DI_V203_CLOSED%IX18.1	
PLC_PRG.PROCESS_IN (43)	Global Read
DI_V203_CLOSED%IX18.1	
PLC_PRG.PROCESS_IN (43)	Global Read
DI_V202_OPEN%IX17.14	
PLC_PRG.PROCESS_IN (39)	Global Read
	GIOSAI Neda
DO_SPARE_24%QX1.7	Clabal Waits
_global_init (28)	Global Write
DI_V202_CLOSED%IX17.15	
PLC_PRG.PROCESS_IN (40)	Global Read
DI_V202_CLOSED%IX17.15	
PLC_PRG.PROCESS_IN (40)	Global Read
DI_V201_OPEN%IX17.12	
PLC_PRG.PROCESS_IN (36)	Global Read
DI_V101_OPEN%IX17.10	
PLC_PRG.PROCESS_IN (33)	Global Read
	OTODAT 1/200
DI_V101_CLOSED%IX17.11	
PLC_PRG.PROCESS_IN (34)	Global Read
LL_ES_CONFIG_OK	
PLC_PRG.ES_SM (4)	Local Read
PLC_PRG.FAULT_LOGIC (10)	Local Read
PLC_PRG.FAULT_LOGIC (10)	Local Write
PLC_PRG.FAULT_LOGIC (37)	Local Read
PLC_PRG.SC_OUTPUTS (142)	Local Read
_global_init (238)	Local Write
DI_V100_CLOSED%IX17.9	
PLC_PRG.PROCESS_IN (31)	Global Read
DO_SPARE_23%QX1.6	
_global_init (27)	Global Write
DO_RPV212_OPEN_CMD%QX1.2	
PLC_PRG.PROCESS_IN (67)	Global Read
PLC_PRG.PROCESS_IN (68)	Global Read
PLC_PRG.PROCESS_OU (23)	Global Write
_global_init (23)	Global Write
DO_RP2111_ON_CMD%QX0.1	
PLC_PRG.PROCESS_OU (4)	Global Write
_global_init (6)	Global Write
DO_RP2110_ON_CMD%QX0.0	
PLC_PRG.PROCESS_OU (3)	Global Write
_global_init (5)	Global Write
DI_V202_OPEN%IX17.14	
PLC_PRG.PROCESS_IN (39)	Global Read
DI_V101_OPEN%IX17.10	
	Clobal Dood
PLC_PRG.PROCESS_IN (33)	Global Read
DI_V101_CLOSED%IX17.11	
PLC_PRG.PROCESS_IN (34)	Global Read
DI_TPV212_OPEN%IX18.12	
PLC_PRG.PROCESS_IN (70)	Global Read
DI_V201_OPEN%IX17.12	
PLC_PRG.PROCESS_IN (36)	Global Read
DI_TPV211_CLOSED%IX18.9	
PLC_PRG.PROCESS_IN (59)	Global Read
	Cloud Hour
DI_V201_CLOSED%IX17.13	Clobal Dood
PLC_PRG.PROCESS_IN (37)	Global Read
DI_V201_CLOSED%IX17.13	
PLC_PRG.PROCESS_IN (37)	Global Read
DI_V100_OPEN%IX17.8	
PLC_PRG.PROCESS_IN (30)	Global Read
DI_TP212_AT_SPEED%IX19.0	
PLC_PRG.PROCESS_IN (74)	Global Read
DI_V100_CLOSED%IX17.9	
PLC_PRG.PROCESS_IN (31)	Global Read
	OTONGT WORK
DI_TP211_TURBO_OK%IX18.15	
PLC_PRG.PROCESS_IN (61)	Global Read
DI_TPV212_CLOSED%IX18.13	
PLC PRG PROCESS IN (71)	Global Read

PLC_PRG.PROCESS_IN... (71) Global Read

Global Read

PLC_PRG.PROCESS_IN... (62)

DI_TP211_AT_SPEED%IX18.14

DI_TPV211_OPEN%IX18.8

PLC_PRG.PROCESS_IN	(58)	Global	Read
DI_TP201_TURBO_OK%IX18.4	(,		
PLC_PRG.PROCESS_IN	(48)	Global	Read
DI_TP212_TURBO_OK%IX19.1			
PLC_PRG.PROCESS_IN	(73)	Global	Read
DI_TPV212_OPEN%IX18.12	· - /		
PLC_PRG.PROCESS_IN	(70)	Global	Read
DI_TPV211_CLOSED%IX18.9	, ,		
PLC_PRG.PROCESS_IN	(59)	Global	Read
DI_TP212_TURBO_OK%IX19.1	()		
PLC_PRG.PROCESS_IN	(73)	Global	Read
DI_TP211_TURBO_OK%IX18.15	· - /		
PLC_PRG.PROCESS_IN	(61)	Global	Read
DI_TPV212_CLOSED%IX18.13	(- /		
PLC_PRG.PROCESS_IN	(71)	Global	Read
DI_TP211_AT_SPEED%IX18.14	, ,		
PLC_PRG.PROCESS_IN	(62)	Global	Read
DI_TP201_AT_SPEED%IX18.5			
PLC_PRG.PROCESS_IN	(50)	Global	Read
DI_SLOTV211_OPEN%IX19.2			
PLC_PRG.PROCESS_IN	(76)	Global	Read
DI_SLOTV211_CLOSED%IX19.3			
PLC_PRG.PROCESS_IN	(77)	Global	Read
DI_SLOTV211_CLOSED%IX19.3			
PLC_PRG.PROCESS_IN	(77)	Global	Read
DI_TP201_AT_SPEED%IX18.5			
PLC_PRG.PROCESS_IN	(50)	Global	Read
DI_RPV212_OPEN%IX18.10			
PLC_PRG.PROCESS_IN	(67)	Global	Read
DI_RPV212_OPEN%IX18.10			
PLC_PRG.PROCESS_IN	(67)	Global	Read
DI_RPV212_CLOSED%IX18.11			
PLC_PRG.PROCESS_IN	(68)	Global	Read
DI_RPV212_CLOSED%IX18.11			
PLC_PRG.PROCESS_IN	(68)	Global	Read
DI_RPV211_OPEN%IX18.6			
PLC_PRG.PROCESS_IN	(55)	Global	Read
DI_RPV211_OPEN%IX18.6			
PLC_PRG.PROCESS_IN	(55)	Global	Read
DI_RPV211_CLOSED%IX18.7			
PLC_PRG.PROCESS_IN	(56)	Global	Read
DI_RPV211_CLOSED%IX18.7			
PLC_PRG.PROCESS_IN	(56)	Global	Read
DI_RP2110_ON%IX16.4			
PLC_PRG.PROCESS_IN	(7)	Global	Read
PLC_PRG.SC_OUTPUTS (1)		Global	Read
DI_PE212_PSL_MIDLO%IX17.6			
PLC_PRG.PROCESS_IN	(27)	Global	Read
PLC_PRG.SC_OUTPUTS (3)		Global	
DI_PE212_PSL_MIDLO%IX17.6			
PLC_PRG.PROCESS_IN	(27)	Global	Read
PLC_PRG.SC_OUTPUTS (3)		Global	
DO_VENT212_SLOW_CMD%QX1.3			
PLC_PRG.PROCESS_IN	(64)	Global	Read
PLC_PRG.PROCESS_OU		Global	Write
_global_init (24)		Global	Write
DI_PE212_PSL_MIDHI%IX17.5			
PLC_PRG.PROCESS_IN	(26)	Global	Read
PLC_PRG.SC_OUTPUTS (3)		Global	Read
DI_PE212_PSL_LO%IX17.7			
PLC_PRG.PROCESS_IN	(28)	Global	Read
PLC_PRG.SC_OUTPUTS (32	2)	Global	Read
DI_PE212_PSL_HI%IX17.4			
PLC_PRG.PROCESS_IN	(25)	Global	Read
PLC_PRG.SC_OUTPUTS (29	9)	Global	Read
DI_PE212_PSL_LO%IX17.7			
PLC_PRG.PROCESS_IN	(28)	Global	Read
PLC_PRG.SC_OUTPUTS (32	2)	Global	Read
DI_PE212_PIY_OK%IX16.10			
PLC_PRG.PROCESS_IN	(24)	Global	Read
PLC_PRG.PROCESS_IN	(25)	Global	Read
PLC_PRG.PROCESS_IN	(26)	Global	Read
PLC_PRG.SC_OUTPUTS (28	3)	Global	Read

DI_PE211_PSL_MIDLO%IX17.2	
PLC_PRG.PROCESS_IN (21)	Global Read
PLC_PRG.SC_OUTPUTS (25)	Global Read
DI_PE211_PSL_MIDLO%IX17.2	
PLC_PRG.PROCESS_IN (21)	Global Read
PLC PRG.SC OUTPUTS (25)	Global Read
	GIODAI NEAG
DI_PE212_PIY_OK%IX16.10	
PLC_PRG.PROCESS_IN (24)	Global Read
PLC_PRG.PROCESS_IN (25)	Global Read
PLC_PRG.PROCESS_IN (26)	Global Read
PLC_PRG.SC_OUTPUTS (28)	Global Read
DI_PE211_PSL_MIDHI%IX17.1	
PLC PRG.PROCESS IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (24)	Global Read
	GIODAI REAU
DI_PE211_PSL_MIDHI%IX17.1	
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (24)	Global Read
DI_PE211_PSL_LO%IX17.3	
PLC_PRG.PROCESS_IN (22)	Global Read
PLC PRG.SC OUTPUTS (26)	Global Read
	GIODAI KEAU
DI_PE211_PSL_LO%IX17.3	
PLC_PRG.PROCESS_IN (22)	Global Read
PLC_PRG.SC_OUTPUTS (26)	Global Read
DO_SPARE_22%QX1.5	
global_init (26)	Global Write
DI_PE211_PIY_OK%IX16.9	
	Clabal D
PLC_PRG.PROCESS_IN (18)	Global Read
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (22)	Global Read
DI_PE211_PIY_OK%IX16.9	
PLC_PRG.PROCESS_IN (18)	Global Read
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.PROCESS_IN (20)	Global Read
PLC_PRG.SC_OUTPUTS (22)	Global Read
DI_PE2111_PSL%IX16.7	
PLC_PRG.PROCESS_IN (10)	Global Read
PLC PRG.SC OUTPUTS (14)	Global Read
DI_PE203_PSL_MIDLO%IX16.14	GIODAI REAG
PLC_PRG.PROCESS_IN (15)	Global Read
PLC_PRG.SC_OUTPUTS (19)	Global Read
DI_PE203_PSL_MIDLO%IX16.14	
PLC_PRG.PROCESS_IN (15)	Global Read
PLC PRG.SC OUTPUTS (19)	Global Read
DI_RP2111_ON%IX16.5	
	Clobal Boad
PLC_PRG.PROCESS_IN (8)	Global Read
PLC_PRG.SC_OUTPUTS (12)	Global Read
DI_PE203_PSL_MIDHI%IX16.13	
PLC_PRG.PROCESS_IN (14)	Global Read
PLC_PRG.SC_OUTPUTS (18)	Global Read
DI_PE203_PSL_LO%IX16.15	
PLC_PRG.PROCESS_IN (16)	Global Read
PLC_PRG.SC_OUTPUTS (20)	Global Read
DI_PE2110_PSL%IX16.6	
PLC_PRG.PROCESS_IN (9)	Global Read
PLC_PRG.SC_OUTPUTS (13)	Global Read
DI_PE203_PSL_HI%IX16.12	
PLC_PRG.PROCESS_IN (13)	Global Read
PLC_PRG.SC_OUTPUTS (17)	Global Read
	GIONAI NEAU
DO_TPV212_OPEN_CMD%QX1.1	
PLC_PRG.PROCESS_IN (70)	Global Read
PLC_PRG.PROCESS_IN (71)	Global Read
PLC_PRG.PROCESS_OU (22)	Global Write
global_init (22)	Global Write
DI_PE202_PSL_LO%IX16.2	
	Clobal Boad
PLC_PRG.PROCESS_IN (5)	Global Read
DO_RPV212_OPEN_CMD%QX1.2	
PLC_PRG.PROCESS_IN (67)	Global Read
PLC_PRG.PROCESS_IN (68)	Global Read
PLC_PRG.PROCESS_OU (23)	Global Write
_global_init (23)	Global Write
DI_PE201_PSL_LO%IX16.1	
	Clobal Band
PLC_PRG.PROCESS_IN (4)	Global Read

```
DI_LL211_ARM_RETRACTED%IX19.5
                                        Global Read
     PLC_PRG.PROCESS_IN... (80)
     PLC_PRG.SC_OUTPUTS (35)
                                           Global Read
on cmd
     PLC_PRG.PROCESS_OU... (9)
                                          Local Read
     PLC_PRG.PROCESS_OU... (12)
                                          Local Read
     PLC_PRG.PROCESS_OU... (21)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (117)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (120)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (125)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (129)
                                         Local Read
     PLC_PRG.VALVES (29)
                                          Local Read
     PLC_PRG.VALVES (78)
                                          Local Read
     PLC_PRG.VALVES (110)
                                          Local Read
     TP_FB (3)
                                          Local Read
     TP_FB (3)
                                           Local Write
     TP_FB (6)
                                           Local Read
     TP_FBinit (6)
                                           Local Write
cactuator_target
     PLC_PRG.ACTUATOR_I... (7)
                                         Local Read
     PLC_PRG.ACTUATOR_O... (4)
                                          Local Read
                                           Local Write
     _global_init (8)
     _global_init (9)
                                           Local Write
     _global_init (10)
                                           Local Write
     _global_init (11)
                                           Local Write
on_cmd
     PLC_PRG.PROCESS_OU... (3)
                                         Local Read
                                          Local Read
     PLC_PRG.SC_OUTPUTS (107)
                                           Local Read
     RP_FB (2)
     RP_FB (2)
                                           Local Write
     RP_FB (4)
                                           Local Read
     RP_FBinit (5)
                                           Local Write
bID
                                         Local Read
     ACTUATOR_SM.CONNECT (25)
     ACTUATOR_SM.DRG1_W... (26)
                                         Local Read
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Read
     ACTUATOR_SM.STATUS... (26)
                                           Local Read
     _global_init (3)
                                           Local Write
oMBMaster
     ACTUATOR_SM (16)
                                         Local Read
     ACTUATOR_SM.CONNECT (25)
                                         Local Write
     ACTUATOR_SM.CONNECT (28)
                                         Local Read
                                         Local Write
     ACTUATOR_SM.DRG1_W... (26)
                                         Local Read
     ACTUATOR_SM.DRG1_W... (29)
     ACTUATOR_SM.PCMD_W... (27)
                                          Local Write
     ACTUATOR_SM.PCMD_W... (30)
                                           Local Read
     ACTUATOR_SM.STATUS... (26)
                                           Local Write
     ACTUATOR_SM.STATUS... (29)
                                           Local Read
     ACTUATORinit (6)
                                           Local Read
off_req
     PLC_PRG.PUMPS (18)
                                           Local Write
     PLC_PRG.PUMPS (26)
                                           Local Write
     PLC_PRG.PUMPS (34)
                                           Local Write
     TP_FB (3)
                                           Local Read
     TP_FBinit (5)
                                           Local Write
LL_TP212_OK
     PLC_PRG.FAULT_LOGIC (21)
                                           Local Read
                                           Local Write
     PLC_PRG.FAULT_LOGIC (21)
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (149)
                                           Local Read
     _global_init (244)
                                           Local Write
off_req
     PLC_PRG.PUMPS (10)
                                           Local Write
     RP_FB (2)
                                           Local Read
     RP_FBinit (4)
                                           Local Write
LL_TP211_OK
     PLC_PRG.FAULT_LOGIC (20)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (20)
                                           Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (148)
                                           Local Read
     _global_init (243)
                                           Local Write
off_ena
     PLC_PRG.PUMPS (16)
                                           Local Write
```

```
PLC_PRG.PUMPS (24)
                                           Local Write
     PLC PRG.PUMPS (32)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (119)
                                          Local Read
     TP_FB (3)
                                          Local Read
     TP_FB (6)
                                           Local Read
     TP_FBinit (3)
                                           Local Write
MAX_SOCKET_FD_SETSIZE
     _global_init (164)
                                          Global Write
LL_PE201_PSL_LO
     PLC_PRG.FAULT_LOGIC (5)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (5)
                                          Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (135)
                                          Local Read
     PLC_PRG.VALVES (4)
                                          Local Read
     PLC_PRG.VALVES (12)
                                          Local Read
     _global_init (232)
                                          Local Write
not_symbol
     PLC_PRG.SC_OUTPUTS (46)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (54)
                                          Local Read
     PLC_PRG.SC_OUTPUTS (66)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (74)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (113)
                                          Local Read
     VALVE_FB (6)
                                          Local Write
     VALVE_FBinit (7)
                                           Local Write
LL_CONFIG_OK
     PLC_PRG.BYPASSES (5)
                                          Local Write
     PLC_PRG.FAULT_LOGIC (11)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     _global_init (229)
                                           Local Write
LL_ACTUATOR_OK
     PLC_PRG.BR_SM (4)
                                           Local Read
     PLC_PRG.BR_SM (13)
                                          Local Read
                                         Local Read
     PLC_PRG.FAULT_LOGIC (3)
     PLC_PRG.FAULT_LOGIC (3)
                                         Local Write
     PLC_PRG.FAULT_LOGIC (37)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (133)
                                         Local Read
     _global_init (230)
                                           Local Write
LL211_ARM_RETRACTED
     PLC_PRG.PROCESS_IN... (80)
                                          Local Write
     PLC_PRG.VALVES (47)
                                           Local Read
     PLC_PRG.VALVES (48)
                                           Local Read
     _global_init (227)
                                           Local Write
ES_STATE
     PLC_PRG.ES_SM (5)
                                           Local Write
     PLC_PRG.ES_SM (9)
                                           Local Read
     PLC_PRG.ES_SM (20)
                                           Local Write
     PLC_PRG.ES_SM (23)
                                           Local Read
     PLC_PRG.ES_SM (34)
                                           Local Write
     PLC_PRG.ES_SM (37)
                                           Local Read
     PLC_PRG.ES_SM (48)
                                           Local Write
     PLC_PRG.ES_SM (50)
                                           Local Write
     PLC_PRG.ES_SM (52)
                                           Local Write
     PLC_PRG.ES_SM (55)
                                           Local Read
     PLC_PRG.ES_SM (66)
                                           Local Write
     PLC_PRG.ES_SM (68)
                                           Local Write
     PLC_PRG.ES_SM (70)
                                           Local Write
     PLC_PRG.ES_SM (73)
                                           Local Read
     PLC_PRG.ES_SM (84)
                                           Local Write
     PLC_PRG.ES_SM (86)
                                           Local Write
     PLC_PRG.ES_SM (88)
                                           Local Write
     PLC_PRG.ES_SM (91)
                                           Local Read
     PLC_PRG.ES_SM (102)
                                           Local Write
     PLC_PRG.ES_SM (104)
                                           Local Write
     PLC_PRG.ES_SM (106)
                                           Local Write
     PLC_PRG.ES_SM (109)
                                           Local Read
     PLC_PRG.ES_SM (120)
                                           Local Write
     PLC_PRG.ES_SM (122)
                                           Local Write
     PLC_PRG.ES_SM (125)
                                           Local Write
     PLC_PRG.ES_SM (128)
                                           Local Read
     PLC_PRG.ES_SM (139)
                                           Local Write
     PLC_PRG.ES_SM (141)
                                           Local Write
     PLC_PRG.ES_SM (143)
                                           Local Write
     PLC_PRG.ES_SM (146)
                                           Local Read
```

```
PLC_PRG.ES_SM (157)
                                            Local Write
     PLC_PRG.ES_SM (159)
                                            Local Write
     PLC_PRG.ES_SM (161)
                                           Local Write
     PLC_PRG.ES_SM (164)
                                           Local Write
     PLC_PRG.ES_SM (167)
                                           Local Read
     PLC_PRG.ES_SM (178)
                                           Local Write
     PLC_PRG.ES_SM (180)
                                           Local Write
     PLC_PRG.ES_SM (182)
                                           Local Write
     PLC_PRG.ES_SM (184)
                                           Local Write
     PLC_PRG.ES_SM (187)
                                           Local Read
     PLC_PRG.ES_SM (198)
                                           Local Write
     PLC_PRG.ES_SM (200)
                                           Local Write
     PLC_PRG.ES_SM (203)
                                           Local Write
     PLC_PRG.ES_SM (205)
                                           Local Write
     PLC_PRG.ES_SM (210)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (244)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (246)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (248)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (250)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (252)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (254)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (256)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (258)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (260)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (262)
PLC_PRG.SC_OUTPUTS (264)
                                           Local Read
                                           Local Read
     PLC_PRG.VALVES (37)
                                           Local Read
     PLC_PRG.VALVES (45)
                                            Local Read
     _global_init (290)
                                            Local Write
DO_VENT211_SLOW_CMD%QX0.11
     PLC_PRG.PROCESS_IN... (52)
PLC_PRG.PROCESS_OU... (15)
                                          Global Read
Global Write
     _global_init (16)
                                            Global Write
DO_VENT211_FAST_CMD%QX0.12
                                          Global Read
Global Write
     PLC_PRG.PROCESS_IN... (52)
     PLC_PRG.PROCESS_OU... (16)
     _global_init (17)
                                            Global Write
ES_REQUEST
     PLC_PRG.ES_SM (47)
                                            Local Read
     PLC_PRG.ES_SM (49)
                                            Local Read
     PLC_PRG.ES_SM (51)
                                            Local Read
     PLC_PRG.ES_SM (65)
                                            Local Read
     PLC_PRG.ES_SM (67)
                                            Local Read
     PLC_PRG.ES_SM (83)
                                            Local Read
     PLC_PRG.ES_SM (85)
                                            Local Read
     PLC_PRG.ES_SM (101)
                                            Local Read
     PLC_PRG.ES_SM (103)
                                            Local Read
     PLC_PRG.ES_SM (119)
                                            Local Read
     PLC_PRG.ES_SM (121)
                                            Local Read
     PLC_PRG.ES_SM (138)
                                            Local Read
     PLC_PRG.ES_SM (140)
                                            Local Read
     PLC_PRG.ES_SM (156)
                                            Local Read
     PLC_PRG.ES_SM (158)
                                            Local Read
     PLC_PRG.ES_SM (177)
                                            Local Read
     PLC_PRG.ES_SM (179)
                                            Local Read
     PLC_PRG.ES_SM (197)
                                            Local Read
     PLC_PRG.ES_SM (199)
                                            Local Read
     PLC_PRG.SC_INPUTS (41)
                                            Local Write
     PLC_PRG.SC_INPUTS (43)
                                            Local Write
     PLC_PRG.SC_INPUTS (45)
                                            Local Write
     PLC_PRG.SC_INPUTS (47)
                                            Local Write
     PLC_PRG.SC_INPUTS (49)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (189)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (191)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (193)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (195)
                                            Local Read
      _global_init (291)
                                            Local Write
DO_VENT212_FAST_CMD%QX1.4
     PLC_PRG.PROCESS_IN... (64)
                                           Global Read
     PLC_PRG.PROCESS_OU... (25)
                                            Global Write
     _global_init (25)
                                            Global Write
DO_V204_OPEN_CMD%QX0.5
     PLC_PRG.PROCESS_IN... (45)
                                            Global Read
```

DIC DDC DDCCECC IN (A6)	Global Read
PLC_PRG.PROCESS_IN (46)	
PLC_PRG.PROCESS_OU (8)	Global Write
_global_init (10)	Global Write
DO_TPV211_OPEN_CMD%QX0.9	
PLC_PRG.PROCESS_IN (58)	Global Read
PLC PRG.PROCESS IN (59)	Global Read
PLC_PRG.PROCESS_OU (13)	Global Write
_global_init (14)	Global Write
ES_CONFIG_OK	
PLC_PRG.BYPASSES (4)	Local Write
PLC_PRG.FAULT_LOGIC (10)	Local Read
PLC_PRG.FAULT_LOGIC (37)	Local Read
_global_init (228)	Local Write
	nocai wiice
DO_TP201_VENT_ENABLE_CMD%QX0.7	
PLC_PRG.PROCESS_OU (10)	Global Write
_global_init (12)	Global Write
DO_V203_OPEN_CMD%QX0.4	
PLC_PRG.PROCESS_IN (42)	Global Read
PLC_PRG.PROCESS_IN (43)	Global Read
PLC_PRG.PROCESS_OU (7)	Global Write
_global_init (9)	Global Write
DO_SPARE_14%QX0.13	
global init (18)	Global Write
	CICAGI WIICG
DO_SLOTV211_OPEN_CMD%QX0.14	
PLC_PRG.PROCESS_OU (18)	Global Write
_global_init (19)	Global Write
	CICAGI WIICG
DO_SLOTV211_CLOSE_CMD%QX0.15	
PLC_PRG.PROCESS_OU (19)	Global Write
_global_init (20)	Global Write
	010201100
DO_TP201_ON_CMD%QX0.6	
PLC_PRG.PROCESS_IN (49)	Global Read
PLC_PRG.PROCESS_OU (9)	Global Write
global_init (11)	Global Write
	GIODAI WIICE
DO_TP201_ON_CMD%QX0.6	
PLC_PRG.PROCESS_IN (49)	Global Read
PLC_PRG.PROCESS_OU (9)	Global Write
_global_init (11)	Global Write
DI_TP201_TURBO_OK%IX18.4	
PLC PRG.PROCESS IN (48)	Global Read
DI_SLOTV211_OPEN%IX19.2	
PLC_PRG.PROCESS_IN (76)	Global Read
DI_RP2111_ON%IX16.5	
PLC_PRG.PROCESS_IN (8)	Global Read
PLC_PRG.SC_OUTPUTS (12)	Global Read
DI_PE211_PSL_HI%IX17.0	
PLC_PRG.PROCESS_IN (19)	Global Read
PLC_PRG.SC_OUTPUTS (23)	Global Read
	GIODAI Read
DI_PE203_PSL_LO%IX16.15	
PLC_PRG.PROCESS_IN (16)	Global Read
PLC_PRG.SC_OUTPUTS (20)	Global Read
	SISDAI NEAU
DO_RPV211_OPEN_CMD%QX0.10	
PLC_PRG.PROCESS_IN (55)	Global Read
PLC_PRG.PROCESS_IN (56)	Global Read
PLC PRG.PROCESS OU (14)	Global Write
_global_init (15)	Global Write
DI_PE203_PSL_HI%IX16.12	
PLC_PRG.PROCESS_IN (13)	Global Read
PLC_PRG.SC_OUTPUTS (17)	Global Read
DI_RP2110_ON%IX16.4	
PLC_PRG.PROCESS_IN (7)	Global Read
PLC_PRG.SC_OUTPUTS (11)	Global Read
	GIUDAI KEAU
DI_PE212_PSL_MIDHI%IX17.5	
PLC_PRG.PROCESS_IN (26)	Global Read
PLC_PRG.SC_OUTPUTS (30)	Global Read
	SISDAI NEAU
DI_PE203_PIY_OK%IX16.8	
PLC_PRG.PROCESS_IN (12)	Global Read
PLC_PRG.PROCESS_IN (12)	
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13)	Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14)	Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13)	Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16)	Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16) DI_PE212_PSL_HI%IX17.4	Global Read Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16) DI_PE212_PSL_HI%IX17.4 PLC_PRG.PROCESS_IN (25)	Global Read Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16) DI_PE212_PSL_HI%IX17.4	Global Read Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16) DI_PE212_PSL_HI%IX17.4 PLC_PRG.PROCESS_IN (25) PLC_PRG.SC_OUTPUTS (29)	Global Read Global Read Global Read
PLC_PRG.PROCESS_IN (12) PLC_PRG.PROCESS_IN (13) PLC_PRG.PROCESS_IN (14) PLC_PRG.SC_OUTPUTS (16) DI_PE212_PSL_HI%IX17.4 PLC_PRG.PROCESS_IN (25)	Global Read Global Read Global Read

```
PLC_PRG.PROCESS_IN... (79)
                                             Global Read
     PLC_PRG.SC_OUTPUTS (34)
                                            Global Read
off_ena
     PLC_PRG.PUMPS (8)
                                            Local Write
     RP_FB (2)
                                            Local Read
     RP_FB (4)
                                            Local Read
     RP_FBinit (2)
                                            Local Write
close rea
     PLC_PRG.VALVES (8)
                                            Local Write
     PLC_PRG.VALVES (16)
                                            Local Write
     PLC_PRG.VALVES (24)
                                            Local Write
     PLC_PRG.VALVES (32)
                                           Local Write
     PLC_PRG.VALVES (40)
                                           Local Write
     PLC_PRG.VALVES (58)
                                           Local Write
     PLC_PRG.VALVES (66)
                                           Local Write
     PLC_PRG.VALVES (74)
                                            Local Write
     PLC_PRG.VALVES (82)
                                            Local Write
     PLC_PRG.VALVES (90)
                                            Local Write
     PLC_PRG.VALVES (98)
                                            Local Write
     PLC_PRG.VALVES (106)
                                            Local Write
     PLC_PRG.VALVES (114)
                                            Local Write
     VALVE_FB (3)
                                            Local Read
     VALVE_FBinit (5)
                                            Local Write
oActuator
     ACTUATOR_SM (3)
                                            Local Read
     ACTUATOR_SM (5)
                                            Local Write
     ACTUATOR_SM (7)
                                            Local Write
     ACTUATOR_SM (9)
                                            Local Read
     ACTUATOR_SM (10)
                                            Local Write
     ACTUATOR_SM (12)
                                            Local Write
     ACTUATOR_SM (14)
                                            Local Read
     ACTUATOR_SM (16)
                                            Local Read
     ACTUATOR_SM (17)
                                            Local Write
     ACTUATOR_SM (18)
                                            Local Write
     ACTUATOR_SM (21)
                                            Local Read
     ACTUATOR_SM (23)
                                            Local Read
     ACTUATOR_SM (25)
                                            Local Read
     ACTUATOR_SM (27)
                                            Local Write
     ACTUATOR_SM (29)
                                            Local Read
     ACTUATOR_SM (31)
                                            Local Write
     ACTUATOR_SM (33)
                                            Local Read
     ACTUATOR_SM (35)
                                            Local Write
     ACTUATOR_SM (37)
                                            Local Read
     ACTUATOR_SM (39)
                                            Local Write
     ACTUATOR_SM (42)
                                            Local Write
     ACTUATOR_SM (46)
                                            Local Read
     ACTUATOR_SM (48)
                                            Local Write
     ACTUATOR_SM (50)
                                            Local Read
     ACTUATOR_SM (52)
                                            Local Write
     ACTUATOR_SM (55)
                                            Local Read
     ACTUATOR_SM (57)
                                            Local Write
     ACTUATOR_SM (59)
                                            Local Read
     ACTUATOR_SM (61)
                                            Local Write
     ACTUATOR_SM (64)
                                            Local Read
     ACTUATOR_SM (65)
                                            Local Write
     ACTUATOR_SM (67)
                                            Local Read
     ACTUATOR_SM (69)
                                            Local Write
     ACTUATOR_SM (72)
                                            Local Read
     ACTUATOR_SM (74)
                                            Local Write
     ACTUATOR_SM (76)
                                            Local Read
     ACTUATOR_SM (78)
                                            Local Write
     ACTUATOR_SM (81)
                                            Local Read
     ACTUATOR_SM (83)
                                            Local Write
     ACTUATOR_SM (85)
                                            Local Read
     ACTUATOR_SM (87)
                                            Local Write
     ACTUATOR_SM (90)
                                            Local Read
     ACTUATOR_SM (92)
                                            Local Read
     ACTUATOR_SM (94)
                                            Local Read
     ACTUATOR_SM (96)
                                            Local Write
     ACTUATOR_SM (99)
                                            Local Write
     ACTUATOR_SM (103)
                                            Local Read
     ACTUATOR_SM (105)
                                            Local Read
     ACTUATOR_SM (111)
                                            Local Write
```

ACTUATOR_SM (116)	Local Write
ACTUATOR_SM (120)	Local Read
ACTUATOR_SM (122)	Local Read
ACTUATOR_SM (125)	Local Write
ACTUATOR_SM (128)	Local Read
ACTUATOR_SM (130)	Local Read
ACTUATOR_SM (132)	Local Read
ACTUATOR_SM (136)	Local Write
ACTUATOR SM (140)	Local Write
= , ,	
ACTUATOR_SM (145)	Local Write
ACTUATOR_SM (146)	Local Write
ACTUATOR_SM.CONNECT (6)	Local Read
ACTUATOR_SM.CONNECT (6)	Local Write
ACTUATOR_SM.CONNECT (9)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR_SM.CONNECT (25)	Local Read
ACTUATOR_SM.CONNECT (25)	Local Write
ACTUATOR SM.CONNECT (28)	Local Read
ACTUATOR SM.CONNECT (31)	Local Write
ACTUATOR_SM.CONNECT (32)	Local Write
ACTUATOR_SM.DRG1_W (5)	Local Read
ACTUATOR_SM.DRG1_W (6)	Local Write
ACTUATOR_SM.DRG1_W (7)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (26)	Local Read
ACTUATOR_SM.DRG1_W (26)	Local Write
ACTUATOR_SM.DRG1_W (29)	Local Read
ACTUATOR_SM.DRG1_W (32)	Local Write
ACTUATOR_SM.DRG1_W (33)	Local Write
ACTUATOR_SM.DRG1_W (34)	Local Write
ACTUATOR_SM.DRG1_W (35)	Local Write
ACTUATOR_SM.DRG1_W (36) ACTUATOR SM.DRG1 W (37)	Local Read
,	Local Write
ACTUATOR_SM.DRG1_W (38)	Local Write
ACTUATOR_SM.DRG1_W (40)	Local Write
ACTUATOR_SM.PCMD_W (5) ACTUATOR SM.PCMD W (6)	Local Read
	Local Write Local Write
ACTUATOR_SM.PCMD_W (7)	
ACTUATOR_SM.PCMD_W (8)	Local Write
ACTUATOR_SM.PCMD_W (27)	Local Write
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Write
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Write
ACTUATOR_SM.PCMD_W (27)	Local Read
ACTUATOR_SM.PCMD_W (27)	Local Write
ACTUATOR_SM.PCMD_W (30)	Local Read
ACTUATOR_SM.PCMD_W (33)	Local Write
ACTUATOR_SM.PCMD_W (34)	Local Write
ACTUATOR_SM.PCMD_W (35)	Local Write
ACTUATOR_SM.PCMD_W (36)	Local Write
ACTUATOR_SM.PCMD_W (37)	Local Read
ACTUATOR_SM.PCMD_W (38)	Local Write
ACTUATOR_SM.PCMD_W (39)	Local Write
ACTUATOR_SM.PCMD_W (41)	Local Write
ACTUATOR_SM.STATUS (5)	Local Read
ACTUATOR_SM.STATUS (6)	Local Write
ACTUATOR_SM.STATUS (7)	Local Write
ACTUATOR_SM.STATUS (26)	Local Write
ACTUATOR_SM.STATUS (26)	Local Read
ACTUATOR_SM.STATUS (26)	Local Write
ACTUATOR_SM.STATUS (26)	Local Read
ACTUATOR_SM.STATUS (26)	Local Write
ACTUATOR_SM.STATUS (26)	Local Read
ACTUATOR_SM.STATUS (26)	Local Write

```
ACTUATOR_SM.STATUS... (29)
                                           Local Read
     ACTUATOR_SM.STATUS... (32)
                                           Local Write
     ACTUATOR_SM.STATUS... (33)
                                           Local Write
     ACTUATOR_SM.STATUS... (34)
                                           Local Write
     ACTUATOR_SM.STATUS... (35)
                                           Local Write
     ACTUATOR_SM.STATUS... (36)
                                           Local Read
     ACTUATOR_SM.STATUS... (37)
                                           Local Read
     ACTUATOR_SM.STATUS... (38)
                                           Local Read
     ACTUATOR_SM.STATUS... (39)
                                           Local Read
     ACTUATOR_SM.STATUS... (40)
                                           Local Write
     ACTUATOR_SM.STATUS... (41)
                                           Local Write
     ACTUATOR_SM.STATUS... (43)
                                           Local Write
     _global_init (6)
                                           Local Read
LLV211_CSD
                                           Local Read
     PLC_PRG.ES_SM (33)
     PLC_PRG.LL_SM (32)
                                           Local Read
     PLC_PRG.PROCESS_IN... (77)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (88)
                                           Local Read
     PLC_PRG.VALVES (37)
                                           Local Read
     PLC_PRG.VALVES (47)
                                           Local Read
     PLC_PRG.VALVES (54)
                                           Local Read
     PLC_PRG.VALVES (62)
                                           Local Read
     PLC_PRG.VALVES (70)
                                           Local Read
     PLC_PRG.VALVES (80)
                                           Local Read
     PLC_PRG.VALVES (86)
                                           Local Read
     PLC_PRG.VALVES (94)
                                           Local Read
     PLC_PRG.VALVES (102)
                                           Local Read
     PLC_PRG.VALVES (112)
                                           Local Read
                                           Local Write
     _global_init (210)
DO_V201_OPEN_CMD%QX0.3
     PLC_PRG.PROCESS_IN... (36)
PLC_PRG.PROCESS_IN... (37)
PLC_PRG.PROCESS_OU... (6)
                                          Global Read
Global Read
Global Write
                                            Global Write
     _global_init (8)
LL_BP211_ON
                                          Local Read
Local Write
     PLC_PRG.FAULT_LOGIC (17)
     PLC_PRG.FAULT_LOGIC (17)
                                          Local Read
     PLC_PRG.FAULT_LOGIC (37)
     PLC_PRG.PUMPS (22)
                                          Local Read
     PLC_PRG.PUMPS (30)
                                           Local Read
     PLC_PRG.SC_OUTPUTS (146)
                                           Local Read
     PLC_PRG.VALVES (78)
                                           Local Read
                                            Local Read
     PLC_PRG.VALVES (110)
     _global_init (242)
                                            Local Write
DO_V101_OPEN_CMD%QX0.2
     PLC_PRG.PROCESS_IN... (33)
PLC_PRG.PROCESS_IN... (34)
                                          Global Read
                                           Global Read
     PLC_PRG.PROCESS_OU... (5)
                                            Global Write
     _global_init (7)
                                            Global Write
DI_TPV211_OPEN%IX18.8
     PLC_PRG.PROCESS_IN... (58)
                                            Global Read
DI_PE2111_PSL%IX16.7
     PLC_PRG.PROCESS_IN... (10)
                                            Global Read
     PLC_PRG.SC_OUTPUTS (14)
                                            Global Read
DI_PE2110_PSL%IX16.6
     PLC_PRG.PROCESS_IN... (9)
                                           Global Read
     PLC_PRG.SC_OUTPUTS (13)
                                            Global Read
not_symbol
     PLC_PRG.SC_OUTPUTS (93)
                                            Local Read
     VALVE_BI_FB (11)
                                            Local Write
     VALVE_BI_FBinit (9)
                                            Local Write
cYAG
     PLC_PRG.BR_SM (125)
                                            Local Read
     PLC_PRG.BR_SM (143)
                                            Local Read
     _global_init (6)
                                            Local Write
not_symbol
     PLC_PRG.SC_OUTPUTS (121)
                                            Local Read
     TP_FB (6)
                                            Local Write
                                            Local Write
     TP_FBinit (7)
DO_TP211_ON_CMD%QX0.8
     PLC_PRG.PROCESS_IN... (62)
                                           Global Read
     PLC_PRG.PROCESS_OU... (12)
                                            Global Write
                                            Global Write
     _global_init (13)
```

```
LL211_LID_CLOSED
                                           Local Write
     PLC_PRG.PROCESS_IN... (79)
                                             Local Write
      _global_init (226)
DO_SPARE_30%QX1.13
                                            Global Write
     _global_init (34)
DO_RP2111_ON_CMD%QX0.1
                                           Global Write
     PLC_PRG.PROCESS_OU... (4)
     _global_init (6)
                                            Global Write
LLV211_OPN
                                           Local Write
     PLC_PRG.PROCESS_IN... (76)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (87)
                                             Local Write
     _global_init (209)
DO_SPARE_26%QX1.9
                                            Global Write
     _global_init (30)
DO_RP2110_ON_CMD%QX0.0
     PLC_PRG.PROCESS_OU... (3)
                                            Global Write
                                             Global Write
     _global_init (5)
LL_PE211_PIY_OK
     PLC_PRG.ES_SM (4)
                                            Local Read
     PLC_PRG.ES_SM (19)
                                            Local Read
     PLC_PRG.FAULT_LOGIC (14)
                                            Local Read
                                           Local Read
Local Read
Local Read
     PLC_PRG.FAULT_LOGIC (14)
     PLC_PRG.FAULT_LOGIC (37)
     PLC_PRG.SC_OUTPUTS (144)
     PLC_PRG.VALVES (78)
                                            Local Read
     _global_init (240)
                                            Local Write
DO_SPARE_25%QX1.8
     _global_init (29)
                                             Global Write
DO_SPARE_14%QX0.13
     _global_init (18)
                                            Global Write
DI_PE203_PIY_OK%IX16.8
     PLC_PRG.PROCESS_IN... (12)
PLC_PRG.PROCESS_IN... (13)
PLC_PRG.PROCESS_IN... (14)
                                           Global Read
Global Read
                                           Global Read
     PLC_PRG.SC_OUTPUTS (16)
                                            Global Read
DO_TP212_ON_CMD%QX1.0
                                         Global Read
Global Write
     PLC_PRG.PROCESS_IN... (74)
PLC_PRG.PROCESS_OU... (21)
                                            Global Write
     _global_init (21)
DO_RPV211_OPEN_CMD%QX0.10
     PLC_PRG.PROCESS_IN... (55)
PLC_PRG.PROCESS_IN... (56)
                                           Global Read
Global Read
     PLC_PRG.PROCESS_OU... (14)
                                            Global Write
                                             Global Write
     _global_init (15)
DI_PE211_PSL_HI%IX17.0
     PLC_PRG.PROCESS_IN... (19)
                                         Global Read
     PLC_PRG.SC_OUTPUTS (23)
                                             Global Read
DI_PE202_PSL_LO%IX16.2
     PLC_PRG.PROCESS_IN... (5)
                                            Global Read
DI_PE101_PSL_LO%IX16.0
     PLC_PRG.PROCESS_IN... (3)
                                             Global Read
cSINS02
     PLC_PRG.BR_SM (53)
                                              Local Read
     PLC_PRG.BR_SM (71)
                                              Local Read
     _global_init (4)
                                              Local Write
cVERSION_MINOR
     PLC_PRG.SC_OUTPUTS (157)
                                             Local Read
     _global_init (2)
                                              Local Write
close_intlk
     PLC_PRG.VALVES (47)
                                             Local Write
     VALVE_BI_FB (8)
                                              Local Read
     VALVE_BI_FB (11)
                                              Local Read
     VALVE_BI_FBinit (3)
                                              Local Write
not_symbol
     RP_FB (4)
                                             Local Write
     RP_FBinit (6)
                                              Local Write
DI_V203_OPEN%IX18.0
     PLC_PRG.PROCESS_IN... (42)
                                            Global Read
DI_V100_OPEN%IX17.8
     PLC_PRG.PROCESS_IN... (30)
                                            Global Read
DI_TP212_AT_SPEED%IX19.0
     PLC_PRG.PROCESS_IN... (74)
                                            Global Read
DI_PE203_PSL_MIDHI%IX16.13
```


```
PLC_PRG.PROCESS_IN... (14)
                                           Global Read
     PLC_PRG.SC_OUTPUTS (18)
                                          Global Read
DI_PE201_PSL_L0%IX16.1
                                         Global Read
     PLC_PRG.PROCESS_IN... (4)
DI_PE101_PSL_L0%IX16.0
     PLC_PRG.PROCESS_IN... (3)
                                         Global Read
DI_LL211_LID_CLOSED%IX19.4
                                        Global Read
     PLC_PRG.PROCESS_IN... (79)
     PLC_PRG.SC_OUTPUTS (34)
                                          Global Read
DI_LL211_ARM_RETRACTED%IX19.5
                                        Global Read
     PLC_PRG.PROCESS_IN... (80)
     PLC_PRG.SC_OUTPUTS (35)
                                         Global Read
cVERSION_MAJOR
     PLC_PRG.SC_OUTPUTS (156)
                                         Local Read
                                          Local Write
     _global_init (1)
cSINS03
     PLC_PRG.BR_SM (89)
                                         Local Read
     PLC_PRG.BR_SM (107)
                                          Local Read
     _global_init (5)
                                          Local Write
count2
                                        Local Write
     PLC_PRG.ACTUATOR_I... (6)
     PLC_PRG.ACTUATOR_I... (6)
                                         Local Read
     PLC_PRG.ACTUATOR_I... (7)
                                         Local Read
     PLC_PRG.ACTUATOR_I... (8)
                                         Local Read
     PLC_PRG.ACTUATOR_I... (11)
                                         Local Read
     PLC_PRG.ACTUATOR_I... (11)
                                         Local Write
     _global_init (168)
                                          Local Write
count
     _global_init (167)
                                           Local Write
cSINS01
    PLC_PRG.BR_SM (19)
                                          Local Read
     PLC_PRG.BR_SM (36)
                                           Local Read
    _global_init (3)
                                           Local Write
close_req
    PLC_PRG.VALVES (50)
                                          Local Write
                                          Local Read
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                          Local Write
     VALVE_BI_FBinit (6)
close_ena
                                         Local Read
     PLC_PRG.SC_OUTPUTS (44)
     PLC_PRG.SC_OUTPUTS (52)
                                         Local Read
                                         Local Read
     PLC_PRG.SC_OUTPUTS (64)
                                         Local Read
     PLC_PRG.SC_OUTPUTS (72)
     PLC_PRG.VALVES (6)
                                          Local Write
     PLC_PRG.VALVES (14)
                                          Local Write
     PLC_PRG.VALVES (22)
                                          Local Write
     PLC_PRG.VALVES (30)
                                          Local Write
     PLC_PRG.VALVES (38)
                                          Local Write
     PLC_PRG.VALVES (56)
                                          Local Write
     PLC_PRG.VALVES (64)
                                          Local Write
     PLC_PRG.VALVES (72)
                                           Local Write
     PLC_PRG.VALVES (80)
                                           Local Write
     PLC_PRG.VALVES (88)
                                           Local Write
     PLC_PRG.VALVES (96)
                                           Local Write
     PLC_PRG.VALVES (104)
                                           Local Write
     PLC_PRG.VALVES (112)
                                           Local Write
     VALVE_FB (3)
                                           Local Read
     VALVE_FB (6)
                                           Local Read
                                           Local Write
     VALVE_FBinit (3)
close_ena
     PLC_PRG.SC_OUTPUTS (90)
                                          Local Read
     PLC_PRG.VALVES (48)
                                           Local Write
     VALVE_BI_FB (4)
                                           Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FB (11)
                                           Local Read
     VALVE_BI_FBinit (4)
                                           Local Write
cBR_SELECTOR_UL
     _global_init (7)
                                          Local Write
AI_PE212_LO_PIY%IW9
    PLC_PRG.SC_OUTPUTS (168)
                                          Global Read
AI_PE212_LO_PIY%IW9
    PLC_PRG.SC_OUTPUTS (168)
                                          Global Read
close_cmd
```

```
PLC_PRG.PROCESS_OU... (19)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (92)
                                            Local Read
     VALVE_BI_FB (8)
                                           Local Read
     VALVE_BI_FB (8)
                                            Local Write
     VALVE_BI_FB (11)
                                            Local Read
     VALVE_BI_FBinit (8)
                                            Local Write
AI_PE212_HI_PIY%IW8
     PLC_PRG.SC_OUTPUTS (167)
                                           Global Read
AI_PE212_HI_PIY%IW8
     PLC_PRG.SC_OUTPUTS (167)
                                            Global Read
BR_STATE
     PLC_PRG.BR_SM (5)
                                            Local Write
     PLC_PRG.BR_SM (9)
                                            Local Read
     PLC_PRG.BR_SM (14)
                                            Local Write
     PLC_PRG.BR_SM (17)
                                            Local Read
     PLC_PRG.BR_SM (23)
                                            Local Write
     PLC_PRG.BR_SM (25)
                                            Local Write
     PLC_PRG.BR_SM (27)
                                            Local Write
     PLC_PRG.BR_SM (29)
                                            Local Write
     PLC_PRG.BR_SM (31)
                                            Local Write
     PLC_PRG.BR_SM (34)
                                            Local Read
     PLC_PRG.BR_SM (40)
                                            Local Write
     PLC_PRG.BR_SM (42)
                                            Local Write
     PLC_PRG.BR_SM (44)
                                            Local Write
     PLC_PRG.BR_SM (46)
                                            Local Write
     PLC_PRG.BR_SM (48)
                                            Local Write
     PLC_PRG.BR_SM (51)
                                            Local Read
     PLC_PRG.BR_SM (57)
                                            Local Write
     PLC_PRG.BR_SM (60)
                                            Local Write
     PLC_PRG.BR_SM (62)
                                            Local Write
     PLC_PRG.BR_SM (64)
                                            Local Write
     PLC_PRG.BR_SM (66)
                                            Local Write
     PLC_PRG.BR_SM (69)
                                            Local Read
     PLC_PRG.BR_SM (75)
                                            Local Write
     PLC_PRG.BR_SM (77)
                                            Local Write
     PLC_PRG.BR_SM (79)
                                            Local Write
     PLC_PRG.BR_SM (81)
                                            Local Write
     PLC_PRG.BR_SM (83)
                                            Local Write
     PLC_PRG.BR_SM (87)
                                            Local Read
     PLC_PRG.BR_SM (93)
                                            Local Write
     PLC_PRG.BR_SM (96)
                                            Local Write
     PLC_PRG.BR_SM (98)
                                            Local Write
     PLC_PRG.BR_SM (100)
                                            Local Write
     PLC_PRG.BR_SM (102)
                                            Local Write
     PLC_PRG.BR_SM (105)
                                            Local Read
     PLC_PRG.BR_SM (111)
                                            Local Write
     PLC_PRG.BR_SM (113)
                                            Local Write
     PLC_PRG.BR_SM (115)
                                            Local Write
     PLC_PRG.BR_SM (117)
                                            Local Write
     PLC_PRG.BR_SM (119)
                                            Local Write
     PLC_PRG.BR_SM (123)
                                            Local Read
     PLC_PRG.BR_SM (129)
                                            Local Write
     PLC_PRG.BR_SM (132)
                                            Local Write
     PLC_PRG.BR_SM (134)
                                            Local Write
     PLC_PRG.BR_SM (136)
                                            Local Write
     PLC_PRG.BR_SM (138)
                                            Local Write
     PLC_PRG.BR_SM (141)
                                            Local Read
     PLC_PRG.BR_SM (147)
                                            Local Write
     PLC_PRG.BR_SM (149)
                                            Local Write
     PLC_PRG.BR_SM (151)
                                            Local Write
     PLC_PRG.BR_SM (153)
                                            Local Write
     PLC_PRG.BR_SM (155)
                                            Local Write
     PLC_PRG.BR_SM (159)
                                            Local Write
     PLC_PRG.SC_OUTPUTS (40)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (48)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (220)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (222)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (225)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (228)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (231)
                                            Local Read
     PLC_PRG.SC_OUTPUTS (234)
                                            Local Read
      _global_init (288)
                                            Local Write
AI_PE211_LO_PIY%IW7
```

PLC_PRG.SC_OUTPUTS (166)	Global Read
AI_PE211_LO_PIY%IW7 PLC_PRG.SC_OUTPUTS (166)	Global Read
AI_PE211_HI_PIY%IW6	
PLC_PRG.SC_OUTPUTS (165) BP211_ON_CMD	Global Read
PLC_PRG.PROCESS_OU (4)	Local Read
PLC_PRG.PUMPS (4)	Local Write
PLC_PRG.SC_OUTPUTS (110) _global_init (310)	Local Read Local Write
AI_PE211_HI_PIY%IW6	20041 112100
PLC_PRG.SC_OUTPUTS (165)	Global Read
AI_PE203_LO_PIY%IW5 PLC_PRG.SC_OUTPUTS (164)	Global Read
AI_PE203_LO_PIY%IW5	
PLC_PRG.SC_OUTPUTS (164) AI_PE203_HI_PIY%IW4	Global Read
PLC_PRG.SC_OUTPUTS (163)	Global Read
AI_PE203_HI_PIY%IW4	
PLC_PRG.SC_OUTPUTS (163) BR_REQUEST	Global Read
PLC_PRG.BR_SM (24)	Local Read
PLC_PRG.BR_SM (26)	Local Read
PLC_PRG.BR_SM (28) PLC_PRG.BR_SM (30)	Local Read Local Read
PLC_PRG.BR_SM (39)	Local Read
PLC_PRG.BR_SM (41)	Local Read Local Read
PLC_PRG.BR_SM (43) PLC_PRG.BR_SM (45)	Local Read
PLC_PRG.BR_SM (47)	Local Read
PLC_PRG.BR_SM (59) PLC_PRG.BR_SM (61)	Local Read Local Read
PLC_PRG.BR_SM (63)	Local Read
PLC_PRG.BR_SM (65)	Local Read
PLC_PRG.BR_SM (74) PLC_PRG.BR_SM (76)	Local Read Local Read
PLC_PRG.BR_SM (78)	Local Read
PLC_PRG.BR_SM (80)	Local Read
PLC_PRG.BR_SM (82) PLC_PRG.BR_SM (95)	Local Read Local Read
PLC_PRG.BR_SM (97)	Local Read
PLC_PRG.BR_SM (99) PLC_PRG.BR_SM (101)	Local Read Local Read
PLC_PRG.BR_SM (110)	Local Read
PLC_PRG.BR_SM (112)	Local Read
PLC_PRG.BR_SM (114) PLC_PRG.BR_SM (116)	Local Read Local Read
PLC_PRG.BR_SM (118)	Local Read
PLC_PRG.BR_SM (131) PLC_PRG.BR_SM (133)	Local Read Local Read
PLC_PRG.BR_SM (135)	Local Read
PLC_PRG.BR_SM (137)	Local Read
PLC_PRG.BR_SM (146) PLC_PRG.BR_SM (148)	Local Read Local Read
PLC_PRG.BR_SM (150)	Local Read
PLC_PRG.BR_SM (152)	Local Read
PLC_PRG.BR_SM (154) PLC_PRG.SC_INPUTS (25)	Local Read Local Write
PLC_PRG.SC_INPUTS (27)	Local Write
PLC_PRG.SC_INPUTS (29) PLC_PRG.SC_INPUTS (31)	Local Write Local Write
PLC_PRG.SC_INPUTS (33)	Local Write
PLC_PRG.SC_INPUTS (35)	Local Write
PLC_PRG.SC_OUTPUTS (172) PLC_PRG.SC_OUTPUTS (174)	Local Read Local Read
PLC_PRG.SC_OUTPUTS (176)	Local Read
PLC_PRG.SC_OUTPUTS (178) PLC_PRG.SC_OUTPUTS (180)	Local Read Local Read
_global_init (289)	Local Write
AI_PE202_PIY%IW2	
PLC_PRG.SC_OUTPUTS (162) AI_PE202_PIY%IW2	Global Read
PLC_PRG.SC_OUTPUTS (162)	Global Read

```
AI_PE201_PIY%IW1
     PLC_PRG.SC_OUTPUTS (161)
                                           Global Read
AI_PE201_PIY%IW1
     PLC_PRG.SC_OUTPUTS (161)
                                           Global Read
BP211_ON
     PLC_PRG.FAULT_LOGIC (17)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     PLC_PRG.PROCESS_IN... (8)
                                           Local Write
     PLC_PRG.SC_OUTPUTS (109)
                                           Local Read
      _global_init (225)
                                           Local Write
AI_PE101_PIY%IW0
     PLC_PRG.SC_OUTPUTS (160)
                                           Global Read
AI_PE101_PIY%IW0
     PLC_PRG.SC_OUTPUTS (160)
                                           Global Read
BP211_PSL
     PLC_PRG.PROCESS_IN... (10)
                                          Local Write
     PLC_PRG.SC_OUTPUTS (147)
                                           Local Read
                                           Local Write
     _global_init (190)
ACTUATOR_OK
     PLC_PRG.ACTUATOR_I... (3)
                                          Local Write
     PLC_PRG.BYPASSES (3)
                                           Local Write
      PLC_PRG.FAULT_LOGIC (3)
                                           Local Read
     PLC_PRG.FAULT_LOGIC (37)
                                           Local Read
     _global_init (248)
                                            Local Write
awStatus
     ACTUATOR_SM (25)
                                            Local Read
     ACTUATOR_SM (29)
                                            Local Read
     ACTUATOR_SM (33)
                                            Local Read
     ACTUATOR_SM (37)
                                            Local Read
     ACTUATOR_SM (94)
                                            Local Read
     ACTUATOR_SM (132)
                                            Local Read
     ACTUATOR_SM.CONNECT (25)
                                           Local Read
     ACTUATOR_SM.STATUS... (26)
                                          Local Read
     ACTUATOR_SM.STATUS... (37)
                                           Local Read
     ACTUATOR_SM.STATUS... (38)
                                           Local Read
     ACTUATOR_SM.STATUS... (39)
                                            Local Read
     ACTUATORinit (2)
                                            Local Write
ACTUATOR_CMD
     PLC_PRG.ACTUATOR_O... (3)
                                           Local Read
     PLC_PRG.ACTUATOR_O... (4)
                                            Local Read
      PLC_PRG.BR_SM (11)
                                            Local Write
     PLC_PRG.BR_SM (19)
                                            Local Write
      PLC_PRG.BR_SM (22)
                                            Local Read
      PLC_PRG.BR_SM (36)
                                            Local Write
     PLC_PRG.BR_SM (53)
                                            Local Write
     PLC_PRG.BR_SM (56)
                                            Local Read
     PLC_PRG.BR_SM (71)
                                            Local Write
     PLC_PRG.BR_SM (89)
                                            Local Write
      PLC_PRG.BR_SM (92)
                                            Local Read
      PLC_PRG.BR_SM (107)
                                            Local Write
      PLC_PRG.BR_SM (125)
                                            Local Write
     PLC_PRG.BR_SM (128)
                                            Local Read
     PLC_PRG.BR_SM (143)
                                            Local Write
      _global_init (247)
                                            Local Write
ACTUATOR_AT_TARGET
      PLC_PRG.ACTUATOR_I... (8)
                                            Local Write
      PLC_PRG.ACTUATOR_I... (13)
                                            Local Write
      PLC_PRG.BR_SM (22)
                                            Local Read
      PLC_PRG.BR_SM (56)
                                            Local Read
      PLC_PRG.BR_SM (92)
                                            Local Read
      PLC_PRG.BR_SM (128)
                                            Local Read
      _global_init (246)
                                            Local Write
a_num
      _global_init (169)
                                            Local Write
Call Tree of PLC_PRG (PRG-ST)
PLC_PRG
             PLC_PRG.PROCESS_INPUTS
             PLC_PRG.SC_INPUTS
             PLC_PRG.ACTUATOR_INPUTS
```

PLC_PRG.BYPASSES



	Page
Project information	A
Actuator_SM (PRG-ST)	1
CONNECT (ST)	4
DRG1_WRITE (ST)	5
PCMD_WRITE (ST)	6
STATUS_READ (ST)	6
PLC_PRG (PRG-ST)	7
Actuator_Inputs (ST)	14
Actuator_Outputs (ST)	14
BR_SM (ST)	14
Bypasses (ST)	16
Clear_Reqs (ST)	16
ES_SM (ST)	17
Fault_Logic (ST)	20
LL_SM (ST)	20
	23
Process_Inputs (ST) Process_Outputs (ST)	23
	24
Pumps (ST)	25
SC_Inputs (ST)	26
SC_Outputs (ST)	
Valves (ST)	30
RP_FB (FB-ST)	32
TP_FB (FB-ST)	32
VALVE_BI_FB (FB-ST)	32
VALVE_FB (FB-ST)	33
Actuator	33
BR_REQ	33
BR_ST	33
PV_REQ	34
PV_ST	3 4
ACTUATOR_VISU	3 4
AUTO_VISU	34
INTLKS_VISU	3 4
PUMPS_VISU	35
SIGNALS_VISU	35
VALVES_VISU	35
Global_Variables	36
Variable_Configuration	36
Global Variables 0	36
Globale_Variablen	36
Version	36
Globale_Variablen	36
Globale_Variablen	38
Alarm configuration	38
PLC Configuration	38
Sampling Trace	42
Task configuration	42
Watch- and Recipe Manager	42
Workspace	42
Parameter Manager	42
Cross Reference List	42
Call Tree of PLC_PRG (PRG-ST)	93