Yes -- Chris Squire Signature Bass Tone

Revised 2026-10-16 following the approved library audit.
Type: Artist. Instrument: Harley Benton passive 5-string P/J.
Full board. Board Option: American Sound (bypassed; retained for legacy full-board builds).
Patch screen name: Yes-Squire. Patch VOL: 55.
Preset tempo: 120 BPM.

Chris Squire-inspired picked P/J bass. Bright, mid-forward drive is intentional. Bass OD is the principal additional drive; the capture still contributes its own character. This serial chain approximates the musical role and is not a true split clean/dirty rig.

Revision intent

Keep the musical role of the original patch while reducing redundant gain, excessive space and unclear switching where identified in audit entry 4.
The module settings and section map below are the active revision.
Audited capture volumes and Michael's explicit patch-level adjustments are preserved.
Keep Bass OD as the principal added drive; Tidal Wave drive stays off in both CTL states.
No hardware audition or measured level match has been performed.

GP-5 settings

Module order: NR -> PRE -> DST -> AMP -> CAB -> EQ -> MOD -> DLY -> RVB.
The encoded N->S block sits between DST and AMP when a SnapTone is used.

AMP/CAB replacement: SnapTone BrightSVT (slot 55): SVT SANS BRIGHT DRIVE (SVT-CL) + Hartke410.
Slot: 55. Always on.
Gain: 50, VOL: 60, Bass: 55, Middle: 50, Treble: 58.
AMP and CAB are both off; the capture already includes its cab/DI character.
The capture voice is fixed across CTL states. Audited VOL is preserved for this slot.

NR - Gate

THRE: 25.
Fixed on. Not on CTL.
Use the lowest threshold that keeps rests quiet. Check soft notes and held-note decay. This gate is before the drives and amp; it does not directly gate noise generated after it.

PRE - Module off

Not used.

DST - Bass OD

Gain: 30.
Blend: 35.
VOL: 60.
Bass: 55.
Treble: 70.
CTL assigned. Loads on; first CTL press switches it off.
Also on an individual MIDI toggle.
Supplies the selected additional drive voice. Use its level and gain as separate controls. A pre-amp boost may add compression instead of a proportional solo-volume increase.

AMP - Module off

Not used.

CAB - Module off

Not used.

EQ - Bass EQ 1

33Hz: 0.
150Hz: -5.
600Hz: 8.
2kHz: 4.
8kHz: 3.
VOL: 50.
Fixed on. Not on CTL.
Shapes note body and cut after the amp/capture. Where assigned to CTL, its output adds the specified lift after the gain stages. Numbers are GP-5 control values, not a calibrated loudness guarantee.

MOD - B-Chorus

Depth: 20.
Rate: 0.8.
VOL: 50.

CTL assigned. Loads off; first CTL press switches it on.
Adds the specified movement. Keep it underneath the note except for intentionally wet artist or ambient voices.

DLY - Module off

Not used.

RVB - Module off

Not used.

Switching and section map

CTL blocks: DST, MOD.

- CTL off / loaded state: Main driven Squire voice. GP-5 active: NR, DST, EQ, N->S.
- First CTL press: Cleaner open passages. GP-5 active: NR, EQ, MOD, N->S.
- Press CTL again to return to the loaded block pattern, provided no shared MIDI block has been changed.

MIDI toggles: DST.
MIDI mapping lives on the controller/device, not in the .prst.

- DST Bass OD: loads on; toggle to remove this block independently.

Before CTL, undo MIDI changes to shared CTL blocks so they match the preceding CTL pattern. CTL flips current states, not a stored scene. After pressing CTL, apply individual MIDI changes.

- DST-only alternative from loaded state: CTL off, MIDI DST off; other MIDI blocks at their load states. GP-5 active: NR, EQ, N->S. Board switches unchanged.

Full pedalboard

Flamma FS-08 Octave -> Donner Ultimate Comp -> Donner Stylish Fuzz -> Joyo Tidal Wave -> Joyo American Sound -> Joyo Narcissus -> Valeton GP-5.
Board settings are set by hand and are not encoded in the .prst.
All numeric pedal positions use the existing 0-100 position shorthand unless a clock position is specified.

Flamma FS-08 Octave

Bypassed throughout.
-2OCT: 0.
-OCT: 0.
+OCT: 0.
+2OCT: 0.
Dry: 100.

Donner Ultimate Comp

On throughout.
COMP: 45.
TONE: 55.
LEVEL: 55.
Mode: TREBLE.

Donner Stylish Fuzz

Bypassed throughout.
Sustain: 25.
Treble: 50.
Bass: 50.
Volume: 50.

Joyo Tidal Wave

Drive off throughout; preamp active.
Drive: 40.
Blend: 55.
Presence: 60.
Level: 55.
Treble: 60.
Middle: 55.
Bass: 50.
Mid-Frequency: 500Hz.
Bass-Shift: 80Hz.
Cab-Sim (DI out): On.
Ground Lift: Off.
The footswitch toggles drive only. Preamp EQ and Level stay active in both states. Cab-Sim/Ground Lift affect the DI path; main instrument output is unchanged.

Joyo American Sound

Bypassed throughout.
Level: 50.
Drive: 10.
Voice: 50.
Low: 50.
Mid: 50.

High: 50.

Joyo Narcissus

Bypassed throughout.
Width: 30.
Depth: 20.
Rate: 20.
Mode: Vintage.

Board choreography

- Flamma FS-08 Octave: Bypassed throughout.
- Donner Ultimate Comp: On throughout.
- Donner Stylish Fuzz: Bypassed throughout.
- Joyo Tidal Wave: Drive off throughout; preamp active.
- Joyo American Sound: Bypassed throughout.
- Joyo Narcissus: Bypassed throughout.

Set the board switches for the section you are entering. Intro-only or clean-only effects may need to start on. Return each pedal to its documented state at the next section. Board pedals are independent of CTL.

Revision record

Approved audit entry 4.
- SnapTone Treble: 70 -> 58.
- PRE: B-Boost -> off.
- PRE: removed from CTL.
- DST Gain: 65 -> 30.
- DST Blend: 60 -> 35.
- EQ 33Hz: 8 -> 0.
- EQ 2kHz: 12 -> 4.
- EQ 8kHz: 15 -> 3.
- Board Tidal Wave: ; Drive off throughout; preamp active.

Pre-revision JSON, Markdown and original file hashes are preserved in Documents/patch-audit-2026-10-16/inventory.json and implementation-manifest.json.
The site piece title and on-disk filenames stay stable; only the short pedal display name may change.