1708 SOC PINOUT 1 - J5p11, J7p1, (PnC related?) 2 - GND 3 - SDA 4 - SCL 5 - POWER OK / SHUTDOWN / ~RESET 6 - D- USB 7 - D+ USB 8 - GND 9 - LED 10 - GND 11 - GU 12 - 3.3v 13 - RSY 14 - U5p3, Light Rumble 15 - B (thru R29, 100) 16 - GND 17 - PK4, Headset Right Speaker (thru FB2) 18 - GND 19 - RSX 20 - J8p11 21 - J8p10 22 - U2p2 (Reg control for J8p9?) 23 - GND 24 - J8p8 (thru R2, 33) 25 - J8p7 26 - J8p5 (thru R1, 33) 27 - J8p4 (thru R3, 33) 28 - GND 29 - PK6, Headset Mic (thru R22, 0 then R229, 0) 30 - GND 31 - 3.3v 32 - PK2, Headset Left Speaker (thru FB1) 33 - Q1p334 - GND 35 - PK7 (thru R10, 10k) 36 - GND (thru a trace, possibly -vRef?) 37 - 3.3v38 - Connected internally to 76, (TP3 on main board) 39 - GND 40 - U9p3 (thru R38, 0) LT/RT VCC for Hall Sensors, 3.2v Reg (pulsed) 41 - GND 42 - vRef (1.8v)43 - NC, goes to TP4 and R12 which is not populated 44 - SW4 (Not Installed) 45 - GND 46 - U8p3 (thru R35, 0) Stick AN+, 1.8v Reg 47 - U4p3, Heavy Rumble 48 - U4p2, LT Rumble 49 - U4p4, Heavy Rumble 50 - U4p1, LT Rumble 51 - GND

52 - LT

```
53 - LSY
54 - LSX
55 - LSC (thru R16, 33)
56 - GND
57 - PK4, Headset (thru R79, 1k)
58 - PK3, Headset
59 - SDA2, J7p3, J8p2 (PnC Battery and Expansion port)
60 - SCL2, J7p2 (thru R15, 0), J8p3 (PnC Battery and Expansion port)
61 - GND
62 - RT
63 - GND
64 - U5p1, RT Rumble
65 - U5p4, Light Rumble
66 - U5p2, RT Rumble
67 - GND
68 - USB 5v Detect (via Divider R7 (1M) and R8 (500k) 0v = No USB 5v,
1.6v = USB 5v present)
69 - GND
70 - J5p3 (3v Wired), (Battery Voltage Wireless)
71 - GND
72 - 3.3v
73 - J1p5
74 - J1p7 (TP72)
75 - J1p6 (TP71)
76 - J1p4, Connected internally to 38
77 - J1p3
78 - GND
79 - GND
```

80 - RSC (thru R21, 33)