```
auto tx. conf. txt
        File: auto tx. conf
auto tx get={
        CmdCode=0x0082 # do NOT change this line
        Action:2=0
                                 # GET
auto tx unreg={
        CmdCode=0x0082 # do NOT change this line
        Action:2=1
                                 # SET
nat keep alive={
        CmdCode=0x0082 # do NOT change this line
        Action:2=1
                                 # SET
        AutoTxT1vType: 2=0x0118
        AutoTxTlvLength:2={
                                         # 58 = 6 + 52 (FrameLen)
                Interval:2=2
                                         \# 1 - 3600 seconds
                Priority:1=7
                                         # Priority, ignored if non-WMM
                Reserved: 1=0
                FrameLength: 2={
                                         #52 = 6 (DA) + 6 (SA) + 2 + 38 (Length)
                        DestMacAddr:6='0x00, 0x40, 0xf4, 0xbf, 0x24, 0xee'
                        SrcMacAddr:6='0x00,0x00,0x00,0x00,0x00,0x00'
                                                 # 38 = 8 (SNAP hdr) + 29 (IP) +
                        Length: 2='0x00, 38'
1 (padding)
                        DSAP:1=0xaa
                                                         # SNAP header
                        SSAP:1=0xaa
                        Ctrl:1=0x03
                        SNAP 0UI:3='0x00, 0x00, 0x00'
                        SNAP^{-}PID: 2=' 0x08, 0x00'
                                                         # IP Packet
                        IPv4:1=0x45
                        IP TOS:1=0x00
                        IP LEN: 2=' 0x00, 29'
                                                         # IP hdr 20 + payload 9
= 29
                        IP ID:2=0xefbe
                        IP Flag FragOffset:2=0x0000
                        IP_TTL:1=128
IP_Prot:1=17
                                                                 # UDP protocol
                        IPhdr cksum:2=0xc5f9
                                                         # may need
re-calculation if changed
                        IPsrcAddr: 4=' 192, 168, 0, 201'
                                                         # 192. 168. 0. 201
                        IPdstAddr: 4=' 192, 168, 0, 1'
                                                         # 192. 168. 0. 1
                        UDPsrcPort: 2=' 0x11, 0x94'
                                                         # 4500
                        UDPdstPort:2='0x11, 0x94'
                                                         # 4500
                        UDP1ength: 2='0x00, 9'
                                                         # UDP hdr 8 + payload 1
= 9
                        UDPcksum: 2=0x985b
                                                                 # may need
re-calculation if changed
                        UDPpayload: 1=0xff
                        padding:1=0
                                                                          # MAC
```

Padding for 32bit alignment, set to 0 第 1 页