

Pall_NF

```
1|      10|      20|      30|      40|      50|      60|      70|      80|      90|     100|     110|
1  (* ===== *)
2  (* SECCIÓN: Pall_NF *)
3  (* La programación del palletizador de las piezas pequeñas no frágiles *)
4  (* ===== *)
5
6  R_TRIG_29 (CLK := IN_Diffuse_Sensor_7);
7
8  IF R_TRIG_29.Q THEN
9      OUT_BeltConveyor_Inclined_1:=TRUE;
10     OUT_Palletizer_1_Belt_Plus:=TRUE;
11 END_IF;
12
13 IF OUT_BeltConveyor_Inclined_1 AND OUT_Palletizer_1_Belt_Plus THEN
14     TON_17 (IN := TRUE, PT := t#10S);
15 ELSE
16     TON_17 (IN := FALSE);
17 END_IF;
18
19 IF TON_17.Q THEN
20     OUT_BeltConveyor_Inclined_1:=FALSE;
21     OUT_Palletizer_1_Belt_Plus:=FALSE;
22     cont_NF:= cont_NF+1;
23 END_IF;
24
25 IF cont_NF=2 THEN
26     SET (OUT => OUT_Palletizer_1_Push);
27     cont_NF:= 0;
28     SET (OUT => OUT_Emitter2_Emit);
29 END_IF;
30
31 TP_18 (IN := OUT_Palletizer_1_Push,
32       PT := T#2S);
33
34 F_TRIG_54 (CLK := TP_18.Q);
35
36 IF F_TRIG_54.Q THEN
37     RESET (OUT => OUT_Palletizer_1_Push);
38     RESET (OUT => OUT_Emitter2_Emit);
39 END_IF;
40
41 F_TRIG_55 (CLK := OUT_Palletizer_1_Push);
42
43 IF F_TRIG_55.Q and OUT_BeltConveyor_6_10 THEN
44     SET (OUT => OUT_Pal_1_Elevator_Move_Limit);
45     SET (OUT => OUT_Palletizer_1_Elevator_Plus);
46     SET (OUT => OUT_Palletizer_1_Clamp);
47 END_IF;
48
49 TP_19 (IN := F_TRIG_55.Q,
50       PT := t#2s);
51
52 F_TRIG_56 (CLK := TP_19.Q );
53
54 IF F_TRIG_56.Q AND OUT_BeltConveyor_6_10 THEN
55     SET (OUT => OUT_Palletizer_1_Open_Plate);
56     RESET (OUT => OUT_Palletizer_1_Clamp);
57 END_IF;
58
59 TP_20 (IN := OUT_Palletizer_1_Open_Plate,
60       PT := T#1S);
61
62 F_TRIG_57 (CLK := TP_20.Q);
63
64 IF F_TRIG_57.Q AND OUT_BeltConveyor_6_10 THEN
65     RESET (OUT => OUT_Palletizer_1_Elevator_Plus);
66     SET (OUT => OUT_Palletizer_1_Elevator_Minus);
67 END_IF;
68
69 TP_21 (IN := OUT_Palletizer_1_Elevator_Minus,
70       PT := t#2s);
71
72 F_TRIG_58 (CLK := TP_21.Q);
73
74 IF F_TRIG_58.Q AND OUT_Palletizer_1_Open_Plate THEN
75     RESET (OUT => OUT_Palletizer_1_Elevator_Minus);
76     RESET (OUT => OUT_Palletizer_1_Open_Plate);
77     SET (OUT => OUT_Roller_Conveyor_NF);
78     SET (OUT => OUT_Palletizer_1_Chain_Plus);
79 END_IF;
```