

Stacker_Crane_NF

```
1|      10|      20|      30|      40|      50|      60|      70|      80|      90|      100|      110|
1  (* ===== *)
2  (* SECCIÓN: Stacker_Crane_NF *)
3  (* Almacenamiento de los pallets con las piezas no frágiles *)
4  (* ===== *)
5
6  IF IN_Diffuse_Sensor_21 THEN
7      OUT_Roller_Conveyor_NF := 1;
8  END_IF;
9
10 F_TRIG_89 (CLK := IN_Diffuse_Sensor_21);
11
12 IF F_TRIG_89.Q THEN
13     RESET (OUT => OUT_Palletizer_1_Chain_Plus);
14 END_IF;
15
16 F_TRIG_48 (CLK := IN_Diffuse_Sensor_20);
17
18 IF F_TRIG_48.Q THEN
19     OUT_Roller_Conveyor_NF := 0;
20     Paso_NF := 0;
21 END_IF;
22
23 TP_33 (IN := F_TRIG_48.Q, PT := T#1S);
24
25 F_TRIG_80 (CLK := TP_33.Q);
26
27 IF F_TRIG_80.Q AND Paso_NF = 0 THEN
28     OUT_StCr_2_Target_Position := Position_NF;
29     Position_NF := Position_NF + 1;
30     OUT_Stacker_Crane_2_Lift := 1;
31 END_IF;
32
33 F_TRIG_81 (CLK := IN_Stacker_Crane_2_Z);
34
35 IF F_TRIG_81.Q AND Paso_NF = 0 THEN
36     OUT_Stacker_Crane_2_Left := 1;
37     Paso_NF := 1;
38 END_IF;
39
40 IF IN_Stacker_Crane_2_Left_Limit and Paso_NF = 1 THEN
41     OUT_Stacker_Crane_2_Lift := 0;
42     Paso_NF := 2;
43 END_IF;
44
45 IF F_TRIG_81.Q AND Paso_NF = 2 THEN
46     OUT_Stacker_Crane_2_Left := 0;
47     Paso_NF := 3;
48 END_IF;
49
50 IF IN_Stacker_Crane_2_Middle_Limit and Paso_NF = 3 THEN
51     OUT_StCr_2_Target_Position := 55;
52 END_IF;
```