A Levelized Comparison of Pulsed and Steady-State Tokamaks

Contents

For	maliziı	ng the Fusion Systems Model	3
3.1	Expla	ining Fixed Variables	3
3.2	Conne	ecting Floating Variables	4
	3.2.1	The Plasma Temperature – \overline{T}	4
	3.2.2	The Plasma Density – \overline{n}	5
	3.2.3	The Plasma Current – I_P	5
	3.2.4	The Tokamak Magnet Strength – B_0	6
	3.2.5	The Tokamak Major Radius – R_0	6
3.3	Enforc	cing Power Balance	6
	3.3.1	Collecting Power Sources	7
	3.3.2	Approximating Radiation Losses	8
	3.3.3	Estimating Heat Conduction Losses	9
	3.3.4	Writing the Lawson Criterion	10
	3.3.5	Finalizing the Primary Constraint	12
3.4	Collec	ting Secondary Constraints	14
	3.4.1	Introducing the Beta Limit	15
	3.1 3.2	3.1 Explaid 3.2 Connect 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.3 Enforce 3.3.1 3.3.2 3.3.3 3.3.4 3.3.5 3.4 Collect	3.2 Connecting Floating Variables

2 CONTENTS

	3.4.2	Giving the Kink Safety Factor	16
	3.4.3	Working under the Wall Loading Limit	17
	3.4.4	Setting a Maximum Power Cap	18
	3.4.5	Listing the Heat Loading Limit	19
3.5	Summ	parizing the Fusion Systems Model	20

Chapter 3

Formalizing the Fusion Systems Model

The goal of this chapter is to step back from the steady current and see the larger picture behind reactor design. As such, a more in-depth description of fixed and floating variables is given. The discussion of floating variables will then lend itself to describing the framework for this fusion systems model. As such, we will derive formulas for the radius and magnetic field of the tokamak. The current will remain a connecting piece while switching gears to pulsed tokamaks and comparing each operation's solving algorithm.

3.1 Explaining Fixed Variables

In this model, fixed variables are ones that remain constant while solving for a reactor. These include geometric scalings (i.e. ϵ , δ , κ), peaking parameters (i.e. ν_n , ν_T , l_i), and a slew of physics constants related to pulsed and steady-state design (e.g. Q, N_G , f_D). For a complete list of fixed variables, consult the appendix. Within this model, fixed variables are second-class variables. As such they often reside in fixed coefficients – K_{\square} – which are treated as constants.

4

3.2 Connecting Floating Variables

Floating variables $-\overline{T}$, \overline{n} , I_P , R_0 , B_0 – are first-class variables of this fusion systems model. They represent the fundamental properties of the plasma and tokamak (that constitute a fusion reactor). As such, they will be reintroduced one at a time, explaining how they fit into the model – and which equation is capable of representing it.

Bluntly, this fusion systems model is just a simple algebra problem: solve five equations with five unknowns (i.e. \overline{T} , \overline{n} , I_P , R_0 , B_0). Although this naive approach would work, we can do a little better by wrangling these five equations down to just one. This was already done while deriving the steady current. It just happened that the current was not directly dependent on the tokamak size or magnet strength.

This will prove more challenging for the generalized current needed for pulsed operation. Even so, this equation will still be boiled down to one equation with a single unknown – I_P . A solution to which can be solved much faster than the naive 5 equation approach. This is one reason the model is so fast.

3.2.1 The Plasma Temperature – \overline{T}

The plasma temperature, measured in keV (kilo-electron-volts), is one of the most finicky variables in the fusion systems model. It first proved trouble-some when it was shown that a pedestal profile – not a parabolic one used here – would be needed for an accurate calculation of bootstrap current. The unusual tabulation for reactivity – (σv) – used in fusion power only further exposed this nonlinearity.

Acknowledging that temperature is the most difficult to handle parameter prompts its use as the scanned variable. What this means practically is scanning temperatures produces curves of reactors. By example, a scan may be run over the average temperatures (\overline{T}): 10, 15, 20, 25, and 30 keV – each corresponding to its own reactor. In equation form, this becomes:

$$\overline{T} = const.$$
 (3.1)

Where the constant is 10 in one run, 15 in the next, and 30 for the fifth one.

3.2.2 The Plasma Density $-\overline{n}$

The cornerstone of this fusion systems model has always been the application of the Greenwald density limit from square one. It is for this reason – as well as being a good approximation – that a parabolic profile was rationalized over a pedestal (H-Mode) one. Repeated, the Greenwald density limit is:

$$\overline{n} = K_n \cdot \frac{I_P}{R_0^2} \tag{3.2}$$

This is an exceptionally simple relationship and why it guided the model. Unlike the next three variables, it is actually used in their derivations. Therefore, any reactor found through this model is considered a *Green-waldian Reactor* – one in H-Mode at the Greenwald density limit.

3.2.3 The Plasma Current $-I_P$

The plasma current is what separates steady-state from pulsed operation. From before, the steady current was found to be:

$$I_P = \frac{K_{BS}\overline{T}}{1 - K_{CD}(\sigma v)} \tag{3.3}$$

This was found by setting the total current equal to the two sources of current: bootstrap and current drive. In fractional form,

$$I_P = I_{BS} + I_{CD} \rightarrow 1 = f_{BS} + f_{CD}$$
 (3.4)

This says that the current fractions of bootstrap and current drive must sum to one. As shown next chapter, inductive sources can be included in this flux balance:

$$1 = f_{BS} + f_{CD} + f_{IN} (3.5)$$

This equation shows how steady-state and pulsed operation can coexist. The final point to make is reducing the model to being purely pulsed – i.e. neglecting the current drive:

$$1 = f_{BS} + f_{IN} (3.6)$$

Therefore next chapter will generalize the steady current to allow pulsed operation. As steady current faced self-consistency issues with η_{CD} , this current will involve its own root solving problem – the description of which will be given in the following two chapters.

3.2.4 The Tokamak Magnet Strength $-B_0$

The tokamak magnet strength has no obvious equation to eliminate it. With foresight, the one this model chooses to use is power balance in a reactor. Similar to current balance, power balance is what separates a reactor from a toaster. As such, it is referred throughout this document as: the primary constraint. It will be derived later this chapter.

3.2.5 The Tokamak Major Radius $-R_0$

Much like the magnet strength, the major radius has no obvious relation to express it. This is convenient, because the model still has yet to resolve one of its most pressing issues: physical and engineering-based constraints. This laundry list of requirements further restricts reactor space to the curves show in the results section. Collectively, these are referred to as the secondary constraints – discussed later this chapter. By miracle, these constraints all just happen to depend on the size of the reactor.

3.3 Enforcing Power Balance

What separates a reactor from a toaster is power balance. It accounts for how the power going into a plasma's core exactly matches the power coming out of it. To approximate this conservation equation, two pairs of powers will be introduced: the sources and the sinks. The sources have already been introduced – they include the alpha power (P_{α}) and the heating power (P_H) . The remaining two powers - the sinks – appear as the radiation and heat conduction losses. Both of which are defined shortly. In equation form, power balance becomes:

$$\sum_{sources} P = \sum_{sinks} P \tag{3.7}$$

or expanded to fit this model:

$$P_{\alpha} + P_{H} = P_{BR} + P_{\kappa} \tag{3.8}$$

For clarity, the left-hand side of this equality are the sources. The remaining two are the sinks: the Bremsstrahlung radiation (P_{BR}) and the heat conduction losses (P_{κ}) .

3.3.1 Collecting Power Sources

As suggested, the two sources of power in a tokamak are: alpha power (P_{α}) and auxiliary heating (P_H) . From earlier, it was determined that alpha particles (i.e. Helium) carried 20% of the total fusion power; or as we put it mathematically:

$$P_{\alpha} = \frac{P_F}{5} \tag{3.9}$$

Additionally, it was determined that heating power is what eventually amplified into fusion power, or in equation form:

$$P_H = \frac{P_F}{Q} \tag{3.10}$$

This allows the sources to be combined together with a new fixed coefficient:

$$P_{src} = P_{\alpha} + P_H = K_P \cdot P_F \tag{3.11}$$

$$K_P = \frac{5+Q}{5\times Q} \tag{3.12}$$

The two sink terms are described next.

3.3.2 Approximating Radiation Losses

All nuclear reactors emit radiation. From a power balance perspective, this means some power has to always be reserved to recoup from its losses — measured in megawatts. In a fusion reactor, the three most important types of radiation are: Bremsstrahlung radiation, line radiation, and synchrotron radiation. Without going into too much detail, this model chooses to only model Bremsstrahlung radiation — as it usually is the most dominant term in the plasma's core.

This radiation power term is therefore one area where the physics model could be greatly improved. Derived shortly, the Bremsstrahlung radiation is almost always the dominant source. However, adding the line-radiation would better handle impurities (i.e. when chunks of the tokamak fall into the plasma) and implementing synchrotron radiation would drive the values closer to real-world experiments (although a description of which is outside the scope of this text).

Bremsstrahlung – or breaking – radiation is what occurs when a charged particle (e.g. an electron) is decelerated (e.g. by changing angle). In a tokamak, this happens all the time as charged particles are spun around and around the machine. As given in Jeff Freidberg's book, this value can be written as:

$$P_{BR} = \int S_{BR} \, d\vec{r} \tag{3.13}$$

For clarity, this is a volume integral where the radiation power density (S_{BR}) is given by:

$$S_{BR} = \left(\frac{\sqrt{2}}{3\sqrt{\pi^5}} \cdot \frac{e^6}{\epsilon_0^2 c^3 h m_e^{3/2}}\right) \cdot \left(Z_{eff} \, n^2 \, T^{1/2}\right) \tag{3.14}$$

The constants in the left set of parentheses all have their usual physics meanings (i.e. c is the speed of light and m_e is the mass of an electron). What is new is the effective charge: Z_{eff} .

The effective charge is a scheme for collapsing the charge that each particle has to a collective value. Fundamental charge, here, is what: neutrons lack, electrons and hydrogen have one of, and helium has two. As such, a plasma

with a purely deuterium and tritium fuel would have an effective charge of one. This value would then quickly rise if a Tungsten tile – with 74 units of fundamental charge – were to fall from the inside of the tokamak into the plasma core.

Using the volume integral – seen in the derivation of fusion power – allows the Bremsstrahlung power to be written as standardized units as:

$$P_{BR} = K_{BR} \, \overline{n}^2 \, \overline{T}^{1/2} R_0^3 \tag{3.15}$$

$$K_{BR} = 0.1056 \frac{(1+\nu_n)^2 (1+\nu_T)^{1/2}}{1+2\nu_n + 0.5\nu_T} Z_{eff} \epsilon^2 \kappa g$$
 (3.16)

This power term represents the radiation power losses in power balance. All that is needed now is heat conduction losses – the hardest plasma behavior to model to date.

3.3.3 Estimating Heat Conduction Losses

Heat is energy that lacks direction on a microscopic level. Macroscopically, it generally moves from hotter areas to colder ones. As hinted by the plasma profile for temperature, heat emanates from the center of the plasma – and migrates towards the inner surface of the tokamak. It therefore seems an important quantity to calculate when balancing power in a plasma's core.

The difficulty of estimating heat conduction, though, lies in the chaotic nature of plasmas – no theory or computation today can properly model it. As such reactor designers have turned to experimentalists for empirical scaling laws based on the ~ 15 strongest tokamaks in the world. These collective are called confinement time scalings, i.e. the ELMy H-Mode Scaling Law.

The derivation of the heat conduction losses (P_{κ}) starts in a manner similar to the Bremsstrahlung radiation. To begin, an equation for P_{κ} is given in Jeff Freidberg's book as:

$$P_{\kappa} = \frac{1}{\tau_E} \int U d\vec{r} \tag{3.17}$$

This volume integral includes two new terms: the confinement time (τ_E)

and the internal energy (U). Before explaining these terms, a qualitative description is in order. As mentioned previously, the heat – or microscopically random – energy is captured by the internal energy (U). Then the confinement time (τ_E) is how long it would take the heat to completely leave the device if the system were immediately turned off.

A formula for confinement time will be delayed to the end of this section, when it is needed to solve for the magnetic field (B_0) . Moving forward, the internal energy, U, has its typical physics meaning – where all three species are assumed to be at the electron temperature (T):

$$U = \frac{3}{2} (n + n_D + n_T) T \tag{3.18}$$

Here again, n_D and n_T – the density of deuterium and tritium, respectively – are related to the electron density (used in this model) through the dilution factor, assuming a 50-50 mix of D-T fuel:

$$n_D = n_T = f_D \cdot \left(\frac{n}{2}\right) \tag{3.19}$$

Foregoing the mathematical rigor of previous sections, the equations here can be combined to form an equation for P_{κ} – the heat conduction losses – in standardized units:

$$P_{\kappa} = K_{\kappa} \frac{R_0^3 \ \overline{n} \ \overline{T}}{\tau_E} \tag{3.20}$$

$$K_{\kappa} = 0.4744 (1 + f_D) \frac{(1 + \nu_n) (1 + \nu_T)}{1 + \nu_n + \nu_T} (\epsilon^2 \kappa g)$$
 (3.21)

Now that all four terms have been defined in power balance, the next step is expanding it and solving for the tokamak's toroidal magnetic field strength: B_0 .

3.3.4 Writing the Lawson Criterion

Before locking in the primary constraint – i.e. the magnet strength (B_0) equation from power balance – it seems appropriate to take a detour and

explain an intermediate solution: the Lawson Criterion. Within the fusion community, the Lawson Criterion is the cornerstone in any argument on the possibility of a design being used as a reactor (and not just some glorified toaster).

An equation for the Lawson Criterion is easily found in the literature as:

$$n\,\tau_E = \frac{60}{E_F} \cdot \frac{T}{\langle \sigma v \rangle} \tag{3.22}$$

Similar to the steady current derived earlier, the right-hand side is only dependent on temperature. Further, as the left-hand side is a measure of difficult to achieve values, the goal is to minimize both sides. This occurs when the plasma temperature is around 15 keV – a fact memorized by many fusion engineers. As will be seen, this is a simplified result of our mode. This is why $\overline{T}=15$ keV is not always the optimum temperature – but usually is in the right neighborhood for reasonable reactor designs.

As all the terms in power balance have already been defined, the starting point will be simply repeating the standardized equations for all four powers.

$$P_{\alpha} = \frac{P_F}{5} \tag{3.9}$$

$$P_H = \frac{P_F}{Q} \tag{3.10}$$

$$P_{BR} = K_{BR} \,\overline{n}^2 \,\overline{T}^{1/2} R_0^3 \tag{3.15}$$

$$P_{\kappa} = K_{\kappa} \, \frac{R_0^3 \, \overline{n} \, \overline{T}}{\tau_E} \tag{3.20}$$

These can then be substituted into power balance:

$$P_{\alpha} + P_H = P_{BR} + P_{\kappa} \tag{3.23}$$

After a couple lines of algebra, power balance can be rewritten in a form analogous to the Lawson Criterion:

$$\overline{n}\,\tau_E = \frac{K_{law}\,\overline{T}}{(\sigma v) - K_{rad}\,\overline{T}^{1/2}} \tag{3.24}$$

$$K_{law} = \frac{K_{\kappa}}{K_{PF}} \tag{3.25}$$

$$K_{rad} = \frac{K_{BR}}{K_{PF}} \tag{3.26}$$

$$K_{PF} = K_P K_F \tag{3.27}$$

As can be seen, this is remarkably similar to the simple Lawson Criterion:

$$n \tau_E = \frac{60}{E_F} \cdot \frac{T}{\langle \sigma v \rangle} \tag{3.22}$$

The main difference is this model does not ignore radiation losses completely. The inclusion of which sets a minimum temperature for a reactor to be physically realizable.* With this intermediate relation in place, the goal is now to give a formula for the confinement time and solve it for the magnet strength (B_0) – the Primary Constraint.

3.3.5 Finalizing the Primary Constraint

The goal now is to transform the Lawson Criterion into an equation for magnet strength (B_0) . This choice to solve the equation for B_0 was completely arbitrary, only motivated by the foresight of how it fits into the fusion systems model. To solve the primary constraint, the confinement time scaling law will need to be introduced. At the end, a messy – albeit highly useful – relation will be the reward.

The energy confinement time $-\tau_E$ – is one of the most elusive terms in all of fusion energy. It is an attempt to boil all the chaotic nature of plasmas into a simple measure of how fast its internal energy would be ejected from

^{*} The denominator of Eq 3.24 has a discontinuity when the $K_{rad}\overline{T}^{1/2}$ term equals (σv) . This temperature sets a barrier between real reactors (for temperatures higher than it) and impossible reactors – at or below it.

the tokamak if the device was instantaneously shut off. As such, reactor designers have turned toward experimentalists for empirical scalings based on the world's tokamaks. These all share the form:

$$\tau_E = K_{\tau} H \frac{I_M^{\alpha_I} R_0^{\alpha_R} a^{\alpha_a} \kappa^{\alpha_{\kappa}} \overline{n}_{20}^{\alpha_n} B_0^{\alpha_B} A^{\alpha_A}}{(P_{src})^{\alpha_P}}$$
(3.28)

This mouthful of a formula is how the field actually designs machines. Let it be known, though, that this fit does a remarkable job having an error of less than 20% on interpolated data. The new terms in this equation are: K_{τ} , H, A, and the α_{\square} factors.

First, K_{τ} is simply a constant fit-makers use in their scalings. Next, H is the (H-Mode) scaling factor – the analogue of K_{τ} used by reactor designers – which can artificially boost the performance of machines (i.e. it helps with cheating). Continuing, A is the average mass number of the fuel source, in atomic mass units. For 50-50 D-T fuel, this is 2.5, as deuterium weighs two amus and tritium weights three. Lastly, the alpha factors (e.g. α_n , α_a , α_P) are fitting parameters that represent each variable's relative importance.

For ELMy H-Mode this confinement scaling can be written as:

$$\tau_E = 0.145 H \frac{I_M^{0.93} R_0^{1.39} a^{0.58} \kappa^{0.78} \overline{n}_{20}^{0.41} B_0^{0.15} A^{0.19}}{(P_{src})^{0.69}}$$
(3.29)

One final remark to make before moving on is that even these fits have subtleties. The value of κ , for example, may have a slightly different geometric meaning. And the exact definition of source power – P_{src} – introduces an even larger area of discrepancy.

Returning to the problem at hand, this model's Lawson Criterion (eq. 3.24) can be simplified after expanding the left-hand side $-\overline{n}\tau_E$ using the Greenwald density and a confinement time scaling law. Albeit a little cumbersome, this can be wrangled into an equation for B_0 !

$$B_0 = \left(\frac{G_{PB}}{K_{PB}} \cdot \left(I_P^{\alpha_I^*} R_0^{\alpha_R^*}\right)^{-1}\right)^{\frac{1}{\alpha_B}}$$
 (3.30)

$$G_{PB} = \frac{\overline{T} \cdot (\sigma v)^{\alpha_P}}{(\sigma v) - K_{rad} \overline{T}^{1/2}}$$
(3.31)

$$K_{PB} = H \cdot \left(\frac{K_{\tau}}{K_{law}}\right) \cdot \frac{(K_G)^{\alpha_n^*}}{(K_{PF})^{\alpha_P}} \cdot \left(\epsilon^{\alpha_a} \kappa^{\alpha_\kappa} A^{\alpha_A}\right)$$
(3.32)

Where we have added new starred alpha values for the density, current, and major radius:

$$\alpha_n^* = 1 + \alpha_n - 2\alpha_P \tag{3.33}$$

$$\alpha_I^* = \alpha_I + \alpha_n^* \tag{3.34}$$

$$\alpha_R^* = \alpha_R + \alpha_a + \alpha_P - 2(1 + \alpha_n) \tag{3.35}$$

This equation for B_0 – derived from power balance – is the primary constraint of our reactor designs. It is the first step in connecting the plasma (i.e. \overline{n} , \overline{T} , and I_P) with the tokamak (i.e. B_0 and R_0). The remaining step is finding an equation – or in this case, equations – for the major radius of the device. These equations will collectively be referred to as: the Secondary Constraints.

3.4Collecting Secondary Constraints

As of now, the only missing equation within our list of fixed variables – i.e. $R_0, B_0, \overline{T}, \overline{n}$, and I_P is for the major radius of the tokamak. This equation will come from around five potential limits, either physical or engineeringbased. Each limit will correspond to its own curve in reactor space. As will be shown, many of these reactors will be invalid (as they violate each other's secondary constraints).

Before tackling teh subject of finding reactors that exist on the fine line of satysfying all secondary constraints, it is essential to collect them one-byone. These are: the Troyon Beta Limit, the Kink Safety Factor, the Wall Loading Limit, the Power Cap Constraint, and the Heat Loading Limit. The goal of this section is to solve each of these constraints for the major radius. As with the primary constraint, this choice of solving for R_0 was completely arbitrary. It just so happens that each limit described here depends on the size of a reactor.

3.4.1 Introducing the Beta Limit

The Beta Limit is the most important secondary constraint – especially for steady-state reactors. It sets a maximum on the amount of pressure a plasma is willing to tolerate. As with future secondary constraints, literature-based equations will be transformed into formulas for R_0 , each with some limiting quantity that can be handled as a fixed variable – as β_N will be used shortly.

The starting point for the beta limit is to define the important plasma physics quantity: β – the plasma beta. This value is a ratio between a plasma's internal pressure and the pressure exerted on it by the tokamak's magnetic configuration. Mathematically,

$$\beta = \frac{\text{plasma pressure}}{\text{magnetic pressure}} = \frac{\overline{p}}{\left(\frac{B_0^2}{2\mu_0}\right)}$$
(3.36)

Using this model's temperature and density profiles, the volume-averaged pressure (\overline{p}) can be written in units of atmospheres (i.e. atm) as:

$$\overline{p} = 0.1581 (1 + f_D) \frac{(1 + \nu_n) (1 + \nu_T)}{1 + \nu_n + \nu_T} \overline{n} \overline{T}$$
(3.37)

Moving forward, the final step is plugging this definition for plasma beta into the physics-based Troyon Beta Limit. Although outside the scope of this text, it is a stability limit set by treating plasmas as a charge-carrying fluid. This equation can be written in the following form, where β_N is the normalized plasma beta – i.e. a fixed variable in this model usually set between 2% and 4%.

$$\beta = \beta_N \frac{I_P}{aB_0} \tag{3.38}$$

Substituting the plasma β from eq. 3.36, into this relation results in the model's first equation for tokamak radius:

$$R_0 B_0 = K_{TB} \overline{T} \tag{3.39}$$

$$K_{TB} = 4.027e - 2(K_G) \left(\frac{\epsilon}{\beta_N}\right) (1 + f_D) \frac{(1 + \nu_n)(1 + \nu_T)}{1 + \nu_n + \nu_T}$$
(3.40)

As mentioned, this is often the dominating constraint in a steady-state reactor. The dominating constraint for pulsed designs – the kink safety factor – will be the focus of the next subsection.

3.4.2 Giving the Kink Safety Factor

Just like how the Troyon Beta Limit set a fluids-based maximum on plasma pressure, the Kink Safety Factor sets one for a plasma's current. This constraint usually only appears in pulsed designs, as it is assumed that getting to this current in steady-state (with only LHCD) would prove extremely unpractical.

The starting point again is an equation from the literature for the kink condition:

$$q_{95} = 5\epsilon^2 f_q \cdot \frac{R_0 B_0}{I_P} \tag{3.41}$$

Here the safety factor $-q_{95}$ – is subscripted by 95, an identifier that this value is taken at the 95% flux surface (i.e. near the statistically drawn edge of the plasma). It typically has values around 3. Next, the f_q variable is a geometric scaling factor:

$$f_q = \frac{1.17 - 0.65\epsilon}{2(1 - \epsilon^2)^2} \cdot \left(1 + \kappa^2 * (1 + 2\delta^2 - 1.2\delta^3)\right)$$
 (3.42)

Combined, the kink safety factor can now be written in standardized units as:

$$R_0 = \frac{K_{SF}I_P}{B_0} (3.43)$$

$$K_{SF} = \frac{q_{95}}{5\epsilon^2 f_a} \tag{3.44}$$

This relation is the secondary constraint important for most pulsed reactor designs. As with the Beta Limit, the two are derived by plasma physics alone. The remaining secondary constraints, however, are engineering-based in origin – these include: the Wall Loading Limit, the Power Cap Constraint, and the Heat Loading Limit. Each will be defined shortly.

3.4.3 Working under the Wall Loading Limit

The first engineering-based secondary constraint – the wall loading limit – will prove to be an important quantity when determining the magnet strength at which reactor cost first starts to increase. As hinted, its definition is nuclear engineering in origin: it is a measure of the maximum neutron damage a tokamak's walls can take over the lifetime of the machine.

The first step in deriving a secondary constraint for wall loading is a description of the problem it models. In a reactor, fusion reactions typically make high-energy neutrons – at 14.1 MeV – that continually blast the inner wall of the tokamak. Therefore a quick-and-dirty metric would be limiting the amount of neutron power that can be unloaded on the surface area of a tokamak. This can be written as:

$$P_W = \frac{P_n}{S_P} \tag{3.45}$$

Here, S_P is the surface area of the tokamak's inner wall and P_n is the neutron power derived in the subsection on fusion power. The quantity, P_W , then served a role analogous to β_N for the beta limit and q_{95} for the kink safety factor – it is a fixed variable representing the maximum allowed wall loading. For fusion reactors, P_W is assumed to be around 2-4 $\frac{\text{MW}}{\text{m}^2}$. It will be shown that the wall loading limit is important in any tokamak – regardless of operating mode (i.e. steady-state or pulsed).

$$S_P = 4\pi^2 a_P R_0 \cdot \frac{\left(1 + \frac{2}{\pi} \left(\kappa_P^2 - 1\right)\right)}{\kappa_P}$$
 (3.46)

With the surface area dimensions being subscripted by P's.

$$a_P = 1.04 a (3.47)$$

$$\kappa_P = 1.3 \,\kappa \tag{3.48}$$

$$\epsilon_P = \frac{a_P}{R_0} \tag{3.49}$$

Finishing this secondary constraint, the Wall Loading limit can be written in standardized units as:

$$R_0 = K_{WL} \cdot I_P^{\frac{2}{3}} \cdot (\sigma v)^{\frac{1}{3}} \tag{3.50}$$

$$K_{WL} = \left(\frac{K_F K_n^2}{5\pi^2 P_W} \cdot \frac{\kappa_P}{\epsilon_P} \cdot \frac{1}{1 + \frac{2}{\pi} \cdot (\kappa_P^2 - 1)}\right)^{\frac{1}{3}}$$
(3.51)

3.4.4 Setting a Maximum Power Cap

As opposed to the previous three secondary constraints, the maximum power cap is more a rule of thumb. Because no reactor – coal, solar, or otherwise – has a 2500 MW reactor, neither should fusion. It makes sense from a practical position after realizing the long history of tokamaks being delayed, underfunded, or completely canceled. Mathematically, this has the simple form:

$$P_E \le P_{CAP} \tag{3.52}$$

Here, P_{CAP} is the maximum allowed power output of the reactor. Similar to the other limiting quantities, P_{CAP} is treated as a fixed variable (i.e. set to 2500 MW). The electrical power output of the reactor (P_E) is then related to the fusion power through:

$$P_E = 1.273 \,\eta_T \cdot P_F \tag{3.53}$$

The constant in front (1.273) represents some extra power the reactor makes as more fuel is bred when the fusion neutrons pass through a tokamak (inside

its blanket). The variable η_T is the thermal efficiency of the reactor – usually around 40%.

Next, substituting in for fusion power and solving for the tokamak's major radius results in:

$$R_0 = K_{PC} \cdot I_P^2 \cdot (\sigma v) \tag{3.54}$$

$$K_{PC} = K_F K_n^2 \cdot \left(\frac{1.273 \,\eta_T}{P_{max}}\right) \tag{3.55}$$

This secondary constraint can be used to create curves of reactors, although it is mainly used as a stopping point for designs – i.e. if you get to the power-cap regime, you have gone too far. This is different then the next constraint, which is basically a glorified warning sign in the contemporary tokamak paradigm.

3.4.5 Listing the Heat Loading Limit

Plasmas are hot. The commonly given fact is one electron volt is around 20,000 °F. Although a bit deceptive, melting a tokamak is an all too real concern. The problem is there is currently no solution to this problem. Although researchers have explored various types of heat divertors, none have been shown to withstand the gigawatts of heat emitted from a reactor-size tokamak. Further, as it is not as glamorous as plasma physics, attempts to tackle the problem head-on have often gone unfunded.

As such, this model takes the approach that we are no worse than the rest of the field. We almost completely ignore the heat load limit and just refer to it at the end, saying "and then the magical divertor will have to deal with solar corona levels of heat." After which, discussion will quickly be redirect to happier concerns.

For thoroughness though, a secondary constraint will still be derived. The first step is giving the heat load limit commonly found in the literature:

$$q_{DV} = K_{DV} \frac{P_F I_P^{1.2}}{R_0^{2.2}}$$
 (3.56)

$$K_{DV} = \frac{18.31e - 3}{\epsilon^{1.2}} \cdot K_P \cdot \left(\frac{2}{1 + \kappa^2}\right)^{0.6} \tag{3.57}$$

After a simple rearrangement and substitution for fusion power, this becomes:

$$R_0 = K_{DH} \cdot I_P \cdot (\sigma v)^{\frac{1}{3.2}} \tag{3.58}$$

$$K_{DH} = \left(\frac{K_{DV} K_F K_n^2}{q_{DV}}\right)^{\frac{1}{3.2}} \tag{3.59}$$

At this point all the secondary constraints have been defined. The next step is taking a step back and motivating the derivation of a current equation suitable for pulsed tokamaks.

3.5 Summarizing the Fusion Systems Model

This chapter focused on the bigger picture behind designing a zero-dimensional fusion systems model. It started with a description of various design parameters and then segued into explaining the five relations needed to close the model – i.e. for \overline{T} , \overline{n} , I_P , B_0 , and R_0 .

Before moving onto generalizing the steady current to model pulsed reactors, a quick recap of the equations will prove beneficial. The first variable tackled was temperature – i.e. scan five evenly-space \overline{T} values between 10 and 30 keV. This was then quickly followed by the Greenwald density limit – the cornerstone of this framework. Through equations, these two can be written as:

$$\overline{T} = const. \tag{3.1}$$

$$\overline{n} = K_n \cdot \frac{I_P}{R_0^2} \tag{3.2}$$

The next variable handled was the steady current:

$$I_P = \frac{K_{BS}\overline{T}}{1 - K_{CD}(\sigma v)} \tag{3.3}$$

As was mentioned before, this only directly depends on temperature, but is strongly affected by a tokamak's configuration $-R_0$ and B_0 - through the current drive efficiency (η_{CD}) . For pulsed reactors, this equation proves too simple as it ignores inductive current. To remedy this situation, current balance will be revisited next chapter. The main point to make now is the R_0 and R_0 dependence will now be explicit.

Moving on, the remaining equations were the primary and secondary constraints for B_0 and R_0 , respectively. It was through these relations that a tokamak's configuration was brought into the fold. The choice of solving the two constraints for their respective variables was completely arbitrary – motivated only by foresight of how they fit into the model. Without repeating them now, they served as the proper vehicles for closing the system of equations. The next step now is to learn how to generalize the current formula and design a pulsed tokamak.