1 List of changes

2	Replaced: Static	•	•	•	•		•		•	٠	•	•	•		•	•	11
3	Replaced: Dynamic					•		 									11
4	Replaced: Intermediate					•		 									13
5	Replaced: Dynamic					•		 									13
6	Replaced: Static					•		 									14
7	Replaced: Static					•		 									17
8	Added: of operation							 			•						29
9	Replaced: dynamic					•		 									29
10	Replaced: static					•		 									29
11	Replaced: static					•		 									29
12	Replaced: dynamic							 	•	•	•				•		29
13	Replaced: Dynamic					•		 									29
14	Added: (see Table 3.1)					•		 									29
15	Replaced: Static					•		 									29
16	Added: The overall structure							 			•				•		30
17	Replaced: many hours					•		 									30
18	Added: density							 	•	•	•				•		30
19	Added: – see Fig. 2-1					•		 									30
20	Replaced: Is it stretched out like					•		 							•		30
21	Replaced: cross-sections							 			•						31
22	Replaced: result from a slice acr							 			•			 •	•		31
23	Added: Their exact usage wit							 									31

24	Replaced: essentially parabolas		•	•			•	 •			•	•		•	32
25	Added: density						•			•					32
26	Replaced: profiles														33
27	Deleted: profiles						•						•		33
28	Added: just												•		33
29	Added: Although not self													•	33
30	Added: The reason \overline{n} is referr												•		34
31	Added: A final point to make	•												•	34
32	Added: Density			•		•	•							•	34
33	Added: density			•		•	•							•	34
34	Added: These are derived in $A \dots$			•			•						•	•	35
35	Replaced: The steady current wi	•												•	35
36	Replaced: a density limit that a														36
37	Replaced: disrupt.	•												•	36
38	Added: These conclusions can														36
39	Added: and	•												•	36
40	Added: .	•												•	36
41	Deleted: and π has its usual m						•						•		36
42	Replaced: it accurately predicts														37
43	Deleted: (i.e. the ones we use)	•												•	38
44	Replaced: dynamic	•												•	38
45	Replaced: static												•	•	38
46	Replaced: static									•				•	38
47	Replaced: in equilibrium														38

48	Replaced: Its underlying behavi	•	•	•	•	•	•	•	 •	٠	•	•	•	•	•	•	•	38
49	Replaced: Utilizing the surface i						•											38
50	Deleted: Here, Q is an arbitrar \dots .						•											38
51	Deleted: This allows the boots \dots .															•		39
52	Added: The second definition					•	•							•				39
53	Deleted: For a more formal loo						•	•										39
54	Added: The instructions to do						•	•										39
55	Deleted: Getting back on track										•							39
56	Deleted: Recognizing that the l						•											39
57	Deleted: In standardized units,						•											39
58	Added: Finally, summarizing						•	•										40
59	Replaced: static																	40
60	Deleted: The next segue on our						•	•						•				40
61	Deleted: The natural place to s						•							•				40
62	Deleted: What this reaction de															•		41
63	Deleted: The final point to ma															•		41
64	Added: The next segue on our										•							41
65	Replaced: Summarized, though,										•							41
66	Replaced: the following volume i															•		41
67	Added: (f_D) . This dilution fa															•		41
68	Replaced: dynamic						•							•				42
69	Deleted: As mentioned before,						•							•				43
70	Replaced: this chapter's													•				43
71	Replaced: static																	43

72	Replaced: static	•	•	•		•					•		 •		•	44
73	Replaced: static						•		•							44
74	Replaced: The											•				44
75	Replaced: chapter							•	•	•		•	 •	•		44
76	Added: Further, each temper \dots .								•	•			 •	•		45
77	Replaced: static	•						•		•		•				47
78	Replaced: dynamic	•						•		•		•				47
79	Replaced: dynamic	•						•		•		•				47
80	Replaced: Static	•						•		•		•				47
81	Replaced: static	•						•		•		•				47
82	Replaced: static						•					•				47
83	Replaced: static															47
84	Replaced: static	•						•		•		•				47
85	Replaced: Dynamic				•			•		•		•			•	48
86	Replaced: Dynamic	•						•		•		•				48
87	Replaced: static						•					•				63
88	Replaced: static						•					•				64
89	Replaced: static						•					•				64
90	Replaced: static															67
91	Replaced: static	•						•		•		•				68
92	Added: reactor design .							•	•	•		•			•	73
93	Added: This generalized plas															73
94	Replaced: This is described by $t \dots$		•					•	•					٠	•	74
95	Added: During this time, a pl															76

96	Added: The exact definitions f	 77
97	Replaced: static	 83
98	Added: (valid for a circular pl	 88
99	Replaced: dynamic	 92
100	Replaced: static	 93
101	Replaced: static	 93
102	Replaced: dynamic	 93
103	Replaced: static	 94
104	Replaced: dynamic	 96
105	Replaced: dynamic	 97
106	Replaced: intermediate	 103
107	Replaced: dynamic	 103
108	Replaced: dynamic (D)	 103
109	Replaced: intermediate (I)	 103
110	Replaced: dynamic	 104
111	Replaced: intermediate	 104
112	Replaced: dynamic	 104
113	Replaced: static	 104
114	Replaced: Intermediate	 105
115	Replaced: intermediate	 105
116	Replaced: Dynamic	 105
117	Replaced: dynamic	 105
118	Replaced: static	 109
119	Replaced: static	 109

120	Replaced: dynamic	•	•	٠	•	 •	٠	٠	•	 •	•	•	•	 •	117
121	Replaced: static									 					120
122	Replaced: dynamic			•		 	•			 	•				124
123	Replaced: static			•			•			 	•				124
124	Replaced: static			•			•			 	•				131
125	Replaced: Static			•			•			 	•				147
126	Replaced: Static			•			•			 	•				147
127	Replaced: static			•			•			 	•				152
128	Replaced: static			•			•			 	•				153
129	Replaced: dynamic									 				 -	154
130	Replaced: static			•						 				 -	154
131	Replaced: dynamic			•			•			 					154
132	Replaced: static			•			•			 	•				154
133	Replaced: dynamic									 				 _	154

Chapter 4

Designing a Pulsed Tokamak

```
Pulsed tokamaks are the flagship of the European fusion reactor design effort. As such,
1201
     this paper's model will now be generalized to accommodate this mode of operation.
1202
     Fundamentally, this involves transforming current balance into flux balance – adding
1203
     inductive (pulsed) sources to stand alongside the LHCD (steady-state) ones.
1204
     The first step in generalizing current balance will be understanding the problem from
1205
     a basic electrical engineering perspective – i.e. with circuit analysis. The resulting
1206
     equation will then be transformed into the flux balance seen in other models from
1207
     the literature. All that will need to be done then is solving the problem for plasma
1208
     current (I_P) and simplifying it for various situations – e.g. steady-state operation.
1209
     This generalized plasma current will then be found to be a function of the other
1210
    dynamic variables (i.e. R_0, B_0, and \overline{T}). This, of course, is more difficult to handle
1211
     computationally than the steady current, which only directly depended on tempera-
1212
     ture (\overline{T}). Discussion about solving this new root solving problem will be the topic of
1213
    the next chapter.
1214
```

₅ 4.1 Modeling Plasmas as Circuits

Although it may have been lost along the way, what makes plasmas so interesting and 1216 versatile – in comparison to gases – is their ability to respond to electric and magnetic 1217 fields. It seems natural then to model plasma current from a circuits perspective (i.e. 1218 with resistors, voltage sources, and inductors). By name, this circuit is referred to as 1219 a transformer where: the plasma is the secondary and the yet-to-be discussed central 1220 solenoid (of the tokamak) is the primary. 1221 The first step in deriving a current equation is to determine the circuit equations 1222 that govern pulsed operation in a tokamak. This will be done in two steps. First, we 1223 will draw a circuit diagram and write the equations that describe it. Next, we will 1224 use a simple schematic for how current evolves in a transformer to boil the resulting 1225 differential equations into simple algebraic ones – as is the hallmark of our model. 1226

227 4.1.1 Drawing the Circuit Diagram

Understanding a circuit always starts with drawing a simple diagram, see Fig. 4-1.

This figure depicts the transformer governing pulsed reactor. The left sub-circuit is the transformer's primary – the central solenoid component of the tokamak that provides most of the inductive current. Whereas, the right sub-circuit is the plasma acting as the transformer's secondary. The central solenoid, here, is then a helically-spiraled metal coil that fits within the inner ring of the doughnut. For now, every other flux source (besides this central solenoid) is neglected.

This is described by the standard circuits involving voltage sources, resistors, and inductors: Hopefully without scaring the reader too much, the circuit equations when only modeling voltage sources, resistors, and inductors—are described by:

$$V_{i} = \sum_{j}^{n} \frac{d}{dt} (M_{ij}I_{j}) + I_{i}R_{i} , \quad \forall i = 1, 2, .., n$$
(4.1)




Figure 4-1: A Simple Plasma Transformer Description

Without going into the inductances (M) and resistances (R), the variable n is the number of sub-circuits, here being 2. Whereas, the variables i and j are the indices of sub-circuits (i.e. 1 for the primary, 2 for the secondary). For illustrative purposes, this would boil down to the following relation for a battery attached to a lightbulb:

$$V = IR (4.2)$$

Back to the transformer diagram, the equations for the two subcircuits can be expanded and greatly simplified. Besides ignoring every inductive source other than the central solenoid, the next powerful assumption is treating the solenoid as a superconductor (i.e. with negligible resistance). Lastly, the inductances between components and themselves are held constant – independent of time. This allows the coupled transformer equations to be written as:

$$V_1 = L_1 \dot{I}_1 - M \dot{I}_2 \tag{4.3}$$

$$-I_2 R_P = L_2 \dot{I}_2 - M \dot{I}_1 \tag{4.4}$$

With I_1 and I_2 going in opposite directions. Note, here, that the subscript on M has been dropped, as there are only two components. This was done in conjunction to adding internal (self-)inductance terms. Mathematically, the mapping between variables is:

$$M = M_{12} = M_{21} (4.5)$$

$$L_1 = M_{11} (4.6)$$

$$L_2 = M_{22} (4.7)$$

Repeated, the one subscript represents the primary – the central solenoid – and the two stands for the plasma as the transformer's secondary. Exact definitions for the inductances will be put off till the end of the next subsection.

1255 4.1.2 Plotting Pulse Profiles

Up until now, little has been discussed that has a time dependence. For steady-state tokamaks, this did not occur because it is an extreme case where pulses basically last the duration of the machine's lifespan (i.e. around 50 years). By definition, though, a pulsed machine has pulses – with around ten scheduled per day. For this reason, a fusion pulse is now investigated in detail.

Transformer pulses between the central solenoid and the plasma occur on the timescale of hours. During this time, a plasma is brought up to some quasi-steady-state current (I_P^*) for around an hour and then ramped back down using the available flux in the solenoid (measured in volt-seconds). For clarity, each pulse is subdivided into four phases: ramp-up, flattop, ramp-down, and dwell. Pictorially represented in Fig. 4-2, these divisions allow a simple scheme for transforming the coupled circuit differential equations – from Eqs. (4.3) and (4.4) – into simple algebraic formulas.

Along the way, we will approximate derivatives with linear piecewise functions. Using t_i to represent the initial time and t_f as the final one, these can be written as:

Tokamak Circuit Profiles




Figure 4-2: Time Evolution of Circuit Profiles

$$\dot{I} = \frac{I(t_f) - I(t_i)}{t_f - t_i} \tag{4.8}$$

1270 In tabular form, the data from Fig. 4-2 can be written in this piecewise fashion as:

Table 4.1: Piecewise Linear Scheme for Pulsed Operation

(a)	Currents			(b) Voltage											
\mathbf{Time}	I_1	$ I_2 $		Phase	$\mathbf{t_i}$	$\mathbf{t_f}$	$\mathbf{V_1}$								
0	$-I_{max}$	0	_	Ramp-Up	0	t_1	$+V_{max}$								
t1	-I	I_P^*		Flattop	t_1	t_2	$+\tilde{V}$								
t2	$+I_{max}$	I_P^*		Ramp-Down	t_2	t_3	$-V_{max}$								
t3	$+\tilde{I}$	0		Dwell	t_3	t_4	$-V_{max}$								
t4	$-I_{max}$	0					•								

The exact definitions for the plasma's inductive current (I_P^*) and the maximum voltage age in the central solenoid (V_{max}) will be put off til the end of the section.

1273 The Ramp-Up Phase – RU

The first phase in every plasma pulse is the ramp-up. During ramp-up, the central solenoid starts discharging from its fully charged values, as the plasma is brought to its quasi-steady-state current. As this occurs on the timescale of minutes – not hours – resistive effects of the plasma can safely be ignored. This results in the ramp-up equations becoming:

$$V_{max} = \frac{1}{\tau_{RU}} \cdot \left(L_1 \cdot (I_{max} - \tilde{I}) - M \cdot I_{ID} \right)$$
(4.9)

$$0 = \frac{1}{\tau_{RU}} \cdot \left(M \cdot (I_{max} - \tilde{I}) - L_2 \cdot I_{ID} \right)$$

$$\tag{4.10}$$

Simplifying these equations will be done shortly, for now the new terms are what is important. The maximum voltage of the solenoid is V_{max} . Next, I_{max} is the solenoid's current at the beginning of ramp-up. Whereas \tilde{I} is the magnitude of the current once the plasma is at its flattop inductive-drive current $-I_{ID}$. The τ_{RU} quantity, then, is the duration of time it takes to ramp-up (i.e. RU). Again, L_1 and L_2 are the internal inductances of the solenoid and plasma, respectively, and M is the mutual inductance between them.

The last step in discussing ramp-up is giving the two important formulas that come from it:

$$\tilde{I} = I_{max} - I_{ID} \cdot \left(\frac{L_2}{M}\right) \tag{4.11}$$

$$\tau_{RU} = \frac{I_{ID}}{V_{max}} \cdot \left(\frac{L_1 L_2 - M^2}{M}\right) \tag{4.12}$$

1288 The Flattop Phase - FT

The most important phase in any reactor's pulse is flattop – the quasi-steady-state time when the tokamak is making electricity (and money). Flattops are assumed to last a couple of hours for a profitable machine, during which the central solenoid completely discharges to overcome a plasma's resistive losses – keeping it in a quasi-steady-state mode of operation. In a steady-state reactor, this phases constitutes the entirety of the pulse.

Although the resistance cannot be safely neglected for flattop – as it was for ramp-up – the plasma's inductive current (I_{ID}) is assumed constant. This leads to its derivative in equations cancelling out! Mathematically,

$$\tilde{V} = \frac{L_1}{\tau_{FT}} \cdot \left(I_{max} + \tilde{I} \right) \tag{4.13}$$

$$I_{ID}R_P = \frac{M}{\tau_{FT}} \cdot \left(I_{max} + \tilde{I}\right) \tag{4.14}$$

As with ramp-up, the simplifications will be given shortly. The new terms here, however, are an intermediate voltage for the central solenoid (\tilde{V}) , and the duration of the flattop (τ_{FT}) . The resistance term was given in Eq. (3.10). Solutions can then be found by substituting \tilde{I} – from Eq. (4.11) – into the flattop equations:

$$\tilde{V} = I_{ID}R_P \cdot \left(\frac{L_1}{M}\right) \tag{4.15}$$

$$\tau_{FT} = \frac{I_{max} \cdot 2M - I_{ID} \cdot L_2}{I_{ID}R_P} \tag{4.16}$$

1302 The Ramp-Down Phase – RD

Due to the simplicity – and symmetry – of this model's reactor pulse, ramp-down is the exact mirror of ramp-up. It takes the same amount of time and results in the same algebraic equations. For brevity, this will just be represented as:

$$\tau_{RD} = \tau_{RU} \tag{4.17}$$

For clarity, this is the time when a plasma's current is brought down from its flattop value to zero.

1308 The Dwell Phase – DW

Where the first three phases had little ambiguity, the dwell phase changes definition from model to model. For now, it is assumed to be the time it takes the central solenoid to reset after a plasma has been completely ramped-down to an off-mode. To get a more realistic duty factor for cost estimates, it could include an evacuation time, set to last around thirty minutes. During this evacuation, a plasma is vacuumed out of a device as it undergoes some inter-pulse maintenance.

Ignoring evacuation for now, the dwell phase involves resetting the central solenoid
when the plasma's current is negligible. This fundamentally means the secondary of
the transformer is nonexistent – the central solenoid is the entire circuit. In equation
form,

$$V_{max} = \frac{L_1}{\tau_{DW}} \cdot \left(I_{max} + \tilde{I} \right) \tag{4.18}$$

Or substituting in \tilde{I} and solving for τ_{DW} ,

$$\tau_{DW} = \frac{L_1}{M} \cdot \frac{(I_{max} \cdot 2M - I_{ID} \cdot L_2)}{V_{max}} \tag{4.19}$$

320 4.1.3 Specifying Circuit Variables

The goal now is to collect the results from the four phases and introduce the inductance, resistance, voltage, and current terms relevant to our model. This will motivate recasting the problem as flux balance in a reactor – the form commonly used in the literature (and discussed next section).

1325 First, collecting the phase durations in one place:

$$\tau_{RU} = \frac{I_{ID}}{V_{max}} \cdot \left(\frac{L_1 L_2 - M^2}{M}\right) \tag{4.12}$$

$$\tau_{FT} = \frac{I_{max} \cdot 2M - I_{ID} \cdot L_2}{I_{ID}R_P} \tag{4.16}$$

$$\tau_{RD} = \tau_{RU} \tag{4.17}$$

$$\tau_{DW} = \frac{L_1}{M} \cdot \frac{(I_{max} \cdot 2M - I_{ID} \cdot L_2)}{V_{max}} \tag{4.19}$$

These can be used in the definition of the duty-factor: the fraction of time a reactor is putting electricity on the grid. Formulaically,

$$f_{duty} = \frac{\tau_{FT}}{\tau_{mulse}} \tag{4.20}$$

$$\tau_{pulse} = \tau_{RU} + \tau_{FT} + \tau_{RD} + \tau_{DW} \tag{4.21}$$

As will turn out, the solving of pulsed current actually only involves Eq. (4.16). What is interesting about this, is that there is no explicit dependence on ramp-down or dwell! Whereas ramp-up passes \tilde{I} to the flattop phase, the other two are just involved in calculating the duty factor.

The remainder of this subsection will then be defining the following circuit variables: I_{ID} , I_{max} , V_{max} , L_1 , L_2 , and M. Again, the resistance was defined last chapter as:

$$R_P = \frac{K_{RP}}{R_0 \overline{T}^{3/2}} \tag{3.10}$$

The Inductive Current $-I_{ID}$

The inductive current is the source of current that separates pulsed from steady-state operation. Quickly fitting it into the previous definitions of current balance – see Eq. (3.3):

$$I_{ID} = I_P - (I_{BS} + I_{CD}) (4.22)$$

As before, I_P is the total plasma current in mega-amps, I_{BS} is the bootstrap current, and I_{CD} is the current from LHCD (i.e. lower hybrid current drive). For this model, the relation can be rewritten as:

$$I_{ID} = I_P \cdot \left(1 - K_{CD}(\sigma v)\right) - K_{BS}\overline{T}$$
(4.23)

The Central Solenoid Maximums – V_{max} and I_{max}

For this simple model, the central solenoid has two maximum values: the voltage and current. The voltage is the easier to give value. Literature values have this around: ²³

$$V_{max} \approx 5 \,\text{kV}$$
 (4.24)

The maximum current, on the other hand, can be defined through Ampere's Law on a helically-shaped central solenoid: ¹³

$$I_{max} = \frac{B_{CS}h_{CS}}{N\mu_0} \tag{4.25}$$

Here, B_{CS} is a magnetic field strength the central solenoid is assumed to operate at (i.e. 12 T), h_{CS} is the height of the solenoid, N is the number of loops, and μ_0 has its usual physics meaning (i.e. $40 \pi \frac{\mu H}{m}$). As will be seen, the value of N does not directly affect the model, as it cancels out in the final flux balance. The height of the central

solenoid will be the focus of an upcoming section on improving tokamak geometry.

The Central Solenoid Inductance – L_1

For a central solenoid with circular cross-sections of finite thickness (d), the inductance can be written as:²⁰

$$L_1 = G_{LT} \cdot \left(\frac{\mu_0 \pi N^2}{h_{CS}}\right) \tag{4.26}$$

$$G_{LT} = \frac{R_{CS}^2 + R_{CS} \cdot (R_{CS} + d) + (R_{CS} + d)^2}{3}$$
(4.27)

Note that R_{CS} is the inner radius of the central solenoid and $(R_{CS} + d)$ is the outer one. In the limit where d is negligible, this says that the inductance is quadratically dependent on the radius of the central solenoid:

$$\lim_{d \to 0} G_{LT} = G_{LT}^{\dagger} = R_{CS}^{2} \tag{4.28}$$

The formulas for both R_{CS} and d will be defined in a few sections.

The Plasma Inductance – L_2

The plasma inductance is a composite of several different terms, but overall scales with radius. Through equation,

$$L_2 = K_{LP} R_0 (4.29)$$

This staticfixed coefficient – K_{LP} – then combines three inductive behaviors of the plasma. The first is its own self inductance (through l_i).⁵ The next is a resistive component through the Ejima coefficient, C_{ejima} , which is usually set to $\sim \frac{1}{3}$.¹⁹ And lastly, a geometric component – involving ϵ and κ – is given by the Hirshman-Neilson

model.²⁴ Mathematically,

$$K_{LP} = \mu_0 \cdot \left(\frac{l_i}{2} + C_{ejima} + \frac{(b_{HN} - a_{HN})(1 - \epsilon)}{(1 - \epsilon) + \kappa d_{HN}}\right)$$
(4.30)

Here the HN values come from the 1985 Hirshman-Neilson paper:

$$a_{HN}(\epsilon) = 2.0 + 9.25\sqrt{\epsilon} - 1.21\epsilon$$
 (4.31)

$$b_{HN}(\epsilon) = \ln(8/\epsilon) \cdot (1 + 1.81\sqrt{\epsilon} + 2.05\epsilon) \tag{4.32}$$

$$d_{HN}(\epsilon) = 0.73\sqrt{\epsilon} \cdot (1 + 2\epsilon^4 - 6\epsilon^5 + 3.7\epsilon^6) \tag{4.33}$$

1367 The Mutual Inductance – M

The mutual inductance – M – represents the coupling between the solenoid primary and the plasma secondary. A common method for treating this mutual inductance is through a coupling coefficient, k, that links the two self-inductances. Formulaically,

$$M = k\sqrt{L_1 L_2} \tag{4.34}$$

The value of the coupling coefficient, k, is always less than (or equal to) 1, but usually has a value around one-third. With all the equations defined, we are now at a position to explain one of the larger nuances of this fusion systems framework: declaring the pulse length of a tokamak.

1375 4.1.4 Reasoning the Pulse Length

This subsection focuses on a quantitative estimate for how to select a pulse length.

As no fusion reactor exists in the world today, the writers believe this is an acceptable

calculation. Further, the resulting length of two hours matches the durations of other studies in the literature.

Starting at the end, our goal is to find the pulse length of a tokamak reactor in seconds. The first piece of information is the expected lifetime of the central solenoid, $N \approx 10$ years. The next is the desired number of shots the machine will likely have, $M \approx 50,000$ shots.* This gives the ballpark estimate of around 10 pulses a day – or a pulse length of two hours.

With the pulse length defined, we are now in a position to justify neglecting the duty factor for pulsed reactors in this model. Using ballpark reactor values – while assuming the central solenoid has around 4000 turns – leads to the following scalings:

$$\tau_{FT} \sim \tau_{pulse} \sim O(\text{hours})$$
 (4.35)

$$\tau_{RU} \sim \tau_{RD} \sim \tau_{DW} \sim O(\text{mins})$$
 (4.36)

As such, even pulsed tokamak reactors should have a duty factor of around unity:

$$f_{duty} \approx 1$$
 (4.37)

Now that all the terms in a pulsed circuit have been explored, we will move on to rearranging the flattop equation to reproduce flux balance. This will then naturally lead to a generalized current equation – which is the main result of the chapter.

392 4.2 Salvaging Flux Balance

The goal of this section is to arrive at a conservation equation for flux balance that mirrors the ones in the literature. The fusion systems model this one attempts to

^{*}This 50,000 shots comes from multiplying the number of pulses run at Diii-D per year by the expected lifetime of the central solenoid (10 years).²⁵

follow most is the PROCESS code. ¹⁹ In a manner similar to power balance, flux balance can be written as:

$$\sum_{sources} \Phi = \sum_{sinks} \Phi \tag{4.38}$$

1397 4.2.1 Rearranging the Circuit Equation

The way to arrive at flux balance from the circuit equation is to rearrange the flattop phase's duration equation:

$$\tau_{FT} = \frac{I_{max} \cdot 2M - I_{ID} \cdot L_2}{I_{ID}R_P} \tag{4.16}$$

Multiplying by the right-hand side's denominator and moving the negative term over yields:

$$2MI_{max} = I_{ID} \cdot (L_2 + R_P \tau_{FT}) \tag{4.39}$$

This equation is flux balance, where the left-hand side are the sources (e.g. the central solenoid), and the other terms are the sinks (i.e. ramp-up and flattop). The source term can currently be encapsulated in:

$$\Phi_{CS} = 2MI_{max} \tag{4.40}$$

The sinks, namely the ramp-up inductive losses (Φ_{RU}) and the flattop resistive losses (Φ_{FT}) , are what drain up the flux. Again, ramp-down and dwell are not included as sinks because flux balance only tracks till the end of flattop. They come into play when measuring the cost of electricity – through the duty factor from Eq. (4.20).

Relabeling terms, flux balance can now be rewritten as:

$$\Phi_{CS} = \Phi_{RU} + \Phi_{FT} \tag{4.41}$$

1410 With the ramp-up and flattop flux given respectively by:

$$\Phi_{RU} = L_2 \cdot I_{ID} \tag{4.42}$$

$$\Phi_{FT} = (R_P \tau_{FT}) \cdot I_{ID} \tag{4.43}$$

On comparing these quantities to the ones from the PROCESS team, Φ_{RU} and Φ_{FT} are exactly the same. The source terms, on the other hand, are off for two reasons – both related to the central solenoid being the only source term in flux balance. This can partially be remedied by adding the second most dominant source of flux a posteriori – i.e. the PF coils. The second, and inherently limiting factor, is the simplicity of the current model. All that can be shown to this regard is that the Φ_{CS} terms does reasonably predict the values from PROCESS.

¹⁴¹⁸ 4.2.2 Importing Poloidal Field Coils

Adding the effect of PF coils – belts of current driving plates on the outer edges of the tokamak – leads to a second-order improvement over relying solely on the central solenoid for flux generation. From the literature, this can be modeled as:²⁰

$$\Phi_{PF} = \pi B_V \cdot \left(R_0^2 - (R_{CS} + d)^2 \right) \tag{4.44}$$

Where again R_{CS} and d are the inner radius and thickness of the central solenoid, respectively. These will be the topic of the next section.

Moving forward, the vertical field $-B_V$ – is a magnetic field oriented up-and-down with the ground. It is needed to prevent a tokamak plasma from spinning out of the

machine. From the literature, the magnitude of this vertical field (valid for a circular plasma) is given by: 19

$$|B_V| = \frac{\mu_0 I_P}{4\pi R_0} \cdot \left(\ln\left(\frac{8}{\epsilon}\right) + \beta_p + \frac{l_i}{2} - \frac{3}{2} \right)$$
 (4.45)

Analogous to the previously covered plasma beta, the poloidal beta can be represented by:²⁶

$$\beta_p = \frac{\overline{p}}{\left(\frac{\overline{B_p}^2}{2\mu_0}\right)} \tag{4.46}$$

Where the average poloidal magnetic field comes from a simple application of Ampere's law:

$$\overline{B_p} = \frac{\mu_0 I_P}{l_p} \tag{4.47}$$

The variable l_p is then the perimeter of the tokamak's cross-sectional halves:

$$l_p = 2\pi a \cdot \sqrt{g_p} \tag{4.48}$$

1433 Here, g_p is another geometric scaling factor,

$$g_p = \frac{1 + \kappa^2 (1 + 2\delta^2 - 1.2\delta^3)}{2} \tag{4.49}$$

Boiled down, this relation for the magnitude of the vertical magnetic field can be written in standardized units as:

$$|B_V| = \left(\frac{1}{10 \cdot R_0}\right) \cdot \left(K_{VI}I_P + K_{VT}\overline{T}\right) \tag{4.50}$$

$$K_{VT} = K_n \cdot (\epsilon^2 g_P) \cdot (1 + f_D) \frac{(1 + \nu_n) (1 + \nu_T)}{1 + \nu_n + \nu_T}$$
(4.51)

$$K_{VI} = \ln\left(\frac{8}{\epsilon}\right) + \frac{l_i}{2} - \frac{3}{2} \tag{4.52}$$

For clarity, this will be plugged into the new PF coil flux contribution (Φ_{PF}) :

$$\Phi_{PF} = \pi B_V \cdot \left(R_0^2 - (R_{CS} + d)^2 \right) \tag{4.44}$$

1437 Which then gets plugged into a more complete flux balance:

$$\Phi_{CS} + \Phi_{PF} = \Phi_{RU} + \Phi_{FT}$$

$$(4.53)$$

The R_{CS} and d terms found in Φ_{PF} will now be discussed as they are needed for this more sophisticated tokamak geometry.

4.3 Improving Tokamak Geometry

From before, this fusion systems model has been said to depend on the major and minor radius $-R_0$ and a, respectively - and along the way, various geometric parameters have been defined (e.g. ϵ , κ , δ) to describe the geometry further. Now three more thicknesses will be added: b, c, and d. Additionally, two fundamental dimension corresponding to the solenoid will be given: the radius (R_{CS}) and height (h_{CS}) . These are the topics of this section.

4.3.1 Defining Central Solenoid Dimensions

The best way to conceptualize tokamak geometry is through cartoon – see Fig. E
What this says is there is a gap at the very center of a tokamak. This gap

Tokamak Dimension Diagram




Figure 4-3: Dimensions of Tokamak Cross-Section

extends radially outwards to R_{CS} meters where the slinky-shaped central solenoid – of thickness d – begins. Between the outer edge of the solenoid and the wall of the torus (i.e. the doughnut) are the blanket and toroidal field (TF) coils.

The blanket and TF coils have thicknesses of b and c, respectively. Before defining b, c, and d, though, it proves fruitful to relate all the quantities in equations for the inner radius (R_{CS}) and height (h_{CS}) of the central solenoid.

$$R_{CS} = R_0 - (a+b+c+d) (4.54)$$

$$h_{CS} = 2 \cdot (\kappa a + b + c) \tag{4.55}$$

Again, this relation is pictorially represented in Fig. E-2. The next step is defining: b, c, and d - to close the variable loop.

458 4.3.2 Measuring Component Thicknesses

In between the inner surface of the central solenoid and the major radius of the tokamak are four thicknesses: a, b, c, and d. This subsection will go over them one-by-one.

The Minor Radius -a

The minor radius was the first of these thicknesses we encountered. To calculate it, we introduced the inverse aspect ratio (ϵ) to relate it to the major radius (R_0):

$$a = \epsilon \cdot R_0 \tag{2.1}$$

The Blanket Thickness -b

The blanket is an area between the TF coils and the torus that is strongly composed of lithium. It serves to both: protect the superconducting magnet structures from neutron damage, as well as breed a little more tritium fuel from stray fusion neutrons.

In equation form, the blanket thickness is given by:²²

$$b = 1.23 + 0.074 \ln P_W \tag{4.56}$$

Here, the constant term (i.e. 1.23) is approximately the mean-free-path of fusion neutrons through lithium-7 – the thickness of lithium needed to reduce the population of neutrons by $\sim 65\%$. While the second term, which includes P_W , is a correction to account for extra wall loading (as discussed in the secondary constraint section). Moving forward, the remaining two thicknesses – c and d – are handled differently,

estimating structural steel portions as well as magnetic current-carrying ones.

The Toroidal Field Coil Thickness – c

The thickness of the TF coils -c – is a little beyond the scope of this paper. It does, however, have a form that combines a structural steel component with a magnetic portion. From one of Jeff's previous models, this can be given as:²²

$$c = G_{CI}R_0 + G_{CO} (4.57)$$

$$G_{CI} = \frac{B_0^2}{4\mu_0\sigma_{TF}} \cdot \frac{1}{(1 - \epsilon_b)} \cdot \left(\frac{4\epsilon_b}{1 + \epsilon_b} + \ln\left(\frac{1 + \epsilon_b}{1 - \epsilon_b}\right)\right) \tag{4.58}$$

$$G_{CO} = \frac{B_0}{\mu_0 J_{TF}} \cdot \frac{1}{(1 - \epsilon_b)} \tag{4.59}$$

The critical stress $-\sigma_{TF}$ in G_{CI} implies it depends on the structural component, whereas the maximum current density $-J_{TF}$ – implies a magnetic predisposition in G_{CO} . The use of G_{\Box} in these quantities, instead of K_{\Box} is because they include the toroidal magnetic field strength $-B_0$. For this reason, they are referred to as dynamicfloating coefficients. Lastly, the term ϵ_b represents the blanket inverse aspect ratio that combines the minor radius with the blanket thickness:

$$\epsilon_b = \frac{a+b}{R_0} \tag{4.60}$$

The Central Solenoid Thickness -d

Finishing this discussion where we started, the central solenoid's thickness -d has a form similar to the TF coil's (i.e. c). In mathematical form, this can be represented as:²²

$$d = K_{DR}R_{CS} + K_{DO} (4.61)$$

$$K_{DR} = \frac{3B_{CS}^2}{6\mu_0 \sigma_{CS} - B_{CS}^2} \tag{4.62}$$

$$K_{DO} = \frac{6B_{CS}\sigma_{CS}}{6\mu_0\sigma_{CS} - B_{CS}^2} \cdot \left(\frac{1}{J_{OH}}\right) \tag{4.63}$$

Here, the use of K_{\square} for the coefficients signifies their use as staticfixed coefficients.

Therefore, B_{CS} must be treated as a staticfixed variable representing the magnetic field strength in the central solenoid. For prospective solenoids using high temperature superconducting (HTS) tape, B_{CS} may be around 20 T. The values of σ_{CS} and J_{CS} have similar meanings to the ones for TF coils. These are collected in a table below with example values representative of our model.

Table 4.2: Example TF Coils and Central Solenoid Critical Values

(a) Stresses [MPa]

(b) Current Densities [MA/m²]

Limit 50 200

${\bf Item}$	Symbol	Limit	\mathbf{Iter}
Solenoid	σ_{CS}	300	Solen
TF Coils	σ_{TF}	600	TF C

Before moving on, it seems important to say that although K_{DI} and K_{DO} do not depend on dynamic floating variables, R_{CS} most definitely does. This is what makes the central solenoid's thickness difficult.

4.3.3 Revisiting Central Solenoid Dimensions

Now that the various thicknesses have been defined (i.e. a, b, c, and d), the equations for the solenoid's dimensions (i.e. R_{CS} and h_{CS}), can now be revisited and simplified. From before,

$$R_{CS} = R_0 - (a+b+c+d) \tag{4.54}$$

$$h_{CS} = 2 \cdot (\kappa a + b + c) \tag{4.55}$$

Utilizing the four thicknesses from before, these can now be expanded to simple 1503 formulas. Repeating the thicknesses: 1504

$$a = \epsilon \cdot R_0 \tag{2.1}$$

$$b = 1.23 + 0.074 \ln P_W \tag{4.56}$$

$$c = G_{CI}R_0 + G_{CO} (4.57)$$

$$d = K_{DR}R_{CS} + K_{DO} (4.61)$$

Plugging these into the central solenoid's dimensions results in:

$$h_{CS} = 2 \cdot (R_0 \cdot (\epsilon \kappa + G_{CI}) + (b + G_{CO}))$$
 (4.64)

$$h_{CS} = 2 \cdot (R_0 \cdot (\epsilon \kappa + G_{CI}) + (b + G_{CO}))$$

$$R_{CS} = \frac{1}{1 + K_{DR}} \cdot (R_0 \cdot (1 - \epsilon - G_{CI}) - (K_{DO} + b + G_{CO}))$$

$$(4.64)$$

These are the complete central solenoid dimension formulas. To make them more 1506 tractable to the reader, they will now be simplified one step at a time. (The same 1507 simplification exercise will be done again after the generalized current is derived later 1508 this chapter.) 1509

The first simplification to make while estimating central solenoid dimensions is to 1510 neglect the magnetic current-carrying portions of the central solenoid and TF coils. 1511 This results in: 1512

$$\lim_{\substack{G_{CO} \to 0 \\ K_{DO} \to 0}} h_{CS} = h_{CS}^{\dagger} = 2R_0 \cdot (K_{EK} + \epsilon_b + G_{CI})$$
(4.66)

$$\lim_{\substack{G_{CO} \to 0 \\ K_{DO} \to 0}} R_{CS} = R_{CS}^{\dagger} = \frac{R_0}{1 + K_{DR}} \cdot (1 - \epsilon_b - G_{CI})$$
(4.67)

The new staticfixed coefficient, here, is:

$$K_{EK} = \epsilon \cdot (\kappa - 1) \tag{4.68}$$

The next simplification is ignoring the TF coil thickness – and thus magnetic field dependence – altogether:

$$\lim_{G_{CI} \to 0} h_{CS}^{\dagger} = h_{CS}^{\dagger} = 2R_0 \cdot (K_{EK} + \epsilon_b) \tag{4.69}$$

$$\lim_{G_{CI} \to 0} R_{CS}^{\dagger} = R_{CS}^{\ddagger} = \frac{R_0}{1 + K_{DR}} \cdot (1 - \epsilon_b) \tag{4.70}$$

These oversimplifications will be used later this chapter while simplifying the generalized current equation to something more tractable. For now, they highlight how the dimensions change as different components are neglected. The next step is bringing plasma physics back into the flux balance equation and solving for the generalized current.

4.4 Piecing Together the Generalized Current

The goal of this section is to quickly expand flux balance using all the defined quantities and then massage it into an equation for plasma current – which is suitable for root solving. This starts with a restatement of flux balance in a reactor:

$$\Phi_{CS} + \Phi_{PF} = \Phi_{RU} + \Phi_{FT} \tag{4.53}$$

$$\Phi_{CS} = 2MI_{max} \tag{4.40}$$

$$\Phi_{PF} = \pi B_V \cdot \left(R_0^2 - (R_{CS} + d)^2 \right) \tag{4.44}$$

$$\Phi_{RU} = L_2 \cdot I_{ID} \tag{4.42}$$

$$\Phi_{FT} = (R_P \tau_{FT}) \cdot I_{ID} \tag{4.43}$$

The first step is realizing that the central solenoid flux can now be rewritten using the new geometry in a standardized form:

$$\Phi_{CS} = K_{CS} \cdot \sqrt{R_0 G_{LT} h_{CS}} \tag{4.71}$$

$$K_{CS} = 2kB_{CS} \cdot \sqrt{\frac{\pi K_{LP}}{\mu_0}} \tag{4.72}$$

Next, we will slightly simplify the PF coil flux using a dynamic floating variable coefficient:

$$\Phi_{PF} = G_V \cdot \frac{K_{VI}I_P + K_{VT}\overline{T}}{R_0} \tag{4.73}$$

$$G_V = \frac{\pi}{10} \cdot \left(R_0^2 - (R_{CS} + d)^2 \right) \tag{4.74}$$

This allows us to rewrite the generalized current as:

$$I_{P} = \frac{(K_{BS} + {}^{G_{IU}}/_{G_{IP}}) \cdot \overline{T}}{1 - K_{CD}(\sigma v) - {}^{G_{ID}}/_{G_{IP}}}$$
(4.75)

1530

$$G_{IU} = K_{VT} G_V + K_{CS} R_0^{3/2} \cdot \frac{\sqrt{h_{CS} G_{LT}}}{\overline{T}}$$
 (4.76)

$$G_{ID} = K_{VI}G_V \tag{4.77}$$

$$G_{IP} = K_{LP}R_0^2 + \frac{K_{RP}\,\tau_{FT}}{\overline{T}^{3/2}} \tag{4.78}$$

As we will show in the next section, this form not only has a form remarkably similar to the steady current – it reduces to it in the limit of infinitely long pulses!

¹⁵³³ 4.5 Simplifying the Generalized Current

This section focuses on making various simplifications to the generalized current:

$$I_{P} = \frac{(K_{BS} + {}^{G_{IU}}/G_{IP}) \cdot \overline{T}}{1 - K_{CD}(\sigma v) - {}^{G_{ID}}/G_{IP}}$$
(4.75)

As promised, this will start with the trivial simplification of the generalized current into steady state. Next it will move on to a basic simplification for the purely pulsed case. These two activities should shed some light on how to interpret the equation in the more complicated hybrid case.

4.5.1 Recovering the Steady Current

The place to start with the steady current is the dynamic floating coefficient, G_{IP} :

$$G_{IP} = K_{LP}R_0^2 + \frac{K_{RP}\tau_{FT}}{\overline{T}^{3/2}}$$
 (4.78)

As can be seen, as $\tau_{FT} \to \infty$, so does the coefficient,

$$\lim_{T_{PT} \to \infty} G_{IP} = \infty \tag{4.79}$$

Because G_{IU} and G_{ID} remain constant, their contribution to plasma current becomes insignificant in this limit. Concretely,

$$\lim_{\tau_{FT} \to \infty} I_P = \frac{K_{BS} \overline{T}}{1 - K_{CD}(\sigma v)} \tag{4.80}$$

This is precisely the steady current given by Eq. (2.30)! The generalized current automatically works when modeling steady-state tokamaks.*

1546 4.5.2 Extracting the Pulsed Current

For pulsed reactors, we have to play a similar game – except now τ_{FT} is expected to be a reasonably sized number (i.e. 2 hours).

With an aim at intuition, the reactor is first treated as purely pulsed – having no current drive assistance:

$$\lim_{\eta_{CD} \to 0} I_P = \frac{(K_{BS} + {}^{G_{IU}}/G_{IP}) \cdot \overline{T}}{1 - ({}^{G_{ID}}/G_{IP})}$$
(4.81)

Next, for simplicity-sake, the PF coil contribution to flux balance is assumed negligible, as it was always just a correction term:

$$\lim_{\Phi_{PF} \ll \Phi_{CS}} G_{IU} = K_{CS} R_0^{3/2} \cdot \frac{\sqrt{h_{CS} G_{LT}}}{\overline{T}}$$
 (4.82)

$$\lim_{\Phi_{PE} \ll \Phi_{CS}} G_{ID} = 0 \tag{4.83}$$

Piecing this altogether, we can write a new current for this highly simplified case,

$$I_P^{\dagger} = K_{BS} \overline{T} + \frac{K_{CS} R_0^{3/2} \cdot \sqrt{h_{CS} G_{LT}}}{K_{LP} R_0^2 + K_{RP} \tau_{FT} \overline{T}^{-3/2}}$$
(4.84)

^{*}It should be noted that this is much harder when setting τ_{FT} to a large, but finite number – as η_{CD} still needs to be solved self-consistently.

As this is not quite simple enough, these previous simplifications will be incorporated:

$$G_{LT}^{\dagger} = R_{CS}^2 \tag{4.28}$$

$$h_{CS}^{\ddagger} = 2R_0 \cdot (K_{EK} + \epsilon_b) \tag{4.69}$$

$$R_{CS}^{\ddagger} = \frac{R_0}{1 + K_{DR}} \cdot (1 - \epsilon_b) \tag{4.70}$$

Taking these into consideration results in the following current formula:

$$I_P^{\ddagger} = K_{BS} \overline{T} + \left(\frac{K_{CS} R_0^3}{K_{LP} R_0^2 + K_{RP} \tau_{FT} \overline{T}^{-3/2}} \cdot \frac{(1 - \epsilon_b) \cdot \sqrt{2(K_{EK} + \epsilon_b)}}{1 + K_{DR}} \right)$$
(4.85)

In the limit that the pulse length drops to zero (and bootstrap current is negligible),

$$\lim_{\tau_{FT} \to 0} I_P^{\ddagger} = R_0 \cdot \left(\frac{K_{CS}}{K_{LP}} \cdot \frac{(1 - \epsilon_b) \cdot \sqrt{2(K_{EK} + \epsilon_b)}}{1 + K_{DR}} \right)$$
(4.86)

This implies that a purely pulsed current scales with major radius to leading order.

4.5.3 Rationalizing the Generalized Current

From the previous two subsections, we arrived at equations for infinitely large and infinitely small pulse lengths:

$$\lim_{\tau_{FT} \to \infty} I_P = \frac{K_{BS} \overline{T}}{1 - K_{CD}(\sigma v)} \tag{4.80}$$

$$\lim_{\tau_{FT} \to 0} I_P^{\ddagger} = R_0 \cdot \left(\frac{K_{CS}}{K_{LP}} \cdot \frac{(1 - \epsilon_b) \cdot \sqrt{2(K_{EK} + \epsilon_b)}}{1 + K_{DR}} \right)$$
(4.86)

What these imply at an intuitive level is that at small pulses, current scales with the major radius. While for long pulses, current sales with plasma temperature. In the general case, of course, the problem becomes much harder to predict.

Bibliography

- ²⁴⁸¹ [1] P J Knight and M D Kovari. A User Guide to the PROCESS Fusion Reactor Systems Code, 2016.
- ²⁴⁸³ [2] Martin Greenwald. Density limits in toroidal plasmas, 2002.
- ²⁴⁸⁴ [3] W Biel, M Beckers, R Kemp, R Wenninger, and H Zohm. Systems code studies on the optimization of design parameters for a pulsed DEMO tokamak reactor, ²⁴⁸⁶ 2016.
- [4] C E Kessel, M S Tillack, F Najmabadi, F M Poli, K Ghantous, N Gorelenkov, X R
 Wang, D Navaei, H H Toudeshki, C Koehly, L El-Guebaly, J P Blanchard, C J
 Martin, L Mynsburge, P Humrickhouse, M E Rensink, T D Rognlien, M Yoda, S I
 Abdel-Khalik, M D Hageman, B H Mills, J D Rader, D L Sadowski, P B Snyder,
 H. St. John, A D Turnbull, L M Waganer, S Malang, and A F Rowcliffe. The
 ARIES advanced and conservative tokamak power plant study. Fusion Science
 and Technology, 67(1):1–21, 2015.
- [5] Jeffrey P Freidberg. Plasma Physics and Fusion Energy, volume 1. 2007.
- ²⁴⁹⁵ [6] Stephen O Dean. Fusion Power by Magnetic Confinement Program Plan. Technical Report 4, 1998.
- ²⁴⁹⁷ [7] DOE. FY 1987 Congressional Budget Request. Technical report.
- ²⁴⁹⁸ [8] DOE. FY 2019 Congressional Budget Request. Technical report.
- ²⁴⁹⁹ [9] Marsha Freeman. The True History of The U.S. Fusion Program. Technical report, 2009.
- [10] D. G. Whytea, A E Hubbard, J W Hughes, B Lipschultz, J E Rice, E S Marmar, M Greenwald, I Cziegler, A Dominguez, T Golfinopoulos, N Howard, L. Lin, R. M. McDermottb, M Porkolab, M L Reinke, J Terry, N Tsujii, S Wolfe, S Wukitch, and Y Lin. I-mode: An H-mode energy confinement regime with L-mode particle transport in Alcator C-Mod. Nuclear Fusion, 50(10), 2010.
- J. W. Connor, T Fukuda, X Garbet, C Gormezano, V Mukhovatov, M Wakatani,
 M. Greenwald, A. G. Peeters, F. Ryter, A. C.C. Sips, R. C. Wolf, E. J. Doyle,
 P. Gohil, C. M. Greenfield, J. E. Kinsey, E. Barbato, G. Bracco, Yu Baranov,

- A. Becoulet, P. Buratti, L. G. Ericsson, B. Esposito, T. Hellsten, F. Imbeaux,
- P. Maget, V. V. Parail, T Fukuda, T. Fujita, S. Ide, Y. Kamada, Y. Sakamoto,
- H. Shirai, T. Suzuki, T. Takizuka, G. M.D. Hogeweij, Yu Esipchuk, N. Ivanov,
- N. Kirneva, K. Razumova, T. S. Hahm, E. J. Synakowski, T. Aniel, X Garbet,
- G. T. Hoang, X. Litaudon, J. Weiland, B. Unterberg, A. Fukuyama, K. Toi,
- S. Lebedev, V. Vershkov, and J. E. Rice. A review of internal transport barrier physics for steady-state operation of tokamaks, apr 2004.
- [12] K C Shaing, A Y Aydemir, W A Houlberg, and M C Zarnstorff. Theory
 of Enhanced Reversed Shear Mode in Tokamaks. *Physical Review Letters*,
 80(24):5353-5356, 1998.
- 2519 [13] David J. Griffiths. Introduction to electrodynamics.
- [14] D C Mcdonald, J G Cordey, K Thomsen, C Angioni, H Weisen, O J W F
 Kardaun, M Maslov, A Zabolotsky, C Fuchs, L Garzotti, C Giroud, B Kurzan,
 P Mantica, A G Peeters, and J Stober. Scaling of density peaking in H-mode
 plasmas based on a combined database of AUG and JET observations. Nucl.
 Fusion, 47:1326–1335, 2018.
- ²⁵²⁵ [15] T Onjun, G Bateman, A H Kritz, and G Hammett. Models for the pedestal temperature at the edge of H-mode tokamak plasmas. *Physics of Plasmas*, 9(10), 2002.
- ²⁵²⁸ [16] G Saibene, L D Horton, R Sartori, and A E Hubbard. Physics and scaling of the H-mode pedestal The influence of isotope mass, edge magnetic shear and input power on high density ELMy H modes in JET Physics and scaling of the H-mode pedestal. *Control. Fusion*, 42:15–35, 2000.
- [17] J Jacquinot,) Jet, S Putvinski,) Jet, G Bosia, Jet), A Fukuyama, U) Okayama, 2532 R Hemsworth, Cea Cadarache), S Konovalov, Rrc Kurchatov), W M Nevins, 2533 Llnl), F Perkins, K A Rasumova, Rrc-) Kurchatov, F Romanelli, Enea-) Frascati, 2534 K Tobita, Jaeri), K Ushigusa, J W Van, U Dam, V Texas), Rrc Vdovin, 2535 S Kurchatov), R Zweben, Erm Koch, Kms-) Brussels, J.-G Wégrowe, Cea-) 2536 Cadarache, V V Alikaev, B Beaumont, A Bécoulet, S Bern-Abei, Pppl), V P 2537 Bhatnagar, Ec Brussels), S Brémond, and M D Carter. Chapter 6: Plasma 2538 auxiliary heating and current drive. ITER Physics Basis Editors Nucl. Fusion, 2539 39, 1999. 2540
- ²⁵⁴¹ [18] D A Ehst and C F F Karney. Approximate formula for radiofrequency current drive efficiency with magnetic trapping, 1991.
- [19] M Kovari, R Kemp, H Lux, P Knight, J Morris, and D J Ward. "PROCESS ":
 A systems code for fusion power plantsâĂŤPart 1: Physics. Fusion Engineering
 and Design, 89(12):3054–3069, 2014.
- ²⁵⁴⁶ [20] Tobias Hartmann, Thomas Hamacher, Hon-Prof rer nat Hartmut Zohm, and Hon-Prof rer nat Sibylle Günter. Development of a Modular Systems Code to

- Analyse the Implications of Physics Assumptions on the Design of a Demonstration Fusion Power Plant.
- [21] B Labombard, E Marmar, J Irby, T Rognlien, and M Umansky. ADX: a high
 field, high power density, advanced divertor and RF tokamak Nuclear Fusion.
 Technical report, 2017.
- ²⁵⁵³ [22] J P Freidberg, F J Mangiarotti, and J Minervini. Designing a tokamak fusion reactor How does plasma physics fit in? *Physics of Plasmas*, 22(7):070901, 2015.
- [23] B. N. Sorbom, J. Ball, T. R. Palmer, F. J. Mangiarotti, J. M. Sierchio, P. Bonoli,
 C. Kasten, D. A. Sutherland, H. S. Barnard, C. B. Haakonsen, J. Goh, C. Sung,
 and D. G. Whyte. ARC: A compact, high-field, fusion nuclear science facility
 and demonstration power plant with demountable magnets. Fusion Engineering
 and Design, 100:378–405, nov 2015.
- ²⁵⁶¹ [24] S P Hirshman and G H Neilson. External inductance of an axisymmetric plasma. ²⁵⁶² Physics of Fluids, 29(3):790–793, 1986.
- ²⁵⁶³ [25] D P Schissel and B B Mcharg. Data Analysis Infrastructure at the Diii-D National Fusion Facility. (October), 2000.
- ²⁵⁶⁵ [26] Jeff P Freidberg, Antoin Cerfon, and Jungpyo Lee. Tokamak elongation: how much is too much? I Theory. *arXiv.org*, pages 1–34, 2015.
- ²⁵⁶⁷ [27] H Bosch and G M Hale. Improved formulas for fusion cross-sections and thermal reactivities. 611.
- [28] Zachary S Hartwig and Yuri A Podpaly. Magnetic Fusion Energy Formulary.
 Technical report, 2014.
- ²⁵⁷¹ [29] John Wesson and David J Campbell. *Tokamaks*, volume 149. Oxford University Press, 2011.
- ²⁵⁷³ [30] C. E. Kessel. Bootstrap current in a tokamak. *Nuclear Fusion*, 34(9):1221–1238, 1994.