Chordpad layout

Four-bank layout for Linux and Android. Pause/resume: A+B+X+Y; release all controls.

Hold the bank bumpers, or add them within 100 ms after pressing a thumb button, before that thumb releases. Tap and release to type; hold 300 ms to repeat. No letter uses a diagonal or two face buttons.

Base: letters and punctuation

D-pad			Face buttons		
	↑ s			Y / △ i	
← t		→ r	X / □ e		B / ○ o
	↓ n			A / × a	

L1

D-pad			Face buttons		
	↑ b			Y / △ u	
← l		→ m	X / □ g		B / ○ p
	↓ d			A / × y	

R1

D-pad			Face buttons		
	↑ w			Y / △ x	
← c		→ f	X / □ h		B / ○ j
	↓ v			A / × k	

L1 + R1

D-pad			Face buttons		
	↑ /			Y / △ '	
← Tab		→ q	X / □ .		B / ○ ;
	↓ z			A / × ,	

R2: hold or tap once

D-pad			Face buttons		
	↑ 1 !			Y / △ = +	
← 4 $		→ 2 @	X / □ - _		B / ○ 0)
	↓ 3 #			A / × 9 (	

Add L1: numbers 5–8

D-pad			Face buttons		
	↑ 5 %			Y / △ [{	
← 8 *		→ 6 ^	X / □ ` ~		B / ○] }
	↓ 7 &			A / × \ |	

R1 + R2: navigation

D-pad			Face buttons		
	↑ ↑			Y / △ PgUp	
← ←		→ →	X / □ Home		B / ○ End
	↓ ↓			A / × PgDn	

Add L1: editing / media

D-pad			Face buttons		
	↑ Vol+			Y / △ PrtSc	
← Prev		→ Next	X / □ Del		B / ○ Stop
	↓ Vol−			A / × Play	

R2 tap twice: function

D-pad			Face buttons		
	↑ F1			Y / △ F12	
← F4		→ F2	X / □ F11		B / ○ F10
	↓ F3			A / × F9	

Add L1: function

D-pad			Face buttons		
	↑ F5			Y / △ ·	
← F8		→ F6	X / □ ·		B / ○ ·
	↓ F7			A / × ·	

Left stick: hold for modifiers

↖ Ctrl + Alt	↑ Alt	↗ Ctrl + Alt + Shift + Meta
← Ctrl	Click L3 Command+D	→ Ctrl + Alt + Meta
↙ Ctrl + Meta	↓ Meta	↘ Alt + Meta

You can map L3 to Dictate on your computer.

Right stick: hold for modifiers

↖ Ctrl + Alt + Shift + Meta	↑ Alt	↗ Ctrl + Alt
← Ctrl + Alt + Meta	Click R3 Command+Shift+D	→ Ctrl
↙ Alt + Meta	↓ Meta	↘ Ctrl + Meta

You can map R3 to Cancel Dictation on your computer.

Hold either stick direction before starting a stroke; L2 adds Shift. Meta = Super / Command. Stick-click shortcuts ignore held modifiers.

Without sticks: tap an unused R1+R2 pair for face modifiers, or L1+L2 for D-pad modifiers. Hold a mirrored direction above (Y/B/A/X = ↑/→/↓/←), including adjacent pairs, across keys or mouse clicks; release to exit. Repeat the tap to cancel. Holding a pair with typing keeps its layer, including R1+R2 navigation.

Control	Behaviour
R1 / L1 alone	Space / Backspace. Hold alone 300 ms to repeat every 80 ms; release stops.
Late bumpers	Only the newest stroke accepts additions, for 100 ms.
Bank freezes	On next thumb press, thumb release, or deadline; bumper releases preserve it.
L2 tap ≤250 ms	Shift for the next key; tap ≤250 ms again to cancel. Hold L2 for momentary Shift.
Hold any output	Repeat after 300 ms, every 80 ms. Release stops without an extra tap.
Hold R1 + R2	Navigation above. Add L1 for editing/media. Consumes R1's Space tap.
R2 taps	Numbers → functions → off. Next key clears selection. Taps ≤250 ms; no gap limit.
Start / Select	Enter / Escape.

First outputs retain press order; small symbols need Shift. Pause/reset clears one-shot selections.
Linux: held modifiers also work with mouse clicks. Android: Shift-click/tap selects text; global mouse modifiers need the ADB helper.