

Zone	Fault	α_{50} pre	α_{50} post	$I_{f,50}^{\text{pre}}$ [pu]	$I_{f,50}^{\text{post}}$ [pu]	Status
87B_A	3ph	—	—	—	—	✓ unchanged
87B_A	ag	—	—	—	—	✓ unchanged
87L	3ph	0.07	0.05	0.56	0.40	↑ improved
87L	ag	0.15	0.10	0.72	0.48	↑ improved
87B_B	3ph	—	—	—	—	✓ unchanged
87B_B	ag	—	—	—	—	✓ unchanged
87T	3ph	—	—	—	—	✓ unchanged
87T	ag	—	—	—	—	✓ unchanged
OC	3ph	0.30	0.30	1.30	1.30	✓ unchanged
OC	ag	0.70	0.70	1.83	1.83	✓ unchanged

— = TPR = 1.000 for all $\alpha \in [0.05, 1.00]$ (no degradation); $I_{f,50}$ is the fault current at α_{50} . OC = overcurrent backup.