DICommands

From Dvd-game

Contents

- 1 Standard Drive Commands
- 2 Cobra Addons
- 3 Qoob Addons
- 4 XenoGC Addons

Standard Drive Commands

Description Bytes 12 Identify A8 00 00 x0 rr rr rr rr ll ll ll ll Read Sector AB 00 00 00 rr rr rr rr Seek/Precache E0 00 00 00 Read Status Ε1 Audio Stream E2 Request Audio Status E3 Motor Stop E4 AudioBufferConfig FE Debug Command FF Debug Enable

The NPDP-Cartridge have several more commands, including the 'NPDP-ID' and Fx for direct read/write access to the harddisk plus firmware flashing and probably more stuff. It's not covered here.

Cobra Addons

The following commands are added by the Cobra firmware.

Bytes	Description	Version
1E	Start swap method	1.0
55	Disable drive code	1.0
A9 00 00 00 rr rr rr rr	Set offset for multigame disks to r	1.0

Qoob Addons

The following commands are added by the Qoob firmware.

Bytes	Description	Versions
10	Post event 0x01 to the backend thread? start drive?	1.3c
11	Set drive status to allow read disc id	1.3c
20 00 00 00 xx	Set drive code flags to x (bit0=audio fix, bit1=enable)	1.3c
A9 00 00 00 rr rr rr rr	Set offset for multigame disks to r	1.3c
E1 00 00 00 rr rr rr rr	Add r to offset for multigame disks	1.3c

XenoGC Addons

The following commands are added by the XenoGC firmware.

Bytes	Description	Versions		
21	Disable audio fix	1.0		
22	Disable DRE recovery	1.0		
25	unload drive code / disable reset logic / Request credits binary	1.0		
Retrieved from "http://tmb.elitedvb.net/dvd-game/index.php/DICommands"				

■ This page was last modified 21:55, 2 February 2006.