

RECOMMENDED VFR PROCEDURES

- Use preferred arrival and departure corridors
- Keep your patterns tight
- Avoid overflying residential areas
- Avoid straight-in VFR arrivals
- Avoid low passes and formation arrivals
- Avoid abrupt maneuvering, power, and sudden propeller RPM changes
- Watch those propeller helical tip speeds!

HELP US TO REDUCE NOISE!

Adhere to Voluntary Restraint from Night Flying Policy (10 PM - 6 AM local)

ARRIVALS

 Remain at traffic pattern altitude (1400' MSL) as long as practical before descending to land.

DEPARTURES

- Climb as quickly as practical to pattern altitude.
- Avoid intersection takeoffs

LIVERMORE MUNICIPAL AIRPORT (KLVK) **PILOT INFORMATION GUIDE**

www.cityoflivermore.net/airport

LOCATION

N 37° 41' 36.20" W 121° 49' 13.30" N 37° 41.603333' W 121° 49.221667' N 37.6933889° W 121.8203611°

Elevation: 400 ft MSL / 121.9 m (surveyed)

Variation: 13.7° E (1/2015)

3 miles West of Livermore, CA (zip = 94551)

AIRPORT OPERATIONS

Open to the public Airport Use : **Sectional Chart:** SAN FRANCISCO

Control Tower: YES (0700-2100 PST/PDT daily)

OAKLAND CENTER ARTCC: FSS: **OAKLAND FSS** (1-866-469-7828)

LVK NOTAM-D Service Available **NOTAM's Facility:**

FBO Hours: 0600-1800 (925-315-4130)

Pattern Altitude: 1400 ft MSL Wind Indicator: Midfield, Lighted

Segmented Circle: YES

Lights

07L/25R: Lighted, PCL on CTAF (3x, 5x, 7x)

07R/25L: NONE

Lighted, PCL on CTAF Taxiways:

White-Green Beacon:

(lighted land airport)

COMMUNICATIONS

ATIS 119.65 925-447-9516 **TOWER** 925-443-0666, 0700-2100 LCL 118.1 128.2 (when necessary) **GROUND** 925-443-0666, 0700-2100 LCL 121.6 925-606-5412 ASOS 119.65 **CTAF** (when tower closed) 118.1 ILS/LOC 110.5 (monitored by FBO) UNICOM 122.95 NDB (REIGA) 374

NORCAL APPROACH: 123.850 RWY 07R/07L/25R/25L

NORCAL DEPARTURE: 125.350 RWY 25R/25L

125.850 RWY 07R/07L

Copyright © 2016, Courtesy Brett M Wayne

