Conteúdo

<u>Conteúdo</u>	i
Lista de Figuras	iii
Lista de Tabelas	v
Glossário	vii
1 Introduction	1
1.1 Background and Motivation	1
1.2 Scope	2
1.3 Outline	2
2 Basic principles of RFID	3
2.1 Contextualization	3
2.2 Radio Frequency Identification (RFID) System	4
2.2.1 Components	5
2.3 electromagnetic Concepts	6
2.3.1 Near-field	6
2.3.2 Far-field	7
2.3.3 Boundaries	7
2.4 Tag	8
2.4.1 Data Quantities	9
2.4.2 Power Supply	9
2.4.3 Coupling	11
2.4.4 Technologies	14
2.5 Reader	15
2.6 Reader Antenna	16
2.6.1 Radiation pattern	16
262 Polarization	17

Lista de Figuras

2.1	RFID system 14	5
2.2	Field for antennas larger than the wavelength of the radiation it emits 17	8
2.3	Fields for antennas equal to, or shorter than, one-half wavelength of the radiation they	
	emit 19	8
2.4	Components of a passive tag 14	9
2.5	Selection of passive Ultra High Frequency (UHF) tag inlays for distinct applications from	
	Alien Technology, LLC 2020 Product Family 21	10
2.6	United States of America (U.S.) Department of Energy prototype active tag with sensors	
	for nuclear materials management working in $433.9MHz$ UHF ISO band 22	10
2.7	CAEN RFID A927Z semi-passive UHF logger tag for temperature monitoring of sensitive	
	products during transportation and storage 23	11
2.8	Inductive coupled RFID system overview 14	12
2.9	Load modulation with subcarriers of a typical High Frequency ($\overline{\text{HF}}$) $\overline{\text{RFID}}$ system [14].	13
2.10	Passive backscatter RFID system 14	13

Lista de Tabelas

2.1 radio requerey (reer) properties in direction materials [50]	2.1 r	radio frequency (R)	properties in different material	ials 36	15
--	-------	---------------------	----------------------------------	---------	----

Glossário

\mathbf{RFID}	Radio Frequency Identification	\mathbf{IFF}	Identify Friend or Foe
\mathbf{RF}	radio frequency	U.S.	United States of America
\mathbf{LF}	Low Frequency	R&D	research and development
\mathbf{HF}	High Frequency	\mathbf{EM}	electromagnetic
\mathbf{UHF}	Ultra High Frequency	\mathbf{EMF}	electromagnetic field
$\mathbf{U}\mathbf{W}\mathbf{B}$	Ultra-wide band	\mathbf{EMW}	electromagnetic wave
UHF RFII	O Ultra High Frequency Radio Frequency	\mathbf{SCM}	Supply Chain Management
	Identification	NFC	Near-field communication
\mathbf{IoT}	Internet of Things	EIRP	Effective Isotropic Radiated Power
\mathbf{IT}	Information Technology	IC	integrated circuit
\mathbf{EPC}	Electronic Product Code	\mathbf{CW}	continuous wave
\mathbf{DoD}	United States Department of Defense	\mathbf{FPGA}	field-programmable gate array

CAPÍTULO 1

Introduction

1.1 Background and Motivation

The new industrial revolution is centered around data. Yet, the true extension of this reformation might not be fully understood.

From manufacturing to retail, information and communication technologies disrupted the understanding of what could be improved through the supply chain [1]. To grasp the advantages of RFID, we have to understand its place within the the other technologies and how it can empower the relationship between manufacturing, transportation, logistics and retail.

The introduction of information and communication technologies in the manufacturing process, has been the foundation of Industry 4.0, which some people refer has the fourth industrial revolution [2]. It expanded the cyber-physical systems [2] of the third industrial revolution and introduced Internet of Things (IoT), cloud and cognitive computing. The rise of wireless communications and the massification of data sensing in the manufacturing processes, allowed these technologies to enhance and optimize production processes, logistics operations and marketing strategies.

Adding IoT provided the network infrastructure for data transfer. Cloud computing enabled on-demand availability of Information Technology (IT) resources, fast deployment times and more efficient management strategies. Cognitive computing contributed with computer vision, signal processing and tools to analyze and process large amounts of data for operational optimizations and pattern recognition. These technologies support the modern digital end-to-end system of a business and its manufacturing processes.

Ultra High Frequency Radio Frequency Identification (UHF RFID) improves the developments made in *Industry 4.0* by adding digital visibility of physical assets. But visibility inside a company is opaque to trading partners and vice versa. Visibility both inside and outside of the company is desirable. With Electronic Product Code (EPC) that is possible. Inside the company, physical objects can be digitalized, identified and wirelessly tracked. Outside,

¹the sequence of processes involved in the production and distribution of a commodity [1]

²a system in which a mechanism is controlled or monitored by computer-based algorithms

frontiers between company methods of operations and tools, can be abstracted in a common set of interfaces and standards that allows visibility of products outside company bounds and share of information between trading partners. This achieves an end-to-end integration of the complete commercialization process, where data from billions of physical items can be shared through the internet, enabling businesses and consumers to identify, locate and engage each item.

The future of RFID seems promising. In 2016, 96% of apparel retailers had plans to deploy tags on their products [3]. The United States Department of Defense (DoD) requires that all contractors must use UHF RFID identification since 2005 [4]. In 2014, Impinj, Intel, Google and Smartrac teamed up to form RAIN RFID, an organization whose mission is to promote the adoption of EPC UHF RFID UHF RFID can greatly improve transport systems with cost reductions, smaller inventory, faster transportation and routing troubleshooting, lower insurance rates and greater efficiency [5].

Development and standardization of <u>UHF RFID</u> enables a symbiotic relation across the chain, connecting production, logistics, retail and client.

1.2 Scope

This dissertation intents to explore the implementation of smart shelve and software for retail inventory management systems following the global supply chain standards.

1.3 Outline

Basic principles of RFID

2.1 Contextualization

The concept of identification using RF dates back to the late 1930s. By this time, the primitive biplanes made of wood and fabric used in Word War I, had evolved to all-metal monoplanes. They were capable of carrying heavy quantities of explosives and travel at hundreds of kilometers per hour, making the conventional method of visual identification of incoming aircrafts obsolete. To counteract this issue, nations invested in research and development that culminated in the development of the microwave radar. By the time of the World War II, both fronts were using radar technologies to detect approaching planes. Still, it remained the problem of identifying allied aircrafts from enemie ones The German aircraft force, Luftwaffe, observed that as pilots rolled their planes, it would change the radio signal reflected back. With this ingeniously simple maneuver, they were capable of discriminate allied aircrafts, being roughly the first RFID passive application.

It was soon later that Watson-Watt, under a British project, developed the first active RFID application to be used in Identify Friend or Foe (IFF) systems. An active RF transmitter was attached to British planes, which on receiving radar signals from base stations, broadcasted a signal identifying the aircraft has allied. [7]

The technology kept advancing through the 1950s and 1960s, mainly in the academic field, but with private companies starting to commercialize anti-theft systems based on 1-bit transponders [2].

In the 1970s the first RFID patents were registered. Kudos to the active tag with rewritable memory and a passive transponder for door lockers. It was during this time that the U.S. National Laboratory of Los Alamos was commissioned, by the Energy Department, to develop a tracking system for nuclear materials. The system revolved around transponders in trucks that would transmit information to readers at the gates of secure facilities. The Agricultural

¹The attack at Pearl Harbor in 1941 was possible due to a mistaken assignment of incoming Japanese aircraft to an unrelated U.S. bomber flight.

²a simple inductive \overline{RC} resonant circuit that detects transponders in field by changes in the reader coil voltage $\overline{[8]}$

Department also requested Los Alamos for an animal tracking system, which was designed in the UHF band with passive transponders, marking the beginning of the UHF RFID technology. These systems were also transposed by the same engineers to automated toll payment systems in the private industry [7], [9], [10].

In the 1980s there was a an surge in investment, with private industries wagering in RFID, fueled by the development of the personal computer and promises of the technology. By the 1990s, deployments of RFID systems had grown significantly. The necessity of compatibility and interaction between proprietary systems rose, being established the first industry standards.

The 2000s followed the same maturation process with slow adoption in the late part of the decade. Despite the interest presented by retail giants like Wal-Mart, and investment by the DoD, compromises created by the RFID industry didn't justified the commitment to the technology. The high cost for investment, technical performance difficulties, conflicting standards, security issues and privacy concerns made the investment stale [11]. Companies had to strangle research and development (R&D) resources due to inexistent tools and complex implementations. Resources required to develop marketing and sales tools, which truly utilize the RFID infrastructure to increase revenue, had to be allocated to deploying RFID systems. Devise economic strategies for suppliers to transit to RFID also seemed to be a problem, since many ordinary companies don't have R&D resources at all to begin with [12]. Another big issue was the standardization of coding schemes in RF tags. The fight for dominance in the UHF RFID market led to multiple coding standards and protocols that made inter-operation among vendor and suppliers infeasible, if not impossible.

In the last decade, despite the advancements in the industry and adoption by big apparel retailers like Zara, Decathlon and Marks & Spencer [13], there are issues that inhibit wide-scale adoption of UHF RFID. These problems will be further discussed in chapter two of this dissertation.

2.2 RFID System

RFID is an identification technology that uses radio waves or electro-magnetic fields to automatically identify physical objects and collect data about them. Generally, RFID solutions start with a radio device called tag. The tag is attached to the object that needs to be identified. When such a object is presented in front of an antenna connected to a suitable RFID reader, the tag transmits data to the reader via the reader antenna. The reader then forwards the information through a communication channel to a software application running on a computer.




Figura 2.1: RFID system [14]

2.2.1 Components

An RFID system is a collection of components that implement an RFID solution. Different references present different descriptions of RFID systems. Many specify where and which components should be implemented. The fact is, depending on the use case and requirements, these components can be implemented in different physical places or not implemented at all. With the current paradigm of IoT, machine learning and cloud computing, the discrimination of these components is even more difficult to establish. It is naive and intricate to predict what RFID system architecture will be like in the next few years.

The component description of RFID systems can be simplified to three physical blocks: Transponder which is attached to the physical object to be identified and is responsible for storing and transmitting appropriate data about the object; Reader which interacts with transponders to read and write data; and Software system that encompass all kinds of hardware and software components that are separated from the reader and support back-end infrastructures and business logic of a system.

From these, all components described in the literature can be specified and clearly added to one of the blocks. The prevalent components used in RFID systems:

Tag RF device that can store and transmit data in a contactless manner using radio waves.

Reader also called *interrogator*, is a device that can read from and write data to compatible RFID tags.

Reader Antenna is a device that is attached to a reader and is responsible for the RF interface with the tag.

Controller is an interface that allows an external entity to communicate with and control the reader's functions and devices connected to it.

Sensor, actuator and annunciator are optional components used for external input and output of the system.

Host and software system is an term for all hardware and software components that are separated from the reader device (e.g. middleware, back-end infrastructure, point-of-sale terminals, etc.)

Communication infrastructure is the wired and wireless network and serial connection infrastructure needed to connect the previously listed components

A run through the specificities of most of the components will be done in the following sections.

2.3 ELECTROMAGNETIC CONCEPTS

Before presenting the intrinsics around RFID system components, a basic expertise in electromagnetic (EM) concepts is paramount. Designing well performant systems requires a good understanding of electromagnetism fundaments and its peculiarities.

In like manner to other wireless technologies, RFID uses electromagnetic fields (EMFs) or electromagnetic waves (EMWs) as interface to transmit information back and forward between reader and transponder. Engineers have to grasp how EMFs and EMWs behave within distance to the reader antenna, how materials in tagged objects can interfere with RF signals, how unaccounted poor RF environments can compromise deployment of RFID systems, to say a few.

An EMF is the phenomenon produced by moving electric charges. It can be described through Maxwell's equations and mathematical abstracted as a combination of an electric field and a magnetic field that interact with each other and their surroundings.

The behavior of the fields changes as the distance from the source increases and are usually defined as two main regions: near-field and far-field. These regions separate RFID technologies in a very concrete way, but should not misled to think that the boundaries are precisely defined. The regions change their behavior in a progressive manner. The rough discrimination between regions in RFID exist to separate mutual coupling and radiation based technologies.

2.3.1 Near-field

Near-field manifests from the electric and magnetic fields near the charges and current that directly produced them. It is the region where phenomena like EM induction and electrostatic occur. This field can be further split in two regions: reactive near-field and radiative near-field. It is in the reactive region that near-field RFID technologies are defined for. It is the closest to the transmitting antenna and is characterized by non-radiative behaviors. In this region, if the energy is not absorbed by a receiver, self-capacitance and self-inductive effects cause the antenna to store energy very near its surface. When electrons from a nearby conductor are placed in this region, field reactive near-field energy is transferred to them, resulting in an energy drain on the transmitter by a change in the impedance viewed by the reader 14, 15.

In the radiative *near-field*, i.e. Fresnel region, the back-coupling of the fields becomes out of phase with the antenna signal, and thus cannot efficiently return inductive or capacitive energy from antenna currents or charges. In this region conductive objects, such as metal structures, can behave as antennas by inductively receiving and then *re-radiating* some of the energy [16].

In the context of RFID technologies, only the reactive zone is considered when referring to the near-field region. The radiative zone is ineffective and rather unpredictable and usually not accounted referring to RFID.

The power of the field differers between field components with the distance (d) from the antenna. The magnetic field strength is proportional to $1/d^3$ and the electric to $1/d^2$. The *near-field* components are quite powerful but usually only suited for close range RFID technologies due to the rapid fall-off with the distance $\boxed{15}$.

2.3.2 Far-field

The far-field region is the region where the EM field behaves as a normal radiating field, composed of EM waves that propagate outwards - i.e. electromagnetic radiation.

EM waves are created as result of uniform vibrations between an electric field and a magnetic field. In other words, EM waves are composed of oscillating magnetic and electric fields. A change in one of the field components reflects an equal change of the other and one can not exist independently. These waves are detached from any feedback from the moving charges that produced it. Means that, after the waves leave the transmitter, they are completely independent of both transmitter and receiver, as opposed to the phenomena in the near-field region.

In this region the radiation amplitude decreases 1/d as the distance (d) from the reader antenna increases, being the suitable option for RFID technologies requiring high reading distances (e.g. UHF RFID).

2.3.3 Boundaries

The boundaries between these regions are characterized by locations where the activity of the associated field components are strongest. It does not mean that the other components aren't present, because they are. The transition between regions is progressive.

The *near* and *far fields* are roughly delimited by approximately one full wavelength of the RF wave emitted from a reader antenna. This can be more precisely defined taking in account the transmitting antenna characteristics.

For antennas whose size is comparable to wavelength or bigger (used in UHF RFID), the far-field boundary is delimited by the Fraunhofer distance, radial from the antenna. The Fraunhofer distance is described by $2D^2/\lambda$, where D is the largest dimension of the radiator and λ the wavelength [15]. A representation of the borders between regions can be seen in figure [2.2]

For small antennas, shorter than half of the wavelength of the emitting radiation, the near-field for RFID applications is usually upper limited by $\lambda/2\pi=0.159\lambda$ [18]. Small antennas are used in Low Frequency (LF) and HFRFID technologies. For these technologies, which depend on the near-field for mutual coupling, the limit of the reactive region is theoretical limit for the read distance. A delimitation of field regions for small antennas can be seen in figure [2.3].




Figura 2.2: Field for antennas larger than the wavelength of the radiation it emits 17




Figura 2.3: Fields for antennas equal to, or shorter than, one-half wavelength of the radiation they emit 19

2.4 TAG

An RFID tag is a device that can store and transmit data to a compatible reader in a contactless manner using radio waves or electro-magnetic fields.

Tag cost is the main factor in long term return on investment in RFID systems. It is the most important consideration when designing systems. After the initial investment in infrastructure, the expenses are mainly the acquirement of new tags. The reduction of cost per tag is the central focus of manufacturers and what allows the technology to be competitive in the world of Supply Chain Management (SCM).

At its simplest composition [3], a tag contains a microchip and an antenna. Depending on the technology the tag architecture and operation varies. Tags are characterized by their chip, power source, memory characteristics and operating frequency. The following subsections will discussed these in detail.

³an inductive RC resonant tag used in anti-theft systems is considered an RFID device, but is far from the requirements of modern RFID paradigms




Figura 2.4: Components of a passive tag 14

2.4.1 Data Quantities

In the contextualization of RFID technologies presented in section 2.1, we discussed the concept of identification and how it can be as simple as World War II FF systems. An unidentified aircraft presents, upon radar lightening, its identification as being friend or foe. In computing language this can be abstracted as true or false, or 1 or 0. This kind of systems does not exchange more than a bit of information, the smallest unit of information, that can represent only two states. This type of transponders are called 1-bit transponders. Despite the limitations, they are still widely used in surveillance and and anti-theft systems. Apparel retailers and other goods retailers have been using them for almost 6 decades and are still well established nowadays. This dissertation requires the identification of more than 2 types of objects, so the following content will jump over technical explanations of this type of transponder 14.

The type of transponder discussed through out this dissertation are n-bit transponders which use an electronic microchip as the data carrying device. These transponders can transfer data in different methods and are currently used in a variety of standards all over the globe.

The following sections of this chapter will approach concepts that are required to understand systems using n-bit tags, specifically UHF RFID. For a deeper analysis of other RFID systems refer to The RFID Handbook by Klaus Finkenzeller.

2.4.2 Power Supply

Passive

Passive tags are characterized for not having an on-board power source. Instead they use themselves the power emitted from the reader antenna to energize itself and transmit the stored data to the reader. As such, tag-to-reader communication is always started by a reader, since it needs to energize the tag.

This makes tags simple and cheap to manufacture, a microchip and an antenna is all there is to it. A few examples of state of the art passive UHF tag inlays can be seen in figure 2.5. The simple constitution makes these tags robust, capable of withstanding corrosive chemicals such as acid and high temperatures 4. These are the type of tags that underwent

 $^{^4}$ The new Impinj M730 and M750 UHF regular tags for item tagging sustains 206°C for 1 minute and can

most technology advancements in the last decade in order to meet performance, compatibility and cost expectations that make mass deployment feasible for companies.









g-tags, Paper/cardboard tagging, documents, folders, envelopes

Optimized for retail automotive tire labels, general automotive assets

Figura 2.5: Selection of passive UHF tag inlays for distinct applications from Alien Technology, LLC 2020 Product Family [21]

Active

Active tags have on-board power source and use it to transmit data to the reader. These type of tags do not need reader's emitted power for data transmission, therefore, in tagto-reader communication, tags can either communicate first or be interrogated by a reader. Usually, active tags stay in a low-power state (i.e. sleep) in the absence of interrogation by the reader. When a reader wants to interact with a tag, issues a wake up command. The tag transits out the low-power state and resolves the interrogation. The RF environment generated by systems with these type of tags has generally much lower RF noise.

Since the presence of the reader is not necessary for data transmission, an active tag can broadcast its data, like a beacon, to its surrounding even in the absence of a reader. This is what is denominated as *transmitter*. Widely used for **loT** applications as *wireless* computers to measure, process and transmit information about sensors, but out the scope of this dissertation.





(a) Tag mounted on Model 9975 drum

Figura 2.6: U.S. Department of Energy prototype active tag with sensors for nuclear materials management working in 433.9MHz UHF ISO band [22]

removed

Semi-passive

Semi-passive tags, also called *semi-active* or *battery assisted* tag, have on-board power source but contrarily to active tags, it is only used for energizing the tag, thus, for transmitting retain data at 125° C for 1 year [20] Tab. 18]

its data, a semi-passive tag uses the reader's emitting power.

There are advantages of using these type of tags over passive ones. Semi-passive tags do not use the reader signal to excite itself, so it can be read from further distances compared to passive tags. Because no time is needed to energize a semi-passive tag, it can also be read much faster than a passive one, making them useful for applications were the tag is in the reading zone for a short period of time (e.g. tolls on highways). Finally, this type of tag might also offer better readability in RF-opaque and RF-absorbent materials.



Figura 2.7: CAEN RFID A927Z semi-passive UHF logger tag for temperature monitoring of sensitive products during transportation and storage [23]

2.4.3 Coupling

We discussed in section 2.3 how electromagnetic fields behave throughout the space surrounding a transmitting antenna. Lets now understand how RFID technologies take advantage of radio frequency to establish a communication channel between reader and tag.

Coupling in RFID refers to the energy absorbed by a receiving antenna when a transmitting one is operating. It is a fundamental concept in RFID communications and affects several aspects of a system including range, frequency and cost. The coupling method and operating frequency are the defining parameters of technology categorization in RFID, presented in section 2.4.4 and used all over the world as a baseline to describe RFID systems.

There are three types of coupling techniques: inductive, capacitive and backscatter. This dissertation focuses on passive tag systems operating in the *remote-couple* (i.e. range from 1cm to 100cm) and *long-range* (i.e further than 100cm). Capacitive coupling is only exploited for data transmission in *close coupling systems* (i.e. range less than 1cm), therefore this type of coupling technique will not be discussed.

Inductive

Inductive-coupling systems, also known as magnetic-coupling, use the near-field magnetic component of the $\overline{\text{EMF}}$ to establish a mutual coupling between reader and tag.

The reader antenna coil generates a strong high frequency EM field. The variation of the magnetic flux excites the cross-section of the tag coil and induces a voltage. Considering the wavelength of the frequency range used (< 135 kHz: 2400m, 13.58MHz: 22.1m) is several times greater than the distance between reader antenna and the transponder, we can treat it just like a simple inductive coupling system, just like a transformer.

This voltage is rectified and supplied to the tag circuitry. The circuitry is actually designed to resonate at the transmission frequency of the reader. The resonance will generate high current in the reader, which produces the required field strength necessary for operation.

To transmit data from tag to reader, inductive systems use load modulation. The microchip changes de load on its coil in relation with the digital data to transmit. When a transponder, resonant at the transmission frequency of the reader, is placed in the reactive *near-field* region, through mutual coupling, energy is drawn by the transponder, being detected by the reader as a voltage drop in the internal resistance of the reader through supply of current to the reader antenna.




Figura 2.8: Inductive coupled RFID system overview 14

This modulation method presents a fundamental problem. Due to weak coupling between antennas, there are voltage fluctuations at the antenna of the reader that are much higher than the fluctuations generated by the load modulation in the transceiver. This is a problem that usually appears in LF RFID systems. Detecting this slight voltages requires highly complicated circuitry which is undesirable. Modern systems (e.g. 13.58MHz HF RFID) use what is called: load modulation with subcarrier. It uses the side bands created around the operating frequency (f_T) for the transmission of data. Switching the load resistor at a high elementary frequency (f_s) , generates two spectral lines at a distance of $\pm f_s$ which contains the modulated signal. An illustration of this can be seen in figure 2.9 The reader can demodulate and retrieve information that is carried in the sidebands of the two subcarrier sidebands, which are themselves created by the modulation of the subcarrier.

Despite wide scale use and established global standardization, this type of coupling presents a few drawbacks. The reading distance is physically limited by the size of the reader antenna and the reactive near-field boundary discussed through out section 2.3. The shrinkage of tag size is technically challenging due to the power emissions regulations and the dependence with the variation of the magnetic flux through the cross-section of the tag antenna coil that excites the tag circuitry. The power consumption is also much higher than the next coupling technique we will look at, making it unsuitable for long-range systems.




Figura 2.9: Load modulation with subcarriers of a typical HF RFID system [14]

Backscatter

Backscatter coupling harvests energy from the EMW, transmitted by the reader antenna, to power the tag circuitry. It is mainly used in *long-range systems* since it is the primarily coupling technique capable of operate in the *far-field* region. To transmit data back to the reader, the tag *reflects* back some of the power as a modulated signal through what is called *modulated reflection cross-section*.

Modulated reflection cross-section functions by the same fundamental principles as the first RFID system invented, presented in section 2.1. EMW are reflected by objects with dimensions greater than around half the wavelength of the wave. The efficiency with which an object reflects EMW is described by its reflection cross-section. Objects that are in resonance with the wave front that hits them, as is the case for antennas tuned to the appropriate frequency, have a particularly large reflection cross-section.

The modulation of the RF signal is created by changing the impedance viewed from the tag antenna, in similar manner to inductive coupling systems. Depicted in figure 2.10, a load resistor, connected in parallel with the antenna, is switched on and off in time with the data stream to be transmitted. The power reflected back changes in amplitude with the changing of impedance of the tag. The reflected signal is picked by the reader antenna. decoupled using a directional coupler and demodulated 14, 24.




Figura 2.10: Passive backscatter RFID system [14]

2.4.4 Technologies

When categorizing systems, the main aspect that defines RFID technologies is the operating frequency. In the previous sections we noticed a clear relation between operating frequency, through the wavelength, and system specifications like reading distance and data transfer speeds. So, it is no accident that this spontaneous categorization happened. RFID technologies tend to mature in a very clear path, being encompassed under use case specific standards with fixed operating frequencies carefully assigned by regulatory RF authorities in each country. It is indeed a useful classification method to summarize a set of specifications that usually need to established a priori to system design.

Being so, it is common in RFID slang to name systems by the frequency band they operate in. There are five preeminent frequency groups: LF, HF, UHF, Microwave and Ultra-wide band (UWB) which will not further discussed being in early phases of technological development. Each of the frequency groups presents characteristics inherent to their physical limitations that should be considered when choosing a technology.

LF. usually operate in the 125KHz to 134KHz frequency range, using passive tags through inductive coupling. Inherently, it has slow read speed and the reading range is limited to around 0.5m. Despite the drawbacks, they have good behavior in metals and liquids and are the most mature technology, probably having the largest installed based system. It is widely used in animal identification (ISO 11784/5 25, 26, ISO 14223 27), access control, logistics and data collection 28 and automotive industry in car ignition keys, to say a few.

HF. operates mostly around the 13.54MHz frequency band. In same manner as LF, it uses inductive coupling. The higher operating frequency allows faster data read speeds while maintaining semi-decent behavior in metals and liquids. Widely used in smart cards [29], [30] for all kinds of applications and is the basis of Near-field communication (NFC) technology [31], [32]. NFC has been receiving a lot of attention. It is a global communication standard with a mature market (being in range high smartphone nowadays). This convened big companies to invest in it, which promoted wide scale manufacturing, resulting in the reduction of tag price (\$0.35 - \$10.00 per tag) and increase in system deployments.

UHF operates in the band of 315MHz to 433MHz using active tags [33], and in 860MHz to 956MHz using passive ones [34]. It is known for the promises it brings to SCM and logistics, being a cheap and affordable technology to wirelessly identify and track every item. It is mainly used in item tracking but it can be used for all kinds of applications. It uses backscatter coupling to transmit data between reader and tag. These frequencies present some drawbacks: poor behavior on liquid and metals is a big problem with passive tags; the allocation of the RF spectrum differs between countries being a huge problem for global deployments. This thematic will be further discussed throughout this dissertation.

Microwave. typically operates at 2.45GHz [5] [35] which is also called Industry, Scientific, and Medical (ISM) band, accepted globally. Uses backscatter coupling with passive, semi-passive and active tags. It performs very poorly in the presence of metals and liquids. For concise information related to each band on RF properties in different materials consult table [2.1]

Tabela 2.1:	RF properties	in different	materials	36	

Material	LF	HF	UHF	Microwave
Clothing	RF-lucent	RF-lucent	RF-lucent	RF-lucent
Dry wood	RF-lucent	RF-lucent	RF-lucent	RF-absorbent
Graphite	RF-lucent	RF-lucent	RF-opaque	RF-opaque
Liquids (some types)	RF-lucent	RF-lucent	RF-absorbent	RF-absorbent
Metals	RF-lucent	RF-lucent	RF-opaque	RF-opaque
Motor oil	RF-lucent	RF-lucent	RF-lucent	RF-lucent
Paper products	RF-lucent	RF-lucent	RF-lucent	RF-lucent
Plastics (some types)	RF-lucent	RF-lucent	RF-lucent	RF-lucent
Shampoo	RF-lucent	RF-lucent	RF-absorbent	RF-absorbent
Water	RF-lucent	RF-lucent	RF-absorbent	RF-absorbent
Wet wood	RF-lucent	RF-lucent	RF-absorbent	RF-absorbent

2.5 Reader

A reader is a device that can read from and write data to compatible RFID tags. It is responsible for sending and receiving RF signals to and from tags. If we strip down all the features dern readers offer, we can isolate three main components: RF front-end, processor, communication interface.

The RF front-end interfaces with the reader antenna. It is responsible for transmitting power and clock cycle via the antenna to tags in the reading zone, and demodulate RF signals received from tags to be further handled by the processor. Readers must adhere to RF modulation requirements and Effective Isotropic Radiated Power (EIRP) regulations if they want to be approved and commercialized. This fact promotes the implementation of the front-end by a dedicated transceiver microchip and complementary electronics, which is usually chosen. There are also efforts in implementing the RF front-end in field-programmable gate arrays (FPGAs), which might change this paradigm in the next few years [37].

The processor is responsible for all logic necessary in the reader. It often comes with other complementary components like memory and dedicated integrated circuits (ICs) for specific tasks. Readers differ in architecture design between manufacturers, but the processor must at least implement the reader protocol to communicate with compatible tags. This includes decoding and error checking of the analog signals from the RF front-end, a controller interface to allow external entities to communicate with it, to transfer stored data, issue commands, accept commands and control the reader functions.

Communication interface is the component that provides communication instruction to a reader which allows external entities to interact with it. It usually comes inside microprocessors

 $^{^55.8\}mathrm{GHz}$ ISO standard was with drawn

and microcontrollers . It usually seen in commercial readers as serial communication interface or ethernet.

Commercial readers come a variety of types which are suited for different applications. The most common are stationary readers. Also called, *fixed* readers, they are what the name implies, used for making fixed reading zones. They also can be mounted on forklifts and inside of trucks. Other types are handheld readers, for a portable reading device and RFID printers which are used to print smart labels.

2.6 Reader Antenna

A reader communicates with tags through its antenna. Antennas are responsible for converting guided continuous waves (CWs) in radiating EMW and vice-versa. It will only be covered radiating antenna theory for it is what is necessary to follow this dissertation.

In handheld readers, the antenna is generally integrated in to the device. In stationary readers is most commonly found as a separate device attached to an antenna port of the reader by means of a cable. There are different groups of antenna designs: antennas composed of a wire, which encompass the dipole, monopole and loop antennas; constituted of an opening, like the horn and cavity backed slot antennas; and printed circuit antennas like path antennas, commonly used in UHF RFID.

rever text

Evaluating antennas for RFID systems can be done through the parameters specified by the manufacturer, a few rules of thumb and engineering sensibility. At UHF we can control the direction of waves and other parameters, and thus improve the readability of tags.

2.6.1 Radiation pattern

An important parameter in antenna selection is the radiation pattern. Radiation pattern is the mathematical description or representation of the radiation properties of the antenna as a function of space coordinates. It illustrates the regions where the antenna's energy is most effective. In RFID is usually called the footprint of the antenna and determines the read zone. Manufacturers usually provide the radiation patterns for RFID antennas in the datasheet.

Manufacturers usually provide the radiation patterns for RFID antennas in the datasheet.

Different antenna designs radiate different patterns. These radiation patterns are classified in three main classes: isotropic, directional and omnidirectional. For UHF RFID directional antennas are really useful since it is possible o maximize directivity, that is, how well the radiation emitted is concentrated in a single direction. This increases reading distances and defines boundaries in reading zones. UHF RFID directional antennas are commonly patch antennas, also called microstrip or planar antennas. They consist of rectangular metal foil or a plate mounted on a substrate such as Teflon or FR-4 (i.e. woven fiberglass cloth with an epoxy resin binder).

It Is also important, when designing RFID systems, to have notion of the deformations that occur in the radiation patterns. *Multi-path* phenomena - the reflection of EMW in RF-opaque objects which causes waves to be scattered and arrive back at the reader in different paths and times - results in *phase* shifts as constructive and destructive interference. This creates leading to

protrusions and dead zones that will inevitably exist in most UHF RFID and microwave systems deployments.

2.6.2 Polarization

Antennas radiate EMW into surrounding space. Polarization is the direction of oscillation of the EMW and has a great importance in tag readability.

EMWs behave similarly to a wave of water. When a wave from a source, like a boat, reaches a buoy, the buoy moves mostly up and down. Analogously, EMW moves electrons in the plane perpendicular to the direction of propagation. The direction in which the field points, determines the polarization of the EMW. Unlike water waves, EMWs are not influenced by gravity, so the electric field can point in any direction in the plane perpendicular to the direction of propagation, and so have different polarizations [6].

The main types of polarization are known as linear and circular. Both types derive from the elliptical polarization, being linear and circular special cases of such.

Linear polarization

Linear polarized antenna emanate EMWs in a linear pattern, that is, emits EMW with only one field of energy.

These antennas have a narrower radiation beam with better directivity compared to circular polarized antennas. This results in longer reading distances and well-defined reading regions, which are essential to good RFID system design.

These advantages can sometimes fall short to the disadvantages. Linear antennas are sensitive to tag orientation with respect to its polarization direction. RFID tag antennas are usually dipoles constituted of narrow metal traces aligned in one direction. If the electric field is directed along the traces, it can push electrons back and forth inducing the voltage necessary to energize the tag IC. If the electric field is directed perpendicular to the trace axis, it moves electrons across the diameter of the trance, producing negligible current, insufficient to power the tag IC. Linear antennas are generally used in applications where tag orientation is fixed and predictable, or in conjunction with other complementary linear antennas.

Circular polarization

Circular polarized antennas solve, to certain degree, the orientation dependence problem produce with detriment of reading distance and a wider radiation beam. These antennas have two constituting energy fields that are equal in amplitude and magnitude, with a phase difference of 90° between them. This results in the electric field vector to be seen as helix like trace, a circular motion propagating through space.

Because the nature of circular polarized antennas, they are to a certain extent, unaffected by tag orientation. A circularly polarized EMW interacts with the linear antenna of a tag, tilted at any angle within the plane perpendicular to the axis of propagation, but in every case only half the transmitted power can be received. Good antenna design in tags can modestly improve energy harvesting performance, e.g. incorporate two dipole antennas on the tag directed orthogonally to one another or physically larger bow-tie antenna designs.

These antennas are widely used in passive UHF RFID, specially in RF environment with high degree of RF reflectance, like due to presence of metals.

Falta só fechar o capítulo e ligar ao seguinte!

Referências

- [1] Oxford Languages and Google English -, es-ES, https://languages.oup.com/google-dictionary-en/.
- [2] B. Marr, What Is Industry 4.0? Here's A Super Easy Explanation For Anyone, en, https://www.forbes.com/sites/bernardmarr/2018/09/02/what-is-industry-4-0-heres-a-super-easy-explanation-for-anyone/.
- [3] B. C. Hardgrave e J. Patton, «2016 State of RFID Adoption Among U.S. Apparel Retailers», en, p. 7,
- [4] DOD Releases Final RFID Policy 2004-08-09 Page 1 RFID Journal https://www.rfidjournal.com/articles/view?1080.
- [5] V. Oana, Barna, C. Maria, I. Surugiu, R. Petrescu e V. Alexandrescu, «RFID Technology in Containers Multimodal Transport», Supply Chain Management Journal, vol. 4, jan. de 2013.
- [6] D. M. Dobkin, The RF in RFID, Second Edition: UHF RFID in Practice, Second. USA: Newnes, 2012, ISBN: 0-12-394583-6.
- [7] The History of RFID Technology | RFID JOURNAL, https://www.rfidjournal.com/the-history-of-rfid-technology.
- [8] André Ventura da Cruz Marnoto Zúquete e N. Borges de Carvalho, *Identificação Por RFID, 2017-2018, Slides*, English, Universidade de Aveiro, 2018.
- [9] J. Landt, "The History of RFID", IEEE Potentials, vol. 24, n.º 4, pp. 8–11, 2005.
- [10] H. Casier, M. Steyaert e A. Roermund, van, eds., Analog Circuit Design: Robust Design, Sigma Delta Converters, RFID, English. Germany: Springer, 2011, ISBN: 978-94-007-0390-2. DOI: 10.1007/978-94-007-0391-9.
- [11] RFID Adoption Stalls: Executive Summary | Computer Economics for IT Metrics, Ratios, Benchmarks, and Research Advisories for IT Management, https://www.computereconomics.com/article.cfm?id=1203.
- [12] S. Gaudin, Some Suppliers Gain from Failed Wal-Mart RFID Edict, en, https://www.cio.com/article/2436434/some-suppliers-gain-from-failed-wal-mart-rfid-edict.html, abr. de 2008.
- [13] RFID in Retail Apparel, en-US, https://gaorfid.com/rfid-in-retail-apparel/.
- [14] K. Finkenzeller, RFID Handbook: Fundamentals and Applications in Contactless Smart Cards and Identification, Second. Wiley Publishing, 2003, ISBN: 0-470-84402-7.
- [15] C. A. Balanis, Antenna Theory: Analysis and Design. Wiley-Interscience, 2005.
- [16] Electromagnetic Radiation: Field Memo / Occupational Safety and Health Administration, https://www.osha.gov/radiofrequency-and-microwave-radiation/electromagnetic-field-memo.
- [17] Zerodamage e Peter R. Franchi et al., Far and Near Fields (Vectorized), en, mar. de 1991.
- [18] P. Nikitin, K. Rao e S. Lazar, «An Overview of near Field UHF RFID», sér. IEEE Int Conf RFID, abr. de 2007, pp. 167–174. DOI: 10.1109/RFID.2007.346165.
- [19] Safety and Health Topics | Radiofrequency and Microwave Radiation Electromagnetic Radiation: Field Memo | Occupational Safety and Health Administration, https://www.osha.gov/SLTC/radiofrequencyradiation/electromagnetic_fieldmemo/electromagnetic.html.

- [20] Impinj M730 & M750 Product Brief / Datasheet, en-US, http://support.impinj.com/hc/en-us/articles/360010797539.
- [21] Alien, Alien Product Family Overview (2020 06 29), jun. de 2020.
- [22] H. Tsai, K. Chen, Y. Liu, J. Norair, S. Bellamy e J. Shuler, «Applying RFID Technology in Nuclear Materials Management», Packaging, Transport, Storage and Security of Radioactive Material, vol. 19, mar. de 2008. DOI: 10.1179/174651008X279000.
- [23] Caen, Caen A927Z Temp Logger Data Sheet 2018.
- [24] RFID Coupling Techniques: Backscatter Capacitive Inductive » Electronics Notes, https://www.electronics-notes.com/articles/connectivity/rfid-radio-frequency-identification/coupling-techniques-capacitive-inductive-backscatter.php.
- [25] ISO, ISO 11784:1996, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/02/58/25881.html.
- [26] —, ISO 11785:1996, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/01/99/19982.html.
- $[27] \quad ----, ISO\ 14223-3:2018, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/05/96/59602.html.$
- [28] —, ISO/IEC 18000-2:2009, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/04/61/46146.
- [29] —, ISO/IEC 15693-2:2019, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/07/36/73601.
- [30] MIFARE, https://www.mifare.net/en/.
- [31] —, ISO/IEC 14443-4:2018, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/07/35/73599.
- [32] —, ISO/IEC 18000-3:2010, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/05/34/53424.
- [33] —, ISO/IEC 18000-7:2014, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/05/73/57336.
- [34] —, ISO/IEC 18000-6:2010, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/04/61/46149.
- [35] —, ISO/IEC 18000-4:2015, en, https://www.iso.org/cms/render/live/en/sites/isoorg/contents/data/standard/06/25/62539.
- [36] S. Lahiri, RFID Sourcebook. IBM Press, 2005, ISBN: 0-13-185137-3.
- [37] Hugo Manuel Oliveira de Miranda, «Sistemas RFID UHF», pt-PT, MSc Dissertation, Universidade de Aveiro, Aveiro, 2015.