

```
-----
10000 SUB CONFIRMF18
10010 CALL F18UNLOCK
10020 CALL POKEV(4096,0,0,7,32,16,0,3,64)
10030 CALL POKER(54,16;55,2)
10040 CALL PEEKV(4096,X)
10050 IF X<>0 THEN 10080
10060 PRINT "F18A REQUIRED!"
10070 END
10080 SUBEND

12000 SUB LOADPALETTE(PALNUM)
12010 ! VPOKE YOUR 32-BYTES (16 COLORS)
      AT VDP 4116 BEFORE CALLING!
12020 ! WILL OVERWRITE THE PROGRAM AT VDP 4096
12030 ! PALNUM IS 0-3 FOR WHICH PALETTE TO LOAD
12040 ! IS VDP@>1000 ALWAYS A SAFE LOCATION?
      MAYBE DEPENDS ON PROGRAM
12050 ! THIS IS THE PROGRAM LOOP BELOW
12060 IF PALNUM>=0 AND PALNUM<=3 THEN 12080
12070 BREAK:;! ILLEGAL PALETTE NUMBER
      - BREAK INSTEAD OF CORRUPT VDP RAM
12080 CALL POKEV(4096,2,0,16,20,2,1,80,PALNUM*32,2,2,0,16)
12090 CALL POKEV(4108,204,112,6,2,22,253,3,64)
12100 ! ASSUMES THE CALLER ALREADY LOADED THE PALETTE
12110 CALL POKER(54,16;55,0)
12120 SUBEND

13000 SUB RESETF18A
13010 ! FIRST RESTORE THE DEFAULT TI PALETTE
13020 ! SINCE THIS CAN'T BE DONE AUTOMATICALLY!
13030 ! IF WE NEVER CHANGED PALETTE 0
      (IE: TRY CHANGING THE CODE ABOVE TO CHANGE PALETTES
      1 AND 2 INSTEAD OF 0 AND 1.
13040 ! USE REGISTER 24 TO CHANGE THE TEXT LAYER TO THE NEW PALETTE)
13050 ! ANYWAY, IF WE DIDN'T CHANGE PALETTE 0,
      THEN THE RESET WOULD BE ENOUGH!
13060 ! JUST POKE IN THE VALUES FOR THE DEFAULT PALETTE,
      AND THEN LOAD PALETTE 0
13070 CALL POKEV(4116,0,0,0,0,2,195,5,214)
13080 CALL POKEV(4124,5,79,7,111,13,84,4,239)
13090 CALL POKEV(4132,15,84,15,118,13,195,14,214)
13100 CALL POKEV(4140,2,178,12,92,12,204,15,255)
13110 CALL LOADPALETTE(0)
13120 ! THEN JUST POKE THE RESET REGISTER AND EVERYTHING
      ELSE IS RESTORED
13130 CALL POKER(50,128)
13140 SUBEND
```