

IO List - Hydrogenation 2

Wilmar Industrial Complex PT MNA Serang, Indonesia

End Customer: Wilmar Industrial Complex PT MNA
Serang, Indonesia

End Customer Reference Number:

Document File Name: 3258585-PSS-PASH-DWG-00043

Document Status: For Final

Authorisations

	Name	Function	Signature
Developed By:	Zul Hasyidi Hassan	Project Engineer	ZHH 
Reviewed By:	Liow Kok Loong	Lead Engineer	LKL 
Released By:	Mohd. Nazim Ismail	Project Manager	MNI 

Distribution

Name	Company	Name	Company

Revision History

Rev	Status	Description	Date	Developed By	Reviewed By
A	For Review	Issued for Review	18-Sep-18	ZHH	LKL
B	For Review	Issued for Review	11-Oct-18	ZHH	LKL
0	For Final	Issued for Final	18-Oct-19	ZHH	LKL

© Emerson Automation Solution. All rights reserved. Unauthorized duplication, in whole or in part, is prohibited. Trademarks identified in this document are owned by one of the Emerson Process Management group of companies. Unless otherwise agreed to in writing by the parties, any information provided in this document is confidential or proprietary and may not be used or disclosed without the expressed written permission of Emerson Process Management.

Emerson Automation Solution Process System and Solutions

No. 1, Block A, Jalan SS13/5, SS13
Subang Jaya, 47500, Selangor
Malaysia
T +60 (3) 5624-2888
F +60 (3) 5638-1010
www.EmersonProcess.com

											RIO CABINET												SYSTEM CABINET		
											Marshalling				Relay				DELTA V				DELTA V		
Vendor's tags	Wilmar's Tags	Emerson's Tags	Module Name	Description	Type	IO Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Classification	Cabinet Name	TB Name	Term. (+)	Term. (-)	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
M1-1303	AG2203-CU	HY2-AG2203-CU	HY2_AG2203	Hydrogenation Reactor Agitator	Motor current feedback	AI		4-20 mA	2 wire	Non-IS	HY2-RMCC_1	TB-AI	1	2						S1	1	1	2	SFO-DCS-006	SFO-CTRL6
PU-309A	PU309A-CU	HY2-PU309A-CU	HY2_PU309A	Cooling Water Pump	Motor current feedback	AI		4-20 mA	2 wire	Non-IS	HY2-RMCC_1	TB-AI	3	4						S1	2	3	4	SFO-DCS-006	SFO-CTRL6
PU-309B	PU309B-CU	HY2-PU309B-CU	HY2_PU309B	Cooling Water Pump	Motor current feedback	AI		4-20 mA	2 wire	Non-IS	HY2-RMCC_1	TB-AI	5	6						S1	3	5	6	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	7	8						S1	4	7	8	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	9	10						S1	5	9	10	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	11	12						S1	6	11	12	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	13	14						S1	7	13	14	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	15	16						S1	8	15	16	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	17	18						S1	9	17	18	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	19	20						S1	10	19	20	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	21	22						S1	11	21	22	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	23	24						S1	12	23	24	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	25	26						S1	13	25	26	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	27	28						S1	14	27	28	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	29	30						S1	15	29	30	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RMCC_1	TB-AI	31	32						S1	16	31	32	SFO-DCS-006	SFO-CTRL6
1-P1301	PU2001-XL	HY2-PU2001-XL	HY2_PU2001		Motor run feedback	DI		DI Dry Contact	2-wire	Non-IS	HY2-RMCC_1	TB-DI	1	2						S3	1	1	NA	SFO-DCS-006	SFO-CTRL6
1-P1301	PU2001-XA	HY2-PU2001-XA	HY2_PU2001		Motor trip feedback	DI		DI Dry Contact	2-wire	Non-IS	HY2-RMCC_1	TB-DI	3	4						S3	2	2	NA	SFO-DCS-006	SFO-CTRL6
1-P1316A	PU2316A-XL	HY2-PU2316A-XL	HY2_PU2316A	Filtered Oil Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	5	6						S3	3	3	NA	SFO-DCS-006	SFO-CTRL6
1-P1316A	PU2316A-XA	HY2-PU2316A-XA	HY2_PU2316A	Filtered Oil Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	7	8						S3	4	4	NA	SFO-DCS-006	SFO-CTRL6
1-P1335A	PU2135A-XL	HY2-PU2135A-XL	HY2_PU2135A	Catalyst Mixing Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	9	10						S3	5	5	NA	SFO-DCS-006	SFO-CTRL6
1-P1335A	PU2135A-XA	HY2-PU2135A-XA	HY2_PU2135A	Catalyst Mixing Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	11	12						S3	6	6	NA	SFO-DCS-006	SFO-CTRL6
1-P1335B	PU2135B-XL	HY2-PU2135B-XL	HY2_PU2135B	Spent Catalyst Dosing Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	13	14						S3	7	7	NA	SFO-DCS-006	SFO-CTRL6
1-P1335B	PU2135B-XA	HY2-PU2135B-XA	HY2_PU2135B	Spent Catalyst Dosing Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	15	16						S3	8	8	NA	SFO-DCS-006	SFO-CTRL6
1-P1350/81B	PU2350B-XL	HY2-PU2350B-XL	HY2_PU2350B	Final Oil Cooler Water Circulating Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	17	18						S3	9	9	NA	SFO-DCS-006	SFO-CTRL6
1-P1350/81B	PU2350B-XA	HY2-PU2350B-XA	HY2_PU2350B	Final Oil Cooler Water Circulating Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	19	20						S3	10	10	NA	SFO-DCS-006	SFO-CTRL6
1-P1378TW	PU2078TW-XL	HY2-PU2078TW-XL	HY2_PU2078TW	Treated Water Circulating Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	21	22						S3	11	11	NA	SFO-DCS-006	SFO-CTRL6
1-P1378TW	PU2078TW-XA	HY2-PU2078TW-XA	HY2_PU2078TW	Treated Water Circulating Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	23	24						S3	12	12	NA	SFO-DCS-006	SFO-CTRL6
1-P1382B	PU2282B-XL	HY2-PU2282B-XL	HY2_PU2282B	Reactor Drop Tank Transfer Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	25	26						S3	13	13	NA	SFO-DCS-006	SFO-CTRL6
1-P1382B	PU2282B-XA	HY2-PU2282B-XA	HY2_PU2282B	Reactor Drop Tank Transfer Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	27	28						S3	14	14	NA	SFO-DCS-006	SFO-CTRL6
1-P1382C	PU2282C-XL	HY2-PU2282C-XL	HY2_PU2282C	Filter Feed Pump	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	29	30						S3	15	15	NA	SFO-DCS-006	SFO-CTRL6
1-P1382C	PU2282C-XA	HY2-PU2282C-XA	HY2_PU2282C	Filter Feed Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	31	32						S3	16	16	NA	SFO-DCS-006	SFO-CTRL6
M1-1303	AG2203-XL	HY2-AG2203-XL	HY2_AG2203	Hydrogenation Reactor Agitator	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	33	34						S3	17	17	NA	SFO-DCS-006	SFO-CTRL6
M1-1303	AG2203-XA	HY2-AG2203-XA	HY2_AG2203	Hydrogenation Reactor Agitator	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	35	36						S3	18	18	NA	SFO-DCS-006	SFO-CTRL6
M1-1335A	AG2135A-XL	HY2-AG2135A-XL	HY2_AG2135A	Catalyst Mixing Tank Agitator	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	37	38						S3	19	19	NA	SFO-DCS-006	SFO-CTRL6
M1-1335A	AG2135A-XA	HY2-AG2135A-XA	HY2_AG2135A	Catalyst Mixing Tank Agitator	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	39	40						S3	20	20	NA	SFO-DCS-006	SFO-CTRL6
M1-1335B	AG2135B-XL	HY2-AG2135B-XL	HY2_AG2135B	Spent Catalyst Collecting Tank Agitator	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	41	42						S3	21	21	NA	SFO-DCS-006	SFO-CTRL6
M1-1335B	AG2135B-XA	HY2-AG2135B-XA	HY2_AG2135B	Spent Catalyst Collecting Tank Agitator	Motor trip feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	43	44						S3	22	22	NA	SFO-DCS-006	SFO-CTRL6
M1-1382B	AG2282B-XL	HY2-AG1282B-XL	HY2_AG1282B	Reactor Drop Tank Agitator	Motor run feedback	DI		DI Dry Contact	2 wire	Non-IS	HY2-RMCC_1	TB-DI	45	46						S3	23	23			

											RIO CABINET														SYSTEM CABINET	
											Marshalling				Relay				DELTA V				DELTA V			
Vendor's tags	Wilmar's Tags	Emerson's Tags	Module Name	Description	Type	IO Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Classification	Cabinet Name	TB Name	Term. (+)	Term. (-)	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller	
TT-1-1335B	TT2135B	HY2-TT2135B	HY2 TT2135B		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	9	10	1	3	BAI-003	7	8	S1	5	9	10	SFO-DCS-006	SFO-CTRL6	
TT-1-1381B-1	TT2381B1	HY2-TT2381B1	HY2-TT2381B1		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	11	12	4	6		10	11	S1	6	11	12	SFO-DCS-006	SFO-CTRL6	
TT-1-1381B-2	TT2381B2	HY2-TT2381B	HY2 TT2381B		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	13	14	1	3	BAI-004	7	8	S1	7	13	14	SFO-DCS-006	SFO-CTRL6	
TT-1-1381W	TT2081W	HY2-TT2081W	HY2 TT2081W		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	15	16	4	6		10	11	S1	8	15	16	SFO-DCS-006	SFO-CTRL6	
TT-1-1382B	TT2282B	HY2-TT2282B	HY2 TT2282B		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	17	18	1	3	BAI-005	7	8	S1	9	17	18	SFO-DCS-006	SFO-CTRL6	
TT-1-1382C-1	TT2282C1	HY2-TT2282C	HY2 TT2282C		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	19	20	4	6		10	11	S1	10	19	20	SFO-DCS-006	SFO-CTRL6	
FT-1-1346A	FT2446A	HY2-FT2446A	HY2 FT2446A		Vortex Flowmeter	AI	0-1757 kg/hr	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	21	22	1	3	BAI-006	7	8	S1	11	21	22	SFO-DCS-006	SFO-CTRL6	
PT-1-1346A	PT2446A	HY2-PT2446A	HY2-PT2446A		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	23	24	4	6		10	11	S1	12	23	24	SFO-DCS-006	SFO-CTRL6	
TT-1-13781TW	TT20781TW	HY2-TT20781TW	HY2 TT20781TW		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	25	26	1	3	BAI-007	7	8	S1	13	25	26	SFO-DCS-006	SFO-CTRL6	
FT-1-1382B	FT2282B	HY2-TT2282B	HY2 FT2282B		Mass	AI	0-15121 kg/hr	4-20 mA HART	4 wire	IS	HY2-RIO-001	TB-AI	27	28	6	5		10	11	S1	14	27	28	SFO-DCS-006	SFO-CTRL6	
PT-1-1316A-4	PT2316A4	HY2-PT2316A4	HY2 PT2316A4		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	29	30	1	3	BAI-008	7	8	S1	15	29	30	SFO-DCS-006	SFO-CTRL6	
PT-1-1316B	PT2316B	HY2-PT2316B	HY2 PT2316B		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	31	32	4	6		10	11	S1	16	31	32	SFO-DCS-006	SFO-CTRL6	
TT-1-1303	TT2203	HY2-TT2203	HY2 TT2203		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	33	34	1	3	BAI-009	7	8	S2	1	1	2	SFO-DCS-006	SFO-CTRL6	
TT-1-1381A	TT2281A	HY2-TT2281A	HY2 TT2281A		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	35	36	4	6		10	11	S2	2	3	4	SFO-DCS-006	SFO-CTRL6	
FT-1-1303-H	FT2203H	HY2-FT2203H	HY2 FT2203H		Mass	AI	0-1320 Nm3/hr	4-20 mA HART	4 wire	IS	HY2-RIO-001	TB-AI	37	38	3	2	BAI-010	7	8	S2	3	5	6	SFO-DCS-006	SFO-CTRL6	
PT-1-1303	PT2203	HY2-PT2203	HY2 PT2203		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	39	40	4	6		10	11	S2	4	7	8	SFO-DCS-006	SFO-CTRL6	
TT-1-1302/82A	TT2002	HY2-TT2002A	HY2 TT2002A		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	41	42	1	3	BAI-011	7	8	S2	5	9	10	SFO-DCS-006	SFO-CTRL6	
PT-1-1341A	PT2041A	HY2-PT2041A	HY2 PT2041A		Vacuum	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	43	44	4	6		10	11	S2	6	11	12	SFO-DCS-006	SFO-CTRL6	
TT-1-1341A	TT2041A	HY2-TT2041A	HY2 TT2041A		RTD	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	45	46	1	3	BAI-012	7	8	S2	7	13	14	SFO-DCS-006	SFO-CTRL6	
FT-1-P1301	FT2001	HY2-FT2001	HY2 FT2001		Mass	AI	0-15605 kg/hr	4-20 mA HART	4 wire	IS	HY2-RIO-001	TB-AI	47	48	6	5		10	11	S2	8	15	16	SFO-DCS-006	SFO-CTRL6	
FT-1332	FT1332	HY2-FT1332	HY2-FT1332			AI					HY2-RIO-001	TB-AI	49	50	1	3	BAI-013	7	8	S2	9	17	18	SFO-DCS-006	SFO-CTRL6	
PT-1-1316C1	PT2316C1	HY2 PT2316C1	HY2 PT2316C1		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	51	52	4	6		10	11	S2	10	19	20	SFO-DCS-006	SFO-CTRL6	
PT-1-1316C2	PT2316C2	HY2-PT2316C2	HY2 PT2316C2		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	53	54	1	3	BAI-014	7	8	S2	11	21	22	SFO-DCS-006	SFO-CTRL6	
PT-1-MP	PT231MP	HY2-PT231MP	HY2 PT231MP		Gauge	AI		4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AI	55	56	4	6		10	11	S2	12	23	24	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AI	57	58						S2	13	25	26	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AI	59	60						S2	14	27	28	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AI	61	62						S2	15	29	30	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AI	63	64						S2	16	31	32	SFO-DCS-006	SFO-CTRL6	
FCV-1-P1378TW	FCV2078W	HY2-FCV2078TW	HY2 FCV2078TW		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AO	1	2	1	2	BAI-001	8	7	S4	1	1	2	SFO-DCS-006	SFO-CTRL6	
TCV-1-1381B	TCV2381B	HY2-TCV2381B	HY2 TCV2381B		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	BAI-002	TB-AO	3	4	1	2	BAI-002	8	7	S4	2	3	4	SFO-DCS-006	SFO-CTRL6	
FCV-1-P1382B	FCV2282B	HY2-FCV2282B	HY2 FT2282B		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AO	5	6	1	2	BAI-003	8	7	S4	3	5	6	SFO-DCS-006	SFO-CTRL6	
TCV-1-1381A	TCV2281A	HY2-TCV2281A	HY2 TT2281A		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AO	7	8	1	2	BAI-004	8	7	S4	4	7	8	SFO-DCS-006	SFO-CTRL6	
PCV-1-1303-H	PCV2203H	HY2-PCV2203H	HY2 PCV2203H		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AO	9	10	1	2	BAI-005	8	7	S4	5	9	10	SFO-DCS-006	SFO-CTRL6	
FCV-1-P1301	FCV2001	HY2-FCV2001	HY2 FT2001		Electro-pneumatic	AO	0-100%	4-20 mA HART	2 wire	IS	HY2-RIO-001	TB-AO	11	12	1	2	BAI-006	8	7	S4	6	11	12	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AO	13	14						S4	7	13	14	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-001	TB-AO	15	16						S4	8	15	16	SFO-DCS-00		

											RIO CABINET														SYSTEM CABINET	
											Marshalling				Relay				DELTA V				DELTA V			
Vendor's tags	Wilmar's Tags	Emerson's Tags	Module Name	Description	Type	IO Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Classification	Cabinet Name	TB Name	Term. (+)	Term. (-)	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller	
XV-1-1381A-BN	V2381ABN-ZO	HY2-V2381ABN-ZO	HY2_V2381ABN	Valve open indication	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	161	162	1	2	BDI-041	5	6	S3	17	17	NA	SFO-DCS-006	SFO-CTRL6	
XV-1-1381A-BN	V2381ABN-ZC	HY2-V2381ABN-ZC	HY2_V2381ABN	Valve close indication	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	163	164	3	4		7	8	S3	18	18	NA	SFO-DCS-006	SFO-CTRL6	
XV-1-1381A-F	V2381AF-ZO	HY2-V2381AF-ZO	HY2_V2381AF	Valve open indication	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	165	166	1	2	BDI-042	5	6	S3	19	19	NA	SFO-DCS-006	SFO-CTRL6	
XV-1-1381A-F	V2381AF-ZC	HY2-V2381AF-ZC	HY2_V2381AF	Valve close indication	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	167	168	3	4		7	8	S3	20	20	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1335A	LSH2135A	HY2-LSH2135A	HY2_LSH2135A	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	169	170	1	2	BDI-043	5	6	S3	21	21	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1335B	LSH2135B	HY2-LSH2135B	HY2_LSH2135B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	171	172	3	4		7	8	S3	22	22	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1335A	LSL2135A	HY2-LSL2135A	HY2_LSL2135A	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	173	174	1	2	BDI-044	5	6	S3	23	23	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1335B	LSL2135B	HY2-LSL2135B	HY2_LSL2135B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	175	176	3	4		7	8	S3	24	24	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1382B	LSL2282B	HY2-LSL2282B	HY2_LSL2282B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	177	178	1	2	BDI-045	5	6	S3	25	25	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1382C	LSL2282C	HY2-LSL2282C	HY2_LSL2282C	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	179	180	3	4		7	8	S3	26	26	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-P1316A	LSL2316AP	HY2-LSL2316AP	HY2_LSL2316AP	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	181	182	1	2	BDI-046	5	6	S3	27	27	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-P1382B	LSL2282BP	HY2-LSL2282BP	HY2_LSL2282BP	Float	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	183	184	3	4		7	8	S3	28	28	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1378TW	LSH2078TW	HY2-LSH2078TW	HY2_LSH2078TW	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	185	186	1	2	BDI-047	5	6	S3	29	29	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1382C-1	LSH2282C	HY2-LSH2282C	HY2_LSH2282C	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	187	188	3	4		7	8	S3	30	30	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1378TW	LSL2078TW	HY2-LSL2078TW	HY2_LSL2078TW	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	189	190	1	2	BDI-048	5	6	S3	31	31	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1316A	LSH2316A	HY2-LSH2316A	HY2_LSH2316A	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	191	192	3	4		7	8	S3	32	32	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1316B	LSH2316B	HY2-LSH2316B	HY2_LSH2316B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	193	194	1	2	BDI-049	5	6	S4	1	1	NA	SFO-DCS-006	SFO-CTRL6	
LSH-1-1382B	LSH2282B	HY2-LSH2282B	HY2_LSH2282B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	195	196	3	4		7	8	S4	2	2	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1303	LSL2203	HY2-LSL2203	HY2_LSL2203	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	197	198	1	2	BDI-050	5	6	S4	3	3	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1316A	LSL2316A	HY2-LSL2316A	HY2_LSL2316A	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	199	200	3	4		7	8	S4	4	4	NA	SFO-DCS-006	SFO-CTRL6	
LSL-1-1316B	LSL2316B	HY2-LSL2316B	HY2_LSL2316B	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	201	202	1	2	BDI-051	5	6	S4	5	5	NA	SFO-DCS-006	SFO-CTRL6	
LSLL-1-1316A	LSLL2316A	HY2-LSLL2316A	HY2_LSLL2316A	Tuning Fork	DI			NAMUR	2 wire NAMUR	IS	HY2-RIO-002	TB-DI	203	204	3	4		7	8	S4	6	6	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	205	206						S4	7	7	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	207	208						S4	8	8	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	209	210						S4	9	9	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	211	212						S4	10	10	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	213	214						S4	11	11	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	215	216						S4	12	12	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	217	218						S4	13	13	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	219	220						S4	14	14	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	221	222						S4	15	15	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	223	224						S4	16	16	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	225	226						S4	17	17	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	227	228						S4	18	18	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	229	230						S4	19	19	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	231	232						S4	20	20	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	233	234						S4	21	21	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	235	236						S4	22	22	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI	237	238						S4	23	23	NA	SFO-DCS-006	SFO-CTRL6	
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-002	TB-DI														

											RIO CABINET										SYSTEM CABINET				
											Marshalling				Relay				DELTA V				DELTA V		
Vendor's tags	Wilmar's Tags	Emerson's Tags	Module Name	Description	Type	IO Type	Range Proposed (kg/H)	Signal Type	Electrical Connection	Classification	Cabinet Name	TB Name	Term. (+)	Term. (-)	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
XV-1-1303-S	V2203S-ZO	HY2-V2203S-ZO	HY2_V2203S		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	9	10	1	2	BDI-003	5	6	S1	5	5	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303-S	V2203S-ZC	HY2-V2203S-ZC	HY2_V2203S		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	11	12	3	4		7	8	S1	6	6	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303-WV	V2203WV-ZO	HY2-V2203WV-ZO	HY2_V2203WV		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	13	14	1	2	BDI-004	5	6	S1	7	7	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303-WV	V2203WV-ZC	HY2-V2203WV-ZC	HY2_V2203WV		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	15	16	3	4		7	8	S1	8	8	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1335	V2235-ZO	HY2-V2235-ZO	HY2_V2235		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	17	18	1	2	BDI-005	5	6	S1	9	9	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1335	V2235-ZC	HY2-V2235-ZC	HY2_V2235		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	19	20	3	4		7	8	S1	10	10	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303V1	V2203V1-ZO	HY2-V2203V1-ZO	HY2_V2203V1		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	21	22	1	2	BDI-006	5	6	S1	11	11	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303V1	V2203V1-ZC	HY2-V2203V1-ZC	HY2_V2203V1		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	23	24	3	4		7	8	S1	12	12	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303V2	V2203V2-ZO	HY2-V2203V2-ZO	HY2_V2203V2		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	25	26	1	2	BDI-007	5	6	S1	13	13	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303V2	V2203V2-ZC	HY2-V2203V2-ZC	HY2_V2203V2		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	27	28	3	4		7	8	S1	14	14	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303VA	V2203VA-ZO	HY2-V2203VA-ZO	HY2_V2203VA		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	29	30	1	2	BDI-008	5	6	S1	15	15	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303VA	V2203VA-ZC	HY2-V2203VA-ZC	HY2_V2203VA		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	31	32	3	4		7	8	S1	16	16	NA	SFO-DCS-006	SFO-CTRL6
TV-1-1382-MPS	V2082MPS-ZO	HY2-V2082MPS-ZO	HY2_V2082MPS		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	33	34	1	2	BDI-009	5	6	S1	17	17	NA	SFO-DCS-006	SFO-CTRL6
TV-1-1382-MPS	V2082MPS-ZC	HY2-V2082MPS-ZC	HY2_V2082MPS		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	35	36	3	4		7	8	S1	18	18	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1302/82A-LPS	V2002ALPS-ZO	HY2-V2002ALPS-ZO	HY2_V2002ALPS		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	37	38	1	2	BDI-010	5	6	S1	19	19	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1302/82A-LPS	V2002ALPS-ZC	HY2-V2002ALPS-ZC	HY2_V2002ALPS		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	39	40	3	4		7	8	S1	20	20	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1302-F	V2002F-ZO	HY2-V2002F-ZO	HY2_V2002F		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	41	42	1	2	BDI-011	5	6	S1	21	21	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1302-F	V2002F-ZC	HY2-V2002F-ZC	HY2_V2002F		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	43	44	3	4		7	8	S1	22	22	NA	SFO-DCS-006	SFO-CTRL6
LSH-1-1303	LSH2203	HY2-LSH2203	HY2_LSH2203		Tuning Fork	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	45	46	1	2	BDI-012	5	6	S1	23	23	NA	SFO-DCS-006	SFO-CTRL6
LSH-1-1302/82A	LSH2002A	HY2-LSH2002A	HY2_LSH2002A		Tuning Fork	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	47	48	3	4		7	8	S1	24	24	NA	SFO-DCS-006	SFO-CTRL6
LSL-1-1302/82A	LSL2002A	HY2-LSL2002A	HY2_LSL2002A		Tuning Fork	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	49	50	1	2	BDI-013	5	6	S1	25	25	NA	SFO-DCS-006	SFO-CTRL6
PS-1-1303	PSH2203	HY2-PSH2203	HY2_PSH2203		Switching	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	51	52	3	4		7	8	S1	26	26	NA	SFO-DCS-006	SFO-CTRL6
PSE-1-1303-1	RD22031	HY2-RD22031	HY2_RD22031			DI		DI Dry Contact	2 wire	IS	HY2-RIO-003	TB-DI	53	54	1	2	BDI-014	5	6	S1	27	27	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1301-BN	V2001BN-ZO	HY2-V2001BN-ZO	HY2_V2001BN		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	55	56	3	4		7	8	S1	28	28	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1301-BN	V2001BN-ZC	HY2-V2001BN-ZC	HY2_V2001BN		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	57	58	1	2	BDI-015	5	6	S1	29	29	NA	SFO-DCS-006	SFO-CTRL6
PS-1-1301-1	PSH2011	HY2-PSH2011	HY2-CT309-SP		Switching	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	59	60	3	4		7	8	S1	30	30	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1301-F	V2001F-ZO	HY2-V2001F-ZO	HY2_V2001F		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	61	62	1	2	BDI-016	5	6	S1	31	31	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1301-F	V2001F-ZC	HY2-V2001F-ZC	HY2_V2001F		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	63	64	3	4		7	8	S1	32	32	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303-WR	V2203WD-ZO	HY2-V2203WD-ZO	HY2_V2203WD		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	65	66	1	2	BDI-017	5	6	S2	1	1	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1303-WR	V2203WD-ZC	HY2-V2203WD-ZC	HY2_V2203WD		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	67	68	3	4		7	8	S2	2	2	NA	SFO-DCS-006	SFO-CTRL6
XV-1-P1382C-F3	V2282CF3-ZO	HY2-V2282CF3-ZO	HY2_V2282CF3		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	69	70	1	2	BDI-018	5	6	S2	3	3	NA	SFO-DCS-006	SFO-CTRL6
XV-1-P1382C-F3	V2282CF3-ZC	HY2-V2282CF3-ZC	HY2_V2282CF3		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	71	72	3	4		7	8	S2	4	4	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1382C-R	V2382CR-ZO	HY2-V2382CR-ZO	HY2_V2382CR		Valve open indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	73	74	1	2	BDI-019	5	6	S2	5	5	NA	SFO-DCS-006	SFO-CTRL6
XV-1-1382C-R	V2382CR-ZC	HY2-V2382CR-ZC	HY2_V2382CR		Valve close indication	DI		NAMUR	2 wire NAMUR	IS	HY2-RIO-003	TB-DI	75	76	3	4		7	8	S2	6	6	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	77	78						S2	7	7	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	79	80						S2	8	8	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	81	82						S2	9	9	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	83	84						S2	10	10	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	85	86						S2	11	11	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	87	88						S2	12	12	NA	SFO-DCS-006	SFO-CTRL6
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	HY2-RIO-003	TB-DI	89	90						S2	13	13	NA		