

```
* @retval None
*/
                                                                                                    81

    May 2014

                                                                                                           void TM_USART_Puts(USART_TypeDef* USARTx, char* str);
/**
* @brief Sends data array to USART port
* @param *USARTx: Pointer to USARTx peripheral you will use
* @param *DataArray: Pointer to data array to be sent over USART
* @param count: Number of elements in data array to be send over
* @retval None
                                                                                                    86
87
                                                                                                    89
                                                                                                    91
                                                                                                          void TM_USART_Send(USART_TypeDef* USARTx, uint8_t* DataArray, uin
                                                                                                    92
93 /**
                                                                                                            * @brief Gets character from internal USART buffer

* @param *USARTx: Pointer to USARTx peripheral you will use

* @retval Character from buffer, or 0 if nothing in buffer
                                                                                                    94
95
                                                                                                    96
97
98
99
                                                                                                          uint8_t TM_USART_Getc(USART_TypeDef* USARTx);
                                                                                                    99
100 /**
101 * @brief Get string from USART
102 *
103 * This function can crea
                                                                                                   101
                                                                                                   103
                                                                                                                                 This function can create a string from USART received
                                                                                                                                 It generates string until "\n" is not recognized or bu
                                                                                                           * @note As of version 1.5, this function automatically adds 0x6
* @param *USARTx: Pointer to USARTx peripheral you will use
* @param *buffer: Pointer to buffer where data will be stored fr
* @param bufsize: maximal number of characters we can add to you
* @retval Number of characters in buffer
                                                                                                   107
                                                                                                   100
                                                                                                   112 */
113 uint16_t TM_USART_Gets(USART_TypeDef* USARTx, char* buffer, uint16
                                                                                                   115 /**
                                                                                                   115 /**
116 * @brief Check if character c is available in internal buffer
117 * @param *USARTx: Pointer to USARTx peripheral you will use
118 * @param c: character to check if it is in USARTx's buffer
19 * @retval Character status:
20 * - 0: Character was not found
21 * -> 0: Character has been found in buffer
122 */
                                                                                                   123 uint8_t TM_USART_FindCharacter(USART_TypeDef* USARTx, uint8_t c);
                                                                                                  132 uint8_t TM_USART_BufferEmpty(USART_TypeDef* USARTx);
                                                                                                           * @brief Checks if internal USARTx buffer is full
* @param *USARTx: Pointer to USARTx peripheral you will use
* @retval Buffer full status:
* - 0: Buffer is not full
* - > 0: Buffer is full
                                                                                                   135
                                                                                                   136
137
138
139
                                                                                                   141 uint8_t TM_USART_BufferFull(USART_TypeDef* USARTx);
                                                                                                   143 /**
                                                                                                              * @brief Clears internal USART buffer
* @param *USARTx: Pointer to USARTx peripheral you will use
                                                                                                           * @brief Clear
* @param *USAR
* @retval None
*/
                                                                                                   146
147
                                                                                                    148 void TM_USART_ClearBuffer(USART_TypeDef* USARTx);
                                                                                                   150
151
                                                                                                           /**

* @brief Sets custom character for @ref TM_USART_Gets() functior

* @param *USARTx: Pointer to USARTx peripheral you will use

* @param Character: Character value to be used as string end

* @note Character will also be added at the end for your buffer

* @retval None
                                                                                                   153
                                                                                                   155
                                                                                                            \begin{tabular}{ll} \emph{void} & \texttt{TM\_USART\_SetCustomStringEndCharacter(USART\_TypeDef* USARTx,} \\ \end{tabular}
                                                                                                 157 VOID IM_USANT.

158
159 /**
160 * @brief Callback for custom pins initialization for USARTX.
161 * When you call TM_USART_Init() function, and if you pass
162 * then this function will be called where you can initial
163 * @note With __weak parameter to prevent link errors if not def
164 * @param *USARTX: Pointer to USARTX peripheral you will use for
165 * @retval None
166 */
1677 Wid TM USART_InitCustomPinsCallback(USART_TypeDef* USARTX);
                                                                                                   169 /**
                                                                                                           /**

* @brief Callback function for receive interrupt on USART1 in cc

* @note With __weak parameter to prevent link errors if not def

* @param c: character received via USART

* @retval None

*/
                                                                                                   173
                                                                                                   175 __weak void TM_USART1_ReceiveHandler(uint8_t c);
                                                                                                  183
                                                                                                   184

185 /**

186 * @brief Callback function for receive interrupt on USART3 in ca

187 * @note With __weak parameter to prevent link errors if not def

188 * @param c: character received via USART

189 * @retval None
                                                                                                    191 __weak void TM_USART3_ReceiveHandler(uint8_t c);
```

## Hardware

Your computer probably has not RS232 connector, but it has USB for sure. You need **USB to serial** converter. I prefer FTDI which is very stable and support 3V3 levels. You can buy converter on ebay for about 5\$. **Connect converter's TX with board's RX and converter's RX with board's TX.** To display data, you need some terminal, I use one from Bray. Open program and set:


- Select your COM port
- baudrate to **9600**
- Data bits to 8
- Parity to none
- Stop bits to 1

## Example

```
Keil project for USART
             Before you start, select your target, on the right of the "Load
                                 Tilen Majerle
                @author
               @author
lilen Majerle
@emmil tilen@mojerle.eu
@website http://stm32f4-discovery.net
@ide Keil uVision 5
@packs STM32F4xx Keil packs version 2.2.0 or greater
@stdperiph STM32F4xx Standard peripheral drivers version
     */
*Include core modules */
#include "stm32f4xx.h"
/* Include my libraries here */
#include "defines.h"
#include "tm_stm32f4_usart.h"
/* Initialize system */
            /* Initialize USART1 at 9600 baud, TX: PB6, RX: PB7 */
TM_USART_Init(USART1, TM_USART_PinsPack_2, 9600);
26
27
28
29
30
31
32
            /* Put string to USART */
TM_USART_Puts(USART1, "Hello world\n\r");
             while (1) {
                                 ι
character from internal buffer */
33
34
                     c = TM_USART_Getc(USART1);
                    f (c) {
    /* If anything received, put it back to terminal */
    TM_USART_Putc(USART1, c);
34
35
36
37
38
39 }
             }
```

This website uses cookies to improve your experience. We'll assume you're ok with this, but you can opt-out if you wish. Accept Read More

Project available on Github, download library below.



Comment will be deleted on breaking these rules without notification!	
How to Fix Thinning Lair	
Have You Tried Everything To Grow Stronger Fuller Hair. See The 3 Things You Need To Avoid	
Hair La Vie	

