



Elektrobit

Functional Safety Concept Lane Assistance

Document Version: [Version]

Template Version 1.0, Released on 2017-06-21



Document history

| Date | Version | Editor | Description |
|----------|---------|----------|-------------|
| 28-10-18 | 1.0 | Madhukar | First Draft |
| | | | |
| | | | |
| | | | |
| | | | |

Table of Contents

Document history

Table of Contents

Purpose of the Functional Safety Concept

Inputs to the Functional Safety Analysis

Safety goals from the Hazard Analysis and Risk Assessment

Preliminary Architecture

Description of architecture elements

Functional Safety Concept

Functional Safety Analysis

Functional Safety Requirements

Refinement of the System Architecture

Allocation of Functional Safety Requirements to Architecture Elements

Warning and Degradation Concept


Purpose of the Functional Safety Concept

Functional Safety Concept documents identified high level system requirements. These requirements are allocated to different parts of the item architecture. Technical safety requirements will be derived from these safety concepts. Validation and verification of the requirements are also presented here.

Inputs to the Functional Safety Concept Safety goals from the Hazard Analysis and Risk Assessment

| ID | Safety Goal |
|----------------|---|
| Safety_Goal_01 | The oscillating steering torque from the Lane Departure Warning function shall be limited. |
| Safety_Goal_02 | The Lane Keeping Assistance function shall be time limited, and additional steering torque shall end after a given time interval so the driver cannot misuse the system for autonomous driving. |
| Safety_Goal_03 | LKA functionality should take the delay in the sensing and actuation of the actuators in consideration. So that it may take corrective action on time. |
| Safety_Goal_04 | The oscillating steering torque from LDW should be gradually increased till deviation from lane is increasing. |

Preliminary Architecture



Description of architecture elements

| Element | Description |
|-------------------------------|--|
| Camera Sensor | Captures road images and provide them to the Camera Sensor ECU. |
| Camera Sensor ECU | Post processing provided images by camera sensor to analyze car position wrt lanes. |
| Car Display | Provides feedback to the driver displaying warnings and the Lane Departure Assistance status. |
| Car Display ECU | Controls the Car Display component to show the Lane Keeping Assistance warning and Lane Departure Assistance status. |
| Driver Steering Torque Sensor | Senses the torque applied to the steering wheel by the driver. |
| Electronic Power Steering ECU | Use the information received from the Driver Steering Torque Sensor and the torque requested by the Lane Keeping Assistance and Lane Warning and request the necessary torque to be applied by the Motor actuator. |
| Motor | Applies the torque indicated by the Electronic Power Steering ECU to the steering wheel. |

Functional Safety Concept The functional safety concept consists of:

- Functional safety analysisFunctional safety requirementsFunctional safety architecture
- Warning and degradation concept

Functional Safety Analysis

| Malfunction ID | Main Function of the Item Related to Safety Goal Violations | Guidewords (NO, WRONG, EARLY, LATE, MORE, LESS) | Resulting Malfunction |
|----------------|--|---|---|
| Malfunction_01 | Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver a haptic feedback | More | The lane departure warning function applies an oscillating torque with very high torque amplitude (above limit) |
| Malfunction_02 | Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver a haptic feedback | Less | The Lane Departure Warning function applies an oscillating torque with very Less torque frequency (below limit) |
| Malfunction_03 | Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane | No | The lane keeping assistance function is not limited in time duration which leads to misuse as an autonomous driving function. |

Functional Safety Requirements

Lane Departure Warning (LDW) Requirements:

| ID | Functional Safety Requirement | A S I L | Fault Tolerant Time Interval | Safe State |
|--|--|------------------|---------------------------------------|----------------------|
| Functional Safety Requirement 01-01 | The lane keeping item shall ensure that the C 50 mS lane departure oscillating torque amplitude is below Max_Torque_Amplitude. | С | 50 ms | Deactivate System |
| Functional Safety Requirement 01-02 | The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency. | С | 50 ms | Deactivate System |

Lane Departure Warning (LDW) Verification and Validation Acceptance Criteria:

| ID | Validation Acceptance Criteria and Method | Verification Acceptance Criteria and Method | |
|--|--|--|--|
| Functional Safety Requirement 01-01 | Validate that the Max_Torque_Amplitude chosen is low enough that the driver does not loose control over the car. | Verify that the system does turn off if LDW Max_Torque_Amplitude is exceeded | |
| Functional Safety Requirement 01-02 | Validate that the Max_Torque_Frequency chosen is low enough that the driver does not loose control over the car. | Verify that the system does turn off if the LDW exceeded Max_Torque_Frequency. | |


Lane Keeping Assistance (LKA) Requirements:

| ID | Functional Safety Requirement | A S I L | Fault Tolerant Time Interval | Safe State |
|--|---|------------------|---------------------------------------|----------------------|
| Functional Safety Requirement 02-01 | Electronic power steering ECU will ensure that the lane keeping assistance torque is applied for only Max_Duration. | В | 500 ms | Deactivate System |

Lane Keeping Assistance (LKA) Verification and Validation Acceptance Criteria:

| ID | Validation Acceptance Criteria and Method | Verification Acceptance Criteria and Method | |
|--|--|--|--|
| Functional Safety Requirement 02-01 | Validate that the max_duration chosen does not encourage drivers from taking their hands off the steering wheel. | Verify that the system deactivte the lane keeping assistance after it exceed max_duration. | |

Refinement of the System Architecture



Allocation of Functional Safety Requirements to Architecture Elements

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|--|---|--|---------------|--------------------|
| Functional Safety Requirement 01-01 | The lane keeping item shall ensure that the C 50 mS lane departure oscillating torque amplitude is below Max_Torque_Amplitude. | х | | |
| Functional Safety Requirement 01-02 | The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency. | х | | |
| Functional Safety Requirement 02-01 | Electronic power steering ECU will ensure that the lane keeping assistance torque is applied for only Max_Duration. | х | | |

Warning and Degradation Concept

| ID | Degradation Mode | Trigger for Degradation Mode | Safe State invoked? | Driver Warning |
|--------|----------------------|------------------------------------|---------------------|----------------|
| WDC-01 | Deactivate System | Malfunction_01 Malfunction_02 | YES | YES (Display) |
| WDC-02 | Deactivate System | Malfunction_03 | YES | YES (Display) |