```
OpenWRT version = BARRIER BREAKER (Bleeding Edge, r41508)
process commands
                          kill -s KILL PID
force kill=
run process in background = ./processname &
adding program to openwrt startup edit the below file
/etc/rc.local
modem configuration
get the vendor and prod id via
cat /sys/kernel/debug/usb/devices
example
P: Vendor=12d1 ProdID=1001 Rev= 0.00
S: Manufacturer=Huawei Technologies
edit the serial module with the correct vendor id
/etc/modules.d/usb-serial
edit modules serial- file with vendor id example below
usbserial vendor=0x12d1 product=0x1001
test ttvUSBX via
                    gcom -d /dev/ttyUSB0 info
FW forwarding
echo 'address=/#/192.168.8.1' >> /etc/dnsmasq.conf
File you need to edit is <a href="mailto://etc/config/firewall">/etc/config/firewall</a>
config redirect
   option name 'Divert DNS'
   option src 'lan'
   option proto 'tcp udp'
   option src_dport '53'
   option dest_port '53'
   option target 'DNAT'
config redirect
    option src
                              lan
    option proto
                               tcp
    option src_dport
    option dest_ip
                              192.168.8.1
    option dest port
If a user tried to access a specific url,
 e.g. \underline{\text{http://facebook.com/login}} he would end up on
    \underline{\text{http://192.168.1.1/login}} and thus be greeted with a 404 error.
Therefore set uhttpd's error page
    to your info page as well. In /etc/config/uhttpd, add/change
"option error_page" to: option error_page '/index.html'
/etc/init.d/firewall restart
```
