

Departure Route Description

All Rwys: Maintain **4200** or as assigned.

- Rwy 08:**
1. Climb hdg **077°** to **1500**. Then climbing RIGHT turn hdg **175°**, intercept V365 OBD from “YUY” NDB.
 2. At MUNBI, hold West on V365.
 3. Expect further clearance 10 minutes after take-off.
- Rwy 26:**
1. Climb track **257°** to the “YUY” NDB. Then climbing LEFT turn, intercept V365 OBD from “YUY” NDB.
 2. At MUNBI, hold West on V365.
 3. Expect further clearance 10 minutes after take-off.

Note: Hill **1079'** aprx 0.3 NM west of threshold rwy 08.

Communication Failure

On recognition of failure proceed as follows:

1. Select transponder code 7600;
2. Maintain **4200**;
3. Proceed to the published hold at **4200** or last assigned altitude if higher, and;
4. 10 minutes after entering the hold, cleared to CYVO for an approach or continue enroute as per flight plan.