







Zone 8

PROFESSIONAL BOWLERS ASSOCIATION. Official Lane Maintenance and Capital Equipment Provider Select Machine																																							
Pattern Information												Pattern Parameters										Supplies Information																	
Date								Pattern Number													Lane Cleaner Brunswick MAX10																		
Pattern Type						Sport					Pattern Name						2012 BEC						Cleaner Mixture Ratio 10 : 1																
Pattern Difficulty High							Mode							Clean & Oil						Cleaner Transition Distance 42 Authority22																			
Pattern Designer BRUNSWICK							Forward Speed							Max Clean							CI	eane	r Sp	ray E	nd I	Dista	ance	Щ	53		Envo	у							
Pattern Volume (ml) 22.44							Start Cleaner Spray							(0																								
Surface Information								Start Squeegee							0						Lane Conditioner Brunswick Connect																		
Surface Type					Synthetic						Start Oiling							1 6 N					Notes Bowling Plaza, St. Maximin																
Surface Brand				ı	Brunswick Pro Lane						Split Pattern								No					Paris, France															
		Age																																					
Z					one1				2			3					4			5				6			7					8							
Zone End Dista					nce 8				16			23				32			40																				
Zone Ratio					L 1.7 : 1				2.4 : 1			2.3 : 1				2.2 : 1			### : 1				### : 1			-	### : 1				###	:	1						
	R 1.7 : 1			2.4 : 1			2.3 : 1			2.3		: 1			###	### : 1			### : 1			### : 1				### : 1													
:	(ml)	ml) 9.39			6.20				3.47				3.37				0.00				0.00			0.00			ı	0.00											
																												40.00											
ZONE L1 L2 L3				7 F L4 L5 L6 L7 L8				Pin Side			1 12 13 14 15			I 16				Number C20 R19 R18 R17			R16 R15 R14 R13				10 Pin Side R12 R11 R10 R9 R				8 R7 R6 R5			R4 R3 R2 R1							
1	40	40	40	40	60	60	60	75	75	75	85	85	85	85	90	90	90	90	90	90	90	90	90	90	90	85	85	85		75	75	75	60	60	60	40	40		40
2	25	25	25	25	30	30	30	43	43	43	58	58	58	58	68	68	68	68	68		68	68	68	68	68	58	58	58		43	43		30	30	30		25		25
3	18	18	18	18	18	18	18	18	25	32	38	42	42	42	42	42	42	42	42	42	42	42	42	42	42	42	42	42	40	28	18		18	18	18	18	18		18
4	15	15	15	15	15	15	15	15	17	21	24	27	31	33	33	33	33	33	33	33	33	33	33	33	33	33	33	30	22	14	14		14	14	14	14	14		14
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
6																																							
7																																							
8																																							
100 - 00 - 00 - 00 - 00 - 00 - 00 - 00							4																															■ Zone ■ Zone ■ Zone	e 2
5 ₅₀ -																																					_	■ Zone	