Embedded System Software 과제 3

(과제 수행 결과 보고서)

과 목 명 : [CSE4116] 임베디드시스템소프트웨어

담당 교수 : 서강대학교 컴퓨터공학과 박성용

학번/이름 : 20151556 변홍수

개발 기간: 2020.05.30.~2020.06.01.

I. 개발 목표

Module Programming, 디바이스 드라이버, interrupt, timer를 활용하여 간단한 Stopwatch 프로그램을 작성한다

Ⅱ. 개발 범위 및 내용

가. Application(테스트 응용 프로그램)

- ✓ Device파일 open()
- ✓ write()로 Stopwatch 시작하며 Sleep
- ✓ Wake Up(Stopwatch 종료)시, Device파일 close()후 프로그램 종료

나. Stopwatch Module

1) fpga_fnd(FND)

- ✓ 초기 상태는 '0000'이다.
- ✓ 앞 두 자리는 분(60분), 뒤 두 자리는 초(60초)를 표시한다.

2) GPIO Button

Button의 입력은 Interrupt를 이용하여 수행한다.

- ✓ Home : Start
 타이머를 시작한다. 1초마다 FND 출력을 갱신한다. Kernel Timer를 사용한다.
- ✓ Back : Pause
 타이머를 일시정지한다. 소수점 이하의 시간은 유지한다.
- ✓ Volume Up : Reset초기 상태로 돌아간다.
- ✓ Volume Down : Exit3초 이상 누르고 있을 시 Application을 종료한다.FND를 '0000'으로 초기화한다.

Ⅲ. 추진 일정 및 개발 방법

가. 추진 일정

2020. 05. 30.

- 응용 프로그램 및 모듈 기초 구현
 - ✓ Volume Down버튼 3초 이상 눌렀을 시 기능 작동 테스트

2020. 05. 31.

- Stopwatch 구현
 - ✓ Kernel Timer 사용
 - ✓ 소수점 이하 유지
 - ✓ FND 작동
- GPIO Button 작동
 - ✓ Interrupt 사용
 - ✓ Home : Start, Back : Pause, Volume Up : Reset, Volume Down : Exit

2020. 06. 01.

- Document 작성

나. 개발 방법

- 1) Application(테스트 응용 프로그램)
- ✓ Device파일 open(), Open실패 시 프로그램 종료
- ✓ write()로 Stopwatch 시작하며 Sleep
- ✓ Wake Up(Stopwatch 종료)시, Device파일 close()후 프로그램 종료

app.c

#include <stdio.h>
#include <unistd.h>
#include <fcntl.h>

2) Stopwatch Module(dev_module.c)

- Define Constant, Global Variable
- ✓ unsigned long long start_time : Stopwatch를 시작할 때 jiffies값 저장
- ✓ int keep_time: Stopwatch가 Pause될 때 카운트 된 시간 값 저장
- ✓ bool timer_continue : Stopwatch가 실행 중일 때 true, 아닐 시 false 저장

```
#define DEVICE_MAJOR 242
#define DEVICE_NAME "stopwatch"
#define FND_ADDRESS 0x08000004 /
#define SUCCESS 0

/* Global Variable */
static int Device_Open = 0;
static unsigned char *fnd_addr;
struct timer_list timer;
struct timer_list end_timer;
bool timer_continue;
unsigned long long start_time;
int keep_time;

wait_queue_head_t wq_write;
DECLARE_WAIT_QUEUE_HEAD(wq_write);
```

- int stopwatch_open(struct inode *inode, struct file *file)
- ✓ Device Open
- ✓ FND 초기화
- ✓ GPIO Button Interrupt Handler 등록

```
int stopwatch open(struct inode *inode, struct file *file){
       int ret;
       int irq;
       printk(KERN_ALERT "Open Module\n");
       /* Don't want to run to two processes at the same time */
       if(Device_Open)
              return -EBUSY;
       Device_Open++;
       keep_time = 0;
       device_write_fnd(0);
       gpio_direction_input(IMX_GPIO_NR(1,11));
       irq = gpio_to_irq(IMX_GPIO_NR(1,11));
       ret=request_irq(irq, inter_handler1, IRQF_TRIGGER_FALLING, "home", 0);
       gpio_direction_input(IMX_GPIO_NR(1,12));
       irq = gpio_to_irq(IMX_GPIO_NR(1,12));
       ret=request_irq(irq, inter_handler2, IRQF_TRIGGER_FALLING, "back", 0);
       gpio_direction_input(IMX_GPIO_NR(2,15));
       irq = gpio_to_irq(IMX_GPIO_NR(2,15));
       ret=request_irq(irq, inter_handler3, IRQF_TRIGGER_FALLING, "volup", 0);
       gpio_direction_input(IMX_GPIO_NR(5,14));
       irq = gpio_to_irq(IMX_GPIO_NR(5,14));
       ret=request_irq(irq, inter_handler4,
                      IRQF TRIGGER FALLING | IRQF TRIGGER RISING, "voldown", 0);
       return SUCCESS;
}
```

int stopwatch_release(struct inode *inode, struct file *file)

✓ Free Interrupt Handler

```
int stopwatch_release(struct inode *inode, struct file *file){
    /* Now Ready for our next caller */
    Device_Open--;

    free_irq(gpio_to_irq(IMX_GPIO_NR(1, 11)), NULL);
    free_irq(gpio_to_irq(IMX_GPIO_NR(1, 12)), NULL);
    free_irq(gpio_to_irq(IMX_GPIO_NR(2, 15)), NULL);
    free_irq(gpio_to_irq(IMX_GPIO_NR(5, 14)), NULL);

    printk(KERN_ALERT "Release Module\n");
    return SUCCESS;
}
```

int stopwatch_write(struct file *filp, const char *buf, size_t count, loff_t *f_pos

✓ User에서 write() 호출 시 wait queue에 추가한 뒤 Sleep한다.

Code 4

- int __init stopwatch_init(void)
- ✓ Device Module을 등록한다.
- ✓ FND Physical Address를 Mapping한다
- ✓ Kernel Timer를 초기화한다.

```
int __init stopwatch_init(void) {
    int result;
    result = register_chrdev(DEVICE_MAJOR, DEVICE_NAME, &fops);
    if(result < 0) {
        printk(KERN_WARNING "Can't get any major\n");
        return result;
    }
    fnd_addr = ioremap(FND_ADDRESS, 0x4);
    init_timer(&timer);
    init_timer(&end_timer);
    printk(KERN_ALERT "Init Module Success\n");
    printk("%s major number : %d\n", DEVICE_NAME, DEVICE_MAJOR);
    return SUCCESS;
}</pre>
```

- void __exit stopwatch_exit(void)
- ✓ Device Module을 제거한다.
- ✓ FND Physical Address를 UnMapping한다
- ✓ Kernel Timer를 삭제한다.

```
void __exit stopwatch_exit(void) {
    unregister_chrdev(DEVICE_MAJOR, DEVICE_NAME);
    iounmap(fnd_addr);
    del_timer_sync(&timer);
    del_timer_sync(&end_timer);
    printk(KERN_ALERT "Remove Module Success\n");
}
```

void kernel_timer_write(unsigned long timeout)

- ✓ bool timer_continue값이 false일 경우 함수를 즉시 종료한다.
- ✓ timer_time 값을 계산 한 뒤 device_write_fnd()를 호출해 FND을 출력한다.
- ✓ Kernel Timer의 expire, function값을 설정하고 add_timer()를 호출한다.

Code 7

void device_write_fnd(int timer_time)

✓ timer_time값을 넘겨받아 분(int min), 초(int sec) 값을 계산하여 FND를 출력한다.

```
void device_write_fnd(int timer_time){
    int min, sec;
    unsigned char value[4];
    unsigned short int value_short = 0;
    timer_time /= HZ;
    sec = timer_time%60;
    timer_time /= 60;
    min = timer_time%60;
    printk("timer: %02d:%02d\n", min, sec);
    value[0] = min/10;
    value[1] = min%10;
    value[2] = sec/10;
    value[3] = sec%10;
    value_short = value[0] << 12 | value[1] << 8 | value[2] << 4 | value[3];</pre>
```

```
outw(value_short, (unsigned int)fnd_addr);
}
```

- void stopwatch end(unsigned long timeout)
- ✓ FND를 초기화하고 _wake_up()을 호출하여 프로세스를 깨운다.

```
void stopwatch_end(unsigned long timeout){
    device_write_fnd(0);
    printk("Wake Up\n");
    __wake_up(&wq_write, 1, 1, NULL);
}
```

- irqreturn_t inter_handler1(int irq, void* dev_id)
- ✓ bool timer_continue값이 true일 경우 함수를 즉시 종료한다. (이미 타이머 실행 중)
- ✓ Pause상태에서 다시 Start된 경우 Start후 1초가 아니라 이전에 카운트 된 시간에서 정확히 그 다음 .00초가 되었을 때 FND출력을 갱신하기 위해, keep_time에 저장된 값을 사용하여 tmp hz를 계산한다.
- ✓ tmp_hz는 Kernel Timer Expire값에 사용된다.

```
irgreturn t inter handler1(int irg, void* dev id) {
       int timer_time;
       int tmp_hz;
       if(timer_continue) {
              printk("Access denied : Timer is running.\n");
              return IRQ_HANDLED;
       }
       timer_continue = true;
       timer_time = keep_time;
       del timer sync(&timer);
       start_time = get_jiffies_64();
       tmp_hz = (int)keep_time % (int)HZ;
       tmp_hz = (int)HZ - tmp_hz;
       printk("Start timer.\n");
       printk("raw data: %llu, expire time: %d, ", keep_time, tmp_hz);
       device_write_fnd(timer_time);
```

```
timer.expires = get_jiffies_64() + tmp_hz;
    timer.function = kernel_timer_write;
    add_timer(&timer);
    return IRQ_HANDLED;
}
```

- irgreturn_t inter_handler2(int irg, void* dev_id)
- ✓ 타이머가 실행 중(timer_continue값이 true)일 때 타이머를 Pause한다.
- ✓ 다시 Start되었을 때 지금까지 저장된 시간을 유지하기 위해 지금까지 카운트 된 시간 값을 keep_time에 저장한다. kernel jiffies값의 차이를 사용하기 때문에 소 수점 이하 둘째 자리(HZ=100)까지 표현할 수 있다.

```
irqreturn_t inter_handler2(int irq, void* dev_id) {
    if(timer_continue){
        printk("Pause timer.\n");
        timer_continue = false;
        keep_time += (get_jiffies_64() - start_time);
    }
    return IRQ_HANDLED;
}
```

Code 11

- irgreturn_t inter_handler3(int irg, void* dev_id)
- ✓ bool timer_continue값이 true일 경우 함수를 즉시 종료한다. (이미 타이머 실행 중)
- ✓ keep_time과 FND출력을 초기화하여 Stopwatch Timer를 Reset한다.

```
irqreturn_t inter_handler3(int irq, void* dev_id) {
    if(timer_continue) {
        printk("Access denied : Timer is running.\n");
        return IRQ_HANDLED;
    }
    printk("Reset timer.\n");
    keep_time = 0;
    device_write_fnd(0);
    return IRQ_HANDLED;
}
```

- irgreturn_t inter_handler4(int irg, void* dev_id)
- ✓ bool timer_continue값이 true일 경우 함수를 즉시 종료한다. (이미 타이머 실행 중)
- ✓ Volume Down 버튼이 눌렸을 시 end_timer를 등록한다. 타이머가 Expire되기 전에 버튼이 떼어졌을 경우 등록된 타이머를 삭제한다.

```
irqreturn_t inter_handler4(int irq, void* dev_id) {
    if(timer_continue) {
        printk("Access denied : Timer is running.\n");
        return IRQ_HANDLED;
    }
    if(gpio_get_value(IMX_GPIO_NR(5, 14))){
        printk("Keep timer.\n");
        del_timer(&end_timer);
    }
    else{
        printk("Exiting timer. Press the button 3seconds.\n");
        end_timer.expires = get_jiffies_64() + 3*HZ;
        end_timer.function = stopwatch_end;
        add_timer(&end_timer);
    }
    return IRQ_HANDLED;
}
```

Code 13

IV. 연구 결과

- fpga device driver와 interrupt를 포함한 stopwatch 기능을 가진 하나의 모듈 구현
- 프로그램 전체 흐름도




Figure 1

V. 기타

타이머를 오래 실행시켰을 때(실험적으로 6분 이상) 간헐적으로 printk()로 출력하는 jiffies값이 1이 증가하는 현상을 발견했다. 특정 케이스에서 반복해서 발견되는 현상이었으면 어느정도 납득을 할 수 있었겠지만 현상이 매우 불규칙적으로 발생하여 원인 파악과 해결을 할 수가 없었다. 커널 타이머와 jiffies관련 지식이 더 필요함을 느꼈다. 이번과제가 마지막으로 리눅스 커널프로그래밍이 끝나 아쉽다.

I. Appendix

dev_module.c (entire)

```
#include <linux/module.h>
#include <linux/fs.h>
#include <linux/interrupt.h>
#include <asm/io.h>
#include <mach/gpio.h>
#include <linux/timer.h>
#include <linux/wait.h>
#define DEVICE MAJOR 242
#define DEVICE NAME "stopwatch"
#define FND ADDRESS 0x08000004
#define SUCCESS 0
/* Global Variable */
static int Device Open = 0;
static unsigned char *fnd addr;
struct timer_list timer;
struct timer_list end_timer;
bool timer_continue;
unsigned long long start_time;
int keep time;
wait queue head t wq write;
DECLARE_WAIT_QUEUE_HEAD(wq_write);
/* Function Prototype */
int stopwatch_open(struct inode *, struct file *);
int stopwatch_release(struct inode *, struct file *);
int stopwatch_write(struct file *filp, const char *buf, size_t count, loff_t
*f pos);
void kernel timer write(unsigned long timeout);
//void device write fnd(int min, int sec);
void device write fnd(int timer time);
void stopwatch end(unsigned long timeout);
irqreturn_t inter_handler1(int irq, void* dev_id);
irqreturn_t inter_handler2(int irq, void* dev_id);
irqreturn_t inter_handler3(int irq, void* dev_id);
```

```
irgreturn t inter handler4(int irg, void* dev id);
* Define file operations structure.
* This structure will hold the functions to be called when a process does something
to the device we created.
* Since a pointer to this structure is kept in the devices table, it can't be
local to init module.
* NULL is for unimplemented functions.
static struct file_operations fops =
{
       .open = stopwatch open,
       .write = stopwatch write,
       .release = stopwatch release,
};
irgreturn t inter handler1(int irg, void* dev id) {
       int tmp_hz;
       if(timer_continue) {
              printk("Access denied : Timer is running.\n");
              return IRQ_HANDLED;
       timer_continue = true;
       del timer sync(&timer);
       start_time = get_jiffies_64();
       tmp hz = (int)keep time % (int)HZ;
       tmp_hz = (int)HZ - tmp_hz;
       printk("Start timer.\n");
       printk("raw data: %d, expire time: %d, ", keep_time, tmp_hz);
       device_write_fnd(keep_time);
       timer.expires = get_jiffies_64() + tmp_hz;
       timer.function = kernel_timer_write;
       add_timer(&timer);
       return IRQ_HANDLED;
}
irqreturn_t inter_handler2(int irq, void* dev_id) {
       if(timer_continue){
              printk("Pause timer.\n");
              timer_continue = false;
              keep_time += (get_jiffies_64() - start_time);
       return IRQ_HANDLED;
}
irqreturn_t inter_handler3(int irq, void* dev_id) {
       if(timer continue) {
              printk("Access denied : Timer is running.\n");
              return IRQ_HANDLED;
       printk("Reset timer.\n");
```

```
keep time = 0;
       device write fnd(0);
       return IRQ HANDLED;
}
irqreturn_t inter_handler4(int irq, void* dev_id) {
       if(timer_continue) {
              printk("Access denied : Timer is running.\n");
              return IRQ_HANDLED;
       if(gpio_get_value(IMX_GPIO_NR(5, 14))){
              printk("Keep timer.\n");
              del timer(&end timer);
       else{
              printk("Exiting timer. Press the button 3seconds.\n");
              end_timer.expires = get_jiffies_64() + 3*HZ;
              end timer.function = stopwatch end;
              add_timer(&end_timer);
       return IRQ_HANDLED;
}
int stopwatch_open(struct inode *inode, struct file *file){
       int ret;
       int irq;
       printk(KERN ALERT "Open Module\n");
       /* Don't want to run to two processes at the same time */
       if(Device Open)
              return -EBUSY;
       Device_Open++;
       keep_time = 0;
       device_write_fnd(0);
       gpio_direction_input(IMX_GPIO_NR(1,11));
       irq = gpio_to_irq(IMX_GPIO_NR(1,11));
       ret=request_irq(irq, inter_handler1, IRQF_TRIGGER_FALLING, "home", 0);
       gpio_direction_input(IMX_GPIO_NR(1,12));
       irq = gpio to irq(IMX GPIO NR(1,12));
       ret=request_irg(irq, inter_handler2, IRQF_TRIGGER_FALLING, "back", 0);
       gpio direction input(IMX GPIO NR(2,15));
       irq = gpio_to_irq(IMX_GPIO_NR(2,15));
       ret=request_irq(irq, inter_handler3, IRQF_TRIGGER_FALLING, "volup", 0);
       gpio_direction_input(IMX_GPIO_NR(5,14));
       irq = gpio_to_irq(IMX_GPIO_NR(5,14));
                                                                  inter_handler4,
       ret=request_irq(irq,
IRQF_TRIGGER_FALLING|IRQF_TRIGGER_RISING, "voldown", 0);
       return SUCCESS;
}
int stopwatch_release(struct inode *inode, struct file *file){
```

```
/* Now Ready for our next caller */
       Device Open--;
       free_irq(gpio_to_irq(IMX_GPIO_NR(1, 11)), NULL);
       free_irq(gpio_to_irq(IMX_GPIO_NR(1, 12)), NULL);
       free_irq(gpio_to_irq(IMX_GPIO_NR(2, 15)), NULL);
       free_irq(gpio_to_irq(IMX_GPIO_NR(5, 14)), NULL);
       printk(KERN_ALERT "Release Module\n");
       return SUCCESS;
}
int stopwatch write(struct file *filp, const char *buf, size t count, loff t
*f_pos){
       printk("sleep on\n");
       interruptible_sleep_on(&wq_write);
       printk("write\n");
       return SUCCESS;
}
/* Initialize the module - Register the character device */
int __init stopwatch_init(void) {
       int result;
       result = register_chrdev(DEVICE_MAJOR, DEVICE_NAME, &fops);
       if(result < 0) {</pre>
              printk(KERN_WARNING "Can't get any major\n");
              return result;
       }
       fnd addr = ioremap(FND ADDRESS, 0x4);
       init timer(&timer);
       init timer(&end timer);
       printk(KERN_ALERT "Init Module Success\n");
       printk("%s major number : %d\n", DEVICE_NAME, DEVICE_MAJOR);
       return SUCCESS;
}
/* Exit the moudle - UnRegister the character device */
void __exit stopwatch_exit(void) {
       unregister_chrdev(DEVICE_MAJOR, DEVICE_NAME);
       iounmap(fnd_addr);
       del timer sync(&timer);
       del_timer_sync(&end_timer);
       printk(KERN_ALERT "Remove Module Success\n");
}
/* Write Timer */
void kernel_timer_write(unsigned long timeout) {
       int timer_time;
       if(!timer_continue) return;
       timer_time = (get_jiffies_64() - start_time + keep_time);
       printk("raw data: %llu, expire time: %d, ", get_jiffies_64() - start_time
+ keep_time, HZ);
       device_write_fnd(timer_time);
       timer.expires = get_jiffies_64() + HZ;
       timer.function = kernel_timer_write;
       add_timer(&timer);
```

```
}
void device_write_fnd(int timer_time){
       int min, sec;
       unsigned char value[4];
       unsigned short int value_short = 0;
       timer_time /= HZ;
       sec = timer_time%60;
       timer_time /= 60;
       min = timer_time%60;
       printk("timer: %02d:%02d\n", min, sec);
       value[0] = min/10;
       value[1] = min%10;
       value[2] = sec/10;
       value[3] = sec%10;
       value_short = value[0] << 12 | value[1] << 8 | value[2] << 4 | value[3];</pre>
   outw(value_short, (unsigned int)fnd_addr);
}
void stopwatch_end(unsigned long timeout){
       device_write_fnd(0);
       printk("Wake Up\n");
       __wake_up(&wq_write, 1, 1, NULL);
}
module_init(stopwatch_init);
module_exit(stopwatch_exit);
MODULE LICENSE("GPL");
MODULE_AUTHOR("Huins");
```