Migration Assessment Notes

Netmagic-CoreSwitch (CBS SX550X Stack) to Cisco Nexus

Date: 23-Mar-2026 | Prepared by: Hassan | Status: Phase 1 – Assessment Complete

1. Device Identity & Hardware Inventory

1.1 Switch Identity

Parameter	Value
Hostname	Netmagic-CoreSwitch
Platform	Cisco CBS SX550X-24 (4-unit stack)
Firmware (Active)	2.5.9.13 (07-Jun-2022)
Firmware (Inactive)	2.5.5.47 (06-May-2020)
Stack Units	4 x SX550X-24
Default Gateway	172.27.8.31
Management VLAN IP	172.27.8.30/24 (VLAN 1)
Loopback1 IP	172.27.7.1/30
OOB Port	Down (not used)

1.2 Unit Serial Numbers

Unit	Model	VID	Serial Number
Unit 1	SX550X-24-K9	V04	DNI262003G8
Unit 2	SX550X-24-K9	V04	DNI262003PE
Unit 3	SX550X-24-K9	V04	DNI262003PN
Unit 4	SX550X-24-K9	V04	DNI262003HW

1.3 SFP Transceivers

Port	PID	Type	VID	Serial Number
te1/0/11	10G-Combo-C			UP
te1/0/23	10G-Combo-C			Down
te2/0/11	10G-Combo-C			UP
te2/0/23	10G-Combo-C			Down
te3/0/11	SFP-10G-LR	Single-mode 10G LR	V02	ACW2607198R
te3/0/23	10G-Combo-C			Down
te4/0/11	SFP-10G-LR	Single-mode 10G LR	V02	ACW260903QL
te4/0/23	10G-Combo-C			Down

i Both SFPs are on Combo-F ports (te3/0/11, te4/0/11) used in Port-Channel 7 to IDC7-SW. Verify Nexus has compatible 10G-LR SFP slots.

2. CPU & Health Alert

> CPU utilization is 100% across 5 seconds, 1 minute, and 5 minutes. The switch was maxed out at time of assessment. This is a serious pre-migration concern.

Action required before migration:

- Run 'show processes cpu sorted' to identify top consumers
- Check if any broadcast storm, MAC flooding, or STP topology change is causing CPU spike
- Correlate with syslog for error conditions
- If CPU has been at 100% for extended periods, the switch may already be degraded — migration urgency increases

3. Port Status Analysis

3.1 Port Utilization Summary (from show interfaces status)

Stack Unit	Total Ports	Up	Down (Free)	Notes
Unit 1 (te1/0/x)	23	17	6 (te1/0/18–23)	te1/0/12 missing (stacking)
Unit 2 (te2/0/x)	22	17	6 (te2/0/18-23 Combo-C)	te2/0/12 missing (stacking)
Unit 3 (te3/0/x)	23	20	5 (te3/0/9-10) + te3/0/21-23	SFP on te3/0/11 active
Unit 4 (te4/0/x)	23	20	2 (te4/0/9-10) + te4/0/21-23	SFP on te4/0/11 active
TOTAL	96	~74	~14 truly free	

te1/0/1 and te2/0/1 are UP but have NO config (no VLAN, no channel-group) — orphan ports. Clarify before migration.

te1/0/23 and te2/0/23 are Combo-C, Down, and unconfigured. Check if reserved.

i 'Down' ports that appear in VLAN 1 untagged member list (te3/0/9, te3/0/10, te3/0/12 etc.) are phantom entries — CBS adds unused ports to default VLAN.

3.2 Speed Negotiation Issues

Several ports are UP but negotiated at sub-10G speeds, indicating potential cabling or NIC issues:

Port	Negotiated Speed	Risk
te1/0/1	1000 Mbps	May be intentional or old NIC
te1/0/6	1000 Mbps	Broad com host — check NIC capability
te1/0/14	1000 Mbps	Access VLAN 14 port
te1/0/15	100 Mbps (!)	CRITICAL — only 100M on a 10G port
te1/0/16	1000 Mbps	Access VLAN 14
te1/0/17	1000 Mbps	Access VLAN 14
te2/0/1	1000 Mbps	No config assigned
te2/0/2	1000 Mbps	Part of Po2
te2/0/6	1000 Mbps	Trunk port, native VLAN 11
te2/0/14–17	1000 Mbps	Access VLAN 14
te2/0/15	100 Mbps (!)	CRITICAL — 100M on 10G port

> te1/0/15 and te2/0/15 are running at 100 Mbps. These connect to the same device (mirrored across stack). This is likely a legacy NIC or faulty cable. Resolve BEFORE migration — Nexus won't mask this.

4. LLDP Neighbors — Connected Devices

4.1 Layer 2 Switches

Switch Port	Neighbor System Name	Neighbor Port	Type
te1/0/2	FS1GSW0832	1/xg26	Bridge (FS Network Switch)
te2/0/2	FS1GSW0832	2/g24	Bridge (same FS switch, dual-homed via Po2)

> FS1GSW0832 is an FS-brand switch connecting via Po2. It dual-homes to both te1/0/2 and te2/0/2. This is your downlink aggregation switch.

4.2 Servers — Units 1 & 2 (Broadcom Dual 10GBase-T)

Ports te1/0/3–11, te2/0/3–11 are all connected to Broadcom Dual 10GBase-T NICs (fw: AFW_214.0.245.0). These are server NICs, each appearing on mirror ports across Unit 1 and Unit 2 — indicating dual-homed server connections via port-channels or active-passive bonding.

4.3 Servers — Units 3 & 4 (Broadcom 57454 / NX-E)

Server Name	Ports (Unit 3)	Ports (Unit 4)	NIC Model
FSNETNTX1121	te3/0/1-2	te4/0/1-2	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1122	te3/0/3-4	te4/0/3-4	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1123	te3/0/5-6	te4/0/5-6	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1124	te3/0/7-8	te4/0/7-8	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1125	te3/0/13-14	te4/0/13-14	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1126	te3/0/15-16	te4/0/15-16	Broadcom 57454 OCP + PCIe eth0, eth1, eth4, eth5
FSNETNTX1127	te3/0/17-18	te4/0/17-18	Broadcom NX-E + 57454 eth0, eth1, eth6, eth7
FSNETNTX1128	te3/0/19-20	te4/0/19-20	Broadcom NX-E + 57454 eth0, eth1, eth6, eth7

> FSNETNTX1121–1128 are all dual-homed across Unit 3 and Unit 4. Each server uses 2 ports per unit (one OCP NIC eth0/1, one PCIe NIC). They connect via Po3–Po11. FSNETNTX1127/1128 appear as Bridge+Router (B,R) — these servers may have routing/gateway functions.

4.4 Uplink to IDC7-SW

Switch Port	Neighbor	Neighbor Port	Channel	Type
te3/0/11	IDC7-SW (MAC: 48:1b:a4:a5:8f:75)	te2/0/4	Po7	Bridge + Router
te4/0/11	IDC7-SW (MAC: 48:1b:a4:a5:8f:75)	te1/0/4	Po7	Bridge + Router

> IDC7-SW is the upstream device (described as **Link-DC7** in Po7 config). This is your WAN/DC uplink — treat it as a critical path. Po7 uses the two SFP-10G-LR transceivers.

> Po7 has only 2 members (one SFP per unit). This is your only uplink to IDC7-SW — single point of failure if either SFP fails. Consider if Nexus design should have more uplink redundancy.

Port Configuration Summary (Range-wise)

5. Port-Channel Configuration

5.1 Port-Channel Membership & Status

Port-Channel	Status	Members	Mode	Description
Po1	Not Present	None	—	Empty — safe to ignore
Po2	Up 10G	te1/0/2 (Active), te2/0/2 (Non-candidate!)	auto (PAgP)	Link to FS1GSW0832
Po3	Up 10G	te3/0/1-2, te4/0/1-2	auto	FSNETNTX1121
Po4	Up 10G	te3/0/3-4, te4/0/3-4	auto	FSNETNTX1122
Po5	Up 10G	te3/0/5-6, te4/0/5-6	auto	FSNETNTX1123
Po6	Up 10G	te3/0/7-8, te4/0/7-8	auto	FSNETNTX1124
Po7	Up 10G	te3/0/11, te4/0/11	auto	**Link-DC7** (IDC7-SW uplink via SFP-LR)
Po8	Up 10G	te3/0/13-14, te4/0/13-14	auto	FSNETNTX1125
Po9	Up 10G	te3/0/15-16, te4/0/15-16	auto	FSNETNTX1126
Po10	Up 10G	te3/0/17-18, te4/0/17-18	auto + LACP short	FSNETNTX1127
Po11	Up 10G	te3/0/19-20, te4/0/19-20	auto + LACP short	FSNETNTX1128
Po12–32	Not Present	None	—	All empty

Po2 shows te2/0/2 as 'Non-candidate'. This means the second member is NOT actively forwarding. Po2 is effectively single-link to FS1GSW0832. Investigate before migration — may cause a traffic drop if te1/0/2 fails.

All port-channels use mode 'auto' (PAgP passive). NX-OS does NOT support PAgP. All channels must be converted to LACP (mode active/passive) on Nexus. Verify the far-end devices also support LACP.

Load balancing method: src-dst-mac. On Nexus, default is also src-dst-mac for L2, but verify with 'port-channel load-balance' on the specific Nexus model.

Po10 and Po11 use 'lacp timeout short' (fast hellos). Replicate this on Nexus: 'lacp rate fast' under each member interface.

Server (port-channel	Trunk / uplink	SFP uplink (fiber)	Orphan / issue	Speed problem	Unused / down

Unit 1 (te1/0/x) — Access & FS switch ports

te1/0/1 Orphan — no VLAN UP 1G	te1/0/2 Po2 → (Misconfigured) FS1GSW0832 UP 1G (active)	te1/0/3 Trunk, native V11 → FS switch	te1/0/4 Trunk, native V11 → FS switch	te1/0/5 Trunk, native V11 → FS switch	te1/0/6 Trunk, native V11 → FS switch
te1/0/7 Trunk, native V11 → FS switch	te1/0/8 Access VLAN 12 Broadcom NIC	te1/0/9 Access VLAN 12 Broadcom NIC	te1/0/10 Access VLAN 12 Broadcom NIC	te1/0/11 Access VLAN 12 Combo-C, 10G	te1/0/12 Stacking port (missing)
te1/0/13 Access VLAN 12 Broadcom NIC	te1/0/14 Access VLAN 14 UP 1G	te1/0/15 Access VLAN 14 ONLY 100 Mbps!	te1/0/16 Access VLAN 14 UP 1G	te1/0/17 Access VLAN 14 UP 1G	te1/0/18 Access VLAN 16 Down
te1/0/19 Access VLAN 16 Down	te1/0/20 Access VLAN 16 Down	te1/0/21 Access VLAN 16 Down	te1/0/22 Access VLAN 36 UP	te1/0/23 Combo-C, Down No config	te2/0/1 Palo Alto GW 172.27.8.31 — UP 1G

Unit 2 (te2/0/x) — Access & FS switch ports

te2/0/2 Po2 → FS1GSW0832 Non-candidate!	te2/0/3 Trunk, native V11 → FS switch	te2/0/4 Trunk, native V11 → FS switch	te2/0/5 Trunk, native V11 → FS switch	te2/0/6 Trunk, native V11 UP 1G	te2/0/7 Trunk, native V11 → FS switch
te2/0/8 Access VLAN 12 Broadcom NIC	te2/0/9 Access VLAN 12 Broadcom NIC	te2/0/10 Access VLAN 12 Broadcom NIC	te2/0/11 Access VLAN 12 Combo-C, 10G	te2/0/12 Stacking port (missing)	te2/0/13 Access VLAN 12 Broadcom NIC
te2/0/14 Access VLAN 14 UP 1G	te2/0/15 Access VLAN 14 ONLY 100 Mbps!	te2/0/16 Access VLAN 14 UP 1G	te2/0/17 Access VLAN 14 UP 1G	te2/0/18 Access VLAN 16 Down	te2/0/19 Access VLAN 16 Down
te2/0/20 Access VLAN 16 Down	te2/0/21 Access VLAN 16 Down	te2/0/22 No config Down	te2/0/23 Combo-C, Down No config		

Server (port-channel)Trunk / uplinkSFP uplink (fiber)Orphan / issueSpeed problemUnused / down

Unit 3 (te2/0/x) — Access & FS switch ports

te3/0/1 Po3 → FSNETNTX1121 eth0 (OCP)	te3/0/2 Po3 → FSNETNTX1121 eth4 (PCIe)	te3/0/3 Po4 → FSNETNTX1122 eth0 (OCP)	te3/0/4 Po4 → FSNETNTX1122 eth4 (PCIe)	te3/0/5 Po5 → FSNETNTX1123 eth0 (OCP)	te3/0/6 Po5 → FSNETNTX1123 eth4 (PCIe)
te3/0/7 Po6 → FSNETNTX1124 eth0 (OCP)	te3/0/8 Po6 → FSNETNTX1124 eth5 (PCIe)	te3/0/9 Unused Down	te3/0/10 Unused Down	te3/0/11 Po7 → IDC7-SW SFP-10G-LR fiber	te3/0/12 Stacking / missing Not in config
te3/0/13 Po8 → FSNETNTX1125 eth0 (OCP)	te3/0/14 Po8 → FSNETNTX1125 eth5 (PCIe)	te3/0/15 Po9 → FSNETNTX1126 eth1 (OCP)	te3/0/16 Po9 → FSNETNTX1126 eth4 (PCIe)	te3/0/17 Po10 → FSNETNTX1127 eth6 (NX-E)	te3/0/18 Po10 → FSNETNTX1127 eth1 (57454)
te3/0/19 Po11 → FSNETNTX1128 eth1 (57454)	te3/0/20 Po11 → FSNETNTX1128 eth6 (NX-E)	te3/0/21 Access VLAN 11 Standalone	te3/0/22 No config Down	te3/0/23 Trunk (standalone) No Po	

Unit 1 (te1/0/x) — Access & FS switch ports

Unit 2 (te2/0/x) — Mirror of Unit 1 (Palo Alto gateway on te2/0/

Unit 2 (te2/0/x) — Access & FS switch ports

te4/0/1 Po3 → FSNETNTX1121 eth0 (OCP)	te4/0/2 Po3 → FSNETNTX1121	eth5 (PCIe) te4/0/3 Po4 → FSNETNTX1122 eth1 (OCP)	te4/0/4 Po4 → FSNETNTX1122 eth5 (PCIe)	te4/0/5 Po5 → FSNETNTX1123 eth1 (OCP)	te4/0/6 Po5 → FSNETNTX1123 eth5 (PCIe)
te4/0/7 Po6 → FSNETNTX1124 eth1 (OCP)	te4/0/8 Po6 → FSNETNTX1124 eth4 (PCIe)	te4/0/9 Unused Down	te4/0/10 Unused Down	te4/0/11 Po7 → IDC7-SW SFP-10G-LR fiber	te4/0/12 Stacking / missing Not in config
te4/0/13 Po8 → FSNETNTX1125 eth4 (PCIe)	te4/0/14 Po8 → FSNETNTX1125 eth1 (OCP)	te4/0/15 Po9 → FSNETNTX1126 eth5 (PCIe)	te4/0/16 Po9 → FSNETNTX1126 eth0 (OCP)	te4/0/17 Po10 → FSNETNTX1127 eth0 (57454)	te4/0/18 Po10 → FSNETNTX1127 eth7 (NX-E)
te4/0/19 Po11 → FSNETNTX1128 eth0 (57454)	te4/0/20 Po11 → FSNETNTX1128 eth7 (NX-E)	te4/0/21 No config Down	te4/0/22 No config Down	te4/0/23 Trunk (standalone) No Po	

Unit 4 (te4/0/x) — Redundant mirror of Unit 3 server links

5.2 Po3–Po11 Architecture (Server Dual-Homing)

Each server (FSNETNTX1121–1128) has 4 ports connected — 2 per stack unit, forming a 4-port channel. This is a cross-stack (cross-unit) port-channel, which is the CBS stack's equivalent of vPC.

> On Nexus, this cross-stack model must be redesigned. If deploying a single Nexus switch, the 4 ports become a standard port-channel. If deploying dual Nexus, use vPC — redesign required.

6. VLAN Database

6.1 Configured VLANs

VLAN ID	SVI IP Address	IPv6 Enabled	Notes
1 (Native/Mgmt)	172.27.8.30/24	Yes (2401:8800:c13:2::82/126)	Management VLAN
10	172.27.10.1/24	No	
11	172.27.11.1/24	No	Used as native VLAN on uplinks te1/0/3-7, te2/0/3-7
12	172.27.12.1/24	No	Access ports te1/0/8-11,13, te2/0/8-11,13; also on Po10,11,13
13	172.27.13.1/24	Yes (2401:8800:c13:2::85/126)	Syslog/NTP/SNMP server subnet
14	172.27.14.1/24	No	Access ports te1/0/14-17, te2/0/14-17
15	172.27.15.1/24	No	Trunked, no access ports assigned
16	172.27.16.1/24	No	Access ports te1/0/18-21, te2/0/18-21
17–19	172.27.17-19.1/24	No	Trunked only
20	172.27.20.1/24	No	
21	172.27.21.1/24	No	te3/0/21 is untagged VLAN 11 access (not 21)
22–35	172.27.22-35.1/24	No (23,27 have IPv6 enabled)	
36	172.27.36.1/24	No	te1/0/22 is access VLAN 36

VLAN ID	SVI IP Address	IPv6 Enabled	Notes
37	172.27.37.1/24	Yes (2401:8800:c13:2::91/124)	
38	172.27.38.1/24	No	
39	172.27.39.1/24	No	
45	No SVI (L2 only)	No	Trunked; no IP — L2-only VLAN

Total: 31 VLANs (VLAN 10–39 plus 45). All SVIs use /24 subnets in the 172.27.x.0/24 space.

VLAN 1 is the management VLAN with IP — this is a security risk. Plan to migrate management to a dedicated VLAN on Nexus. VLAN 1 should be pruned from all trunks on Nexus.

VLANs 15, 17–20, 24, 26, 28–31, 33, 35, 38 have SVIs with IPs but NO access ports. Verify these are in use via routing or trunked to downstream devices — otherwise candidates for cleanup.

7. Interface Configuration Mapping

7.1 Trunk Ports — Units 1 & 2 (te1/0/3–7, te2/0/3–7)

10 trunk ports (5 per unit) carrying all VLANs. Native VLAN = 11. These connect to the FS1GSW0832 switch (which in turn connects servers on U1/U2 via LLDP). Not in any port-channel.

These 10 trunks to the same downstream switch are NOT bundled into port-channels. This is unusual and may create STP issues (multiple active trunks to same switch). Verify FS1GSW0832 side config. On Nexus, these should likely be bundled or properly pruned.

7.2 Access Port Summary

VLAN	Ports (Unit 1)	Ports (Unit 2)	Count
VLAN 11 (untagged)	te1/0/3-7 (native on trunk)	te2/0/3-7 (native on trunk)	10 trunk native
VLAN 12	te1/0/8-11, te1/0/13	te2/0/8-11, te2/0/13	10 ports
VLAN 14	te1/0/14-17	te2/0/14-17	8 ports
VLAN 16	te1/0/18-21	te2/0/18-21	8 ports
VLAN 36	te1/0/22	—	1 port
VLAN 11 access	—	te3/0/21 (Unit 3)	1 port

7.3 Notable Unconfigured Ports

Port	Status	Issue
te1/0/1	UP, 1G	No VLAN, no channel-group, no description — orphan
te2/0/1	UP, 1G	Same as te1/0/1 — orphan
te1/0/23	Down, Combo-C	No config — likely unused SFP combo slot
te2/0/23	Down, Combo-C	No config — likely unused
te3/0/22	Down	No config
te4/0/22	Down	No config

Port Configuration

8. Spanning Tree

STP mode: Rapid-PVST (rapid-pvst) good, this translates directly to Nexus Rapid-PVST.

STP priority: 4096 this switch is the Root Bridge for all VLANs. Must preserve this on Nexus.

With STP priority 4096, this switch is the root for ALL VLANs. Nexus default priority is 32768. If Nexus is not explicitly configured with 4096, another device will win root election during cutover — causing a topology reconvergence and potential traffic blackhole.

i NX-OS command to set root: 'spanning-tree vlan 1-39,45 priority 4096' or use 'spanning-tree vlan X root primary'

9. Routing & Layer 3

9.1 IP Routing

The switch is acting as a Layer 3 switch (has SVIs for 31 VLANs). No explicit 'ip routing' command found in CBS config — CBS enables routing implicitly when SVIs are assigned IPs.

i On NX-OS, you must explicitly enable 'feature interface-vlan' and 'ip routing' for SVI routing to work.

9.2 Default Gateway

Type	Address	Note
IPv4 Default Gateway	172.27.8.31	Upstream router — must be reachable on VLAN 1 or management VLAN on Nexus
IPv6 Default Gateway	2401:8800:c13:2::81 (VLAN 1)	IPv6 upstream

Type	Address	Note
Loopback1 IP	172.27.7.1/30	Used as SNTP source interface — replicate on Nexus

No OSPF, BGP, or MPLS config found in this CBS switch. It is purely a Layer 3 access/distribution switch with static default routing. Confirm with upstream router (172.27.8.31) if any routing protocols need to be enabled on Nexus.

9.3 IPv6 Config

IPv6 is selectively enabled on VLANs 1, 13, 23, 27, 37. The /126 and /124 prefixes are from 2401:8800:c13:2::/64 range.

VLAN	IPv6 Address
VLAN 1	2401:8800:c13:2::82/126
VLAN 13	2401:8800:c13:2::85/126
VLAN 37	2401:8800:c13:2::91/124
VLAN 23	ipv6 enable (no explicit address)
VLAN 27	ipv6 enable (no explicit address)

i On NX-OS: use 'ipv6 address ...' under each SVI. 'ipv6 enable' without address enables link-local only — replicate as-is.

10. Management Plane

10.1 AAA / Users

RADIUS server config contains PLAINTEXT credentials in the config (radius server user commands with passwords visible). These must NOT be replicated in plaintext on Nexus. Use encrypted form or TACACS+.

Username	Privilege	Auth Method	Note
cnfmgr	15	Local (encrypted)	Migrate to Nexus local user
fsnetrw	15	Local (encrypted)	Migrate to Nexus local user
nikhil.k	15	Local (encrypted)	Migrate
ajinkya.b	15	Local (encrypted)	Migrate
nikhil.kadam	15	RADIUS group 'Router Users'	Plain password in config — SECURITY RISK

Username	Privilege	Auth Method	Note
yogesh.yerum	15	RADIUS group 'Router Users'	Plain password in config — SECURITY RISK

10.2 SNMP

Parameter	Value
SNMP Server	Enabled
Location	Netmagic Datacenter
Contact	Nikhil Kadam
Community	FSNET (read-only)
Allowed Managers	172.27.13.14, 172.27.13.19, 172.27.13.191
View	Default

i On Nexus: 'feature snmp', then replicate community and allowed hosts. Consider upgrading to SNMPv3 on Nexus.

10.3 Syslog

Parameter	Value
Syslog Host 1	172.27.13.13
Syslog Host 2	172.27.13.14
Syslog Host 3	172.27.13.29
Buffer	500 messages, level debugging
Console logging	Critical only

10.4 NTP / SNTP

Parameter	Value
NTP Server 1	172.27.13.11

Parameter	Value
NTP Server 2	172.27.13.12
Source Interface	Loopback1 (172.27.7.1)
Timezone	IN +5:30 (IST)

i CBS uses 'sntp' NX-OS uses 'ntp'. Syntax changes: 'ntp server 172.27.13.11 use-vrf management' on Nexus. Loopback source: 'ntp source-interface loopback0'.

10.5 SSH & HTTP

SSH server is enabled — replicate on Nexus with 'feature ssh'.

HTTP server is DISABLED (no ip http server) — good security posture. Keep it disabled on Nexus.

i Exec timeout is 5 minutes on console, SSH, and telnet. Telnet is configured — consider disabling telnet on Nexus (use SSH only).

10.6 Security Banner

Login and exec banners are configured: 'AUTHORIZED ACCESS ONLY / DISCONNECT ASAP IF YOU ARE NOT AUTHORISED / ACCESS MONITORED AND RECORDED'. Replicate on Nexus.

11. Security Config

Feature	Current Status	Nexus Action
CDP	Disabled (no cdp run)	Keep disabled or enable selectively on Nexus
Voice VLAN	Auto-triggered with OUI table	Re-evaluate need on Nexus
SYN Protection	Mode: Report	Nexus has IP Source Guard / CoPP — replicate intent
SSD (Secure Sensitive Data)	Enabled with passphrase	Not applicable on Nexus — manage credentials separately
Port Security	Not configured	Opportunity to add on Nexus
802.1X	Not configured	Opportunity to add on Nexus
DHCP Snooping	Not found in config	Add on Nexus for server VLANs
ARP Inspection	Not found in config	Add on Nexus
ACLs	Not found in config	Opportunity to add on Nexus

12. Feature Gap — CBS SX550X vs NX-OS

Feature	CBS SX550X	Cisco NX-OS	Action Required
Port-channel protocol	PAgP (mode auto)	LACP only	Change all to LACP — verify far end
STP mode	Rapid-PVST	Rapid-PVST / MST	Direct migration, set priority 4096
SNTP	sntp server	ntp server	Syntax change
IP routing	Implicit	Explicit (ip routing + feature interface-vlan)	Must configure explicitly
Interface naming	te1/0/1	Ethernet1/1	Full renaming needed
Port-channel naming	Po1	port-channel1	Rename in configs
VRF	Not used	vrf context	Not needed unless multi-VRF planned
HSRP/VRRP	Not configured	Can use anycast GW with vPC	Plan if dual-Nexus
Stacking	CBS stack (te1–4)	vPC (if dual switch) or single chassis	Architecture decision
SSD	Cisco CBS specific	Not applicable	Remove from migration scope
Voice VLAN OUI	Supported	Not natively same	Re-evaluate VoIP design
IPv6 enable	ipv6 enable under SVI	ipv6 enable under SVI	Direct translation
RADIUS plaintext user	radius server user	Not recommended	Remove, use TACACS+ or local

13. Missing Data — Collect Before Migration

The following were not captured in this session and must be collected:

#	Missing Command / Data	Why Needed
1	show spanning-tree detail	Confirm root bridge, port roles, topology
2	show interfaces counters errors	Pre-migration baseline — CRC, drops, resets

#	Missing Command / Data	Why Needed
3	show logging	Check recent errors, flaps, STP TCN events
4	show processes cpu sorted	Identify cause of 100% CPU
5	show mac address-table	MAC count per VLAN — sizing for Nexus CAM table
6	show ip route	Confirm routing table — static routes or dynamic
7	show ip arp	ARP table — identify all active L3 endpoints
8	show interfaces counters	Traffic baseline per port before migration
9	show environment all	Fan, temperature, power supply health
10	show lacp neighbor detail	Verify LACP state on Po10/Po11
11	FS1GSW0832 config	Understand downlink switch before cutting Po2
12	IDC7-SW config	Understand uplink switch before cutting Po7 (critical uplink)

14. Critical Risks Summary

#	Risk	Severity	Action
1	CPU at 100% — switch may be unstable	CRITICAL	Diagnose before migration
2	Po2 has non-candidate member — single link to FS switch	HIGH	Investigate and fix
3	PAgP used — Nexus only supports LACP	HIGH	Convert all channels to LACP
4	te1/0/15 & te2/0/15 running at 100 Mbps on 10G ports	HIGH	Fix cable/NIC before migration
5	STP root priority 4096 — must be set on Nexus immediately	HIGH	Set priority before any trunk comes up
6	VLAN 1 used as management with IP — security risk	MEDIUM	Plan management VLAN migration

#	Risk	Severity	Action
7	Plaintext RADIUS passwords in running config	MEDIUM	Remove, use encrypted auth
8	No DHCP snooping or ARP inspection	MEDIUM	Add on Nexus as security hardening
9	Po7 is only uplink to IDC7-SW — single path	HIGH	Plan redundant uplink on Nexus
10	IP routing implicit on CBS — must be explicit on NX-OS	HIGH	Must not forget or SVIs won't route
11	10 unbundled trunks to FS switch may cause STP issues	MEDIUM	Audit and bundle or prune

15. Recommended Nexus Migration In the Separate Configuration.

Netmagic-CoreSwitch Migration Assessment | Phase 1 | Hassan | 23-Mar-2026