# DPG for Engineers

Truman E. Ellis, Jesse L. Chan, Leszek F. Demkowicz, Jay Gopalakrishnan

October 21, 2014

#### Abstract

We discuss and explain the discontinuous Petrov-Galerkin finite element method with an engineering audience in mind.

# 1 Motivation and Introductory Concepts

The discontinuous Petrov-Galerkin finite element method is a promising new framework for automated computing of a broad class of partial differential equations.

### 1.1 A Framework for Automated Computing

## 1.2 Mathematical Fundamentals

#### 1.2.1 Banach, Hilbert, and Sobolev Spaces

Consider a bounded domain,  $\Omega \in \mathbb{R}^d$  and a vector space of functions defined on  $\Omega$ . A Banach space is a complete normed vector space. An example of which is  $L_1(\Omega)$  which is the set of all functions defined on  $\Omega$  such that the  $L_1$  norm  $\|u\|_{L_1(\Omega)} := \int_{\Omega} |u|$  is finite. A Hilbert space is a Banach space where the norm is defined through an inner product. An example of which is  $L_2(\Omega)$  for which the norm is  $\|u\|_{L_2(\Omega)} := (u,u)_{L_2(\Omega)}^{\frac{1}{2}} := (\int_{\Omega} u^2)^{\frac{1}{2}}$ . Finally, a Sobolev space is a Hilbert space where the inner product contains derivatives of the function. A common Sobolev space is  $H^1(\Omega)$  where  $\|u\|_{H^1(\Omega)}^2 := \|u\|_{L_2(\Omega)}^2 + \|\nabla u\|_{L_2(\Omega)}^2$ .

#### 1.2.2 Variational Formulations, Dual Spaces, and Riesz Maps

Consider a Banach space U. The dual space, U' is the set of all linear functionals on U such that the pairing  $\langle u, w \rangle_{U \times U'} \in \mathbb{R}$  for all  $u \in U$  and  $w \in U'$ . Any PDE problem can abstractly be written as: find solution  $u \in U$  such that

$$Bu = l$$

where  $B: U \to V'$  maps functions to some dual space and  $l \in U'$ . By the calculus of variations, this is equivalent to the problem: find solution  $u \in U$  such that

$$\langle Bu, v \rangle = \langle l, v \rangle$$

for all functions  $v \in V$  and v is called a test function. This defines a bilinear form b(u,v) = f(v) where u is often called the trial function. Now let U and V be Hilbert rather than merely Banach. The Riesz representation theorem defines a bijective, isometric mapping from every member in V to a corresponding member in the dual space V'. We denote this mapping  $R_V: V \to V'$ . Thus, we can take our operator equation representing the strong form of our PDE

$$Bu - l = 0 \in V'$$

and map it back to V via the inverse Riesz map:

$$R_V^{-1}(Bu-l) = 0 \quad \in V.$$

- 1.3 Ritz Methods and Least Squares
- 1.4 SUPG Or Stability Through the Appropriate Test Space
- 2 Development of a DPG Method for the Poisson Equation
- 3 DPG for Well Posed PDEs