* AC= ASSIGNABLE CONTROL

011 Chorus 1
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	23.6	OFF	OFF	0	100	3.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	30	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	38.1	OFF	OFF	0	100	4.2	2.5	R10	10			
4	ON	IN	NOR	4->4	OFF	SIN	47.6	OFF	OFF	0	100	3.7	2.5	L10	10	8.5	5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	3.5	2.5	L10	6.5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	3.5	100	3.8	2.5	R10	6.5			
7	ON	IN	NOR	7->7	OFF	SIN	341	OFF	OFF	4.3	100	4.7	2.5	L10	6.5			
8	ON	IN	NOR	8->8	OFF	SIN	450	OFF	OFF	3.4	100	3.3	2.5	R10	6.5			

012 Chorus 2
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	25.1	OFF	OFF	0	100	3	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	33.4	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	43.1	OFF	OFF	0	100	3.4	2.5	R10	10			
4	ON	IN	NOR	4->4	OFF	SIN	50	OFF	OFF	0	100	4.2	2.5	L10	10	10	6.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	3.5	2.5	L10	6			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	3.5	100	3.8	2.5	R10	6			
7	ON	IN	NOR	7->7	OFF	SIN	341	OFF	OFF	4.3	100	4.7	2.5	L10	6			
8	ON	IN	NOR	8->8	OFF	SIN	450	OFF	OFF	3.4	100	3.3	2.5	R10	6			

013 Chorus 3
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	25.1	OFF	OFF	0	100	3	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	33.4	OFF	OFF	0	100	4.5	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	95.6	OFF	OFF	0	100	3.4	2.5	R7.0	7			
4	ON	IN	NOR	4->4	OFF	SIN	120	OFF	OFF	0	100	4.2	2.5	L7.0	5.7	10	6.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	3.5	2.5	L10	4.5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	3.5	100	3.8	2.5	R10	4.5			
7	ON	IN	NOR	7->7	OFF	SIN	341	OFF	OFF	4.3	100	4.7	2.5	L10	4.5			
8	ON	IN	NOR	8->8	OFF	SIN	450	OFF	OFF	3.4	100	3.3	2.5	R10	4.5			

021 Chorus 4
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	15.1	OFF	OFF	0	100	3.8	2.7	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	29	OFF	OFF	0	100	4.3	2.7	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	41.1	OFF	OFF	0	100	5	2.7	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	37	OFF	OFF	0	100	5.6	2.7	R10	10	8	7.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	6	100	3.5	2.7	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	5.2	100	3.8	2.7	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	5.8	100	4.7	2.7	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	463	OFF	OFF	5	100	3.3	2.7	R10	4			

022 Chorus 5
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	21.6	OFF	OFF	0	100	3.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	29	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	50	OFF	OFF	0	100	4.2	2.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	40	OFF	OFF	0	100	3.7	2.5	R10	10	8	8	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	5	100	3.5	2.5	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	3.8	2.5	R10	5			
7	ON	IN	NOR	7->7	OFF	SIN	341	OFF	OFF	5	100	4.7	2.5	L10	5			
8	ON	IN	NOR	8->8	OFF	SIN	450	OFF	OFF	3.8	100	3.3	2.5	R10	5			

023 Chorus 6
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	21.6	OFF	OFF	0	100	3.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	29	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	43.2	OFF	OFF	0	100	4.3	2.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	37	OFF	OFF	0	100	3.7	2.5	R10	10	8.5	6.5	C
5	ON	IN	NOR	5->5	OFF	SIN	301	OFF	OFF	6	100	3.4	2.5	L10	4.5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	5.2	100	2.3	2.5	R10	4.5			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

031 Chorus 7
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	31.5	OFF	OFF	0	25.4	4.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	22.6	OFF	OFF	0	25.4	5.2	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	40	OFF	OFF	0	25.4	4	2.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	48	OFF	OFF	0	25.4	4.9	2.5	R10	5	8	8	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	5	100	3.8	2.5	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	361	OFF	OFF	4	100	4.2	2.5	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5	100	3.5	2.5	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	3	100	5	2.5	R10	4			

032 Chorus 8
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	31.5	OFF	OFF	0	100	4.7	3	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	22.6	OFF	OFF	0	100	4.8	3	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	40	OFF	OFF	0	100	6.2	1.7	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	48	OFF	OFF	0	100	7.1	1.7	R10	10	7.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	5	100	3.8	2.7	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	351	OFF	OFF	4	100	4.2	2.7	R10	5			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5	100	3.5	2.7	L10	5			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	3	100	5	2.7	R10	5			

033 Chorus 9
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	31.5	OFF	OFF	0	25.4	4.5	5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	22.6	OFF	OFF	0	25.4	5.2	5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	40	OFF	OFF	0	25.4	4	5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	48	OFF	OFF	0	25.4	4.9	5	R10	10	7.5	8.2	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	5	100	3.8	3.5	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	341	OFF	OFF	4	100	4.2	3.2	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5	100	3.5	3.5	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	4	100	5	3.2	R10	4			

* AC= ASSIGNABLE CONTROL

111 Chorus 10
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	19.4	OFF	OFF	0	25.4	4.5	2.7	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	15	OFF	OFF	0	25.4	5.2	2.7	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	6	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	5	100	3.8	3	L10	3.5			
6	ON	IN	NOR	6->6	OFF	SIN	351	OFF	OFF	4	100	4.2	3	R10	3.5			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5	100	3.5	3	L10	3.5			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	3	100	5	3	R10	3.5			

112 Chorus 11
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	23.6	OFF	OFF	0	25.4	3.9	5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	30	OFF	OFF	0	25.4	5.2	5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	40.9	OFF	OFF	0	25.4	4	3.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	48.2	OFF	OFF	0	25.4	4.9	3.5	R10	10	8	8	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

113 Chorus 12
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	22	OFF	OFF	0	100	4.7	2.3	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	27.1	OFF	OFF	0	100	5.8	2.3	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	30	OFF	OFF	0	100	6.8	1	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	40	OFF	OFF	0	100	7.2	1	R10	10	7.5	7.5	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5	100	3.5	3.2	L10	4.5			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	3	100	5	3.2	R10	4.5			

121 Stereo Enhanced Lead Solo Patch 1
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	29.7	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	40	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	96	OFF	OFF	0	100	0	0	L5.0	4			
4	ON	IN	NOR	4->4	OFF	SIN	110	OFF	OFF	0	100	0	0	R5.0	4	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	0	0	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	5			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	3.5	100	0	0	L10	5			
8	ON	IN	NOR	8->8	OFF	SIN	461	OFF	OFF	3	100	0	0	R10	5			

122 Stereo Enhanced Lead Solo Patch 2
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	25	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	36.8	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	96	OFF	OFF	0	100	0	0	L7.5	7			
4	ON	IN	NOR	4->4	OFF	SIN	110	OFF	OFF	0	100	0	0	R7.5	7	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	276	OFF	OFF	4.5	100	0	0	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	370	OFF	OFF	4	100	0	0	R10	5			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	3.5	100	0	0	L10	5			
8	ON	IN	NOR	8->8	OFF	SIN	461	OFF	OFF	3	100	0	0	R10	5			

123 Stereo Enhanced Lead Solo Patch 3
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	36.1	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	45.4	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	92	OFF	OFF	0	100	0	0	L7.5	8.5			
4	ON	IN	NOR	4->4	OFF	SIN	112	OFF	OFF	0	100	0	0	R7.5	8.5	8.1	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	0	0	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	4	100	0	0	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	455	OFF	OFF	3.5	100	0	0	R10	4			

131 Stereo Enhanced Lead Solo Patch 4
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	36.1	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	45	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	134	OFF	OFF	0	100	0	0	C	5			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	2.5	100	0	0	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	2	100	0	0	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	1.7	100	0	0	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	455	OFF	OFF	1	100	0	0	R10	4			

132 Stereo Enhanced Lead Solo Patch 5
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	20.5	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	37.7	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	96	OFF	OFF	0	100	0	0	L5.0	4.5			
4	ON	IN	NOR	4->4	OFF	SIN	110	OFF	OFF	0	100	0	0	R5.0	4.5	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	0	0	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	4			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	3.5	100	0	0	L10	4			
8	ON	IN	NOR	8->8	OFF	SIN	461	OFF	OFF	3	100	0	0	R10	4			

133 Stereo Enhanced Lead Solo Patch 6
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	29.7	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	40	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	96	OFF	OFF	0	100	0	0	L5.0	6			
4	ON	IN	NOR	4->4	OFF	SIN	110	OFF	OFF	0	100	0	0	R5.0	6	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	0	0	L10	5.5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	5.5			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	3.5	100	0	0	L10	5.5			
8	ON	IN	NOR	8->8	OFF	SIN	461	OFF	OFF	3	100	0	0	R10	5.5			

211 Stereo Enhanced Lead Solo Patch 7
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	23.1	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	33.1	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	110	OFF	OFF	0	100	0	0	C	7.5			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	0	0	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	5			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

212 Stereo Enhanced Lead Solo Patch 8
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	31.8	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	42.1	OFF	OFF	0	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	95	OFF	OFF	0	100	0	0	L0.0	6			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	ON	IN	NOR	7->7	OFF	SIN	333	OFF	OFF	4	100	0	0	L10	4.5			
8	ON	IN	NOR	8->8	OFF	SIN	445	OFF	OFF	3.8	100	0	0	R10	4.5			

213 Stereo Enhanced Lead Solo Patch 9
by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	21.2	OFF	OFF	0	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	32.1	OFF	OFF	0	100	0	0	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	5	100	0	0	L10	4			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	4	100	0	0	R10	4			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

221 Volume Pedal Swell FX 1 by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	21.6	OFF	OFF	0	100	3.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	29	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	350	OFF	OFF	4	100	4.2	2.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	463	OFF	OFF	3	100	3.7	2.5	R10	10	7.5	5	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	5.4	100	3.5	2.5	L10	10			
6	ON	IN	NOR	6->6	OFF	SIN	347	OFF	OFF	4.2	100	3.8	2.5	R10	10			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	5.8	100	4.7	2.5	R10	10			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	5	100	3.3	2.5	L10	10			

222 Volume Pedal Swell FX 2 by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	23.1	OFF	OFF	0	100	3.5	2.5	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	33.6	OFF	OFF	0	100	4	2.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	43.3	OFF	OFF	0	100	4.2	2.5	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	51.1	OFF	OFF	0	100	3.7	2.5	R10	10	7.5	0	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	6	100	3.5	2.5	L10	10			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	5.2	100	3.8	2.5	R10	10			
7	ON	IN	NOR	7->7	OFF	SIN	345	OFF	OFF	5.8	100	4.7	2.5	L10	10			
8	ON	IN	NOR	8->8	OFF	SIN	465	OFF	OFF	5	100	3.3	2.5	R10	10			

223 Single Source Point Stereo Microphone + Echos by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	5.25	OFF	OFF	0	100	0	0	L10	7			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	ON	IN	REV	3->3	OFF	SIN	5.48	OFF	OFF	0	100	0	0	R10	10			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	8	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	4	100	0	0	L10	3.7			
6	ON	IN	NOR	6->6	OFF	SIN	341	OFF	OFF	3.5	100	0	0	R10	3.7			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	4	100	0	0	L10	3.7			
8	ON	IN	NOR	8->8	OFF	SIN	400	OFF	OFF	3.5	100	0	0	R10	3.7			

231 Vintage Echo 1 by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	321	OFF	OFF	4.7	100	3.7	2.3	L10	5.5			
6	ON	IN	NOR	6->6	OFF	SIN	429	OFF	OFF	4	100	4.1	2.3	R10	5.5			
7	ON	IN	NOR	7->7	OFF	SIN	360	OFF	OFF	3.5	100	4.6	2.3	C	5			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

232 Vintage Echo 2 by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	300	OFF	OFF	4.5	100	4.5	2	L10	5.5			
6	ON	IN	NOR	6->6	OFF	SIN	400	OFF	OFF	3.7	100	5.4	2	R10	5.5			
7	ON	IN	NOR	7->7	OFF	SIN	355	OFF	OFF	3.5	100	3.9	2	L10	5.5			
8	ON	IN	NOR	8->8	OFF	SIN	461	OFF	OFF	2.7	100	3.4	2	R10	5.5			

233 Vintage Echo 3 by Allan Holdsworth

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.5	8.5	C
5	ON	IN	NOR	5->5	OFF	SIN	250	OFF	OFF	4.5	100	3.5	2	L10	5			
6	ON	IN	NOR	6->6	OFF	SIN	330	OFF	OFF	4	100	4.1	2	R10	5			
7	ON	IN	NOR	7->7	OFF	SIN	300	OFF	OFF	3.5	100	3.1	2	L10	5			
8	ON	IN	NOR	8->8	OFF	SIN	401	OFF	OFF	3	100	4.5	2	R10	5			

311 Reverse Phase 4-Band Stereo Chorus 1 (Sine Wave Modulation)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	11.3	OFF	OFF	0	100	3.3	4.5	L10	10			
2	ON	IN	REV	2->2	1	SIN	11.3	OFF	OFF	0	100	0	4.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	15.7	OFF	OFF	0	100	4	4	R10	10			
4	ON	IN	REV	4->4	3	SIN	15.7	OFF	OFF	0	100	0	4	L10	10	10	10	C
5	ON	IN	NOR	5->5	OFF	SIN	21.1	OFF	OFF	0	100	5	2.5	L10	10			
6	ON	IN	REV	6->6	5	SIN	21.1	OFF	OFF	0	100	0	2.5	R10	10			
7	ON	IN	NOR	7->7	OFF	SIN	27	OFF	OFF	0	100	5.7	1.5	R10	10			
8	ON	IN	REV	8->8	7	SIN	27	OFF	OFF	0	100	0	1.5	L10	10			

312 Reverse Phase 4-Band Stereo Chorus 2 (Triangle Wave Modulation)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	TRI	11.3	OFF	OFF	0	100	3.3	6	L10	10			
2	ON	IN	REV	2->2	1	TRI	11.3	OFF	OFF	0	100	0	6	R10	10			
3	ON	IN	NOR	3->3	OFF	TRI	15.7	OFF	OFF	0	100	4	5.5	R10	10			
4	ON	IN	REV	4->4	3	TRI	15.7	OFF	OFF	0	100	0	5.5	L10	10	10	10	C
5	ON	IN	NOR	5->5	OFF	TRI	21.1	OFF	OFF	0	100	5	3.5	L10	10			
6	ON	IN	REV	6->6	5	TRI	21.1	OFF	OFF	0	100	0	3.5	R10	10			
7	ON	IN	NOR	7->7	OFF	TRI	27	OFF	OFF	0	100	5.7	2.5	R10	10			
8	ON	IN	REV	8->8	7	TRI	27	OFF	OFF	0	100	0	2.5	L10	10			

313 6-Band Chorus + Stereo Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	2	TRI	15.1	OFF	OFF	0	100	5.7	4.5	L10	7.6			
2	ON	IN	NOR	2->2	OFF	SIN	19.1	OFF	OFF	0	100	4.5	4.1	R10	7.6			
3	ON	IN	NOR	3->3	4	TRI	25	OFF	OFF	0	100	5.8	4.7	L10	7.6			
4	ON	IN	NOR	4->4	OFF	TRI	30	OFF	OFF	0	100	3.9	4.9	R10	7.6	10	10	C
5	ON	IN	NOR	5->5	6	TRI	37.2	OFF	OFF	0	100	4.9	3.5	L10	7.6			
6	ON	IN	NOR	6->6	OFF	TRI	44	OFF	OFF	0	100	3.5	4.4	R10	7.6			
7	ON	1	NOR	7->7	OFF	TRI	400	OFF	3.2	4	0	0	0	L10	8			
8	ON	2	NOR	8->8	OFF	TRI	532	OFF	3.2	1.8	100	0	0	R10	6.9			

321 8-Band Chorus 1 (AC: Stereo Effect)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	14.1	OFF	OFF	0	100	5.7	4.5	L10	7.5			
2	ON	IN	NOR	2->2	OFF	SIN	18.1	OFF	OFF	0	100	4.5	4.1	L10	7.5			
3	ON	IN	NOR	3->3	OFF	TRI	20.1	OFF	OFF	0	100	5.8	4.7	L10	7.5			
4	ON	IN	NOR	4->4	OFF	TRI	25.1	OFF	OFF	0	100	3.9	4.9	R10	7.5	10	10	C
5	ON	IN	NOR	5->5	OFF	TRI	29.1	OFF	OFF	0	100	4.9	3.5	L10	7.5			
6	ON	IN	NOR	6->6	OFF	TRI	35.1	OFF	OFF	0	100	3.5	4.4	R10	7.5			
7	ON	IN	NOR	7->7	OFF	SIN	42	OFF	OFF	0	100	3	3	L10	8			
8	ON	IN	NOR	8->8	OFF	SIN	50	OFF	OFF	0	100	3.5	3	R10	8			

322 8-Band Chorus 2

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	15.2	OFF	OFF	0	100	2.1	7.9	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	80	OFF	OFF	0	100	8.1	1.7	C	10			
3	ON	IN	NOR	3->3	OFF	SIN	50	OFF	OFF	0	100	1.6	10	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	0.43	OFF	OFF	0	100	2.5	7.6	C	10	10	10	C
5	ON	IN	NOR	5->5	OFF	SIN	2.72	OFF	OFF	4.1	25	5.8	10	C	10			
6	ON	IN	NOR	6->6	OFF	SIN	7.51	OFF	OFF	7.2	93.4	5.8	4.1	L10	10			
7	ON	IN	NOR	7->7	OFF	SIN	200	OFF	OFF	2.2	9.38	0	0	R10	8.4			
8	ON	IN	NOR	8->8	OFF	SIN	4	OFF	OFF	7.7	19.5	3.1	1.1	C	10			

323 Rotary Chorus (AC: Rotary Speed)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	5	OFF	10	0	100	3.6	8.5	L10	10			
2	ON	IN	NOR	2->2	1	SIN	5	OFF	10	0	100	3	8.5	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	8	10	OFF	0	100	8.3	3.3	L10	10			
4	ON	IN	NOR	4->4	3	SIN	8	10	OFF	0	100	7	3.3	R10	10	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

* AC= ASSIGNABLE CONTROL

331 Flanger Chorus (AC: Flanger Feedback)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	REV	1->1	OFF	SIN	15.8	OFF	OFF	0	100	4	4.5	L10	8			
2	ON	IN	NOR	2->2	OFF	SIN	18	OFF	OFF	0	100	4.5	4.1	R10	8			
3	ON	IN	NOR	3->3	OFF	SIN	21.1	OFF	OFF	0	100	4.6	4.1	L10	7.5			
4	ON	IN	NOR	4->4	OFF	SIN	23.8	OFF	OFF	0	100	5.1	4.1	R10	7.5	10	10	C
5	ON	IN	NOR	5->5	OFF	SIN	27	OFF	OFF	0	100	4	4.4	L10	7.5			
6	ON	IN	NOR	6->6	OFF	SIN	29.5	OFF	OFF	0	100	2.9	4.4	R10	7.5			
7	ON	IN	NOR	7->7	OFF	SIN	3	OFF	3.2	7.5	100	3.6	9.1	L10	8.3			
8	ON	IN	NOR	8->8	OFF	SIN	5.7	OFF	3.2	7.9	100	2.1	9.4	R10	8.3			

332 Stereo Flanger + Stereo Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	3	NOR	1->1	OFF	SIN	4	OFF	OFF	7	100	3.6	8.2	L10	8.5			
2	ON	5	NOR	2->2	OFF	SIN	4.83	OFF	OFF	8	100	2.7	8.4	R10	8.5			
3	ON	IN	NOR	3->4	OFF	SIN	800	OFF	OFF	2.3	100	0	0	L10	5			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	ON	IN	NOR	5->6	OFF	SIN	1000	OFF	OFF	1.8	100	0	0	R10	5			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

333 Delay Chorus

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->2	OFF	SIN	400	OFF	OFF	2.9	100	0	0	L10	7.5			
2	ON	IN	NOR	1->2	OFF	SIN	↑	↑	↑	↑	99.6	3.8	2.8	L10	7.5			
3	ON	IN	NOR	3->4	OFF	SIN	501	OFF	OFF	2.5	100	0	0	R10	7.5			
4	ON	IN	NOR	3->4	OFF	SIN	↑	↑	↑	↑	99.2	3.2	3.4	R10	7.5	8	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

411 Stereo Multi-Delay (Doubling + Medium Delay + Long Delay)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	40.1	OFF	OFF	0	100	0	0	L10	7			
2	ON	IN	NOR	2->2	OFF	SIN	60	OFF	OFF	0	100	0	0	R10	7			
3	ON	1	NOR	3->3	OFF	SIN	145	OFF	OFF	0	100	0	0	L10	5			
4	ON	2	NOR	4->4	OFF	SIN	237	OFF	OFF	0	100	0	0	R10	5	10	10	C
5	ON	1	NOR	5->5	OFF	SIN	400	OFF	OFF	4.1	100	0	0	L10	10			
6	ON	2	NOR	6->6	OFF	SIN	550	OFF	OFF	3.1	100	0	0	R10	10			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

412 Stereo Filter Delay + Chorus

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	5.61	OFF	10	0	100	5.3	5.8	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	5	10	OFF	0	100	5.9	6.5	R10	10			
3	ON	1	NOR	3->3	OFF	SIN	300	OFF	9.3	3.7	100	0	0	L10	10			
4	ON	2	NOR	4->4	OFF	SIN	600	10	5	1.7	100	0	0	R10	10	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

413 Reverse Phase Stereo Multi-Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	200	OFF	OFF	5	100	0	0	R10	10			
2	ON	IN	NOR	2->2	OFF	SIN	320	OFF	OFF	4.5	100	0	0	L10	10			
3	ON	IN	NOR	3->3	OFF	SIN	431	OFF	OFF	4	100	0	0	R10	10			
4	ON	IN	NOR	4->4	OFF	SIN	697	OFF	OFF	3.6	100	0	0	L10	10	8.2	10	C
5	ON	IN	REV	5->5	OFF	SIN	200	OFF	OFF	5	100	0	0	L10	10			
6	ON	IN	REV	6->6	OFF	SIN	320	OFF	OFF	4.5	100	0	0	R10	10			
7	ON	IN	REV	7->7	OFF	SIN	431	OFF	OFF	4	100	0	0	L10	10			
8	ON	IN	REV	8->8	OFF	SIN	697	OFF	OFF	3.6	100	0	0	R10	10			

421 Short + Long Delay for Distortion Solo (AC: Long Delay Feedback)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	40	0.1	0.1	0	100	0	0	L10	8			
2	ON	IN	NOR	2->2	OFF	SIN	60	0.1	0.1	0	100	0	0	R10	8			
3	ON	IN	NOR	3->3	OFF	SIN	400	OFF	0.1	4.1	100	0	0	L10	10			
4	ON	IN	NOR	4->4	OFF	SIN	572	OFF	0.1	3.5	100	0	0	R10	10	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

422 8-Tap Multi Tap Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	100	OFF	0.4	7.2	100	0	0	L10	10			
2	ON	IN	NOR	2->2	OFF	SIN	151	OFF	0.8	7.1	100	0	0	R10	10			
3	ON	IN	NOR	3->3	OFF	SIN	211	OFF	1.2	5.4	100	0	0	L10	9			
4	ON	IN	NOR	4->4	OFF	SIN	280	OFF	1.6	4.5	100	0	0	R10	9	7	10	C
5	ON	IN	NOR	5->5	OFF	SIN	361	OFF	2	3.2	100	0	0	L10	8			
6	ON	IN	NOR	6->6	OFF	SIN	450	OFF	2.4	3.2	100	0	0	R10	8			
7	ON	IN	NOR	7->7	OFF	SIN	551	OFF	2.8	2.7	100	0	0	L10	7			
8	ON	IN	NOR	8->8	OFF	SIN	661	OFF	3.2	2.5	100	0	0	R10	7			

423 Reverse Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	0.02	OFF	OFF	0	100	0	0	L10	3			
2	ON	1	NOR	2->2	OFF	SIN	20	OFF	OFF	0	100	0	0	L9.0	4			
3	ON	2	NOR	3->3	OFF	SIN	500	OFF	OFF	0	100	0	0	L7.0	5			
4	ON	3	NOR	4->4	OFF	SIN	90	OFF	OFF	0	100	0	7.5	L4.0	6	10	0	C
5	ON	4	NOR	5->5	OFF	SIN	141	OFF	OFF	0	100	0	0	L1.0	7			
6	ON	5	NOR	6->6	OFF	SIN	200	OFF	OFF	0	100	0	0	R2.5	8			
7	ON	6	NOR	7->7	OFF	SIN	270	OFF	OFF	0	100	0	0	R6.0	9			
8	ON	7	NOR	8->8	OFF	SIN	350	OFF	OFF	0	100	0	0	R10	10			

431 Multi Tap Pan Delay (AC: Delay Time)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	0.02	OFF	OFF	0	100	0	4.4	L10	6			
2	ON	IN	NOR	2->2	OFF	SIN	150	OFF	OFF	0	100	0	4.3	L7.5	7			
3	ON	IN	NOR	3->3	OFF	SIN	300	OFF	OFF	0	100	0	0	C	8			
4	ON	IN	NOR	4->4	OFF	SIN	451	OFF	OFF	0	100	0	0	R7.4	9	6.7	7	C
5	ON	IN	NOR	5->5	OFF	SIN	600	OFF	OFF	5.4	100	0	0	R10	10			
6	ON	IN	NOR	6->7	OFF	SIN	1000	OFF	OFF	3	100	0	0	L10	10			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

432 Multi Tap Ping-Pong Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	1330	OFF	OFF	0.5	12.5	0	0	L5.0	9.2			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	25	0	0	C	8.4			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	37.5	0	0	R5.0	7.6			
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	50	0	0	R10	6.8	8.2	10	L10
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	62.5	0	0	R5.0	6			
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	75	0	0	C	5.2			
7	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	87.5	0	0	L5.0	4.4			
8	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	100	0	0	L10	3.6			

433 Volume Style Delay (AC: Delay Time)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	S.DN	1970	2	6.1	3.6	100	10	0	L10	10			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	85.5	9	0	R10	9			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	70.3	8	0	L8.1	8			
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	57	7	0	R7.1	7	10	0	C
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	43	6	0	L6.1	6			
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	28.5	5	0	R5.0	5			
7	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	14.5	4	0	L4.1	4			
8	ON	IN	NOR	1->8	OFF	S.DN	↑	↑	↑	↑	0	3	0	R3.1	3			

* AC= ASSIGNABLE CONTROL

5 1 1 — 3-Head Monaural Tape Echo (AC: Tape Speed)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->3	OFF	SIN	841	2.1	8.5	0	100	1.5	1.8	C	3.2	6.2	10	C
2	ON	IN	NOR	1->3	OFF	SIN	↑	↑	↑	↑	72.3	0.9	1.8	C	5.9			
3	ON	IN	NOR	1->3	OFF	SIN	↑	↑	↑	↑	40.2	0.7	1.8	C	10			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 1 2 — 4-Head Monaural Tape Echo (AC: Tape Speed)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->4	OFF	SIN	1120	2.1	8.5	0	100	1.5	1.8	C	3.2	6.2	10	C
2	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	75	0.9	1.8	C	5.9			
3	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	50	0.7	1.8	C	8			
4	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	25	0	0	C	10			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 1 3 — 5-Head Monaural Tape Echo (AC: Tape Speed)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->5	OFF	SIN	1400	2.1	8.5	0	100	1.5	1.8	C	3.2	5.9	10	C
2	ON	IN	NOR	1->5	OFF	SIN	↑	↑	↑	↑	81.2	0.9	1.8	C	5.4			
3	ON	IN	NOR	1->5	OFF	SIN	↑	↑	↑	↑	62.9	0.7	1.8	C	6.7			
4	ON	IN	NOR	1->5	OFF	SIN	↑	↑	↑	↑	44.1	1	1.8	C	8.7			
5	ON	IN	NOR	1->5	OFF	SIN	↑	↑	↑	↑	25	1.2	1.8	C	10			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 2 1 — Stereo Doubling

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	40	OFF	OFF	0	100	0	0	L10	10	10	10	C
2	ON	IN	NOR	2->2	OFF	SIN	60	OFF	OFF	0	100	0	0	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 2 2 — Stereo Slapback Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	90	OFF	OFF	0	100	0	0	L10	8	10	10	C
2	ON	IN	NOR	2->2	OFF	SIN	141	OFF	OFF	0	100	0	0	R10	8			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 2 3 — Tremolo Chorus (AC: Speed)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	0.12	OFF	5.7	8	100	6.6	10	C	10	10	0	C
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 3 1 — Simple Stereo Chorus 1

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	TRI	30	OFF	2	0	100	4	3.4	L10	10	10	10	R10
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 3 2 — Simple Stereo Chorus 2 (AC: Speed, Depth)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	20	OFF	1	0	100	3.5	3.5	L10	10	10	10	C
2	ON	IN	REV	2->2	1	SIN	20	OFF	1	0	100	0	3.5	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

5 3 3 — Simple Flanger

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	4.07	OFF	OFF	6	100	1.8	9.6	C	10	10	10	C
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

6 1 1 — Reverb 1 (AC: Reverb Time)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	60	0.3	0.3	0	40.2	0	0	L10	8.1	6	10	C
2	ON	1	NOR	2->2	OFF	SIN	90	0.1	0.1	0	40.6	0	0	R10	8			
3	ON	2	NOR	3->3	OFF	SIN	151	0.1	0.1	1.1	40.6	0	0	L8.0	9			
4	ON	1	NOR	4->4	OFF	SIN	211	0.1	0.1	1.3	40.2	0	0	R8.0	9			
5	ON	4	NOR	5->5	OFF	SIN	310	OFF	OFF	3.6	40.2	0	0	C	9			
6	ON	4	NOR	6->6	OFF	SIN	426	OFF	OFF	3.9	39.8	0	0	L10	9			
7	ON	5	NOR	7->7	OFF	SIN	496	2	2	3.2	41	0	0	L10	6.3			
8	ON	IN	NOR	8->8	OFF	SIN	697	2	2	3.7	40.2	0	0	R10	6.8			

6 1 2 — Reverb 2

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	100	OFF	4	6.5	50	0	0	L10	10	3.2	10	C
2	ON	1	NOR	2->2	OFF	SIN	121	OFF	4	6.1	50	0	0	R10	10			
3	ON	2	NOR	3->3	OFF	SIN	150	OFF	4	5.6	50	0	0	L5.0	10			
4	ON	3	NOR	4->4	OFF	SIN	211	OFF	4	5.3	34	0	0	R5.0	10			
5	ON	4	NOR	5->5	OFF	SIN	234	OFF	4	4.7	50	0	0	C	10			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

6 1 3 — Modulation Reverb

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	100	OFF	4	6.5	50	1	5	L10	10	3.2	10	C
2	ON	1	NOR	2->2	OFF	SIN	121	OFF	4	6.1	50	2	4	R10	10			
3	ON	2	NOR	3->3	OFF	SIN	150	OFF	4	5.6	50	3	3	L5.0	10			
4	ON	3	NOR	4->4	OFF	SIN	211	OFF	4	5.3	34	4	2	R5.0	10			
5	ON	4	NOR	5->5	OFF	SIN	234	OFF	4	4.7	50	5	1	C	10			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

* AC= ASSIGNABLE CONTROL

621 Chorus + Delay + Reverb (AC: Chorus Level)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	7	NOR	1->1	OFF	SIN	100	OFF	4	6.5	50	1	5	L10	6			
2	ON	1	NOR	2->2	OFF	SIN	121	OFF	4	6.1	50	2	4	R10	6			
3	ON	2	NOR	3->3	OFF	SIN	150	OFF	4	5.6	50	3	3	L5.0	6			
4	ON	3	NOR	4->4	OFF	SIN	211	OFF	4	5.3	34	4	2	R5.0	6	8	10	C
5	ON	4	NOR	5->5	OFF	SIN	234	OFF	4	4.7	50	5	1	C	6			
6	ON	IN	NOR	6->6	OFF	SIN	10	OFF	OFF	0	100	4	6	C	7.2			
7	ON	6	NOR	7->7	OFF	SIN	270	OFF	3.8	5	100	0	0	C	6			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

622 Analog Reverb Simulation

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->6	OFF	SIN	92.1	1.6	4.3	5.6	11.3	0	0	C	9.4			
2	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	21.1	0	0	C	8.7			
3	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	36.7	0	0	C	8.5			
4	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	52	0	0	C	6.9	8.5	10	C
5	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	83.6	0	0	C	7			
6	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	100	0	0	C	6.8			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

623 Reverse Phase Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->2	OFF	SIN	600	OFF	OFF	3.6	100	0	0	L10	10			
2	ON	IN	REV	1->2	OFF	SIN	↑	↑	↑	↑	100	0	0	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

631 6-Tap Multi Tap Delay (AC: Tempo)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->6	OFF	SIN	1010	OFF	7	1.1	0	0	0	C	3.4			
2	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	11.3	0	0	C	6.5			
3	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	23	0	0	C	10			
4	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	34	0	0	C	10	10	10	C
5	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	55.9	0	0	C	7			
6	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	77.7	0	0	C	5			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

632 Long Stereo Delay

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	5890	OFF	7.8	2.8	50.4	0.9	10	L10	10			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	100	0.9	10	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

633 Tremolo Delay (AC: Tremolo Depth)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	1800	OFF	2	4.5	0	0	0	C	4			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	12.5	0	0	C	5.5			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	25	0	0	C	7			
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	37.5	0	0	C	8.5			
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	50	0	0	C	10	10	0	C
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	62.5	0	0	C	8.5			
7	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	75	0	0	C	7			
8	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	87.5	0	0	C	5.5			

711 Rhythm Delay 1 (AC: Tempo)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->2	OFF	SIN	750	OFF	OFF	2.7	100	0	0	L10	6.3			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	ON	IN	NOR	3->4	OFF	SIN	1000	OFF	OFF	0	100	5.8	2	R10	6.7			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	ON	IN	NOR	5->5	OFF	SIN	377	OFF	OFF	0	100	7.4	1.4	L1.4	7.4			
6	ON	IN	NOR	6->6	OFF	SIN	250	OFF	OFF	0	100	0	0	R5.0	3.7			
7	ON	IN	NOR	7->8	OFF	SIN	876	OFF	OFF	0	100	8.9	2.3	R10	4.8			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

712 Rhythm Delay 2 (AC: Tempo)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	2400	OFF	OFF	0	0	0	0	C	10			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	19.1	0	0	C	10			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	37.9	0	0	C	10			
4	ON	IN	NOR	1->8	OFF	S.DN	↑	↑	↑	↑	62.9	4.6	7.6	C	10	10	10	C
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	77	0	0	C	10			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

713 Rhythm Delay 3 (AC: Tempo)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->6	OFF	SIN	3670	OFF	OFF	0	0	0	0	L10	10			
2	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	8.59	0	0	L10	10			
3	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	17.2	0	0	L10	10			
4	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	55.1	0	0	R10	10			
5	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	64.1	0	0	R10	10	10	0	C
6	ON	IN	NOR	1->6	OFF	SIN	↑	↑	↑	↑	72.3	0	0	R10	10			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

721 Rhythm Delay 4 (AC: Tempo)

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->2	OFF	SIN	800	OFF	OFF	5	25.4	0	0	L10	10			
2	ON	IN	NOR	1->2	OFF	SIN	↑	↑	↑	↑	75	0	0	R10	10			
3	ON	IN	NOR	3->4	OFF	SIN	800	OFF	OFF	5	100	0	0	C	10			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

722 Ritardando

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	1800	OFF	OFF	0	6.25	0	0	C	10			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	13.7	0	0	C	9.5			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	22.3	0	0	C	9			
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	32.4	0	0	C	8.5			
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	45.3	0	0	C	8	6.5	10	C
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	60.2	0	0	C	7.5			
7	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	78.1	0	0	C	7			
8	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	100	0	0	C	6.5			

723 Accelerando

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->8	OFF	SIN	1600	OFF	OFF	0	21.9	0	0	C	10			
2	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	39.8	0	0	C	9.2			
3	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	54.7	0	0	C	8.4			
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	67.6	0	0	C	7.6			
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	77.7	0	0	C	6.8	6.5	10	C
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	86.3	0	0	C	6			
7	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	93.8	0	0	C	5.2			
8	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	100	0	0	C	4.4			

AC= ASSIGNABLE CONTROL

Column headers for all tables: **EFFECT BAND | SWITCH | CONNECT | PHASE | GROUP | SYNC | WAVE | DELAY TIME | LCF | HCF | FEEDBACK | TAP | SPEED | DEPTH | PAN | LEVEL** (followed by EFFECT LEVEL, DIRECT LEVEL, DIRECT PAN per patch)

731 Scratch Sound

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2	ON	IN	NOR	2->3	OFF	SIN	600	OFF	OFF	0	29.7	0	0	C	10
3	ON	IN	NOR	2->3			↑	↑	↑	↑	100	0	0	L10	0
4	ON	3	NOR	4->5	OFF	S.UP	800	OFF	OFF	0	100	0	10	R10	0
5	ON	4	NOR	4->5	OFF	SIN	↑	↑	↑	↑	100	8.2	9.9	R10	5
6	ON	5	NOR	6->8	OFF	SIN	1600	3.1	OFF	0	100	0	0	L10	10
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

732 Rhythm Delay 5 (AC: Tempo)

EFFECT LEVEL 10 · DIRECT LEVEL 0 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->8	OFF	SIN	1150	OFF	OFF	0	0	0	0	C	10
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	37.5	0	0	C	10
5	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	50	0	0	C	10
6	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	62.5	0	0	C	10
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	ON	IN	NOR	1->8	OFF	SIN	↑	↑	↑	↑	87.5	0	0	C	10

733 Dotted 8th Sequence Phrase w/Tap Tempo

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->2	OFF	SIN	486	OFF	OFF	0	75	0	0	C	10
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

811 Sound Effect 1

EFFECT LEVEL 4.4 · DIRECT LEVEL 0 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	SIN	100	OFF	OFF	4.6	100	5.2	9.6	L10	10
2	ON	1	NOR	2->2	OFF	SIN	150	OFF	OFF	3.8	100	3.2	4.7	R9.6	10
3	ON	2	NOR	3->3	OFF	SIN	184	OFF	OFF	3.8	100	4.5	3	L10	10
4	ON	3	NOR	4->4	OFF	SIN	200	OFF	OFF	4.1	100	2.3	5.3	L10	10
5	ON	4	NOR	5->5	OFF	SIN	246	OFF	OFF	3.8	100	3.4	3.6	L10	10
6	ON	5	NOR	6->6	OFF	SIN	300	3.1	OFF	4.7	100	0.8	5.1	L10	10
7	ON	6	NOR	7->7	OFF	SIN	370	4.5	OFF	3.4	100	4.9	1.8	L10	10
8	ON	7	NOR	8->8	OFF	SIN	400	5.2	OFF	5.7	100	2	2.2	R2.5	10

812 Sound Effect 2

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	S.DN	93.1	OFF	OFF	8.6	100	6	10	R10	10
2	ON	1	NOR	2->2	OFF	SIN	300	OFF	OFF	5.4	100	2.7	10	L10	10
3	ON	2	NOR	3->3	OFF	SIN	247	OFF	OFF	3.2	27.7	0	0	C	10
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

813 Sound Effect 3 (AC: Alters Sound)

EFFECT LEVEL 5.8 · DIRECT LEVEL 0 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	SIN	6	0.1	OFF	10	100	4.4	10	C	6
2	ON	1	NOR	2->2	OFF	TRI	9	0.2	OFF	10	100	5.4	10	C	5.9
3	ON	2	NOR	3->3	OFF	SIN	367	0.1	OFF	4.9	100	0	0	C	6
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

821 Techno Sound (AC: Alters Sound)

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	S.DN	8.35	OFF	1.4	10	100	10	8.7	C	4.3
2	ON	1	NOR	2->2	OFF	SIN	1.17	0.4	OFF	7.6	100	10	9.2	C	10
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

822 Steel Drum (AC: Stereo Effect)

EFFECT LEVEL 6.5 · DIRECT LEVEL 6.5 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	REV	1->1	OFF	TRI	3.07	OFF	OFF	9.7	100	0	10	L10	10
2	ON	IN	REV	2->2	OFF	TRI	1.46	OFF	OFF	9.7	100	0	10	R10	10
3	ON	IN	REV	3->3	OFF	TRI	1.8	OFF	OFF	9.7	100	0	10	L10	10
4	ON	IN	REV	4->4	OFF	TRI	1.64	OFF	OFF	9.7	100	0	10	R10	10
5	ON	IN	REV	5->5	OFF	TRI	3.18	OFF	OFF	9.7	100	0	10	L10	10
6	ON	IN	REV	6->6	OFF	TRI	4.75	OFF	OFF	9.6	100	0	10	R10	10
7	ON	IN	REV	7->7	OFF	SIN	3.28	OFF	OFF	9.7	100	0	0	L10	10
8	ON	IN	REV	8->8	OFF	SIN	4.12	OFF	OFF	9.7	100	0	0	R10	10

823 Tape Echo w/Abnormal Head (AC: Tape Speed)

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	SIN	600	OFF	10	2.7	100	0.6	10	C	8.6
2	ON	IN	NOR	2->2	OFF	SIN	600	OFF	10	10	100	0.7	10	C	1.1
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

831 Sound Effect 4

EFFECT LEVEL 10 · DIRECT LEVEL 10 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	S.DN	400	OFF	OFF	7	29.7	9.3	8.2	L0.2	5.2
2	ON	1	NOR	2->2	OFF	SIN	30	OFF	OFF	9.1	100	1.4	1.4	R10	6.6
3	ON	1	NOR	3->3	OFF	SIN	34.5	OFF	OFF	8.6	100	1.8	4.8	L10	6.6
4	ON	IN	NOR	4->4	OFF	SIN	207	OFF	OFF	5.3	100	0	0	C	10
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-

832 Doppler Effect (AC: Delay Time)

EFFECT LEVEL 10 · DIRECT LEVEL 0 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->8	OFF	S.DN	1970	2	6.1	3.2	100	2	8.9	L10	10
2	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	85.5	1	5	L7.0	9
3	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	70.3	0	5	L4.0	8
4	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	57	0	4	L0.9	7
5	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	43	0	3.1	R3.0	6
6	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	28.5	0	2	R7.1	5
7	ON	IN	NOR	1->8	1	SIN	↑	↑	↑	↑	14.5	0	1	R10	4
8	ON	IN	NOR	1->8	1	S.DN	↑	↑	↑	↑	0	0	0	R10	3

833 Sound Effect 5

EFFECT LEVEL 2.9 · DIRECT LEVEL 2.3 · DIRECT PAN C

Band	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL
1	ON	IN	NOR	1->1	OFF	SIN	15.2	OFF	OFF	0	100	2.1	7.9	L10	10
2	ON	1	NOR	2->2	OFF	SIN	80	OFF	OFF	0	100	8.1	1.7	C	10
3	ON	2	NOR	3->3	OFF	SIN	50	OFF	OFF	0	100	1.6	10	L10	10
4	ON	3	NOR	4->4	OFF	SIN	0.43	OFF	OFF	0	100	2.5	7.6	C	10
5	ON	4	NOR	5->5	OFF	SIN	2.72	OFF	OFF	4.1	25	5.8	10	C	10
6	ON	5	NOR	6->6	OFF	SIN	7.51	OFF	OFF	7.2	93.4	5.8	4.1	L10	10
7	ON	6	NOR	7->7	OFF	SIN	200	OFF	OFF	2.2	9.38	0	0	R10	8.4
8	ON	7	NOR	8->8	OFF	SIN	4	OFF	OFF	7.7	19.5	3.1	1.1	C	10

* AC= ASSIGNABLE CONTROL

9۱۱ Blank

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

9۱2 Tap Parameter Sample

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	361	OFF	OFF	0	100	0	0	C	10			
2	ON	IN	NOR	2->2	OFF	SIN	361	OFF	OFF	0	100	0	0	C	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

9۱3 Connect Sample

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	600	OFF	OFF	0	100	0	0	C	10			
2	ON	IN	NOR	2->2	OFF	SIN	80	OFF	OFF	0	100	0	0	C	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

92۱ 16-Beat

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->4	OFF	SIN	459	0.1	OFF	4.8	100	0	0	C	10			
2	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	25	0	0	C	6.5			
3	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	50	0	0	C	7.1			
4	ON	IN	NOR	1->4	OFF	SIN	↑	↑	↑	↑	75	0	0	C	6.5	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

922 Sync Parameter Sample

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	10	OFF	OFF	0	100	3	6.1	L10	10			
2	ON	IN	NOR	2->2	1	SIN	10	OFF	OFF	0	100	0	6.1	R10	10			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

923 Wave Parameter Sample

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	ON	IN	NOR	1->1	OFF	SIN	30	OFF	OFF	0	100	5.7	10	L10	10			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	5.7	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

93۱ Loop Sampling 1

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			

932 Loop Sampling 2

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	ON	IN	NOR	8->8	OFF	SIN	300	OFF	OFF	3.7	100	0	0	C	7.6			

933 Loop Sampling 3

EFFECT BAND	SWITCH	CONNECT	PHASE	GROUP	SYNC	WAVE	DELAY TIME	LCF	HCF	FEEDBACK	TAP	SPEED	DEPTH	PAN	LEVEL	EFFECT LEVEL	DIRECT LEVEL	DIRECT PAN
1	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
2	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
3	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
4	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	10	10	C
5	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
6	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
7	OFF	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
8	ON	1	NOR	8->8	OFF	SIN	300	OFF	OFF	3	100	0	0	C	8			