

Deep Research 2026 10 05 Operations Routing Capacity

Source type: DubboEwaste repository document

Repository path: docs/DEEP-RESEARCH-2026-10-05-OPERATIONS-ROUTING-CAPACITY.md

Source commit: c2103b6090c8

Pack generated: 6 October 2026

Regional ITAD Deep Research 2026 — Operations, Routing & Capacity

Research date: 5 October 2026

Scope: intake, routing, inventory velocity, barcodes, workstations, parts, chargers, vintage exceptions and two-day-per-week capacity.

1. ITAD is a flow business, not a storage business

The strongest operational theme across public Australian ITAD models is that value comes from a controlled sequence:

collect → identify → secure data → assess → route → reuse/resell or recycle → report

WorkVentures publicly describes collection, itemisation, data sanitisation, assessment, reuse/recycling determination and traceability. SustainIT describes secure collection, detailed assessment, data/identity cleansing, itemised buyback offer and then refurbish/resell/reuse/recycle. Renew IT combines buyback, sanitisation, resale and recycling.

Sources:

- <https://workventures.com.au/e-waste/>
- <https://www.sustainit.com.au/>
- <https://renew-it.com/services/>

For a small operator, the lesson is not to copy their warehouse size. It is to copy the clear disposition path.

Every accepted asset should have a next route within a short, defined period.

2. Recommended routing model

Front-door decisions

At intake ask, in this order:

1. Is it safe to accept?
2. Is ownership/source clear enough to take custody?
3. Is it data-bearing?

4. Can it physically fit within the current controlled capacity?
5. Is there a plausible reuse/resale or downstream route?
6. Is there an unusual collector/high-value reason not to follow the normal route?

If any answer creates uncertainty, use EXCEPTION-HOLD, not an improvised new process.

Stable routing buckets

QUICK-REFURB

Use when:

- boots or has an obvious simple path;
- no severe damage;
- likely resale/community value;
- modular repair only;
- parts readily available or already in stock.

Examples:

- SSD/RAM upgrade;
- OS deployment;
- charger/dock match;
- cleaning;
- battery replacement where economical;
- minor keyboard/fan work.

REFURB-CAPPED

Use when:

- likely value exceeds expected repair cost;
- diagnosis is reasonably bounded;
- required parts/work are known.

Every item gets:

- fault;
- expected sale/reuse value;
- estimated labour;
- parts budget;
- review date;
- abandon-to-parts/downstream threshold.

PARTS-DONOR

Use when:

- whole-device repair is not economical;
- valuable modular components are known;
- data-bearing media are separately controlled;

- harvested components have actual demand.

VINTAGE-REVIEW

Use for unusual older hardware before destructive teardown.

Examples:

- IBM-era ThinkPads;
- unusual beige desktops;
- period gaming systems;
- vintage Apple;
- rare enterprise/server/network gear;
- complete branded systems with original accessories/documentation.

This is a short research hold, not an excuse to save everything.

DOWNSTREAM

Use when:

- reuse is unsafe, impossible or economically irrational;
- no worthwhile parts path exists;
- the asset is obsolete for the intended market;
- repair would consume disproportionate labour;
- the item belongs in a certified/specialist stream.

EXCEPTION-HOLD

Use for:

- unknown ownership;
- data state problem;
- MDM/Autopilot/Activation Lock/FRP;
- battery hazard;
- contamination;
- unusual data sensitivity;
- no downstream path;
- possible recall;
- disputed grading/value;
- potentially collectible hardware.

3. Category routing taxonomy

Business laptop

Minimum checks

- identity/model/serial;
- battery condition;
- display/hinge/case;
- charger;
- BIOS/UEFI lock;
- storage present;
- MDM/Autopilot/work-school ownership state;
- basic POST/boot;
- keyboard/touchpad;
- Wi-Fi;
- ports.

High-value route

Quick refurb, especially business-grade models with replaceable storage/RAM/battery and current OS support.

Stop conditions

Swollen/wet/fire-affected battery, unclear ownership, firmware lock, data exception.

Parts candidates

RAM, SSD, display, keyboard, battery if healthy and reusable, charger, dock, fan, casing.

Desktop / mini PC

Usually one of the easiest Phase 0 categories:

- no embedded lithium in many models;
- modular RAM/storage;
- standard diagnostics;
- easy clean/reimage;
- useful for offices/community/gaming-light roles.

Check:

- BIOS lock;
- storage/data;
- PSU/power adapter;
- display outputs;
- network;
- fan/noise;
- case condition.

All-in-one

Treat as laptop-like repair complexity plus desktop bulk:

- display is integral;
- stands/power adapters matter;

- storage may be awkward;
- shipping risk higher.

Accept only where likely route is known.

Monitor

No data sanitisation in ordinary monitors, but:

- bulky;
- screen damage;
- power adapter;
- dead pixels/backlight;
- stand availability;
- transport/storage.

Do not accept unlimited low-value monitors. Prefer 24-inch+ or models with known demand, subject to local market.

Smartphone/tablet

Require:

- IMEI/serial;
- account/activation lock;
- FRP/MDM;
- battery state;
- screen/touch;
- cameras;
- charging;
- carrier/blacklist considerations where relevant;
- secure reset/data state.

These are high-value but higher lock/battery/fraud-risk devices. Phase in after computer workflow is stable.

Chromebook

Check:

- enterprise enrolment/deprovisioning;
- Auto Update Expiration/support;
- battery;
- storage/data;
- charger;
- screen/keyboard.

Enterprise lock can make otherwise working devices uneconomic for reuse.

Server/network hardware

Potentially valuable but model-specific:

- configuration/data;
- storage/controllers;
- passwords;
- licences;
- rails/PSUs/transceivers;
- noise/power;
- specialised buyers.

Only accept when a buyer/downstream route is likely.

Gaming PC

May justify deeper component testing:

- GPU;
- PSU;
- thermals;
- storage;
- RAM;
- motherboard;
- cosmetic condition.

High-value components can make parts routes attractive.

Gaming laptop

Potentially high resale, but diagnosis and repair can become labour-heavy:

- thermal stress;
- GPU/board failures;
- display/hinge damage;
- proprietary power supplies.

Keep a stricter repair-margin decision.

4. Two-day-per-week capacity model

A side operation fails when arrival rate exceeds closure/outflow rate.

Simple weekly backlog formula:

$\text{closing backlog} = \text{opening backlog} + \text{inbound} - \text{closed/outbound}$

Even a small positive difference compounds.

Scenario assumptions

These are modelling assumptions, not industry benchmarks:

- 2 operating days/week;
- 5 effective processing hours/day after collection/admin;
- 10 effective technical hours/week.

Average hands-on minutes/device | Theoretical technical throughput

30 min | 20/week

45 min | 13/week

60 min | 10/week

90 min | 6–7/week

150 min | 4/week

Real throughput is lower because of:

- listings;
- messages;
- packing;
- collections;
- parts ordering;
- photography;
- data reports;
- customer paperwork;
- downstream preparation.

Recommended pilot intake

Start 4–6 serialized data-bearing devices/week.

Raise only after four weeks where:

- no location/data confusion;
- no chronic WIP overflow;
- outbound keeps up;
- median processing time is known;
- sale-ready devices actually leave.

Backlog tripwire

If:

inbound > closed/outbound

for two consecutive operating weeks, reduce or stop intake until backlog falls.

That rule is simple enough to automate on the dashboard.

5. Physical WIP limits

Maintain small visual caps:

```
Zone | Initial cap
Intake / unassessed | 2
Unwiped / restricted | 4
Repair / WIP | 3
Cleared QA | 2
Sale-ready | 4
Total serialized held | 12
```

These are experimental shed-management caps and do not substitute for planning/fire/insurance limits.

A full zone should block new intake into that lane.

6. Inventory velocity metrics

Track by device and by source:

- intake date;
- route-decision date;
- sanitisation-complete date;
- repair-complete date;
- listing date;
- sale/reuse/downstream date;
- total hands-on minutes;
- parts spend;
- fees/freight;
- gross proceeds;
- downstream fee/rebate;
- return/rework.

Derived:

```
days_to_route
days_in_wip
days_to_close
gross_recovery_per_device
net_recovery_before_labour
net_recovery_per_operator_hour
repair_conversion_rate
return_rate
source_reuse_rate
```

Source quality score

A useful experimental source score:

- +2 quick refurb;
- +1 clean downstream/reusable parts;
- 0 ordinary recycle;
- -1 blocked by lock/ownership;

- -2 hazardous/unacceptable.

Combine with average value and labour, rather than using score alone.

7. Repair economics

Do not ask only: "Can this be fixed?"

Ask:

- what will it sell/redeploy for?
- how long will diagnosis take?
- what is parts cost?
- how long will parts take?
- what is return risk?
- is there a better parts/downstream route?

Experimental caps

Start with:

- 30-minute diagnosis cap;
- 60-90 minute repair labour cap for ordinary low/mid-value office devices;
- exceptions only with documented expected margin or community purpose.

Review after device 30.

The Australian Productivity Commission found repair barriers including access to parts, tools and information in consumer-electronics markets. This reinforces treating reparability and parts access as part of the economics, not assuming every fault is equally repairable.

Source: <https://www.pc.gov.au/inquiries-and-research/repair/report/>

8. Barcode / QR workflow

For Phase 0 use:

QR code + human-readable AssetFlow ID

The QR should resolve to:

`/assets/{uuid or stable token}`

The printed text should still show:

- AssetFlow code;
- manufacturer/model;
- optional data-state cue;
- optional source/job.

Why:

- phone cameras work;
- low-cost scanners can work;
- visible ID is usable when scanning fails;
- no RFID infrastructure;
- easy batch print.

GS1 guidance supports lifecycle-unique asset identifiers and human-readable barcode information.

Sources:

- <https://www.gs1.org/standards/id-keys/giai>
- <https://www.gs1au.org/what-we-do/barcodes>

Do not add RFID yet

RFID's no-line-of-sight/multi-tag reading is powerful at warehouse scale, but adds:

- tag cost;
- readers;
- placement/material issues;
- software integration;
- process design.

Trigger for RFID research:

- hundreds/thousands of simultaneously held assets;
- repeated bulk cycle counts;
- labour evidence showing scanning is a bottleneck.

9. Workstations and controlled handoffs

A workstation should mean a processing context, not necessarily a permanent physical bench.

Phase 0 profiles:

- RECEIVING;
- WIPE;
- DIAGNOSTICS;
- REPAIR;
- GRADING;
- PARTS.

One physical bench can switch profiles if:

- data/safety separation is maintained;
- AssetFlow records who did what;
- tools/evidence match the operation.

The practitioner's point that modest double-handling can be rational is consistent with mature operations where collection, data sanitisation, assessment and resale are separate stages.

Double handling becomes bad when:

- identity is lost;
- device waits without owner;
- same test is repeated;
- status is not updated;
- physical and digital locations diverge.

10. Parts harvesting matrix

Usually worth considering

RAM

High reuse density, easy storage/testing, broad demand.

Record DDR generation, capacity, speed, form factor, test status.

SSD

High reuse value if health and data state are known.

Never put an unidentified/unsanitised drive in general parts stock.

Business laptop chargers

Useful but require connector/wattage/condition tracking.

Docks

Good business-device resale/use where compatibility is known.

Displays

Worth harvesting from popular laptop families if intact and removal is economical.

Keyboards / palmrests

Worth it where model demand is known and condition is good.

Wi-Fi cards / fans

Small and easy to store, but low individual value. Keep only common/known parts.

Selective only

- CPUs;
- desktop PSUs;
- motherboards;
- laptop system boards;
- hinges/cases;

- speakers/webcams;
- optical drives.

Harvest only where demand or internal reuse exists.

Usually clutter unless specialised

- unidentified cables;
- broken plastics;
- obsolete low-capacity RAM;
- low-value proprietary parts without model labelling;
- piles of untested low-value HDDs.

11. Charger inventory system

The practitioner's "shedloads of chargers" warning is operationally important.

Track:

- manufacturer;
- connector family;
- voltage;
- amperage;
- wattage;
- polarity where relevant;
- USB-C PD wattage;
- OEM/third-party;
- condition;
- tested status;
- compatible families;
- bin/location.

Suggested physical buckets:

1. USB-C PD $\leq 45W$
2. USB-C PD 60–70W
3. USB-C PD 90–100W+
4. Lenovo slim-tip
5. Lenovo round
6. Dell barrel small/large
7. HP blue-tip/common barrel
8. Microsoft Surface
9. Apple MagSafe families
10. misc known-good labelled

11. quarantine/untested

Do not use universal/adapted chargers where voltage/polarity/identification requirements are uncertain.

12. Vintage preservation

Vintage value is an exception lane, not a default.

Quick VINTAGE-REVIEW triggers

Hold before dismantling if:

- IBM-branded ThinkPad;
- unusually old Apple;
- beige/pre-2000 PC;
- complete Windows 95/98/XP-era branded system;
- rare graphics/sound/expansion hardware;
- unusual workstation/server;
- complete machine with manuals/media/box;
- distinctive industrial/proprietary hardware.

15-minute rule

Spend a maximum of 15 minutes on initial sold-market/recent-community research.

Then choose:

- preserve/sell whole;
- parts;
- normal refurb;
- downstream.

Do not let nostalgia defeat capacity.

13. MDM/ownership locks as an economic control

WorkVentures notes that an active MDM lock can prevent otherwise useful donated devices from being refurbished and redistributed.

Source: <https://workventures.com.au/refurbishment/>

AssetFlow should therefore treat:

- Windows work/school/Autopilot;
- Apple MDM/Activation Lock;
- Android FRP/enterprise;
- Chromebook enterprise enrolment

as early triage, not a late surprise after labour has been spent.

Recommended status:

HOLD-OWNERSHIP-LOCK

Do not attempt bypass techniques that defeat legitimate ownership/security controls.

14. Reuse age is market-specific

There is no single age at which a laptop becomes “e-waste”.

PonyUp says its primary reuse focus is corporate equipment roughly 2-5 years old and notes other equipment can still be reused. The National Device Bank uses practical minimum specifications for devices intended for digital inclusion. Vintage collectors may value much older hardware.

Sources:

- <https://www.ponyupforgood.com/faq>
- <https://nationaldevicebank.org.au/>

Therefore route by:

- supported OS/security;
- battery/condition;
- performance;
- buyer/community requirement;
- repair cost;
- demand.

Not calendar age alone.

15. Recycling is not a failure

TechCollect’s model deliberately handles true end-of-life technology through certified material recovery, while reuse-focused operators send viable equipment into second life.

Sources:

- <https://techcollect.com.au/about-us/where-does-our-e-waste-go/>
- <https://techcollect.com.au/about-us/safety-environment/>

Use the hierarchy:

1. continued use;
2. refurbishment/redeployment;
3. parts reuse where sensible;
4. responsible material recovery.

Do not force unreliable equipment into reuse merely to improve a reuse percentage.

16. Downstream batching

Downstream partners may require:

- minimum weights;
- sorted categories;
- pallets/cages;
- scheduled collection;
- commodity grades.

AssetFlow should record:

- downstream vendor;
- category;
- batch/pallet;
- count/weight;
- dispatch date;
- receipt/weight ticket;
- expected rate;
- deductions;
- final settlement;
- certificate/document.

This turns scrap/downstream pricing into an auditable business process rather than memory.

17. Automation maturity model

Level 0 — spreadsheet

Not sufficient once custody/data risk becomes real.

Level 1 — AssetFlow identity

Asset/job/lot, QR, source, location, data state.

Level 2 — repeatable processing

Diagnostics, sanitisation, repair, grade, evidence, route.

Level 3 — workstation/batch

Batch label print, scanner-first moves, workload queues.

Level 4 — external tooling

Sanitisation/diagnostic report imports and APIs.

Level 5 — commercial automation

FMV, customer contracts, settlements, SLA reporting.

Level 6 — warehouse optimisation

RFID, advanced WMS, automated stations, customer portals, high-volume analytics.

Do not skip to Level 6 because mature ERP screenshots look impressive.

18. AssetFlow additions from operations research

High-value additions:

- backlog/inbound-vs-outflow dashboard;
- WIP-cap warnings;
- route decision timestamp;
- hands-on minutes;
- repair labour/parts cap;
- source quality analytics;
- days-held ageing;
- ownership-lock status;
- charger/accessory inventory;
- downstream price book;
- parts demand/use tracking;
- vintage-review flag.

Lower priority:

- RFID;
- complex automated FMV;
- multi-warehouse optimisation;
- elaborate integrations before stable volume.

Sources

- WorkVentures e-waste process: <https://workventures.com.au/e-waste/>
- WorkVentures refurbishment: <https://workventures.com.au/refurbishment/>
- SustainIT: <https://www.sustainit.com.au/>
- Renew IT services: <https://renew-it.com/services/>
- PonyUp FAQ: <https://www.ponyupforgood.com/faq>
- PonyUp reusable device guide: <https://www.ponyupforgood.com/donate-devices-tlc>
- National Device Bank: <https://nationaldevicebank.org.au/>
- Productivity Commission Right to Repair: <https://www.pc.gov.au/inquiries-and-research/repair/report/>
- TechCollect downstream: <https://techcollect.com.au/about-us/where-does-our-e-waste-go/>

- TechCollect recycling/reuse distinction: <https://techcollect.com.au/about-us/safety-environment/>
- GS1 global asset identifier: <https://www.gs1.org/standards/id-keys/giai>