= Diving cylinder =

A diving cylinder , scuba tank or diving tank is a gas cylinder used to store and transport the high pressure breathing gas required by a scuba set . It may also be used for surface @-@ supplied diving or as decompression gas or an emergency gas supply for surface supplied diving or scuba . Cylinders provide gas to the diver through the demand valve of a diving regulator or the breathing loop of a diving rebreather .

Diving cylinders are usually manufactured from aluminium or steel alloys , and are normally fitted with one of two common types of cylinder valve for filling and connection to the regulator . Other accessories such as manifolds , cylinder bands , protective nets and boots and carrying handles may be provided . Various configurations of harness may be used to carry the cylinder or cylinders while diving , depending on the application . Cylinders used for scuba typically have an internal volume (known as water capacity) of between 3 and 18 litres (0 @ .@ 11 and 0 @ .@ 64 cu ft) and a maximum working pressure rating from 184 to 300 bars (2 @ ,@ 670 to 4 @ ,@ 350 psi) . Cylinders are also available in smaller sizes , such as 0 @ .@ 5 , 1 @ .@ 5 and 2 litres , however these are often not used for breathing , instead being used for purposes such as inflation of surface marker buoys , drysuits and buoyancy compensators . Scuba divers may dive with a single cylinder , a pair of similar cylinders , or a main cylinder and a smaller " pony " cylinder , usually carried on the diver 's back . For specialised diving , more that two cylinders may be needed , or the cylinders may be mounted at the waist (" side @ -@ mount ") .

When pressurised , a cylinder carries an equivalent volume of free gas greater than its water capacity , because the gas is compressed to several hundred times atmospheric pressure . The selection of an appropriate set of diving cylinders for a diving operation is based on the amount of gas required to safely complete the dive . Diving cylinders are most commonly filled with air , but because the main components of air can cause problems when breathed underwater at higher pressure , divers may choose to breathe from cylinders filled with mixtures of gases other than air . A cylinder containing such mixtures needs to be labelled to indicate its contents for safety reasons . Many jurisdictions have regulations that govern the filling , recording of contents , and labelling for diving cylinders . Periodic inspection and testing of cylinders is often obligatory to ensure the safety of operators of filling stations . Pressurised diving cylinders are considered dangerous goods for commercial transportation , and regional and international rules for colouring and labelling may also apply .

= = Terminology = =

The term " diving cylinder " tends to be used by gas equipment engineers , manufacturers , support professionals , and divers speaking British English . " Scuba tank " or " diving tank " is more often used colloquially by non @-@ professionals and native speakers of American English . The term " oxygen tank " is commonly used by non @-@ divers when referring to diving cylinders ; however , this is a misnomer . These cylinders typically contain (compressed atmospheric) breathing air , or an oxygen @-@ enriched air mix . They rarely contain pure oxygen , except when used for rebreather diving , shallow decompression stops in technical diving or for in @-@ water oxygen recompression therapy . Breathing pure oxygen at depths greater than 6 metres (20 ft) , equivalent to a partial pressure of oxygen of 1 @.@ 6 bars (1 @.@ 6 atm) , can result in oxygen toxicity , a highly dangerous condition that can trigger seizures and thus lead to drowning .

Diving cylinders have also been referred to as bottles or flasks, usually with one of the epithets scuba, diving, or bailout. Cylinders may also be called aqualungs, a genericized trademark derived from the Aqua @-@ lung equipment made by the Aqua Lung / La Spirotechnique company, although that is more properly applied to an open circuit scuba set or open circuit diving regulator. Diving cylinders may also be specified by their application, as in bailout cylinders, stage cylinders, deco cylinders, sidemount cylinders, pony cylinders, suit inflation cylinders, etc.

The functional diving cylinder consists of the pressure vessel and a cylinder valve :

```
= = = The pressure vessel = = =
```

The pressure vessel is a seamless cylinder normally made of cold @-@ extruded aluminium or forged steel . Filament wound composite cylinders are used in fire fighting breathing apparatus and oxygen first aid equipment because of their low weight , but are rarely used for diving , due to their high positive buoyancy . They are occasionally used when portability for accessing the dive site is critical , such as in cave diving . Composite cylinders certified to ISO @-@ 11119 @-@ 2 or ISO @-@ 11119 @-@ 3 may only be used for underwater applications if they are manufactured in accordance with the requirements for underwater use and are marked ? UW ? .

```
= = = = Aluminium cylinders = = = =
```

An especially common cylinder provided at tropical dive resorts is the " aluminium @-@ S80 " which is an aluminium cylinder design with an internal volume of 0 @.@ 39 cubic feet (11 @.@ 0 L) rated to hold a nominal volume of 80 cubic feet (2 @,@ 300 L) of atmospheric pressure gas at its rated working pressure of 3 @,@ 000 pounds per square inch (207 bar) . Aluminium cylinders are also often used where divers carry many cylinders , such as in technical diving in water which is warm enough that the dive suit does not provide much buoyancy , because the greater buoyancy of aluminium cylinders reduces the amount of extra buoyancy the diver would need to achieve neutral buoyancy . They are also sometimes preferred when carried as " sidemount " or " sling " cylinders as the near neutral buoyancy allows them to hang comfortably along the sides of the diver 's body , without disturbing trim , and they can be handed off to another diver or stage dropped with a minimal effect on buoyancy . Most aluminium cylinders are flat bottomed , allowing then to stand upright on a level surface , but some were manufactured with domed bottoms .

The aluminium alloys used for diving cylinders are 6061 and 6351. 6351 alloy is subject to sustained load cracking and cylinders manufactured of this alloy should be periodically eddy current tested according to national legislation and manufacturer 's recommendations. 6351 alloy has been superseded for new manufacture, but many old cylinders are still in service.

```
= = = = Manufacture = = = =
```

Aluminium cylinders are usually manufactured by cold extrusion of aluminium billets in a process which first presses the walls and base , then trims the top edge of the cylinder walls , followed by press forming the shoulder and neck . The final structural process is machining the neck outer surface , boring and cutting the neck threads and O @-@ ring groove . The cylinder is then heat @-@ treated , tested and stamped with the required permanent markings . Aluminium diving cylinders commonly have flat bases , which allows them to stand upright on horizontal surfaces , and which are relatively thick to allow for rough treatment and considerable wear . This makes them heavier than they need to be for strength , but the extra weight at the base also helps keep the centre of gravity low which gives better balance in the water and reduces excess buoyancy .

```
= = = = Steel cylinders = = = =
```

In cold water diving , where a diver wearing a highly buoyant thermally insulating dive suit has a large excess of buoyancy , steel cylinders are often used because they are denser than aluminium cylinders . They also often have a lower mass than aluminium cylinders with the same gas capacity , due to considerably higher material strength , so the use of steel cylinders can result in both a lighter cylinder and less ballast required for the same gas capacity , a two way saving on overall dry weight carried by the diver .

Steel cylinders are more susceptible than aluminium to external corrosion, particularly in seawater,

and may be galvanized or coated with corrosion barrier paints to resist corrosion damage. It is not difficult to monitor external corrosion, and repair the paint when damaged, and steel cylinders which are well maintained have a long service life, often longer than aluminium cylinders, as they are not susceptible to fatigue damage when filled within their safe working pressure limits.

Steel cylinders are manufactured with domed (convex) and dished (concave) bottoms . The dished profile allows them to stand upright on a horizontal surface , and is the standard shape for industrial cylinders . The cylinders used for emergency gas supply on diving bells are often this shape , and commonly have a water capacity of about 50 litres (" J ") . Domed bottoms give a larger volume for the same cylinder mass , and are the standard for scuba cylinders up to 18 litres water capacity , though some concave bottomed cylinders have been marketed for scuba .

```
= = = = = Manufacture = = = = =
```

Steel alloys used for dive cylinder manufacture are authorised by the manufacturing standard . For example , the US standard DOT 3AA requires the use of open @-@ hearth , basic oxygen , or electric steel of uniform quality . Approved alloys include 4130X , NE @-@ 8630 , 9115 , 9125 , Carbon @-@ boron and Intermediate manganese , with specified constituents , including manganese and carbon , and molybdenum , chromium , boron , nickel or zirconium .

Steel cylinders may be manufactured from steel plate discs , which are cold drawn to a cylindrical cup form , in two or three stages , and generally have a domed base if intended for the scuba market , so they cannot stand up by themselves . After forming the base and side walls , the top of the cylinder is trimmed to length , heated and hot spun to form the shoulder and close the neck . This process thickens the material of the shoulder . The cylinder is heat @-@ treated by quenching and tempering to provide the best strength and toughness . The cylinders are machined to provide the neck thread and o @-@ ring seat (if applicable) , then chemically cleaned or shot @-@ blasted inside and out to remove mill @-@ scale . After inspection and hydrostatic testing they are stamped with the required permanent markings , followed by external coating with a corrosion barrier paint or hot dip galvanising .

```
= = = = Cylinder neck = = =
```

The neck of the cylinder is internally threaded to fit a cylinder valve . There are several standards for neck threads , these include :

Taper thread (17E) , with a 12 % taper right hand thread , standard Whitworth 55 ° form with a pitch of 14 threads per inch (5 @.@ 5 threads per cm) and pitch diameter at the top thread of the cylinder of 18 @.@ 036 millimetres (0 @.@ 71 in) . These connections are sealed using thread tape and torqued to between 120 and 150 newton metres (89 and 111 lbf \cdot ft) on steel cylinders , and between 75 and 140 N \cdot m (55 and 103 lbf \cdot ft) on aluminium cylinders .

Parallel threads are made to several standards:

M25x2 ISO parallel thread, which is sealed by an O @-@ ring and torqued to 100 to 130 N \cdot m (74 to 96 lbf \cdot ft) on steel, and 95 to 130 N \cdot m (70 to 96 lbf \cdot ft) on aluminium cylinders;

M18x1.5 parallel thread, which is sealed by an O @-@ ring, and torqued to 100 to 130 N \cdot m (74 to 96 lbf \cdot ft) on steel cylinders, and 85 to 100 N \cdot m (63 to 74 lbf \cdot ft) on aluminium cylinders;

- 3 / 4 " x14 BSP parallel thread, which has a 55 ° Whitworth thread form, a pitch diameter of 25 @.@ 279 millimetres (0 @.@ 9952 in) and a pitch of 14 threads per inch (1 @.@ 814 mm);
- 3 / 4 " x14 NGS (NPSM) parallel thread , sealed by an O @-@ ring , torqued to 40 to 50 N \cdot m (30 to 37 lbf \cdot ft) on aluminium cylinders , which has a 60 ° thread form , a pitch diameter of 0 @.@ 9820 to 0 @.@ 9873 in (24 @.@ 94 to 25 @.@ 08 mm) , and a pitch of 14 threads per inch (5 @.@ 5 threads per cm) ;
- 3 / 4 " x16 UNF , sealed by an O @-@ ring , torqued to 40 to 50 N \cdot m (30 to 37 lbf \cdot ft) on aluminium cylinders .

The 3/4 " NGS and 3/4 " BSP are very similar , having the same pitch and a pitch diameter that only differs by about 0 @.@ 2 mm (0 @.@ 008 in), but they are not compatible , as the thread

forms are different.

All parallel thread valves are sealed using an O @-@ ring at top of the neck thread which seals in a chamfer or step in the cylinder neck and against the flange of the valve.

The shoulder of the cylinder carries stamp markings providing required information about the cylinder.

```
= = = The cylinder valve = = =
```

The purpose of the cylinder valve or pillar valve is to control gas flow to and from the pressure vessel and to provide a connection with the regulator or filling hose. Cylinder valves are usually machined from brass and finished by a protective and decorative layer of chrome @-@ plating. A metal or plastic dip tube or valve snorkel screwed into the bottom of the valve extends into the cylinder to reduce the risk of liquid or particulate contaminants in the cylinder getting into the gas passages when the cylinder is inverted, and blocking or jamming the regulator. Some of these dip tubes have a plain opening, but some have an integral filter.

Cylinder valves are classified by four basic aspects: The cylinder thread specification, the connection to the regulator, pressure rating, and other distinguishing features.

```
= = = = Cylinder thread variations = = = =
```

Cylinder threads may be in two basic configurations: Taper thread and parallel thread. These thread specifications are detailed in a previous section. The valve thread specification must exactly match the neck thread specification of the cylinder. Improperly matched neck threads can fail under pressure and can have fatal consequences if someone is hit by the flying valve or cylinder.

```
= = = = Connection to the regulator = = =
```

A rubber o @-@ ring forms a seal between the metal of the pillar valve and the metal of the diving regulator . Fluoroelastomer (e.g. viton) O @-@ rings may be used with cylinders storing oxygen @-@ rich gas mixtures to reduce the risk of fire . There are two basic types of cylinder valve to regulator connection in general use for Scuba cylinders containing air :

A @-@ clamp or yoke connectors - the connection on the regulator surrounds the valve pillar and presses the output O @-@ ring of the pillar valve against the input seat of the regulator . The connection is officially described as connection CGA 850 yoke . The yoke is screwed down snug by hand (overtightening can make the yoke impossible to remove later without tools) and the seal is created by clamping the O @-@ ring between the surfaces of the regulator and valve . When the valve is opened , cylinder pressure expands the O @-@ ring against the outer surface of the O @-@ ring groove in the valve . Insufficient clamping force may allow the pressure to extrude the O @-@ ring between the valve and regulator faces , resulting in a leak . This type of connection is simple , cheap and very widely used worldwide . It has a maximum pressure rating of 232 bar and the weakest part of the seal , the O @-@ ring , is not well protected from overpressurisation .

DIN screw thread connectors - the regulator screws into the cylinder valve trapping the O @-@ ring securely between the sealing face of the valve and the O @-@ ring groove in the regulator . These are more reliable than A @-@ clamps because the O @-@ ring is well protected , but many countries do not use DIN fittings widely on compressors , or cylinders which have DIN fittings , so a diver traveling abroad with a DIN system may need to take an adaptor , either for connecting the DIN regulator to a rented cylinder , or for connecting an A @-@ clamp filler hose to a DIN cylinder valve .

There are also cylinder valves for scuba cylinders containing gases other than air:

The new European Norm EN 144 @-@ 3:2003 introduced a new type of valve, similar to existing 232 bar or 300 bar DIN valves, however, with a metric M26 \times 2 fitting on both the cylinder and the regulator. These are intended to be used for breathing gas with oxygen content above that normally found in natural air in the Earth 's atmosphere (i.e. 22 ? 100 %). From August 2008, these were

required in the European Union for all diving equipment used with nitrox or pure oxygen . The idea behind this new standard is to prevent a rich mixture being filled to a cylinder that is not oxygen clean . However even with use of the new system there still remains nothing except human procedural care to ensure that a cylinder with a new valve remains oxygen @-@ clean - which is exactly how the previous system worked .

An M 24x2 male thread cylinder valve was supplied with some Dräger semi @-@ closed circuit recreational rebreathers (Dräger Ray) for use with nitrox mixtures . The regulator supplied with the rebreather had a compatible connection .

```
= = = = Pressure rating = = =
```

Yoke valves are rated between 200 and 240 bar , and there does not appear to be any mechanical design detail preventing connection between any yoke fittings , though some older yoke clamps will not fit over the popular 232 / 240 bar combination DIN / yoke cylinder valve as the yoke is too narrow .

DIN valves are produced in 200 bar and 300 bar pressure ratings. The number of threads and the detail configuration of the connections is designed to prevent incompatible combinations of filler attachment or regulator attachment with the cylinder valve.

232 bar DIN (5 @-@ thread , G5 / 8) Outlet / Connector # 13 to DIN 477 part 1 - (technically they are specified for cylinders with 300 bar test pressure)

 $300\ bar\ DIN\ (\ 7\ @-\ @$ thread , G5 / 8) Outlet / Connector # 56 to DIN 477 part 5 - these are similar to 5 @-@ thread DIN fitting but are rated to 300 bar working pressures . (technically they are specified for cylinders with 450 bar test pressure) . The 300 bar pressures are common in European diving and in US cave diving .

Adaptors are available to allow connection of DIN regulators to yoke cylinder valves (A @-@ clamp or yoke adaptor) , and to connect yoke regulators to DIN cylinder valves . (plug adaptors and block adaptors) Plug adaptors are rated for 232 / 240 bar , and can only be used with valves which are designed to accept them . Block adaptors are generally rated for 200 bar , and can be used with almost any 200 bar DIN valve .

```
= = = Other distinguishing features = = = =
```

```
= = = = = Plain valves = = = = =
```

The most commonly used cylinder valve type is the single outlet plain valve , sometimes known as a " K " valve , which allows connection of a single regulator , and has no reserve function . It simply opens to allow gas flow , or closes to shut it off . Several configurations are used , with options of DIN or A @-@ clamp connection , and vertical or transverse spindle arrangements . The valve is operated by turning a knob , usually rubber or plastic , which affords a comfortable grip . Several turns are required to fully open the valves . Some DIN valves are convertible to A @-@ clamp by use of an insert which is screwed into the opening .

Y and H cylinder valves have two outlets , each with its own valve , allowing two regulators to be connected to the cylinder . If one regulator " freeflows " , which is a common failure mode , or ices up , which can happen in water below about 5 $^{\circ}$ C , its valve can be closed and the cylinder breathed from the regulator connected to the other valve . The difference between an H @-@ valve and a Y @-@ valve is that the Y @-@ valve body splits into two posts roughly 90 $^{\circ}$ to each other and 45 $^{\circ}$ from the vertical axis , looking like a Y , while an H @-@ valve is usually assembled from a valve designed as part of a manifold system with an additional valve post connected to the manifold socket , with the valve posts parallel and vertical , which looks a bit like an H. Y @-@ valves are also known as " slingshot valves " due to their appearance .

Reserve lever or " J @-@ valve " . Until the 1970s , when submersible pressure gauges on regulators came into common use, diving cylinders often used a mechanical reserve mechanism to indicate to the diver that the cylinder was nearly empty. The gas supply was automatically cut @-@ off by a spring loaded valve when the gas pressure reached the reserve pressure. To release the reserve, the diver pulled down on a rod that ran along the side of the cylinder and which activated a lever to open a bypass valve. The diver would then finish the dive before the reserve (typically 300 pounds per square inch (21 bar)) was consumed. On occasion, divers would inadvertently trigger the mechanism while donning gear or performing a movement underwater and, not realizing that the reserve had already been accessed, could find themselves out of air at depth with no warning whatsoever. The J @-@ valve got its name from being item " J " in one of the first scuba equipment manufacturer catalogs. The standard non @-@ reserve yoke valve at the time was item " K ", and is often still referred to as a K @-@ valve . J @-@ valves are still occasionally used by professional divers in zero visibility, where the submersible pressure gauge (SPG) can not be read. While the recreational diving industry has largely discontinued support and sales of the J @-@ valve , the US Department of Defense, the US Navy, NOAA (the National Oceanographic and Atmospheric Administration) and OSHA (the national Occupational Health and Safety Administration) all still allow or recommend the use of J @-@ valves as an alternative to a bailout cylinder or as an alternative to a submersible pressure gauge. They are generally not available through recreational dive shops, but are still available from some manufacturers. They can be significantly more expensive than K @-@ valves from the same manufacturer.

Less common in the 1950s thru 1970s was an R @-@ valve which was equipped with a restriction that caused breathing to become difficult as the cylinder neared exhaustion , but that would allow less restricted breathing if the diver began to ascend and the ambient water pressure lessened , providing a larger pressure differential over the orifice . It was never particularly popular because , were it necessary for the diver to descend (as is often necessary in cave and wreck diving , breathing would become progressively more difficult as the diver went deeper , eventually becoming impossible until the diver could ascent to a low enough ambient pressure .

```
= = = = Handed valves = = = =
```

Some cylinder valve models have axial spindles - in line with the cylinder axis , and are not handed . Standard side @-@ spindle valves have the handwheel on the diver 's right side when back @-@ mounted . Side @-@ spindle valves used with manifolds must be a handed pair - one with the handwheel to the right and the other with the handwheel to the left , but in all cases the valve is opened by turning the handwheel anticlockwise , and closed by turning it clockwise . This is the convention with almost all valves for all purposes . Left hand side @-@ spindle valves are used by sidemount divers .

```
= = = = Bursting disk = = = =
```

Some national standards require that the cylinder valve includes a bursting disk , a pressure relief device that will release the gas before the cylinder fails in the event of overpressurization . If a bursting disk ruptures during a dive the entire contents of the cylinder will be lost in a very short time . The risk of this happening to a correctly rated disc , in good condition , on a correctly filled cylinder is very low .

```
= = = Accessories = = =
```

Additional components for convenience, protection or other functions, not directly required for the function as a pressure vessel.

```
= = = = Manifolds = = =
```

A cylinder manifold is a tube which connects two cylinders together so that the contents of both can be supplied to one or more regulators . There are three commonly used configurations of manifold :

The oldest type is a tube with a connector on each end which is attached to the cylinder valve outlet , and an outlet connection in the middle , to which the regulator is attached . A variation on this pattern includes a reserve valve at the outlet connector . The cylinders are isolated from the manifold when closed , and the manifold can be attached or disconnected while the cylinders are pressurised .

More recently, manifolds have become available which connect the cylinders on the cylinder side of the valve, leaving the outlet connection of the cylinder valve available for connection of a regulator. This means that the connection cannot be made or broken while the cylinders are pressurised, as there is no valve to isolate the manifold from the interior of the cylinder. This apparent inconvenience allows a regulator to be connected to each cylinder, and isolated from the internal pressure independently, which allows a malfunctioning regulator on one cylinder to be isolated while still allowing the regulator on the other cylinder access to all the gas in both cylinders.

These manifolds may be plain or may include an isolation valve in the manifold, which allows the contents of the cylinders to be isolated from each other. This allows the contents of one cylinder to be isolated and secured for the diver if a leak at the cylinder neck thread, manifold connection, or burst disk on the other cylinder causes its contents to be lost.

A relatively uncommon manifold system is a connection which screws directly into the neck threads of both cylinders , and has a single valve to release gas to a connector for a regulator . These manifolds can include a reserve valve , either in the main valve or at one cylinder . This system is mainly of historical interest .

```
= = = = Valve cage = = =
```

Also known as a manifold cage or regulator cage, this is a structure which can be clamped to the neck or shoulder of the cylinder or manifolded cylinders to protect the valves and regulator first stages from impact and abrasion damage while in use and from rolling the valve closed by friction of the handwheel against an overhead. A valve cage is often made of stainless steel, and some designs can snag on obstructions.

```
= = = = Cylinder bands = = =
```

Cylinder bands are straps, usually of stainless steel, which are used to clamp two cylinders together as a twin set. The cylinders may be manifolded or independent. It is usual to use a cylinder band near the top of the cylinder, just below the shoulders, and one lower down. The conventional distance between centrelines for bolting to a backplate is 11 inches (280 mm).

```
= = = = Cylinder boot = = =
```

A cylinder boot is a hard rubber or plastic cover which fits over the base of a diving cylinder to protect the paint from abrasion and impact , to protect the surface the cylinder stands on from impact with the cylinder , and in the case of round bottomed cylinders , to allow the cylinder to stand upright on its base . Some boots have flats moulded into the plastic to reduce the tendency of the cylinder to roll on a flat surface . It is possible in some cases for water to be trapped between the boot and the cylinder , and if this is seawater and the paint under the boot is in poor condition , the surface of the cylinder may corrode in those areas . This can usually be avoided by rinsing in fresh water after use and storing in a dry place . The added hydrodynamic drag caused by a cylinder boot is trivial in comparison with the overall drag of the diver , but some boot styles may present a slightly increased risk of snagging on the environment .

```
= = = = Cylinder net = = =
```

A cylinder net is a tubular net which is stretched over a cylinder and tied on at top and bottom . The function is to protect the paintwork from scratching , and on booted cylinders it also helps drain the surface between the boot and cylinder , which reduces corrosion problems under the boot . Mesh size is usually about 6 millimetres (0 @.@ 24 in) . Some divers will not use boots or nets as they can snag more easily than a bare cylinder and constitute an entrapment hazard in some environments such as caves and the interior of wrecks . Occasionally sleeves made from other materials may be used to protect the cylinder .

```
= = = = Cylinder handle = = =
```

A cylinder handle may be fitted, usually clamped to the neck, to conveniently carry the cylinder. This can also increase the risk of snagging in an enclosed environment.

```
= = = Dust caps and plugs = = =
```

These are used to cover the cylinder valve orifice when the cylinder is not in use to prevent dust , water or other materials from contaminating the orifice . They can also help prevent the O @-@ ring of a yoke type valve from falling out . The plug may be vented so that the leakage of gas from the cylinder does not pressurise the plug , making it difficult to remove .

```
= = Cylinder pressure rating = =
```

The thickness of the cylinder walls is directly related to the working pressure, and this affects the buoyancy characteristics of the cylinder. A low @-@ pressure cylinder will be more buoyant than a high @-@ pressure cylinder with similar size and proportions of length to diameter and in the same alloy.

```
= = = Working pressure = = =
```

Scuba cylinders are technically all high @-@ pressure gas containers, but within the industry in the US there are three nominal working pressure ratings (WP) in common use;

low pressure (2400 to 2640 psi ? 165 to 182 bar),

standard (3000 psi ? 207 bar), and

high pressure (3300 to 3500 psi? 227 to 241 bar).

US made aluminum cylinders usually have a standard working pressure of 3 @,@ 000 pounds per square inch (210 bar) , and the compact aluminum range have a working pressure of 3 @,@ 300 pounds per square inch (230 bar) . Some steel cylinders manufactured to US standards are permitted to exceed the nominal working pressure by 10 % and this is indicated by a ' + ' symbol . This extra pressure allowance is dependent on the cylinder passing the appropriate higher standard periodical hydrostatic test .

Those parts of the world using the metric system usually refer to the cylinder pressure directly in bar but would generally use " high pressure " to refer to a 300 bars (4 @,@ 400 psi) working pressure cylinder , which can not be used with a yoke connector on the regulator . 232 bar is a very popular working pressure for scuba cylinders in both steel and aluminium .

```
= = = Test pressure = = =
```

Hydrostatic test pressure (TP) is specified by the manufacturing standard. This is usually 1 @.@ 5 × working pressure, or in the USA, 1 @.@ 67 × working pressure.

```
= = = Developed pressure = = =
```

Cylinder working pressure is specified at a reference temperature , usually 15 $^{\circ}$ C or 20 $^{\circ}$ C. and cylinders also have a specified maximum safe working temperature , often 65 $^{\circ}$ C. The actual pressure in the cylinder will vary with temperature , as described by the gas laws , but this is acceptable in terms of the standards provided that the developed pressure when corrected to the reference temperature does not exceed the specified working pressure stamped on the cylinder . This allows cylinders to be safely and legally filled to a pressure that is higher than the specified working pressure when the filling temperature is greater than the reference temperature , but not more than 65 $^{\circ}$ C , provided that the filling pressure does not exceed the developed pressure for that temperature , and cylinders filled according to this provision will be at the correct working pressure when cooled to the reference temperature .

= = = Pressure monitoring = = =

The internal pressure of a diving cylinder is measured at several stages during use. It is checked before filling, monitored during filling and checked when filling is completed. This can all be done with the pressure gauge on the filling equipment.

Pressure is also generally monitored by the diver . Firstly as a check of contents before use , then during use to ensure that there is enough left at all times to allow a safe completion of the dive , and often after a dive for purposes of record keeping and personal consumption rate calculation .

The pressure is also monitored during hydrostatic testing to ensure that the test is done to the correct pressure .

Most diving cylinders do not have a dedicated pressure gauge, but this is a standard feature on most diving regulators, and a requirement on all filling facilities.

There are two widespread standards for pressure measurement of diving gas . In the USA and perhaps a few other places the pressure is measured in pounds per square inch (psi) , and the rest of the world uses bar . Sometimes gauges may be calibrated in other metric units , such as kilopascal (kPa) or megapascal (MPa) , or in atmospheres (atm , or ATA) , particularly gauges not actually used underwater .

= = Cylinder capacity = =

There are two commonly used conventions for describing the capacity of a diving cylinder. One is based on the internal volume of the cylinder. The other is based on nominal volume of gas stored.

```
= = = Internal volume = = =
```

The internal volume is commonly quoted in most countries using the metric system . This information is required by ISO 13769 to be stamped on the cylinder shoulder . It can be measured easily by filling the cylinder with fresh water . This has resulted in the term ' water capacity ', abbreviated as WC which is often marked on the cylinder shoulder . It 's almost always expressed as a volume in litres , but sometimes as mass of the water in kg . Fresh water has a density close to one kilogram per litre so the numerical values will be similar .

```
= = = = Standard sizes by internal volume = = = =
```

These are representative examples , for a larger range , the on @-@ line catalogues of the manufacturers such as Faber , Pressed Steel , Luxfer , and Catalina may be consulted . The applications are typical , but not exclusive .

22 litres: Available in steel, 200 and 232bar, 20 litres: Available in steel, 200 and 232bar,

18 litres: Available in steel, 200 and 232 bar, used as single or twins for back gas.

16 litres: Available in steel, 200 and 232bar, used as single or twins for back gas.

- 15 litres: Available in steel, 200 and 232 bar, used as single or twins for back gas
- 12 @.@ 2 litres: Available in steel 232, 300 bar and aluminium 232 bar, used as single or twins for back gas
- 12 litres: Available in steel 200, 232, 300 bar, and aluminium 232 bar, used as single or twins for back gas
- 11 litres: Available in aluminium, 200, 232 bar used as single, twins for back gas or sidemount
- 10 @.@ 2 litres: Available in aluminium, 232 bar, used as single or twins for back gas
- 10 litres: Available in steel, 200, 232 and 300 bar, used as single or twins for back gas, and for bailout
- 9 @.@ 4 litres: Available in aluminium, 232 bar, used for back gas or as slings
- 8 litres: Available in steel, 200 bar, used for Semi @-@ closed rebreathers
- 7 litres: Available in steel, 200, 232 and 300 bar, and aluminium 232 bar, back gas as singles and twins, and as bailout cylinders. A popular size for SCBA
- 6 litres: Available in steel, 200, 232, 300 bar, used for back gas as singles and twins, and as bailout cylinders. Also a popular size for SCBA
- 5 @.@ 5 litres: Available in steel, 200 and 232 bar,
- 5 litres: Available in steel, 200 bar, used for rebreathers
- 4 litres: Available in steel, 200 bar, used for rebreathers and pony cylinders
- 3 litres: Available in steel, 200 bar, used for rebreathers and pony cylinders
- 2 litres: Available in steel, 200 bar, used for rebreathers, pony cylinders, and suit inflation
- 1 @.@ 5 litres: Available in steel, 200 and 232 bar, used for suit inflation
- 0 @.@ 5 litres: Available in steel and aluminium, 200 bar, used for buoyancy compensator and surface marker buoy inflation

= = = Nominal volume of gas stored = = =

The nominal volume of gas stored is commonly quoted as the cylinder capacity in the USA . It is a measure of the volume of gas that can be released from the full cylinder at atmospheric pressure . Terms used for the capacity include ' free gas volume ' or ' free gas equivalent ' . It depends on the internal volume and the working pressure of a cylinder . If the working pressure is higher , the cylinder will store more gas for the same volume .

The nominal working pressure is not necessarily the same as the actual working pressure used . Some steel cylinders manufactured to US standards are permitted to exceed the nominal working pressure by 10 % and this is indicated by a ' + ' symbol . This extra pressure allowance is dependent on the cylinder passing the appropriate periodical hydrostatic test and is not necessarily valid for US cylinders exported to countries with differing standards . The nominal gas content of these cylinders is based on the 10 % higher pressure .

For example , common Aluminum 80 (Al80) cylinder is an aluminum cylinder which has a nominal 'free gas ' capacity of 80 cubic feet (2 @,@ 300 L) when pressurized to 3 @,@ 000 pounds per square inch (210 bar) . It has an internal volume of 10 @.@ 94 litres (0 @.@ 386 cu ft) .

= = = = Standard sizes by volume of gas stored = = = =

Aluminum C100 ia a large (13.11), high pressure (3 @,@ 300 pounds per square inch (228 bar) cylinder. Heavy at 42 @.@ 0 pounds (19 @.@ 1 kg).

Aluminum S80 is probably the most ubiquitous cylinder , used by resorts in many parts of the world for back gas , but also popular as a sling cylinder for decompression gas , and as side @-@ mount cylinder in fresh water , as it has nearly neutral buoyancy . These cylinders have an internal volume of approximately 11 litres (0 @.@ 39 cu ft) and working pressure of 3 @,@ 000 pounds per square inch ($207\ bar$) . They are also sometimes used as manifolded twins for back mount , but in this application the diver needs more ballast weights than with most steel cylinders of equivalent capacity .

Aluminium C80 is the high pressure equivalent, with a water capacity of 10 @.@ 3 I and working

pressure 3 @,@ 300 pounds per square inch (228 bar).

Aluminum S40 is a popular cylinder for side @-@ mount and sling mount bailout and decompression gas for moderate depths, as it is small diameter and nearly neutral buoyancy, which makes it relatively unobtrusive for this mounting style. Internal volume is approximately 5 @.@ 8 litres (0 @.@ 20 cu ft) and working pressure 3 @,@ 000 pounds per square inch (207 bar).

Aluminum S63 (9 @.@ 0 I) 3 @,@ 000 pounds per square inch (207 bar), and steel HP65 (8 @.@ 2 I) are smaller and lighter than the Al80, but have a lower capacity, and are suitable for smaller divers or shorter dives.

Steel LP80 2 @,@ 640 pounds per square inch (182 bar) and HP80 (10 @.@ 11) at 3 @,@ 442 pounds per square inch (237 bar) are both more compact and lighter than the Aluminium S80 and are both negatively buoyant, which reduces the amount of ballast weight required by the diver.

Steel HP119 (14 @.@ 8 I), HP120 (15 @.@ 3 I) and HP130 (16 @.@ 0 I) cylinders provide larger amounts of gas for nitrox or technical diving.

= = Applications and configurations of diving cylinders = =

Divers may carry one cylinder or multiples, depending on the requirements of the dive. Where diving takes place in low risk areas, where the diver may safely make a free ascent, or where a buddy is available to provide an alternative air supply in an emergency, recreational divers usually carry only one cylinder. Where diving risks are higher, for example where the visibility is low or when recreational divers do deeper or decompression diving, and particularly when diving under an overhead, divers routinely carry more than one gas source.

Diving cylinders may serve different purposes. One or two cylinders may be used as a primary breathing source which is intended to be breathed from for most of the dive. A smaller cylinder carried in addition to a larger cylinder is called a " pony bottle " . A cylinder to be used purely as an independent safety reserve is called a " bailout bottle " or Emergency Gas Supply (EGS) . A pony bottle is commonly used as a bailout bottle , but this would depend on the time required to surface .

Divers doing technical diving often carry different gases, each in a separate cylinder, for each phase of the dive:

- " travel gas " is used during the descent and ascent . It is typically air or nitrox with an oxygen content between 21 % and 40 % . Travel gas is needed when the bottom gas is hypoxic and therefore is unsafe to breathe in shallow water .
- " bottom gas " is only breathed at depth . It is typically a helium @-@ based gas which is low in oxygen (below 21 %) or hypoxic (below 17 %) .
- " deco gas " is used at the decompression stops and is generally one or more nitrox mixes with a high oxygen content , or pure oxygen , to accelerate decompression .
- a "stage" is a cylinder holding reserve, travel or deco gas. They are usually carried "side slung", clipped on either side of the diver to the harness of the backplate and wing or buoyancy compensator, rather than on the back, and may be left on the distance line to be picked up for use on return (stage dropped). Commonly divers use aluminium stage cylinders, particularly in fresh water, because they are nearly neutrally buoyant in water and can be removed underwater with less effect on the diver 's overall buoyancy.

For safety , divers sometimes carry an additional independent scuba cylinder with its own regulator to mitigate out @-@ of @-@ air emergencies should the primary breathing gas supply fail . For much common recreational diving where a controlled emergency swimming ascent is acceptably safe , this extra equipment is not needed or used . This extra cylinder is known as a bail @-@ out cylinder , and may be carried in several ways , and can be any size that can hold enough gas to get the diver safely back to the surface .

```
= = = Open @-@ circuit scuba = = =
```

For open @-@ circuit scuba divers, there are several options for the combined cylinder and

regulator system:

Single cylinder consists of a single large cylinder , usually back mounted , with one first @-@ stage regulator , and usually two second @-@ stage regulators . This configuration is simple and cheap but it has only a single breathing gas supply : it has no redundancy in case of failure . If the cylinder or first @-@ stage regulator fails , the diver is totally out of air and faces a life @-@ threatening emergency . Recreational diver training agencies train divers to rely on a buddy to assist them in this situation . The skill of gas sharing is trained on most entry level scuba courses . This equipment configuration , although common with entry @-@ level divers and used for most sport diving , is not recommended by training agencies for any dive where decompression stops are needed , or where there is an overhead environment (wreck diving , cave diving , or ice diving) as it provides no functional redundancy .

Single cylinder with dual regulators consists of a single large back mounted cylinder , with two first @-@ stage regulators , each with a second @-@ stage regulator . This system is used for diving where cold water makes the risk of regulator freezing high and functional redundancy is required . It is common in continental Europe , especially Germany . The advantage is that a regulator failure can be solved underwater to bring the dive to a controlled conclusion without buddy breathing or gas sharing . However , it is hard to reach the valves , so there may be some reliance on the dive buddy to help close the valve of the free @-@ flowing regulator quickly .

Main cylinder plus a small independent cylinder: this configuration uses a larger, back mounted main cylinder along with an independent smaller cylinder, often called a "pony" or "bailout cylinder". The diver has two independent systems, but the total 'breathing system' is now heavier, and more expensive to buy and maintain.

The pony is typically a 2 to 5 litre cylinder . Its capacity determines the depth of dive and decompression duration for which it provides protection . Ponies may be fixed to the diver 's buoyancy compensator (BC) or main cylinder behind the diver 's back, or can be clipped to the harness at the diver 's side or chest or carried as a sling cylinder . Ponies provide an accepted and reliable emergency gas supply but require that the diver is trained to use them .

Another type of small independent air source is a hand @-@ held cylinder filled with about 85 litres (3 @.@ 0 cu ft) of free air with a diving regulator directly attached, such as the Spare Air. This source provides only a few breaths of gas at depth and is most suitable as a shallow water bailout.

Independent twin sets or independent doubles consists of two independent cylinders and two regulators , each with a submersible pressure gauge . This system is heavier , more expensive to buy and maintain and more expensive to fill than a single cylinder set . The diver must swap demand valves during the dive to preserve a sufficient reserve of gas in each cylinder . If this is not done , then if a cylinder should fail the diver may end up having an inadequate reserve . Independent twin sets do not work well with air @-@ integrated computers as they usually only monitor one cylinder . The complexity of switching regulators periodically to ensure both cylinders are evenly used may be offset by the redundancy of two entirely separate breathing gas supplies . The cylinders may be mounted as a twin set on the diver 's back , or alternatively can be carried in a sidemount configuration where penetration of wrecks or caves requires it , and where the cylinder valves are in easy reach .

Plain manifolded twin sets , or manifolded doubles with a single regulator , consist of two back mounted cylinders with their pillar valves connected by a manifold but only one regulator is attached to the manifold . This makes it relatively simple and cheap but means there is no redundant functionality to the breathing system , only a double gas supply . This arrangement was fairly common in the early days of scuba when low pressure cylinders were manifolded to provide a larger air supply than was possible from the available single cylinders . It is still in use for large capacity bailout sets for deep commercial diving .

Isolation manifolded twin sets or manifolded doubles with two regulators, consist of two back mounted cylinders with their pillar valves connected by a manifold, with a valve in the manifold that can be closed to isolate the two pillar valves. In the event of a problem with one cylinder the diver may close the isolator valve to preserve gas in the cylinder which has not failed. The advantages of this configuration include: a larger gas supply than from a single cylinder; automatic balancing of

the gas supply between the two cylinders; thus, no requirement to constantly change regulators underwater during the dive; and in most failure situations, the diver may close a valve to a failed regulator or isolate a cylinder and may retain access to all the remaining gas in both the tanks. The disadvantages are that the manifold is another potential point of failure, and there is a danger of losing all gas from both cylinders if the isolation valve cannot be closed when a problem occurs. This configuration of cylinders is often used in technical diving.

Sling cylinders are a configuration of independent cylinders used for technical diving . They are independent cylinders with their own regulators and are carried clipped to the harness at the side of the diver . Their purpose may be to carry either stage , travel , decompression , or bailout gas while the back mounted cylinder (s) carry bottom gas . Stage cylinders carry gas to extend bottom time , travel gas is used to reach a depth where bottom gas may be safely used if it is hypoxic at the surface , and decompression gas is gas intended to be used during decompression to accelerate the elimination of inert gases . Bailout gas is an emergency supply intended to be used to surface if the main gas supply is lost .

Side @-@ mount cylinders are cylinders clipped to the harness at the diver 's sides which carry bottom gas when the diver does not carry back mount cylinders. They may be used in conjunction with other side mounted stage, travel and / or decompression cylinders where necessary. Skilled side @-@ mount divers may carry as many as three cylinders on each side. This configuration was developed for access through tight restrictions in caves. Side mounting is primarily used for technical diving, but is also sometimes used for recreational diving, when a single cylinder may be carried, complete with secondary second stage (octopus) regulator, in a configuration sometimes referred to as monkey diving.

= = = Rebreathers = = =

Diving cylinders are used in rebreather diving in two roles:

As part of the rebreather itself. The rebreather must have at least one source of fresh gas stored in a cylinder; many have two and some have more cylinders. Due to the lower gas consumption of rebreathers, these cylinders typically are smaller than those used for equivalent open @-@ circuit dives. Rebreathers may use internal cylinders, or may also be supplied from " off @-@ board " cylinders, which are not directly plumbed into the rebreather, but connected to it by a flexible hose and coupling and usually carried side slung.

oxygen rebreathers have an oxygen cylinder

semi @-@ closed circuit rebreathers have a cylinder which usually contains nitrox or a helium based gas.

closed circuit rebreathers have an oxygen cylinder and a " diluent " cylinder , which contains air , nitrox or a helium based gas .

Rebreather divers also often carry an external bailout system if the internal diluent cylinder is too small for safe use for bailout for the planned dive. The bailout system is one or more independent breathing gas sources for use if the rebreather should fail:

Open @-@ circuit: One or more open circuit scuba sets. The number of open @-@ circuit bailout sets, their capacity and the breathing gases they contain depend on the depth and decompression needs of the dive. So on a deep, technical rebreather dive, the diver will need a bail out " bottom " gas and a bailout " decompression " gas (es). On such a dive, it is usually the capacity and duration of the bailout sets that limits the depth and duration of the dive - not the capacity of the rebreather.

Closed @-@ circuit: A second rebreather containing one or more independent diving cylinders for its gas supply. Using another rebreather as a bail @-@ out is possible but uncommon. Although the long duration of rebreathers seems compelling for bail @-@ out, rebreathers are relatively bulky, complex, vulnerable to damage and require more time to start breathing from, than easy @-@ to @-@ use, instantly available, robust and reliable open @-@ circuit equipment.

= = = Surface supplied diver emergency gas supply = = =

Surface supplied divers are usually required to carry an emergency gas supply sufficient to allow them to return to a place of safety if the main gas supply fails . The usual configuration is a back mounted single cylinder supported by the diver 's safety harness , with first stage regulator connected by a low pressure hose to a bailout block , which may be mounted on the side of the helmet or band @-@ mask or on the harness to supply a lightweight full @-@ face mask . Where the capacity of a single cylinder in insufficient , plain manifolded twins or a rebreather may be used . For closed bell bounce and saturation dives the bailout set must be compact enough to allow the diver to pass through the bottom hatch of the bell . This sets a limit on the size of cylinders that can be used .

= = = Emergency gas supply on diving bells = = =

Diving bells are required to carry an on @-@ board supply of breathing gas for use in emergencies . The cylinders are mounted externally as there is insufficient space inside . They are fully immersed in the water during bell operations , and may be considered diving cylinders .

= = = Other uses of compressed gas cylinders in diving operations = = =

Divers also use gas cylinders above water for storage of oxygen for first aid treatment of diving disorders and as part of storage "banks" for diving air compressor stations, gas blending, surface supplied breathing gas and gas supplies for decompression chambers and saturation systems. Similar cylinders are also used for many purposes not connected to diving. For these applications they are not diving cylinders and may not be subject to the same regulatory requirements as cylinders used underwater.

= = Gas calculations = =

It is necessary to know the approximate length of time that a diver can breathe from a given cylinder so that a safe dive profile can be planned.

There are two parts to this problem: The cylinder and the diver.

= = = The cylinder 's capacity to store gas = = =

Two features of the cylinder determine its gas carrying capacity:

cylinder gas pressure : when filled this normally ranges between 200 and 300 bars (2 @, @ 900 and 4 @, @ 400 psi), but the actual value should be measured for a real situation, as the cylinder may not be full.

internal volume: this normally ranges between 3 litres and 18 litres for single cylinders.

To calculate the quantity of gas:

Volume of gas at atmospheric pressure

= (cylinder volume) x (cylinder pressure) / (atmospheric pressure)

In those parts of the world using the metric system the calculation is relatively simple as atmospheric pressure may be approximated as 1 bar , So a 12 @-@ litre cylinder at 232 bar would hold almost $12 \times 232 / 1 =$

2 @,@ 784 litres (98 @.@ 3 cu ft) of air at atmospheric pressure (also known as free air) .

In the US the capacity of a diving cylinder is specified directly in cubic feet of free air at the nominal working pressure , as the calculation from internal volume and working pressure is relatively tedious in imperial units . For examle , in the US and in many diving resorts in other countries , one might find aluminum cylinders of US manufacture with an internal capacity of 0 @.@ 39 cubic feet (11 L) filled to a working pressure of 3 @,@ 000 psi (210 bar) ; Taking atmospheric pressure as 14 @.@ 7 psi , this gives 0 @.@ 39 x 3000 / 14 @.@ 7 = 80 ft 3 These cylinders are described as " 80 cubic foot cylinders " , (the common " aluminum 80 ") .

Up to about 200 bar the ideal gas law remains valid and the relationship between the pressure , size of the cylinder and gas contained in the cylinder is linear ; at higher pressures there is proportionally less gas in the cylinder . A 3 @-@ litre cylinder filled to 300 bar will only carry contain 810 litres (29 cu ft) of atmospheric pressure gas and not the 900 litres expected from the ideal gas law .

= = = Diver gas consumption = = =

There are three main factors to consider:

the rate at which the diver consumes gas , specified as surface air consumption (SAC) or respiratory minute volume (RMV) of the diver . In normal conditions this will be between 10 and 25 litres per minute (L / min) for divers who are not working hard . At times of extreme high work rate , breathing rates can rise to 95 litres per minute . For International Marine Contractors Association (IMCA) commercial diving gas planning purposes , a working breathing rate of 40 litres per minute is used , whilst a figure of 50 litres per minute is used for emergencies . RMV is controlled by blood CO2 levels , and is usually independent of oxygen partial pressures , so does not change with depth . The very large range of possible rates of gas consumption results in a significant uncertainty of how long the supply will last , and a conservative approach is required for safety where an immediate access to an alternative breathing gas source is not possible . Scuba divers are expected to monitor the remaining gas pressure sufficiently often that they are aware of how much is still available at all times during a dive .

ambient pressure : the depth of the dive determines this . The ambient pressure at the surface is 1 bar (15 psi) at sea level . For every 10 metres (33 ft) in seawater the diver descends , the pressure increases by 1 bar (15 psi) . As a diver goes deeper , the breathing gas is delivered at a pressure equal to ambient water pressure , and the amount of gas used is proportional to the pressure . Thus , it requires twice as much mass of gas to fill the diver 's lungs at 10 metres (33 ft) as it does at the surface , and three times as much at 20 metres (66 ft) . The mass consumption of breathing gas by the diver is similarly affected .

time at each depth . (usually approximated as time at each depth range)

To calculate the quantity of gas consumed: