
## Cresat C3 v2,0

## Layout Wotes:

- · Main goal move everything to the left side of the board
- · Remove JP9 (not ased), JP8 (FTDI VUSB to VBUS)
- · Add flat ribbon connector to replace J7 (ARM SWD), C3\_FTDI Connector
- Add From library J-TEConnectivity X-1734592-X

  Device 2-1734592-0

  Foot print TE\_2-1734592-0
- · Make all GND and 3,3V trace width 0,3048
- · Make all Non GND and 3.3V Wire width 0,254 (or 0,2 under eMMC)
- · Make sure that the edge clearance is maintained
- · Make all components 0603 (Recistors, Capacitors)
- Connection Plan for eMMC to arrange connections to pull up resistor notworks



· Add (per Ian)
Protection Circuit
For OPD

O ohm resistor (as place holder) for protection einemit.

Make Symbol and footprint for TVS diode

Little fuse SZISMB5. OAT3G