Performance-Portable Implicit Scale-Resolving Compressible Flow Using libCEED

SIAM CSE 2023

James Wright February 27, 2023

Ann and H.J. Smead Department of Aerospace Engineering Sciences



Outline

- 1. What is libCEED?
- 2. libCEED Overview
- 3. Fluid Simulations with libCEED
- 4. Accuracy and Performance of High-Order Scale-Resolving Simulations

· C library for element-based discretizations



- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available



- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available
- Designed for matrix-free operator evaluation

- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available
- · Designed for matrix-free operator evaluation
- · Portable to different hardware via computational backends



- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available
- Designed for matrix-free operator evaluation
- · Portable to different hardware via computational backends
 - · Code that runs on CPU also runs on GPU without changes



- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available
- Designed for matrix-free operator evaluation
- · Portable to different hardware via computational backends
 - · Code that runs on CPU also runs on GPU without changes
 - · Computational backend selectable at runtime, using runtime compilation



- · C library for element-based discretizations
 - · Bindings for Fortran, Rust, Python, and Julia available
- · Designed for matrix-free operator evaluation
- · Portable to different hardware via computational backends
 - · Code that runs on CPU also runs on GPU without changes
 - · Computational backend selectable at runtime, using runtime compilation
- Geared toward high-order element discretizations

libCEED Overview


$$A = \mathcal{P}^T \mathcal{E}^T B^T D B \mathcal{E} \mathcal{P}$$

global domain all (shared) dofs




T-vector

$$A = \mathcal{P}^T \mathcal{E}^T B^T D B \mathcal{E} \mathcal{P}$$




$$A = \mathcal{P}^T \mathcal{E}^T B^T D B \mathcal{E} \mathcal{P}$$




L-vector

$$A = \mathcal{P}^T \mathcal{E}^T B^T DB \mathcal{E} \mathcal{P}$$



$$A = \mathcal{P}^T \mathcal{E}^T B^T DB \mathcal{E} \mathcal{P}$$



Fluid Simulations with libCEED



Compressible Navier-Stokes

$$\boldsymbol{U}_{,t} + \boldsymbol{F}_{i,i}(\boldsymbol{U}) - S(\boldsymbol{U}) = 0$$

for

$$\boldsymbol{U} = \begin{bmatrix} \rho \\ \rho u_i \\ E \equiv \rho e \end{bmatrix}, \quad \boldsymbol{F}_i(\boldsymbol{U}) = \underbrace{\begin{pmatrix} \rho u_i \\ \rho u_i u_j + p \delta_{ij} \\ (\rho e + p) u_i \end{pmatrix}}_{\boldsymbol{F}_i^{\text{adv}}} + \underbrace{\begin{pmatrix} 0 \\ -\sigma_{ij} \\ -\rho u_i \sigma_{ij} - kT_{,i} \end{pmatrix}}_{\boldsymbol{F}_i^{\text{diff}}}, \quad \boldsymbol{S}(\boldsymbol{U}) = - \begin{pmatrix} 0 \\ \rho \boldsymbol{g} \\ 0 \end{pmatrix}$$

convert to primitive variable formulation

Find
$$oldsymbol{U} \in \mathcal{S}^h$$

$$\int_{\Omega} \boldsymbol{v} \cdot (\boldsymbol{U}_{,t} - \boldsymbol{S}(\boldsymbol{U})) d\Omega - \int_{\Omega} \boldsymbol{v}_{,i} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) d\Omega + \int_{\partial\Omega} \boldsymbol{v} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) \cdot \hat{\boldsymbol{n}} d\partial\Omega$$

Find
$$oldsymbol{U} \in \mathcal{S}^h$$

$$\int_{\Omega} \boldsymbol{v} \cdot (\boldsymbol{U}_{,t} - \boldsymbol{S}(\boldsymbol{U})) \, d\Omega - \int_{\Omega} \boldsymbol{v}_{,i} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) \, d\Omega$$

$$+ \int_{\partial\Omega} \boldsymbol{v} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) \cdot \hat{\boldsymbol{n}} \, d\partial\Omega$$

$$+ \int_{\Omega} \mathcal{P}(\boldsymbol{v})^{T} \, (\boldsymbol{U}_{,t} + \boldsymbol{F}_{i,i}(\boldsymbol{U}) - \boldsymbol{S}(\boldsymbol{U})) \, d\Omega = 0 \,, \, \forall \boldsymbol{v} \in \mathcal{V}^{h}$$
SUPG

Find
$$m{U} \in \mathcal{S}^h$$

$$\int_{\Omega} m{v} \cdot \left(m{U}_{,t} - m{S}(m{U}) \right) \, \mathrm{d}\Omega - \int_{\Omega} m{v}_{,i} \cdot m{F}_i(m{U}) \, \mathrm{d}\Omega$$

$$+ \int_{\partial \Omega} m{v} \cdot m{F}_i(m{U}) \cdot \widehat{m{n}} \, \, \mathrm{d}\partial\Omega$$

$$+ \int_{\Omega} \mathcal{P}(m{v})^T \, \left(m{U}_{,t} + m{F}_{i,i}(m{U}) - S(m{U}) \right) \, \mathrm{d}\Omega = 0 \,, \; \forall m{v} \in \mathcal{V}^h$$

SUPG

Further simplified into residual form:

$$\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})=0$$

Find
$$\boldsymbol{U} \in \mathcal{S}^h$$

$$\int_{\Omega} \boldsymbol{v} \cdot \left(\boldsymbol{U}_{,t} - \boldsymbol{S}(\boldsymbol{U})\right) d\Omega - \int_{\Omega} \boldsymbol{v}_{,i} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) d\Omega$$

$$+ \int_{\partial \Omega} \boldsymbol{v} \cdot \boldsymbol{F}_{i}(\boldsymbol{U}) \cdot \widehat{\boldsymbol{n}} d\partial \Omega$$

$$+ \int_{\Omega} \mathcal{P}(\boldsymbol{v})^{T} \left(\boldsymbol{U}_{,t} + \boldsymbol{F}_{i,i}(\boldsymbol{U}) - \boldsymbol{S}(\boldsymbol{U})\right) d\Omega = 0, \ \forall \boldsymbol{v} \in \mathcal{V}^{h}$$

SUPG

Further simplified into residual form:

$$\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U}) = 0$$

$$\Rightarrow \quad \mathcal{P}^{T}\mathcal{E}^{T}B^{T}GB\mathcal{E}\mathcal{P} = 0$$

Implicit Timestepping

Implicit timestepping requires solving:

$$\frac{\mathrm{d}\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})}{\mathrm{d}\boldsymbol{U}}\Delta\boldsymbol{U}=\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})$$

Implicit Timestepping

Implicit timestepping requires solving:

$$\frac{\mathrm{d}\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})}{\mathrm{d}\boldsymbol{U}}\Delta\boldsymbol{U}=\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})$$

- Store $\frac{d\mathcal{G}}{dI}$ directly
 - · Pros: Opens up preconditioning options
 - · Cons: Is large, expensive to store

Implicit Timestepping

Implicit timestepping requires solving:

$$\frac{\mathrm{d}\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})}{\mathrm{d}\boldsymbol{U}}\Delta\boldsymbol{U}=\mathcal{G}(\boldsymbol{U}_{,t},\boldsymbol{U})$$

- Store $\frac{d\mathcal{G}}{dII}$ directly
 - Pros: Opens up preconditioning options
 - · Cons: Is large, expensive to store
- Finite difference matrix-free approximation:

$$rac{\mathrm{d}\mathcal{G}(oldsymbol{U}_{,t},oldsymbol{U})}{\mathrm{d}oldsymbol{U}}\Deltaoldsymbol{U}pproxrac{\mathcal{G}(oldsymbol{U}_{,t},oldsymbol{U}+\epsilon\Deltaoldsymbol{U})-\mathcal{G}(oldsymbol{U}_{,t},oldsymbol{U})}{\epsilon}$$

- · Pros: Just need a residual evaluation, cheap (in programming and computation)
- · Cons: Approximation, accuracy limited to $\sqrt{\epsilon_{
 m machine}}$

$$\frac{\mathrm{d}\mathcal{G}}{\mathrm{d}oldsymbol{U}}\Deltaoldsymbol{U} = \frac{\mathrm{d}}{\mathrm{d}oldsymbol{U}}\left[\mathcal{G}(oldsymbol{U}_t,oldsymbol{U})
ight]\Deltaoldsymbol{U}$$

$$\frac{\mathrm{d}\mathcal{G}}{\mathrm{d}\boldsymbol{U}}\Delta\boldsymbol{U} = \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\mathcal{G}(\boldsymbol{U}_{,t}, \boldsymbol{U}) \right] \Delta \boldsymbol{U}$$
$$= \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\boldsymbol{\mathcal{P}}^T \mathcal{E}^T \boldsymbol{B}^T \boldsymbol{G} \boldsymbol{B} \mathcal{E} \boldsymbol{\mathcal{P}} \right] \Delta \boldsymbol{U}$$

$$\frac{\mathrm{d}\mathcal{G}}{\mathrm{d}\boldsymbol{U}} \Delta \boldsymbol{U} = \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\mathcal{G}(\boldsymbol{U}_{,t}, \boldsymbol{U}) \right] \Delta \boldsymbol{U}$$
$$= \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\boldsymbol{\mathcal{P}}^T \mathcal{E}^T \boldsymbol{B}^T \boldsymbol{G} \boldsymbol{B} \mathcal{E} \boldsymbol{\mathcal{P}} \right] \Delta \boldsymbol{U}$$
$$= \left[\boldsymbol{\mathcal{P}}^T \mathcal{E}^T \boldsymbol{B}^T \frac{\mathrm{d}\boldsymbol{G}}{\mathrm{d}\boldsymbol{U}} \boldsymbol{B} \mathcal{E} \boldsymbol{\mathcal{P}} \right] \Delta \boldsymbol{U}$$

$$\frac{\mathrm{d}\mathcal{G}}{\mathrm{d}\boldsymbol{U}} \Delta \boldsymbol{U} = \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\mathcal{G}(\boldsymbol{U}_{,t}, \boldsymbol{U}) \right] \Delta \boldsymbol{U}$$
$$= \frac{\mathrm{d}}{\mathrm{d}\boldsymbol{U}} \left[\boldsymbol{\mathcal{P}}^T \mathcal{E}^T \boldsymbol{B}^T \boldsymbol{G} \boldsymbol{B} \mathcal{E} \boldsymbol{\mathcal{P}} \right] \Delta \boldsymbol{U}$$
$$= \left[\boldsymbol{\mathcal{P}}^T \mathcal{E}^T \boldsymbol{B}^T \frac{\mathrm{d}\boldsymbol{G}}{\mathrm{d}\boldsymbol{U}} \boldsymbol{B} \mathcal{E} \boldsymbol{\mathcal{P}} \right] \Delta \boldsymbol{U}$$

- Store intermediary data at quadrature points to improve efficiency ("taping")
 - · We store U, viscous stress, and stabilization perturbation $(\mathcal{P}(v))$
- · Pros: Exact Jacobian matrix-vector product (potentially faster convergence)
- · Cons: More expensive than residual evaluation (but not by too much)

Code Architecture

- PETSc used for handling everything libCEED doesn't
 - $\mathcal{P}, \mathcal{P}^T$ (Partition global-to-local operations)
 - · Time integration, linear, non-linear equation solving
 - Strong boundary conditions

Code Architecture

- PETSc used for handling everything libCEED doesn't
 - $\cdot \mathcal{P}, \mathcal{P}^T$ (Partition global-to-local operations)
 - Time integration, linear, non-linear equation solving
 - Strong boundary conditions
- PETSc calls a libCEED operator when it needs the residual evaluation



Code Architecture

- PETSc used for handling everything libCEED doesn't
 - $\cdot \mathcal{P}, \mathcal{P}^T$ (Partition global-to-local operations)
 - Time integration, linear, non-linear equation solving
 - Strong boundary conditions
- PETSc calls a libCEED operator when it needs the residual evaluation
- libCEED Operator based on user-implemented CeedQFunctions (D)
 - Use different CeedQFunctions for volume vs boundary integrals
 - · Combined into a single **CeedOperator** to represent $\mathcal{G}(U_t, U)$



1. PETSc gets $oldsymbol{U}^L = {\color{red} {\cal P} } oldsymbol{U}^G$ from current solution

- 1. PETSc gets $oldsymbol{U}^L = \mathcal{P} oldsymbol{U}^G$ from current solution
- 2. PETSc calls libCEED to get $G^L = \underbrace{\mathcal{E}^T B^T DB \mathcal{E}}_{I} U^L$

- 1. PETSc gets $oldsymbol{U}^L = \mathcal{P} oldsymbol{U}^G$ from current solution
- 2. PETSc calls libCEED to get $G^L = \underbrace{\mathcal{E}^T B^T DB \mathcal{E}}_{L} U^L$
- 3. PETSc gets $G^G = \mathcal{P}^T G^L$

- 1. PETSc gets $oldsymbol{U}^L = \mathcal{P} oldsymbol{U}^G$ from current solution
- 2. PETSc calls libCEED to get $G^L = \underbrace{\mathcal{E}^T B^T DB\mathcal{E}}_{} U^L$
- 3. PETSc gets $G^G = \mathcal{P}^T G^L$
- 4. PETSc uses G^G to compute new solution value

- 1. PETSc gets $oldsymbol{U}^L = \mathcal{P} oldsymbol{U}^G$ from current solution
- 2. PETSc calls libCEED to get $G^L = \underbrace{\mathcal{E}^T B^T DB \mathcal{E}}_{} U^L$
- 3. PETSc gets $G^G = \mathcal{P}^T G^L$
- 4. PETSc uses $m{G}^G$ to compute new solution value ...or whatever else it wants

Accuracy and Performance of High-Order Scale-Resolving Simulations

Flat Plate Boundary Layer, Zero Pressure Gradient

Problem Description:

- $Re_{\theta} \approx 970$ boundary layer at inflow, $M \approx 0.1$
- Synthetic turbulence generation (STG) used for inflow structures
- · Internal damping layer (IDL) used in STG development region to prevent pressure wave growth
- asdf
- Domain size of $\{27 \times 24 \times 4\}\delta_0$

High-Order Approach

- Test 3 different order elements, Q_1, Q_2, Q_3 tensor-product hexes
- Maintain DOF resolution (DOFs per physical length)

lames Wright · SIAM CSF 2023

- DOF resolution for streamwise and spanwise was $\Delta x^+ = 30$ and $\Delta z^+ = 12$
 - For Q_1 , this is about half the resolution required for DNS resolution

Support and References

This work was supported by.... Add in sponsor support (DOE, ECP, etc)

