

V01 CHENG-CHIH LEE

**CHENG-CHIH LEE**

# **LightSwarm**

**CHENG-CHIH LEE**

**2025/11/02**

## #Summary

This project is built upon the previous lab and creates a swarm to connect at most three ESP32's and a Raspberry Pi (as a data logger). The RPi will have a button and four LEDs (Red, Green, Yellow, White). The ESP will have an analog light sensor (photoresistor in the package).

The following links show the reference code for lightswarm logic.

- [ESP 8266 LightSwarm.ino](#) [Download LightSwarm.ino](#)(obtained from Prof. Shovic's github)
- [Raspberry Pi LightSwarm.py](#) [Download LightSwarm.py](#)(obtained from Prof. Shovic's github)
- Python 3 version: [github.com/switchdoclabs/SDL\\_Pi\\_LightSwarm](#)[Links to an external site.](#)

Each of the three ESP32's in the swarm is identical. There are no software differences and no hardware differences. They can communicate with each other by broadcasting messages to exchange sensor readings. One of them, the ESP32 with the highest reading, will become the "Master" and will forward the readings to the RPi for data logging.

\*I teared down the legacy code and fit it into FreeRTOS architecture.

(key words: ESP32, Raspberry Pi 5, UDP, Photocell Sensor, GPIO, FreeRTOS, threading)

## #OUTLINE

**-Version History**

**-Components used / Pin Definition / Schematics**

**-Overall Flow-chart**

**-Protocol**

**-State Machine**

**-Part 1-1 Raspberry Pi WiFi setup and packet delivery**

**-Part 1-2 Rpi correctly reacts to received packets and error condition**

**-Part 2-1 ESP WiFi setup and packet delivery**

**-Part 2-2 ESP correctly reacts to received packets**

## # Version History

<b><i>Version</i></b>	<b><i>Date</i></b>	<b><i>Comment</i></b>	<b><i>Known Issue/Fix</i></b>
v01_Beta	11/04/2025	Beta version	

## #Components used

1. Photocell with a 10k pull-down resistor.
2. External LEDs. Need resistors (330 Ohm).
3. A button. Need a pull-down resistor (10k Ohm), digital input and with interrupt mode set to that pin.

## #Pin Definition for *ESP32*

Pin Name	Definition	Usage and comments
LED_BUILTIN	GPIO 2	Built in onboard LED (fixed)
PHOTO_CELL	GPIO 34	ADC Sampling pin for Photocell sensor

Table.1 Pin Definition




Fig.1 Schematics

#Pin Definition for *Raspberry Pi*

Pin Name	Definition	Usage and comments
LED_R	GPIO 26	Pin for Red External LED
LED_Y	GPIO 13	Pin for Red External YELLOW
LED_G	GPIO 6	Pin for Red External GREEN
LED_W	GPIO 5	Pin for Red External WHITE
BTN	GPIO 16	Pin for External Push Button

Table.2 Pin Definition






Fig.2 Schematics

## #Overall Flow-chart



## #State Machine



## #Protocols

During my development, UDP broadcasting is configured. That means all devices in the network should be able to receive all packets sent. No IP is hardcoded in any device. Port is set as 1996.

**Laptop : IP ----, Port 1996**  
**RPi : IP ----, Port 1996**  
**ESP32 : IP ----, Port 1996**

Byte	Field	Value	Description
<b>0</b>	0xF0	Constant	<b>Start-of-frame marker.</b> Helps receivers validate the packet type.
<b>1</b>	LIGHT_UPDATE_PACKET (=0)	0	<b>Packet type ID</b> — distinguishes from reset, blink, etc.
<b>2</b>	localIP[3]	e.g., 123	<b>Node ID</b> — the last octet of its IP (unique in local subnet). Used as swarm identifier.
<b>3</b>	masterState	0 or 1	<b>Role flag:</b> 1 = master, 0 = slave.
<b>4</b>	VERSIONNUMBER	e.g., 28	<b>Firmware version</b> for compatibility tracking.
<b>5–6</b>	clearColor (high, low)	sensor value	<b>Clear (luminance)</b> 16-bit reading from the photocell (moving average).
<b>7–8</b>	redColor (high, low)	Not used	Placeholder for <b>red channel intensity</b> . (Unused here since no color sensor.)
<b>9–10</b>	greenColor (high, low)	Not used	Placeholder for green.
<b>11–12</b>	blueColor (high, low)	Not used	Placeholder for blue.
<b>13</b>	0x0F	0x0F	<b>End-of-frame marker</b> (symmetrical with start marker).

## Part 1-1 Raspberry Pi WiFi setup and packet delivery

Files: talk\_v03.py, UDP\_v03.py, state\_machine\_v03.py, LightSwarm.py

In this project, the LightSwarm functionality is modified/integrated into the previous “we\_need\_to\_talk” project. talk\_v03 works as the main file, initializing some threads. UDP\_v03 works as the UDP rx/tx library module. The state machine module is modified to keep only two states, including operation and reset Swarm. And the RPi is connected to my personal hotspot named IPhoneKL. WiFi related functionalities are developed in the “**UDP\_v03.py**” module.

### #WiFi Setup and UDP

For the UDP setup, it's set to broadcast mode, thus sending to 255.255.255.255. port is 1996.

```

state_machine_v03.py talk_v03.py UDP_v03.py LightSwarm.py
1 #Kevin Lee 10/11/2025
2 #v03 Kevin Lee 11/03/2025 Modified for LightSwarm Project
3 import socket
4 print("#####")
5 print("!!!!!!Hi!!!!>0<!!!!!!")
6 print("#####")
7 #UDP_IP = input("Enter Listening IP or Enter to default 0.0.0.0:") or "0.0.0.0"
8 #UDP_PORT = 8386
9 #Laptop_UDP_IP = input("Enter Laptop IP or Enter to default 172.20.10.4:") or "172.20.10.4"
10 #Laptop_UDP_PORT = 823
11 #ESP32_UDP_IP = input("Enter ESP32 IP or Enter to default 172.20.10.2:") or "172.20.10.2"
12 #ESP32_UDP_PORT = 1996
13 UDP_IP = "255.255.255.255"
14 UDP_PORT = 1996
15
16 sock = socket.socket(socket.AF_INET, socket.SOCK_DGRAM)
17 sock.setsockopt(socket.SOL_SOCKET, socket.SO_BROADCAST, 1) ...# ?::allow broadcast
18 sock.bind((UDP_IP, UDP_PORT))
19
20
21
22
23
24

```

In the main file (**talk\_v03.py**), I put UDP\_Receive() and processPacket() to **thread** to make sure it keeps listening.

```

state_machine_v03.py talk_v03.py UDP_v03.py LightSwarm.py
1 #Kevin Lee 10/11/2025
2 #v03 Kevin Lee 11/03/2025 Modified for LightSwarm Project
3 import time
4 import threading
5 import UDP_v03 as UDP
6 import state_machine_v03 as STATE
7 import LightSwarm as LS
8
9 if __name__ == '__main__':
10     ...
11     STATE.gpio_setup()
12     receiver_thread = threading.Thread(target=UDP.UDP_Receive, daemon=True)
13     receiver_thread.start() # Put UDP listening to thread to ensure listening
14     processPacket_thread = threading.Thread(target=LS.processPacket, daemon=True)
15     processPacket_thread.start()
16     print("#####")
17     print("System Up! Listening to LightSwarm Packets!!!")
18     print("#####")
19
20     try:
21         while True:
22             time.sleep(0.5) ...# keep main thread alive
23     except KeyboardInterrupt:
24         print("Exiting...")

```

This UDP module also works as a layer for state\_machine and LightSwarm to exchange the LSCommand. The set functionset ***LSCommand(cmd)*** is for writing to this layer; ***get*** functions are for accessing values.


```

40     def get_message_r():
41         ... #for getting the received UDP message
42         return message_r
43
44     def get_new_msg_cnt():
45         ... #for getting the UDP message incoming status
46         return new_msg_cnt
47
48     def getLSCommand():
49         global LScmd
50         return LScmd
51
52     def setLSCommand(cmd):
53         global LScmd
54         LScmd = cmd

```

For UDP **sending**, I developed ***UDP\_Send()*** method to send messages to both my laptop and ESP32 for the beta version. This method will later be called by the ***state\_maching*** module.

For UDP **receiving**, I developed ***UDP\_Receive()*** method to receive messages. Now RPi is listening to all UPDs with this method put to thread. Upon receiving UPDs, it also updated the ***new\_msg\_cnt*** for checking message incoming status.



```

19
20     message_r = "", ""
21     new_msg_cnt = 0
22     LScmd = ""
23
24     def UDP_Send(message):
25         ... #BroadCast UDP
26         ... sock.sendto(message, (UDP_IP, UDP_PORT)).encode()
27
28         print(f"Broadcasting UDP Message:{message} to:{UDP_IP}:{UDP_PORT}")
29
30     def UDP_Receive():
31         ... global message_r
32         ... global new_msg_cnt
33
34         while True:
35             ... data, addr = sock.recvfrom(1024)
36             ... message_r = (data, addr) #store tuple (bytes, address)
37             ... new_msg_cnt += 1
38             ... print(f"Received {len(data)} bytes from {addr}: {list(data)}")
39
40     def get_message_r():
41         ... #for getting the received UDP message
42         return message_r
43
44     def get_new_msg_cnt():
45         ... #for getting the UDP message incoming status
46         return new_msg_cnt
47
48     def getLSCommand():
49         global LScmd
50         return LScmd
51
52     def setLSCommand(cmd):
53         global LScmd
54         LScmd = cmd

```

## Part 1-2 Rpi reacts to received packets

### #State Machine

In the State machine, 4 state transitions are developed. The **button\_callback()** is attached to external push button input interrupt for triggering state change.


```

28     blink_stop .... = threading.Event() #for stop led·blink
29     blink_rgy_stop = threading.Event() #for stop led·rgy·blink
30     photosns_stop .. = threading.Event() #for stop photo·sense
31
32     def button_callback(channel):
33         state_machine()
34
35     def state_machine():
36         global sys_state
37
38         if sys_state == 0: #from init to operation
39             m_operation()
40
41         elif sys_state == 1: #from norm to down
42             photosns_stop.set()
43             blink_rgy_stop.set()
44             m_pwr_dwn() #to pwr·down
45             sys_state = 0 #put back to initial stat
46
47         elif sys_state == 2: #from err
48             # Stop·blinking
49             blink_stop.set()
50             sys_state = 0
51

```

## #Operation Mode *m\_operation()*

This state is triggered when status flag **sys\_state == 0** and the **button is pressed**. The sys\_state is then set to 1 indicating it's in operation mode. The photosensing and RGY led indicating tasks will be put to threading.




```

129     def m_operation():
130         ...
131         global sys_state
132         global message_r
133         err = 0
134         ...
135         sys_state = 1
136         GPIO.output(led_w, GPIO.HIGH)
137         print("#####")
138         print("In operation mode")
139         print("#####")
140         photosns_stop.clear() #clear the stop event
141         photosns_thread = threading.Thread(target=photo_sns, daemon=True)
142         photosns_thread.start()
143         ...
144         blink_rgy_stop.clear() #clear the stop event
145         blink_RGY_thread = threading.Thread(target=blink_rgy_led, daemon=True)
146         blink_RGY_thread.start()
147         ...
148         time.sleep(1)
149
150

```

### **#Photocell value process *photo\_sns()***

When *photo\_sns()* is put to thread, with ***sys\_state==1 and the thread is not stopped***. This method checks if the packet is from a master device or not, clear led indicator thread stop flag and it also shuts down leds accordingly.




```

57     def photo_sns():
58         global new_msg_cnt
59         global pre_msg_cnt
60         global led_ind
61         global bright_value
62         value = 0
63         print("#####")
64         print("In photo sns.now")
65         print("#####")
66
67         while sys_state==1 and not photosns_stop.is_set():
68             pre_msg_cnt = new_msg_cnt
69             device_id, isMaster, value = LS.getLSMasterBright()
70             #print("photo_sns Receiving Packet. device_id, isMaster, value")
71             new_msg_cnt = UDP.get_new_msg_cnt()
72
73             if(isMaster):
74                 blink_ryg_stop.clear()
75                 bright_value = value
76                 print("bright_value = ",bright_value," value= ",value)
77                 if device_id is 0:
78                     led_ind = led_g
79                     #print("LED indicator is:", led_g, '\n')
80                     GPIO.output(led_r, GPIO.LOW)
81                     GPIO.output(led_y, GPIO.LOW)
82                 elif device_id is 1:
83                     led_ind = led_y
84                     #print("LED indicator is:", led_y, '\n')
85                     GPIO.output(led_r, GPIO.LOW)
86                     GPIO.output(led_g, GPIO.LOW)
87                 elif device_id is 2:
88                     led_ind = led_r
89                     #print("LED indicator is:", led_r, '\n')
90                     GPIO.output(led_y, GPIO.LOW)
91                     GPIO.output(led_g, GPIO.LOW)
92
93             time.sleep(0.5)

```

**#Power Down mode m\_pwr\_dwn()****Works as reset Swarm task**

During normal operation, when the external button is pressed, the state machine will generate the photo\_sns() and blink\_rgy\_stop() thread stopping event and sent **UDP.setLSCommand("RESETSWARM")**.



```

state_machine_v03.py talk_v03.py UDP_v03.py LightSwarm.py
152 def m_pwr_dwn():
153     global sys_state
154     sys_state = 3
155
156     UDP.setLSCommand("RESETSWARM") #setting LS cmd to UDP layer
157     print("#####")
158     print("Reset Swarm")
159     print("#####")
160     GPIO.output(led_r, GPIO.HIGH)
161     GPIO.output(led_y, GPIO.HIGH)
162     GPIO.output(led_g, GPIO.HIGH)
163     GPIO.output(led_w, GPIO.HIGH)
164     time.sleep(0.5)
165     GPIO.output(led_r, GPIO.LOW)
166     time.sleep(0.5)
167     GPIO.output(led_y, GPIO.LOW)
168     time.sleep(0.5)
169     GPIO.output(led_g, GPIO.LOW)
170     time.sleep(1.5)
171     GPIO.output(led_w, GPIO.LOW)
172     #Enter pwr_dwn procedure

```

The operation method will then put RPi back to initial state to wait for the button pressed to join the Swarm again.

## Part 2-1 ESP WiFi setup and packet delivery

ESP is connected to my hotspot. It is also developed to UDP broadcasting.

```
LightSwarm.ino
12  char ssid[] = "iPhoneKL"; // your network SSID (name)
13  char pass[] = [REDACTED]; // your network password
14
15  unsigned int localPort = 1996; // local port to listen for UDP packets
16  IPAddress serverAddress = IPAddress(255, 255, 255, 255); // default no IP Address

114 Serial.print("Connecting to ");
115 Serial.println(ssid);
116 WiFi.begin(ssid, pass);
117
118 // initialize Swarm Address - we start out as swarmID of 0
119
120 ~ while (WiFi.status() != WL_CONNECTED) {
121   delay(500);
122   Serial.print(".");
123 }
124 Serial.println("");
125
126 Serial.println("WiFi connected");
127 Serial.println("IP address: ");
128 Serial.println(WiFi.localIP());
129
130 Serial.println("Starting UDP");
131
132 udp.begin(localPort);      // bind & listen on port
133 //udp.setBroadcast(true);    // allow broadcast TX
```

**Swarm data array is initialized here.**

```
137 // initialize light sensor and arrays
138 int i;
139 for (i = 0; i < SWARMSIZE; i++)
140 {
141   swarmAddresses[i] = 0;
142   swarmClear[i] = 0;
143   swarmTimeStamp[i] = -1;
144 }
145 swarmClear[mySwarmID] = 0;
146 swarmTimeStamp[mySwarmID] = 1; // I am always in time to myself
147 clearColor = swarmClear[mySwarmID];
148 swarmVersion[mySwarmID] = VERSIONNUMBER;
149 swarmState[mySwarmID] = masterState;
150 Serial.print("clearColor=");
151 Serial.println(clearColor);
152 // set SwarmID based on IP address
153 localIP = WiFi.localIP();
154 swarmAddresses[0] = localIP[3];
155 mySwarmID = 0;
156 Serial.print("MySwarmID=");
157 Serial.println(mySwarmID);
```

## #Tasks

After WiFi connection, six tasks are created. **UDP receiving Task** for UDP receiving, **Task\_PhotoSns** for Photocell sensing, **Task\_UDP\_Send** for sending UDP packet. **Task\_Swarm** for Swarm logic implementation. **Task\_LED\_Blink** for controlling Built-In led blinking behavior. **Task\_Monitor** for checking stack watermark.

```

159  /*Mutesx to protect shared swarm data field*/
160  swarmMutex = xSemaphoreCreateMutex();
161  /*Task Creation*/
162  xTaskCreatePinnedToCore(Task_PhotoSns, "Task_PhotoSns", 4096, NULL, 1, &xHandle_Task_PhotoSns, 1);
163  xTaskCreatePinnedToCore(Task_UDP_Receive, "Task_UDP_Receive", 4096, NULL, 2, &xHandle_Task_UDP_Receive, 1);
164  xTaskCreatePinnedToCore(Task_UDP_Send, "Task_UDP_Send", 4096, NULL, 1, &xHandle_Task_UDP_Send, 1);
165  xTaskCreatePinnedToCore(Task_Swarm, "Task_Swarm", 4096, NULL, 1, &xHandle_Task_Swarm, 1);
166  xTaskCreatePinnedToCore(Task_LED_Blink, "Task_LED_Blink", 4096, NULL, 1, &xHandle_Task_LED_Blink, 1);
167  xTaskCreatePinnedToCore(Task_Monitor, "Task_Monitor", 4096, NULL, 1, NULL, 1);

```

## #UDP Receiving **UDP\_Receive(void)**

In the **UDP\_Receive()** function, UDP incoming messages are processed by calling the **Packet\_Helper** function. There's a mutex set to protect the incoming packet.

```

356 void Task_UDP_Receive(void *pvParameters){
357
358     for(;;){
359         int cb = udp.parsePacket();
360         if (cb) {
361             udp.read(packetBuffer, PACKET_SIZE);
362             xSemaphoreTake(swarmMutex, portMAX_DELAY);
363             // update swarm arrays and clearColor
364             Incoming_Packet_Helper(packetBuffer);
365             xSemaphoreGive(swarmMutex);
366         }
367         vTaskDelay(100 / portTICK_PERIOD_MS);
368     }
369 }
```

## #UDP Sending **UDP\_Send(const char\* msg)**

In the **UDP\_Send()** function, **broadcastARandomUpdatePacket()** is called and **sendLightUpdatePacket()** is called accordingly.

```

371 void Task_UDP_Send(void *pvParameters){
372     for(;;){
373         vTaskDelay(1); // let RX run first
374         broadcastARandomUpdatePacket();
375         vTaskDelay(1000 / portTICK_PERIOD_MS);
376     }
377 }
```

```

206 void broadcastARandomUpdatePacket()
207 {
208     int sendToLightSwarm = 255;
209     int randomDelay;
210     randomDelay = random(0, MAXDELAY);
211     Serial.print("Delay = ");
212     Serial.print(randomDelay);
213     Serial.print("ms : ");
214
215     vTaskDelay(randomDelay / portTICK_PERIOD_MS);
216
217     IPAddress sendSwarmAddress(255, 255, 255, sendToLightSwarm); // my Swarm Address
218     sendLightUpdatePacket(sendSwarmAddress);
219 }
```

## Part 2-2 ESP correctly reacts to received packets

### #Task\_Swarm

The Task\_Swarm is for checking the main logic for Light Swarm by calling checkAndSetIfMaster().

```

379  void Task_Swarm(void *pvParameters){
380    for(;;){
381      // Check to see if I am master!
382      checkAndSetIfMaster();
383      vTaskDelay(500 / portTICK_PERIOD_MS);
384    }
385  }

221  void checkAndSetIfMaster()
222  {
223    int i;
224    int howLongAgo;
225    for (i = 0; i < SWARMSIZE; i++)
226    {
227
228    #ifdef DEBUG
229      Serial.print("swarmClear[ ");
230      Serial.print(i);
231      Serial.print("] = ");
232      Serial.print(swarmClear[i]);
233      Serial.print("  swarmTimeStamp[ ");
234      Serial.print(i);
235      Serial.print("] = ");
236      Serial.println(swarmTimeStamp[i]);
237    #endif
238      Serial.print("#");
239      Serial.print(i);
240      Serial.print("/");
241      Serial.print(swarmState[i]);
242      Serial.print("/");
243      Serial.print(swarmVersion[i]);
244      Serial.print(":");
245      // age data
246      howLongAgo = millis() - swarmTimeStamp[i]

```

## #Photocell sensing function

The **Photo\_Sns(void)** function is developed to execute sensing with analog reading. A moving average function **MovAvg(uint16\_t input, uint16\_t \*buffer)** is used to derive 5 sec sliding window average.

```
LightSwarm.ino
530
531 int Photo_Sns(void){
532     int val = 0u;
533
534     val = analogRead(PHOTO_SNS_PIN);
535     val = MovAvg(val, &PHOTO_READINGS[0]);/*Moving average*/
536     data_cnt+=1;
537     sprintf(photo_sns_buffer, "%d", val); /*convert int → text*/
538     Serial.print("Photo Sns Read=");
539     Serial.print(photo_sns_buffer);
540     Serial.println(" ");
541     return val;
542 }
543
544 uint16_t MovAvg(uint16_t input, uint16_t *buffer)[
545     /*Buffer with 5 elements*/
546     float avg = 0.0f;
547
548     buffer[4] = buffer[3];
549     buffer[3] = buffer[2];
550     buffer[2] = buffer[1];
551     buffer[1] = buffer[0]; /*pop out old element and push new*/
552     buffer[0] = input;
553
554     avg = (buffer[0]+buffer[1]+buffer[2]+buffer[3]+buffer[4])/5;
555
556     return avg;
557 }
```