A Synthetic Aperture Focusing Algorithm for Ultrasonic Imaging

1 Imaging Problem

We develop an ultrasonic imaging method for a flaw in a plate. Synthetic aperture focusing concept will be used for this purpose. The imaging algorithm is formulated for a reasonably general model of a ultrasonic testing (UT) shown schematically in Fig.*. In this model, it is assumed that the incident ultrasonic wave is excited at a point x_s on the top plate surface. The echoes returning from the flaw are also observed on the top surface over an aperture \mathcal{R} . The ultrasonic echo signal captured with an transducer is usually given as a temporal waveform, and is called an A-scan in the context of ultrasonic nondestructive testing. We adopt this terminology in this article, and denote the A-scan captured at x as $a(x,t;x_s)$ where t is the time elapsed from the time of incident wave excitation. Since A-scans are captured on \mathcal{R} , the whole dataset available for the imaging is written as

$$\mathcal{D} = \{ a(\boldsymbol{x}, t; \boldsymbol{x}_s) | \boldsymbol{x} \in \mathcal{R}, t > 0 \}.$$
 (1)

For given dataset \mathcal{D} , we consider synthesizing an image $I(x_P)$ of the unknown flaw, thereby estimate the location and size of the flaw.

2 Synthetic Aperture Imaging Algorithm

The present synthetic imaging algorithm may be divided into two parts. The first part is a delay-and-sum operation on the measured A-scans \mathcal{D} . The second part is a sampling or projection operation on the resulting summed A-scan. The delay law and the nature of the samplig/projection are both related closely to the travel time of the ultrasonic wave. It is thus convenient to introduce a handy notation for the travel time. When an ultrasonic wave travels from \mathbf{y} to \mathbf{x} taking a flight time t_f , we write

$$t_f = T_f(\boldsymbol{x}, \boldsymbol{y}). \tag{2}$$

It reads "the travel time from y to x is t_f ". In eq.(2), it is meant that t_f is a single travel time, while T_f is the function which returns the travel time for given point of departure and arrival. To process an A-scan with the help of time-of-flight concept, it is necessary to decompose $a(x, t; x_s)$ into the incident and scattered components as

$$a(\boldsymbol{x}, t; \boldsymbol{x}_s) = a^{in}(\boldsymbol{x}, t; \boldsymbol{x}_s) + a^{sc}(\boldsymbol{x}, t; \boldsymbol{x}_s).$$
(3)

As in eq.(3), quantities associated with the incident and scattered wave components are and will be denoted with the superscripts "in" and "sc", respectively. With this decomposition, we may associate a flight time

$$t^{in}(\mathbf{x}) = T_f(\mathbf{x}, \mathbf{x}_s), (\mathbf{x} \in \mathcal{R})$$
(4)

with the incident wave component $a^{in}(\mathbf{x}, t; \mathbf{x}_s)$. If $t^{in}(\mathbf{x})$ is estimated for every $\mathbf{x} \in \mathcal{R}$, the incident wave pulse in each A-scan can be aligned at the origin of the coordinate t = 0 by translating $a(\mathbf{x}, t)$ by $t^{in}(\mathbf{x})$ as $a(\mathbf{x}, t + t^{in}(\mathbf{x}))$. The A-scans translated thus are then superimposed as

$$\bar{a}^{in}(t) = \int_{\mathcal{R}} a\left(\boldsymbol{x}, t + t^{in}(\boldsymbol{x})\right) dx, \tag{5}$$

so that the incident wave pulse in $\bar{a}^{in}(t)$ be amplified to a degree dependent on the accuracy of the estimated travel time. Clearly, eq.(5) is a delay-and-sum in which the waveform $a(\boldsymbol{x},t)$ is delayed by $-t^{in}(\boldsymbol{x})$ and summed over the aperture \mathcal{R} .

A summed A-scan similar to eq.(5) may be obtained for the scattered wave component $a^{sc}(\boldsymbol{x},t)$. Associating the flight time, however, with the scattered wave component is not straightforward. This is because scattered waves are generated at every point on the scattereing object. Consequently, it is not possible to pinpoint where exaxtly is a scattered wave is originated from. A simple and practical trick to circumvent this difficulty is to model the scattering object as a collection of small, point-like scatterers distributed densely but discretely over the surface of the object. Then the flight time can be assigned to each constituent point scatterer with no ambiguity. This approach may be formulated more rigorously if we descritize an integral representation of the scattered field, which is beyond the scope of this article. When one of the point scatteres is located at x_P , the flight time for the scattered wave is given by

$$t_P^{sc}(\boldsymbol{x}) = T_f(\boldsymbol{x}_P, \boldsymbol{x}_s) + T_f(\boldsymbol{x}, \boldsymbol{x}_P). \tag{6}$$

The subscript P in eq.(6) is to remind that the flight time depend on the location of the point scatterer. Then we can align and amplify the scattered wave packets at t = 0 by the following delay-and-sum operation.

$$\bar{a}_P^{sc}(t) = \int_{\mathcal{R}} a^{sc}(\boldsymbol{x}, t + t_P^{sc}(\boldsymbol{x})) d\boldsymbol{x}$$
 (7)

The degree of amplicification depends obviously on the accuracy of the estimated t_P^{sc} . It is equally or more important to note that the amplification would not occur if there were not the scattere at x_P , or if the scattered waves from x_P did not take the path we have considerd in estimating $t_P^{sc}(x)$ On the other hand, if there is no scattering object at x_P , then there is no wave packet in $a^{sc}(x,t)$ to be amplified. Thus the summed A-scan would be rather quiet having a small norm. This means the summed A-scan \bar{a}_P^{sc} can be used as a measure of scattering intensity at x_P . If the intensity is measued by a scalar quantitity by samping or a projection, then we may synthesize a map of scattered intesity by

$$I(\boldsymbol{x}_P) = \mathcal{S}\left[\bar{a}_P^{sc}(t)\right] \tag{8}$$

where S denote the sampling(projection) operator from a space of A-scan waveforms to the non-negative real coordinate R^+ . The simplest choice for S is a sampling by Dirac's delta function

$$\mathcal{S}\left[\bar{a}_P^{sc}(t)\right] = \langle \delta(t), \, \bar{a}_P^{sc} \rangle = \bar{a}_P^{sc}(0) \tag{9}$$

where $\langle \cdot, \cdot \rangle$ means the dot product defined by

$$\langle f, g \rangle = \int f(t)g(t)dt.$$
 (10)

This is reasonable because the \bar{a}_P^{sc} is constructed so that the wave packet is amplified at t=0. However, this is not often a good choice as the real A-scan is not an ideal pulse, and hence the peak amplitude always comes after the theoretically estimated flight time. A better alternative to automatically account such delay is to take a cross correlation

$$\mathcal{S}\left[\bar{a}_{P}^{sc}(t)\right] = \frac{\left\langle \bar{a}^{in}(t), \bar{a}_{P}^{sc}(t) \right\rangle}{\left\langle \bar{a}^{in}(t), \bar{a}^{in}(t) \right\rangle} \tag{11}$$

where the uncertainty regarding the delay is compensated by the uncertainty of summed incident wave pulse shape. We can further generalize the projection S, e.g. as

$$\mathcal{S}\left[\bar{a}_{P}^{sc}(t)\right] = \left\| a^{in}(t) * a^{sc}(t) \right\|_{p} \tag{12}$$

where * denotes a convolution product and $\|\cdot\|_p$ means the p-norm. However, we're not going to elaborate the projection, but rather, investigate how a relatively simple projection (11) works with the A-scans measured with an LDV.

3 Numerical Implementation

3.1 Incident and scattered wave splitting

$$u(x,t) = \int U(k,\omega)e^{i(kx-\omega t)}dkd\omega \tag{13}$$

The spectral content $U(k,\omega)$ corresponds to the left(right) going wave in space-time domain when $k\omega > 0 (< 0)$. Thus we can split u into the left and right going wave by a frequency-wave number domain filtering

$$u^{\pm}(x,t) = \int U(k,\omega)H(\pm k\omega)e^{i(kx-\omega t)}dkd\omega$$
 (14)

where H(s) is the Heaviside unit step function.

$$H(s) = \begin{cases} 1 & (s > 0) \\ 0 & (s < 0) \end{cases}$$
 (15)

3.2 Construction of the flight time function

There are infinitely many wave paths in the plate due to the wave reverberation. The number of paths increases exponentially if the mode conversion upon reflection at the plate surfaces are taken into account. We look at small number of them to make the problem tractable. Furthermore, mode preseving ray paths that accampanies small number of reflections will be considerd. This makes the ray tracing problem greatly simple. To obtain the travel time, in a homogeneous material it suffice to obtain the travel path that connect the source to the receiver point after a given number of reflection. The ray paths for an arbitray many reflections can be constructed by a successive application of a so called "image point method". The procedure of the image point method is illustrated in Fig.*, which should make the concept of the method clear.