

13 SEP 13 (10-2) Eff 19 Sep

BANDA ACEH, INDONESIA




© JEPPESEN, 2010, 2013. ALL RIGHTS RESERVED.

WITT/BTJ SULTAN ISKANDAR MUDA \*ATIS 126.7 128.6 Apt Elev 65' GNSS Required Alt Set: hPa Trans level: FL130 Trans alt: 11000' BANDA ACEH, INDONESIA INDONESIA RNAV STAR




© JEPPESEN, 2016. ALL RIGHTS RESERVED.


BANDA ACEH INDONESIA



© JEPPESEN, 2010, 2013. ALL RIGHTS RESERVED.




WITT/BTJ SULTAN ISKANDAR MUDA



© JEPPESEN, 2016. ALL RIGHTS RESERVED.

MOSOL 2E



CHANGES: New procedures at this airport.

© JEPPESEN, 2016. ALL RIGHTS RESERVED.

JEPPESEN BANDA ACEH, INDONESIA WITT/BTJ Apt Elev 65 1 JUN 18 (10-9) SULTAN ISKANDAR MUDA N05 31.0 E095 25.2 **\*SULTAN Tower** 126.7 122.2 -95-24 95-25 95-26 Jet engine aircraft are to be parked on the Eastern apron with western, northern or southern heading and shall not turn near 17 terminal building to avoid jet blast toward terminal building. Elev 65' All aircraft taxiing shall not make one wheel turns in order to avoid damage to apron, taxiway or runway. Aircraft heavier than F-28 are requested to turn on turning areas only. - 05-32 Rwy 17 right traffic pattern. PARKING GATE COORDINATES COORDINATES GATE NO5 31.0 E095 25.1 1, 2 3 thru 6 NO5 31.1 E095 25.1 N05 31.2 E095 25.1 7, 8 **⊚**VOR Control Tower Terminal 05-31 05-31 Bldg Area NDB **⊙**196 95-25 WP ADDITIONAL RUNWAY INFORMATION **USABLE LENGTHS** LANDING BEYOND **RWY** Threshold Glide Slope **TAKE-OFF** WIDTH 17 HIALS REIL PAPI-L 7274' 2217m 148' 35 REIL PAPI-L 45m **TAKE-OFF** AIR CARRIER AIR CARRIER (FAR 121) All Rwys All Rwys LVP must be in Force RCLM (DAY only) RCLM (DAY only) Adequate Vis Ref C 250m Eng 400m 400m 3 & 4 D 300m

## BANDA ACEH, INDONESIA SULTAN ISKANDAR MUDA


SOLIAN ISKANDAK MOD						
STRAIGHT-IN RWY		Α	В	С	D	
1 <i>7</i>	ILS	<b>287′</b> (227 <b>′</b> )	<b>287′</b> (227 <b>′</b> )	<b>306′</b> (246 <b>′</b> )	<b>306′</b> (246 <b>′</b> )	
	FULL/Limited	800m	800m	800m	800m	
	ALS out	1200m	1200m	1300m	1300m	
	LNAV			<b>550′</b> (485 <b>′</b> )	<b>550′</b> (485 <b>′</b> )	
		NOT APPLICABLE	NOT APPLICABLE	2300m	2300m	
	ALS out			3000m	3000m	
	<b>O</b> LOC	<b>600′</b> (540 <b>′</b> )				
		1600m	1600m	2400m	2800m	
	ALS out	1600m	1600m	2400m	2800m	
	LOC	<b>600′</b> (540 <b>′</b> )				
		2200m	2200m	2400m	2800m	
	ALS out	2600m	2600m	2800m	2800m	
	• VOR DME	<b>600′</b> (540 <b>′</b> )				
		1600m	1600m	2000m	2800m	
	ALS out	1600m	1600m	2400m	2800m	
	VOR	<b>720′</b> (660′)	<b>720′</b> (660′)	<b>720′</b> (660′)	<b>720′</b> (660′)	
		2800m	2800m	3000m	3200m	
	ALS out	3200m	3200m	3400m	3400m	


<sup>●</sup> Continuous Descent Final Approach

CIRCLE-TO-LAND	100 KT	135 KT	180 KT	205 KT
After VOR 17	730′(665′)	730′(665′)	730′(665′)	770′(705′)
	3200m	3200m	3400m	3600m
After ILS 17	950′(885′)	950′(885′)	2300′(2235′)	2300′(2235′)
	② 1600m	<b>②</b> 1600m	② 2400m	3600m
After VOR DME 17	1300′(1235′)	1300′(1235′)	2300′(2235′)	2300′(2235′)
	5000m	5000m	5000m	5000m
After RNAV (GNSS) 17	NOT APPLICABLE	NOT APPLICABLE	<b>2200</b> ′(2135′) <b>5000m</b>	<b>2200</b> ′(2135′) <b>5000m</b>

② Or higher minimums of preceding straight-in approach.

T	TAKE-OFF								
	LVP must be in Force								
	RCLM (DAY only) or RL	RCLM (DAY only) or RL	NIL (DAY only)						
A B C	250m	400m	500m						
D	300m	1							





JEPPESEN

WITT/BTJ

BANDA ACEH, INDONESIA