VertuoPlus Deluxe

Price

Price = 279.00
Bundle Price with Milk Frother = 349.00
=> Milk Frother: Aeroccino 3

Cup Sizes

Espresso	Double Espresso	Gran Lungo	Long Coffee
40 ml Espresso	80 ml Double Espresso	150 ml Gran Lungo	230 ml Long Coffee

Specifications

- Dimensions (W x D x H): 14.2 x 42.3 x 32.5 cm
- Weight: 4.58 kg
- Warranty: 1 year
- Removable Water Tank: 1.8 L
- Automatic Power Off: after 9 minutes of non-use
- Heat-Up Time: 15 - 20 sec
- Capsule Container Capacity: 10 capsules

Premise

VertuoPlus prepares freshly brewed Coffee and authentic espresso with cream at the touch of a button thanks to the revolutionary Centrifusion and code reading parametric extraction technologies.

Helpful Links

Name of Link	URL
Machine Manual	https://www.nespresso.com/shared_res/manuals/vertuoline/www_VERTUOPLUS_D_NESPRESSO_Z1(EN_FR_ES).pdf
Machine Assistance VertuoPlus Deluxe	https://www.nespresso.com/ca/ca/machine-assistance#!/VertuoPlus/troubleshooting
YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUxkelWWmfC-u3i5gbB88pQn&feature=shared
Descaling Guide	https://www.nespresso.com/static/us/documents/VertuoPlus%20Descaling%20Guide.pdf
Descaling Video	https://youtu.be/QLgY0whpesE?feature=shared
Factory Reset Instructions	https://www.mymorningespresso.com/how-to-reset-nespresso-machine/?expand_article=1#4-vertuo-plus-or-vertuoplus-deluxe

Factory Reset Instructions

1. NOTE: Choose special function by pressing the lever down: 1 time for “Descaling”. 2 times for “Emptying the system”. 3 times for “Reset to factory settings”.
2. Turn the machine “OFF” by pushing the lever down for 3 seconds.
3. To enter “Factory settings” mode, push the button and the lever down at the same time for 3 seconds. ORANGE steady light indicates entry into the Special Functions Menu.
4. Choose function by pressing the lever down 3 times for “Reset to factory settings”.
5. NOTE: the machine will blink 3 times every 2 seconds until the button will be pressed.
6. NOTE: Choose function within 2 minutes or else the machine will go back to Ready mode. ORANGE light will blink 3 times every 2 seconds, indicating the “Factory reset” function.
7. Push the button to confirm. ORANGE light will blink 3 times in 3 seconds to confirm reset is done and then go to steady GREEN. The machine is now ready to use.
8. NOTE: It is possible at any time to exit the Special Functions menu by pushing the button and pressing the lever down at the same time for 3 seconds. GREEN steady light indicates the machine is ready.

Descaling

Descaling Alert = The button illuminates in Half GREEN and Half RED steady light.

- Descaling needed: Machine can be operated when alert appears only a few times after this alert before descaling becomes necessary.
- Refer to Descaling Guide on how to perform the descaling procedure.

First Time Use Procedure

1. Rinse and clean the water tank before filling it only with fresh drinking water. Put the water tank in place.
2. Ensure the capsule container and the cup support are in place. For your safety, operate the machine only with cup support and capsule container in position.

3. Plug the machine into the outlet.
4. Turn the machine “ON” by pushing the button. GREEN light will blink while the machine is heating up.
5. Steady GREEN lights will indicate the machine is ready.
6. Place a cup of at least 0.8 L under the coffee outlet.
7. Open the machine head by pressing the lever up to eject the capsule and then push the lever down to close it.
8. Push the button 3 times in 2 seconds to start cleaning and let the cleaning procedure complete automatically. ORANGE lights will blink during the operation. It will take less than 2 minutes before a flow comes out. The procedure consists of 3 cycles of pumping water in, internal cleaning and water flowing from the outlet to complete.
9. This procedure may take up to 5 minutes. The procedure can be stopped at any time by pushing the button. The button will go to steady GREEN. To restart the cleaning process, follow the instructions starting at point 8. To brew a coffee, insert a capsule, push the lever down to close the machine and push the button.

Notes

- The VertuoPlus can be considered a mid-tier machine with a good product lifetime.
- The button used to automatically open the lid of the machine is an excellent feature because some of the other machine models require one to manually open the lid to put in a capsule. This can be challenging for those that are unable to have strong grip with their hand which consists of some seniors and/or those with arthritis.
- This machine model has one of the biggest water tanks which can accommodate multiple cups of coffee.
- The base of the water tank can be retracted to the side of the machine and behind it too.

Colour Variations

VertuoPlus Deluxe

Machine Name	Machine Photo
VertuoPlus Deluxe - Black	