adc.c Page 1 of 4

```
/**
 * @file adc.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 July 15
 * @brief Provides basic ADC functionality
#include "stm3214xx_11_dma.h"
#include "adc.h"
 * @brief Initialize DMA for the ADC
 * @param values Array to store ADC values
 ^{\star} @param numValues Number of values in values array
 * @retval None
static void ADC_Init_DMA(uint16_t * values, int numValues);
/** @brief Delay between ADC end of calibration and ADC enable */
#define ADC_DELAY_CALIB_ENABLE_CPU_CYCLES (LL_ADC_DELAY_CALIB_ENABLE_ADC_CYCLES * 32)
/** @brief Number of possible ADC channels */
#define ADC_NUM_CHANNELS 24
/** @brief Array of ADC channels */
uint32_t ADC_CHANNELS[ADC_NUM_CHANNELS] = {
    LL_ADC_CHANNEL_0,
    LL_ADC_CHANNEL_1,
    LL_ADC_CHANNEL_2,
    LL ADC CHANNEL 3,
    LL_ADC_CHANNEL_4,
    LL_ADC_CHANNEL_5,
    LL_ADC_CHANNEL_6,
    LL_ADC_CHANNEL_7,
    LL_ADC_CHANNEL_8,
    LL_ADC_CHANNEL_9,
    LL_ADC_CHANNEL_10,
   LL_ADC_CHANNEL_11,
   LL_ADC_CHANNEL_12,
    LL_ADC_CHANNEL_13,
   LL_ADC_CHANNEL_14,
    LL_ADC_CHANNEL_15,
    LL_ADC_CHANNEL_16,
    LL_ADC_CHANNEL_VREFINT,
                                   // ADC1 Only, Uses Channel 0
                                    // ADC1 or ADC3
    LL_ADC_CHANNEL_TEMPSENSOR,
    LL_ADC_CHANNEL_VBAT,
                                    // ADC1 or ADC3
   LL_ADC_CHANNEL_DAC1CH1_ADC2,
                                    // ADC2 Only
                                    // ADC2 Only
    LL_ADC_CHANNEL_DAC1CH2_ADC2,
                                    // ADC3 Only, Uses Channel 14
    LL_ADC_CHANNEL_DAC1CH1_ADC3,
    LL_ADC_CHANNEL_DAC1CH2_ADC3
                                    // ADC3 Only, Uses Channel 15
/** @brief Array of ADC channel ranks */
uint32_t ADC_RANKS[16] = {
    LL_ADC_REG_RANK_1,
    LL_ADC_REG_RANK_2,
    LL_ADC_REG_RANK_3,
    LL ADC REG RANK 4,
    LL_ADC_REG_RANK_5,
    LL_ADC_REG_RANK_6,
    LL_ADC_REG_RANK_7,
    LL_ADC_REG_RANK_8,
    LL_ADC_REG_RANK_9,
    LL_ADC_REG_RANK_10,
    LL_ADC_REG_RANK_11,
    LL_ADC_REG_RANK_12,
    LL_ADC_REG_RANK_13,
```

```
LL_ADC_REG_RANK_14,
    LL_ADC_REG_RANK_15,
    LL_ADC_REG_RANK_16
/**
 * @brief DMA transfer value
 * 0: DMA transfer is not completed @n
 * 1: DMA transfer is completed @n
 * 2: DMA transfer has not been started yet (initial state)
volatile uint8_t dmaTransferStatus = 2;
/**
* @brief ADC group sequence conversion value
* 0: ADC group regular sequence conversions are not completed
 * 1: ADC group regular sequence conversions are completed
*/
volatile uint8_t adcConversionStatus = 0;
/* Initialize ADC with DMA*/
void Init_ADC(uint32_t channels, uint16_t * values, int numValues)
{
   int i, j;
    // Check if the ADC is already enabled
    if (LL_ADC_IsEnabled(ADCx_BASE)) {
       return;
    }
    // Initialize DMA for the ADC
    ADC_Init_DMA(values, numValues);
    // Enable ADC interrupts
    // Set the ADC IRQ to a greater priority than the DMA IRQ
   NVIC_SetPriority(ADCx_IRQ, 0);
   NVIC_EnableIRQ(ADCx_IRQ);
    // Enable the ADC clock
   ADCx_CLK_ENABLE();
    // Set the ADC clock
   LL_ADC_SetCommonClock(__LL_ADC_COMMON_INSTANCE(ADCx_BASE), LL_ADC_CLOCK_SYNC_PCLK_DIV2);
    // Enable the internal ADC channels
   LL_ADC_SetCommonPathInternalCh(__LL_ADC_COMMON_INSTANCE(ADCx_BASE), (LL_ADC_PATH_INTERNAL_VRE
FINT | LL_ADC_PATH_INTERNAL_TEMPSENSOR | LL_ADC_PATH_INTERNAL_VBAT));
    // Delay for the internal ADC channels to stablize
    // The temperature sensor takes the longest time to stabalize
    i = ((LL_ADC_DELAY_TEMPSENSOR_STAB_US * (SystemCoreClock / (100000 * 2))) / 10);
    while (i != 0) {
        i--;
    }
    // Set the ADC to have a external timer trigger source
    LL_ADC_REG_SetTriggerSource(ADCx_BASE, LL_ADC_REG_TRIG_EXT_TIM8_TRGO);
    // Set the ADC to trigger on the rising edge
   LL_ADC_REG_SetTriggerEdge(ADCx_BASE, LL_ADC_REG_TRIG_EXT_RISING);
    // Set the ADC to perform a single conversion
   LL_ADC_REG_SetContinuousMode(ADCx_BASE, LL_ADC_REG_CONV_SINGLE);
    // Set the ADC conversion data transfer
   LL_ADC_REG_SetDMATransfer(ADCx_BASE, LL_ADC_REG_DMA_TRANSFER_UNLIMITED);
    // Set the ADC overrun behavior
   LL_ADC_REG_SetOverrun(ADCx_BASE, LL_ADC_REG_OVR_DATA_OVERWRITTEN);
    // Set the ADC sequencer length
```

adc.c Page 3 of 4

```
LL_ADC_REG_SetSequencerLength(ADCx_BASE, numValues - 1);
    // Enable specified ADC channels
   for (i = 0, j = 0; i < ADC_NUM_CHANNELS; i++) {</pre>
        if (channels & (1 << i)) {
            LL_ADC_REG_SetSequencerRanks(ADCx_BASE, ADC_RANKS[j], ADC_CHANNELS[i]);
            LL_ADC_SetChannelSamplingTime(ADCx_BASE, ADC_CHANNELS[i], ADCx_SAMPLERATE);
       if (j \ge numValues | j \ge 16) break;
    }
    // Enable ADC interupts for conversion completion
   LL_ADC_EnableIT_EOS (ADCx_BASE);
    // Enable ADC interupts for overrun
   LL_ADC_EnableIT_OVR(ADCx_BASE);
    // Disable the ADC deep power down mode
   LL_ADC_DisableDeepPowerDown (ADCx_BASE);
    // Enable the ADC internal voltage regulator
   LL_ADC_EnableInternalRegulator(ADCx_BASE);
   \ensuremath{//} Delay for the ADC internal voltage regulator to stabilize
   i = ((LL_ADC_DELAY_INTERNAL_REGUL_STAB_US * (SystemCoreClock / (100000 * 2))) / 10);
   while (i != 0) {
       i--;
    // Start the ADC calibration
   LL_ADC_StartCalibration(ADCx_BASE, LL_ADC_SINGLE_ENDED);
    // Wait for the ADC calibration to finish
   while (LL_ADC_IsCalibrationOnGoing(ADCx_BASE) != 0);
    // Delay to allow ADC calibration to enable
   i = (ADC_DELAY_CALIB_ENABLE_CPU_CYCLES >> 1);
   while (i != 0) {
       i--;
    // Enable the ADC
   LL_ADC_Enable(ADCx_BASE);
    // Wait for the ADC to be ready
   while (LL_ADC_IsActiveFlag_ADRDY(ADCx_BASE) == 0);
    // Start the ADC conversion
   LL_ADC_REG_StartConversion(ADCx_BASE);
static void ADC_Init_DMA(uint16_t *values, int numValues)
    // Enable DMA interrupts
    // Set the DMA IRQ to a lower priority than the ADC IRQ
   NVIC_SetPriority(DMAx_IRQ, 1);
   NVIC_EnableIRQ(DMAx_IRQ);
    // Enable the DMA clock
   DMAx_CLK_ENABLE();
    // Configure the DMA transfer
   LL_DMA_ConfigTransfer(DMAx_BASE, DMAx_CHANNEL,
        LL_DMA_DIRECTION_PERIPH_TO_MEMORY
        LL_DMA_MODE_CIRCULAR
       LL_DMA_PERIPH_NOINCREMENT
        LL_DMA_MEMORY_INCREMENT
        LL_DMA_PDATAALIGN_HALFWORD
        LL_DMA_MDATAALIGN_HALFWORD
        LL_DMA_PRIORITY_HIGH );
```

adc.c Page 4 of 4

```
// Select ADCx_BASE as the DMA transfer request
   LL_DMA_SetPeriphRequest(DMAx_BASE, DMAx_CHANNEL, LL_DMA_REQUEST_0);
    // Set the DMA transfer address source and destination
   LL_DMA_ConfigAddresses(DMAx_BASE, DMAx_CHANNEL,
        LL_ADC_DMA_GetRegAddr(ADCx_BASE, LL_ADC_DMA_REG_REGULAR_DATA),
        (uint32_t)values, LL_DMA_DIRECTION_PERIPH_TO_MEMORY);
    // Set the DMA transfer size
   LL_DMA_SetDataLength(DMAx_BASE, DMAx_CHANNEL, numValues);
    // Enable DMA transfer complete interrupts
   LL_DMA_EnableIT_TC(DMAx_BASE, DMAx_CHANNEL);
   // Enable DMA transfer error interrupts
   LL_DMA_EnableIT_TE(DMAx_BASE, DMAx_CHANNEL);
    // Enable the DMA channel
   LL_DMA_EnableChannel(DMAx_BASE, DMAx_CHANNEL);
}
/* DMA transfer complete callback */
void ADC_DMA_TransferComplete_Callback(void)
{
    // Update the DMA transfer status
   dmaTransferStatus = 1;
    // Verify the ADC conversion was completed
   if (adcConversionStatus != 1) {
       ADC_DMA_TransferError_Callback();
    // Reset the ADC conversion status
   adcConversionStatus = 0;
}
/* DMA transfer error callback */
void ADC_DMA_TransferError_Callback(void)
{
    // Handle the error
    //while(1);
/\star ADC group regular end of sequence conversions interruption callback \star/
void ADC_ConvComplete_Callback(void)
    // Update the ADC conversion status
   adcConversionStatus = 1;
}
/* ADC group regular overrun interruption callback */
void ADC_OverrunError_Callback(void)
    // Disable ADC overrun interrupts
   LL_ADC_DisableIT_OVR(ADCx_BASE);
```

dac.c Page 1 of 1

```
* @file dac.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 July 29
 * @brief Provides basic DAC functionality
*/
#include "dac.h"
/* Initialize the DAC interface */
int Init_DAC(void)
    volatile uint32_t i = 0;
    // Enable the peripheral clock for the DAC
   DACx_CLK_ENABLE();
    // Set the DAC trigger source to software
    LL_DAC_SetTriggerSource(DACx_BASE, DAC_LMD_CHANNEL, LL_DAC_TRIG_SOFTWARE);
    // Configure the DAC output for channel 1
   LL_DAC_ConfigOutput (DACx_BASE, DAC_LMD_CHANNEL, LL_DAC_OUTPUT_MODE_NORMAL, LL_DAC_OUTPUT_BUFF
ER_ENABLE, LL_DAC_OUTPUT_CONNECT_GPIO);
    // Enable the DMA underrun interrupt for channel 1
    //LL_DAC_EnableIT_DMAUDR2(DACx_BASE);
    // Enable the DAC for channel 1
    LL_DAC_Enable(DACx_BASE, DAC_LMD_CHANNEL);
    // Delay to allow the DAC voltage to settle
   i = ((LL_DAC_DELAY_STARTUP_VOLTAGE_SETTLING_US * (SystemCoreClock / (100000 * 2))) / 10);
    while (i != 0)
        i--;
    }
    // Enable the DAC
   LL_DAC_EnableTrigger(DACx_BASE, DAC_LMD_CHANNEL);
   return 0;
}
/* Adjust the DAC output value */
void DAC_SetValue(uint32_t value)
{
    // Set the DAC value
   LL_DAC_ConvertData12RightAligned(DACx_BASE, DAC_LMD_CHANNEL, 0xFFF & value);
    // Tigger a DAC conversion
   LL_DAC_TrigSWConversion(DACx_BASE, DAC_LMD_CHANNEL);
```

```
/**
* @file hw_map.c
* @author Kyle Bernier
* @author Daeghan Elkin
* @date 2018 September 8
* @brief Maps hardware peripherals to board specific features
*/
#include "hw_map.h"
/* Initializes hardware required by peripherals */
void HW_Init_GPIO(void)
   // Enable the clock for GPIO port A
   LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOA);
    //----
   // ADC Setup
   //----
   // Enable the clock for GPIO port B
   LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOB);
   // Enable the clock for GPIO port E
   LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOE);
   // Configure the GPIO pin as a ADC input
   LL_GPIO_SetPinMode(ADC_BAT_GPIO_PORT, ADC_BAT_GPIO_PIN, LL_GPIO_MODE_ANALOG);
    // Map GPIO pin to the ADC
   LL_GPIO_EnablePinAnalogControl(ADC_BAT_GPIO_PORT, ADC_BAT_GPIO_PIN);
   // Configure the GPIO pin as a ADC input
   LL_GPIO_SetPinMode(ADC_LMD_GPIO_PORT, ADC_LMD_GPIO_PIN, LL_GPIO_MODE_ANALOG);
   // Map GPIO pin to the ADC
   LL_GPIO_EnablePinAnalogControl(ADC_LMD_GPIO_PORT, ADC_LMD_GPIO_PIN);
   // Configure the GPIO pin as a ADC input
   LL_GPIO_SetPinMode(ADC_RES_GPIO_PORT, ADC_RES_GPIO_PIN, LL_GPIO_MODE_ANALOG);
   // Map GPIO pin to the ADC
   LL_GPIO_EnablePinAnalogControl(ADC_RES_GPIO_PORT, ADC_RES_GPIO_PIN);
   // Configure the GPIO pin as a ADC input
   LL_GPIO_SetPinMode(ADC_CRNT_GPIO_PORT, ADC_CRNT_GPIO_PIN, LL_GPIO_MODE_ANALOG);
   // Map GPIO pin to the ADC
   LL_GPIO_EnablePinAnalogControl(ADC_CRNT_GPIO_PORT, ADC_CRNT_GPIO_PIN);
   // DAC Setup
   //----
   \ensuremath{//} Configure the GPIO pin as a DAC input
   LL_GPIO_SetPinMode(DAC_LMD_GPIO_PORT, DAC_LMD_GPIO_PIN, LL_GPIO_MODE_ANALOG);
   //----
   // PWM Setup
   // Enable the peripheral clock of GPIOs
   PWMx_GPIO_CLK_ENABLE();
   \ensuremath{//} GPIO TIM configuration
   LL_GPIO_SetPinMode(PWMx_GPIO_PORT, PWMx_GPIO_PIN, LL_GPIO_MODE_ALTERNATE);
   PWMx_SET_GPIO_AF();
   LL_GPIO_SetPinSpeed(PWMx_GPIO_PORT, PWMx_GPIO_PIN, LL_GPIO_SPEED_FREQ_HIGH);
   LL_GPIO_SetPinOutputType(PWMx_GPIO_PORT, PWMx_GPIO_PIN, LL_GPIO_OUTPUT_PUSHPULL);
   LL_GPIO_SetPinPull(PWMx_GPIO_PORT, PWMx_GPIO_PIN, LL_GPIO_PULL_NO);
    // Enable the timer peripheral clock
   PWMx_CLK_ENABLE();
    //----
```

hw_map.c Page 2 of 2

```
// USART Setup
// Enable the peripheral clock of GPIO Port
USARTx_GPIO_CLK_ENABLE();
// Configure Tx Pin
LL_GPIO_SetPinMode(USARTx_TX_GPIO_PORT, USARTx_TX_PIN, LL_GPIO_MODE_ALTERNATE);
USARTx_SET_TX_GPIO_AF();
LL_GPIO_SetPinSpeed(USARTx_TX_GPIO_PORT, USARTx_TX_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinOutputType(USARTx_TX_GPIO_PORT, USARTx_TX_PIN, LL_GPIO_OUTPUT_PUSHPULL);
LL_GPIO_SetPinPull(USARTx_TX_GPIO_PORT, USARTx_TX_PIN, LL_GPIO_PULL_UP);
// Configure Rx Pin
LL_GPIO_SetPinMode(USARTx_RX_GPIO_PORT, USARTx_RX_PIN, LL_GPIO_MODE_ALTERNATE);
USARTx_SET_RX_GPIO_AF();
LL_GPIO_SetPinSpeed(USARTx_RX_GPIO_PORT, USARTx_RX_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinOutputType(USARTx_RX_GPIO_PORT, USARTx_RX_PIN, LL_GPIO_OUTPUT_PUSHPULL);
LL_GPIO_SetPinPull(USARTx_RX_GPIO_PORT, USARTx_RX_PIN, LL_GPIO_PULL_UP);
// Enable USART peripheral clock and clock source
USARTx_CLK_ENABLE();
// Set clock source
USARTx_CLK_SOURCE();
//----
// SPI Setup
// Enable the peripheral clock of GPIO Port
SPIx_GPIO_CLK_ENABLE();
// Configure the SPI SCK pin
LL_GPIO_SetPinMode(SPI_CJ125_SCK_PORT, SPI_CJ125_SCK_PIN, LL_GPIO_MODE_ALTERNATE);
LL_GPIO_SetAFPin_8_15(SPI_CJ125_SCK_PORT, SPI_CJ125_SCK_PIN, LL_GPIO_AF_5);
LL_GPIO_SetPinSpeed(SPI_CJ125_SCK_PORT, SPI_CJ125_SCK_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinPull(SPI_CJ125_SCK_PORT, SPI_CJ125_SCK_PIN, LL_GPIO_PULL_DOWN);
// Configure the SPI MISO pin
LL_GPIO_SetPinMode(SPI_CJ125_MISO_PORT, SPI_CJ125_MISO_PIN, LL_GPIO_MODE_ALTERNATE);
LL_GPIO_SetAFPin_8_15(SPI_CJ125_MISO_PORT, SPI_CJ125_MISO_PIN, LL_GPIO_AF_5);
LL_GPIO_SetPinSpeed(SPI_CJ125_MISO_PORT, SPI_CJ125_MISO_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinPull(SPI_CJ125_MISO_PORT, SPI_CJ125_MISO_PIN, LL_GPIO_PULL_DOWN);
// Configure the SPI MOSI pin
LL_GPIO_SetPinMode(SPI_CJ125_MOSI_PORT, SPI_CJ125_MOSI_PIN, LL_GPIO_MODE_ALTERNATE);
LL_GPIO_SetAFPin_8_15(SPI_CJ125_MOSI_PORT, SPI_CJ125_MOSI_PIN, LL_GPIO_AF_5);
LL_GPIO_SetPinSpeed(SPI_CJ125_MOSI_PORT, SPI_CJ125_MOSI_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinPull(SPI_CJ125_MOSI_PORT, SPI_CJ125_MOSI_PIN, LL_GPIO_PULL_DOWN);
// Configure the SPI Select pin
LL_GPIO_SetPinMode(SPI_CJ125_SEL_PORT, SPI_CJ125_SEL_PIN, LL_GPIO_MODE_ALTERNATE);
LL_GPIO_SetAFPin_8_15(SPI_CJ125_SEL_PORT, SPI_CJ125_SEL_PIN, LL_GPIO_AF_5);
LL_GPIO_SetPinSpeed(SPI_CJ125_SEL_PORT, SPI_CJ125_SEL_PIN, LL_GPIO_SPEED_FREQ_HIGH);
LL_GPIO_SetPinPull(SPI_CJ125_SEL_PORT, SPI_CJ125_SEL_PIN, LL_GPIO_PULL_DOWN);
//----
// LED initialization
MODIFY_REG(GPIOA->MODER, GPIO_MODER_MODE8, GPIO_MODER_MODE8_0);
MODIFY_REG(GPIOC->MODER, GPIO_MODER_MODE9, GPIO_MODER_MODE9_0);
```

}

main.c Page 1 of 8

```
* @file main.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 May 27
 * @brief Runs overall control for the CJ125 and LSU4.9 sensor.
 ^{\star} This program uses the values provided by the CJ125 to maintain the temperature of
 ^{\star} the LSU4.9 sensor. It utilizes the calibration values seen by the CJ125 to generate a
 ^{\star} lookup table for both Lambda and Temperature values. This removes the need for
 * hard-coding a lookup table, at the expense of speed. This, however, results in more
 * accurate readings and control.
#include "stm3214xx.h"
#include "stm3214xx_ll_rcc.h"
#include "stm3214xx_11_system.h"
#include "stm3214xx_11_utils.h"
#include "arm_math.h"
#include <math.h>
#include "hw_map.h"
#include "adc.h"
#include "dac.h"
#include "pwm.h"
#include "usart.h"
#include "spi.h"
#include "cj125.h"
void Initialize_Heater(void);
void SystemClock_Config(void);
void Generate_Lookup_Tables(void);
/**
* @brief ADC values array.
 * Array index pertains to: @n
 * 0: Internal 3V3 reference @n
 * 1: Battery voltage @n
 * 2: Lambda value from CJ125 @n
 * 3: Sensor resistance from CJ125 @n
 * 4: Current sense
 */
uint16_t adc_vals[5] = \{0, 0, 0, 0, 0\};
* @brief Lookup table for lambda values.
 * Values are calculated and inserted into array based on all possible ADC values.
uint16_t lambda_Lookup[4096];
/**
 * @brief Lookup table for temperature values.
 * Values are calculated and inserted into array based on all possible ADC values.
uint16_t temp_Lookup[4096];
 * @brief The optimal ADC resistance value the CJ125 outputs during calibration.
^{\star} This value is used to generate the temperature lookup table and as the control for the PID.
uint16_t optimal_resistance;
 ^{\star} @brief The optimal ADC resistance value the CJ125 outputs during calibration.
```

```
* This value is used to generate the lambda lookup table.
uint16_t optimal_lambda;
 * @brief The current voltage the PWM signal is using.
 * Used as a reference during the PID control of the PWM signal
uint32_t currentV;
/**
* @brief Internal reference voltage of STM32.
 * This calculation is highlighted on page 583 of the RM0351 Reference Manual.
* /
uint32_t VDDA;
/**
 * @def CONDENSATION
 * @brief Sensor resistance once condensation point has been reached.
 * This value represents the resistance of the actual sensor as it heats up. The higher
 ^{\star} the resistance, the hotter the sensor.
 */
#define CONDENSATION 3900
/**
* @def Kp
 * @brief Proportional coefficient for the PID controller.
 * The proportional control is proportional to the error between the desired sensor
 ^{\star} resistance and the current resistance.
#define Kp 60
/**
 * @def Ki
 * @brief Integral coefficient for the PID controller.
 * The integral control is used to overcome steady state error for the P control. @n
 * In general the integral component is used for accumulating the running errors until the system
 stabilizes.
 */
#define Ki 0.8
/**
* @def Kd
* @brief Derivative coefficient for the PID controller.
 ^{\star} The derivative control is used to prevent overshoot from the P control. @n
 * In general the derivative component is used to prevent the system from overshooting the desire
d result.
 */
#define Kd 0
 * @def PREAMBLE
 * @brief Preamble signifies the start of a UART transmission.
#define PREAMBLE 0xFFFF
 * @def Vbat3V3
 * @brief Actual measured value for the 3V3 line on the PCB.
* This value is required to make acurate readings of the battery voltage.
 */
#define Vbat3V3 3286
 * @brief Main program entrypoint.
```

```
* @return Should not return.
int main (void)
   uint8_t i = 0;
   uint16_t response = 0;
   uint16_t lambda, lambda_adc, temp, temp_adc;
    int16_t derivative, error, change;
    int16_t integral = 0;
    int16_t last_error = 0;
   uint32_t desiredV, Vbat;
    //uint64_t t1, t2, diff; // Only used for timing
    float pwm_duty_cycle;
    // Initialize the GPIO pins
   HW_Init_GPIO();
    // Config the system clock to 8MHz
    SystemClock_Config();
    // Initialize ADC on channels 0, 8, 11, 12, and 16
    Init_ADC(0x11901, (uint16_t *)adc_vals, 5);
    // Initialize DAC
    Init_DAC();
    // Initialize PWM with duty cycle of 0%
    Init_PWM();
    // Initialize USART connection to external device
    Init_USART();
    // Initialize SPI connection to CJ125
    Init_SPI();
    // Determine actual value of the 3.3V the STM is using.
   LL_mDelay(500);
     _disable_irq();
    VDDA = VREFINT_CAL_VREF* (*VREFINT_CAL_ADDR) / adc_vals[0];
    __enable_irq();
    // Enable cycle counter; Used for timing
    //CoreDebug->DEMCR |= CoreDebug_DEMCR_TRCENA_Msk;
    //DWT->CYCCNT = 0;
    //DWT->CTRL |= DWT_CTRL_CYCCNTENA_Msk;
    // Loop until CJ125 is ready. When CJ125 responds OK move on.
    while (response != CJ125_DIAG_REG_OK) {
        response = SPI_Transfer(CJ125_DIAG_REG);
        LL_mDelay(200);
    }
    // Enter CJ125 calibration mode
    response = SPI_Transfer(CJ125_CALIBRATE_MODE);
    // Delay to allow CJ125 to properly calibrate
    LL_mDelay(2000);
    // Store optimal resistance the CJ125 sees for the sensor
    do {
         _disable_irq();
        optimal_resistance = adc_vals[3];
         _enable_irq();
    } while (optimal_resistance > 830 | optimal_resistance < 780);</pre>
    // Store optimal lambda the CJ125 sees for the sensor
    do {
         _disable_irq();
        optimal_lambda = adc_vals[2];
         _enable_irq();
    } while (optimal_lambda > 1300 || optimal_lambda < 1100);</pre>
    // Set CJ125 into normal operation mode with an amplification of 8
    response = SPI_Transfer(CJ125_V8_MODE);
    //response = SPI_Transfer(CJ125_V17_MODE);
    // Set t1 to how many clock cycles have gone by
```

main.c Page 4 of 8

```
//t1 = DWT->CYCCNT;
// Initialize heater before using it
Initialize_Heater();
// Set t2 to how many clock cycles have gone by
//t2 = DWT->CYCCNT;
// Determine the amount of time passed since start
//diff = t2-t1;
// Continuous loop to read in values from CJ125, adjust heater, and output data.
while(1) {
    // Read lambda and temp values from CJ125
     _disable_irq();
    lambda_adc = adc_vals[2];
    temp_adc = adc_vals[3];
    __enable_irq();
    // Find lambda and temp values in lookup table
    lambda = lambda_Lookup[lambda_adc];
    temp = temp_Lookup[temp_adc];
    // Output lambda value via DAC
    // Contract specification only calls for 0.65 to 1.36, so all other values are capped
    if (lambda >= 650 && lambda < 1360) {
        DAC_SetValue((lambda-650)*4096/710);
    } else if (lambda >= 1360) {
        DAC_SetValue(4095);
    } else if (lambda < 650) {</pre>
        DAC_SetValue(0);
    // Determine battery voltage
     _disable_irq();
    Vbat = (adc_vals[1] * Vbat3V3 / 4096) * 955 / 187;
    __enable_irq();
    // Determine error between desired value and current value
    error = optimal_resistance - temp_adc;
    // Set integral term
    integral = integral + error;
    // Set derivative term
    derivative = error - last_error;
    // Calculate desired change to result in 0 error
    change = (Kp * error) + (Ki * integral) + (Kd * derivative);
    // Set current error to last error for next loop through
    last_error = error;
    // Set voltage based on desired change
    if (currentV - change > Vbat) {
        desiredV = Vbat;
    } else if (currentV - change < 0) {</pre>
        desiredV = 0;
    } else {
        desiredV = currentV - change;
    // Transmit over UART every 200 \, \mathrm{ms}
    if (i == 20) {
        // Turn on LED before UART Transmit
        SET_BIT(GPIOC->ODR, GPIO_ODR_OD9_Msk);
        // Transmit preamble before data
        USART_Transmit((uint8_t *)PREAMBLE, 2);
        // Transmit lambda value over UART
        USART_Transmit((uint8_t *)(&lambda), 2);
```

main.c Page 5 of 8

```
// Transmit temperature value over UART
            USART_Transmit((uint8_t *)(&temp), 2);
            // Transmit Current PWM voltage
            USART_Transmit((uint8_t *)(&desiredV), 2);
            // Turn off LED after UART transmission
            CLEAR_BIT(GPIOC->ODR, GPIO_ODR_OD9_Msk);
            i = 0;
       }
        // Calculate PWM duty cycle
        pwm_duty_cycle = pow((float)desiredV / Vbat, 2);
        //pwm_duty_cycle = pow((float)2000 / Vbat, 2);
        // Adjust PWM signal for heater so it stays at 780C
        LL_TIM_OC_SetCompareCH2(PWMx_BASE, LL_TIM_GetAutoReload(PWMx_BASE)*pwm_duty_cycle);
       i++;
       // Delay 10ms
       LL_mDelay(10);
}
* @brief System Clock Configuration.
\mbox{\ensuremath{^{\star}}} The system Clock is configured as follows :
     System Clock source = PLL (MSI)
                                                     @n
     SYSCLK (Hz)
                                     = 80000000
     HCLK (Hz)
                                     = 80000000
                                                     @n
     AHB Prescaler
                                     = 1
                                                     0 n
     APB1 Prescaler
                                    = 1
                                                     ۵n
     APB2 Prescaler
                                    = 1
                                                    @n
                                    = 4000000
     MSI Frequency(Hz)
    PLL_M
                                     = 1
                                                    @n
     PLL_N
                                     = 40
                                                    @n
                                     = 2
                                                     @n
     PLL_R
     Flash Latency (WS)
                                     = 4
* @retval None
void SystemClock_Config(void) {
   // MSI configuration and activation
   LL_FLASH_SetLatency(LL_FLASH_LATENCY_4);
   LL_RCC_MSI_Enable();
   while(LL_RCC_MSI_IsReady() != 1);
    // Main PLL configuration and activation
   LL_RCC_PLL_ConfigDomain_SYS(LL_RCC_PLLSOURCE_MSI, LL_RCC_PLLM_DIV_1, 4, LL_RCC_PLLR_DIV_2);
   LL_RCC_PLL_Enable();
   LL_RCC_PLL_EnableDomain_SYS();
   while(LL_RCC_PLL_IsReady() != 1);
    // Sysclk activation on the main PLL
   LL_RCC_SetAHBPrescaler(LL_RCC_SYSCLK_DIV_1);
   LL_RCC_SetSysClkSource(LL_RCC_SYS_CLKSOURCE_PLL);
   while(LL_RCC_GetSysClkSource() != LL_RCC_SYS_CLKSOURCE_STATUS_PLL);
    // Set APB1 & APB2 prescaler
   LL_RCC_SetAPB1Prescaler(LL_RCC_APB1_DIV_1);
   LL_RCC_SetAPB2Prescaler(LL_RCC_APB2_DIV_1);
    // Set systick to 1ms in using frequency set to 80MHz
   LL_Init1msTick(8000000);
    // Update CMSIS variable
   LL_SetSystemCoreClock(8000000);
}
 * @brief Heater initialization routine
```

```
* Initializes heater to a starting voltage of less than 2V during the condensation phase.
 * Once past condensation phase heater voltage is ramped up at a rate of 0.4V/s until
 * reaching a maximum of 13V. This is highlighted in section 1.6 of the LSU 4.9 manual.
 * @retval None
 */
void Initialize_Heater(void) {
    int i = 0;
    float pwm_duty_cycle;
    uint16_t CurADC, VbatADC, UR;
    uint16_t maxCurADC = 0;
    uint32_t Vbat, maxCur, res;
    // Warm up heater, supply <= 2V to heater until out of condensation phase
    // Uses the current sense value to determine when condensation phase is over
        // Calculate the battery voltage from the ADC
         __disable_irq();
        Vbat = (adc_vals[1] * Vbat3V3 / 4096) * 955 / 187;
        __enable_irq();
        // Set initial "warm-up" voltage to 2V
        currentV = 2000;
        // Calculate PWM duty cycle using equation found in LSU 4.9 manual
        pwm_duty_cycle = pow((float)currentV / Vbat, 2);
        // Set PWM signal to equivalent of 2Vrms
        LL_TIM_OC_SetCompareCH2(PWMx_BASE, LL_TIM_GetAutoReload(PWMx_BASE)*pwm_duty_cycle);
        // Sample current sense ADC to determine the maximum value
        for (i= 0; i < 50; i++) {
             _disable_irq();
            CurADC = adc_vals[4];
             _enable_irq();
            if (CurADC > maxCurADC) {
                maxCurADC = CurADC;
                __disable_irq();
                VbatADC = adc_vals[1];
                __enable_irq();
            // Delay 10ms
            LL_mDelay(10);
        }
        // Determine the actual current based on ADC values
        maxCur = (maxCurADC * VDDA / 4096);
        // Determine the actual voltage at highest ADC value
        Vbat = (VbatADC * Vbat3V3 / 4096) * 955 / 187;
        // Determine sensor resisitance
        res = Vbat * 7 * 50 / maxCur - 23;
        // Reset max current value for next loop through
        maxCurADC = 0;
        // Delay for 500ms
        LL_mDelay(50);
    } while (res < CONDENSATION);</pre>
    // Generate lookup tables for both lambda and temperature values
    Generate_Lookup_Tables();
    //currentV = 8500;
    \ensuremath{//} Ramp up voltage at a rate of
    i = 0;
    do {
        // Get the current battery voltage
         _disable_irq();
        Vbat = (adc_vals[1] * Vbat3V3 / 4096) * 955 / 187;
```

main.c Page 7 of 8

```
__enable_irq();
        // Transmit over UART every 200ms
        if (i == 40) {
            // Turn on LED before UART Transmit
            SET_BIT(GPIOC->ODR, GPIO_ODR_OD9_Msk);
            // Transmit preamble before data
            USART_Transmit((uint8_t *)PREAMBLE, 2);
            // Transmit lambda value over UART
            USART_Transmit((uint8_t *)(&lambda_Lookup[optimal_lambda]), 2);
            // Transmit temperature value over UART
            USART_Transmit((uint8_t *)(&temp_Lookup[optimal_resistance]), 2);
            // Transmit Current PWM voltage
            USART_Transmit((uint8_t *)(&currentV), 2);
            // Turn off LED after UART transmission
            CLEAR_BIT(GPIOC->ODR, GPIO_ODR_OD9_Msk);
            i = 0;
        }
        // Calculate duty cycle, equation from LSU 4.9 datasheet
        pwm_duty_cycle = pow((float)currentV / Vbat, 2);
        // Set PWM signal to equivalent of ramp up voltage RMS
        LL_TIM_OC_SetCompareCH2(PWMx_BASE, LL_TIM_GetAutoReload(PWMx_BASE)*pwm_duty_cycle);
        // Read resistance value of sensor; Won't be valid till 780C is hit
         _disable_irq();
        UR = adc_vals[3];
         _enable_irq();
        // Ramp up voltage by 200mV/s
        currentV += 1;
        // Delay 5ms
       LL_mDelay(5);
    } while (currentV < 11000 && UR > optimal_resistance);
}
/**
^{\star} @brief Generates lookup tables for lambda and temperature values
* Equations were determined by applying best fit curves to plots present in
  the LSU4.9 manual. @n
 * MATLAB was used to fit the plots.
* @retval None
*/
void Generate_Lookup_Tables(void) {
   uint16_t i;
   int32_t uacal, ua, urcal, ur, lambda, temp;
   float ip, o2, ri;
    // Determine resistance calibration value for calculations further on
   ur = optimal_resistance * VDDA * (365 + 187) / 365 / 4096;
   urcal = -((15.5 * 0.000158 * 301) * 1000 - ur) * 17;
   // Determine lambda calibration value for calculations further on
   uacal = optimal_lambda * VDDA * (365 + 187) / 365 / 4096;
   for (i = 0; i < 4096; i++) {
        // Calculate the Lambda value
        ua = i * VDDA * (365 + 187) / 365 / 4096;
        ip = (ua - uacal) * 1000 / (61.9 * 8); // / 1000;
        o2 = ip * 0.2095 / 2540;
        lambda = (o2 / 3 + 1) / (1 - 4.77 * o2) * 1000;
```

main.c Page 8 of 8

```
//lambda = (492.3 * exp(-pow((ip - 3.869) / 0.772, 2)) + 2.183 * exp(-pow((ip - 2.288) / 2.1
0.714,\ 2))\ +\ 1.09\ *\ \exp(-pow((ip\ -\ 2.8)\ /\ 6.656,\ 2))\ +\ 1.011\ *\ \exp(-pow((ip\ -\ 1.697)\ /\ 1.112,\ 2)))
) * 1000;
                                     lambda = 10119;
                                     // Set lambda lookup table value
                                     lambda_Lookup[i] = lambda;
                                     \ensuremath{//} Calculate the temperature value
                                     ur = i * VDDA * (365 + 187) / 365 / 4096;
ri = (ur - urcal / 17) / (15.5 * 0.158);
                                     temp = 4445 * pow(ri, -0.4449) + 428.6;
                                     if (temp >= 7049 | temp <= 0) {
                                                       temp = 7049;
                                     // Set temperature lookup table value
                                     temp_Lookup[i] = temp;
                 }
}
```

```
* @file pwm.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 September 9
 * @brief Provides basic PWM functionality
*/
#include "pwm.h"
* @brief Current state of the PWM signal; 1: high, 0: low.
 * Value is set during PWM interrupts.
*/
uint8_t pwm_state = 0;
/* Initialize PWM */
void Init_PWM(void)
{
    // Enable PWM interrupts
   NVIC_SetPriority(PWMx_IRQ, 2);
   NVIC_EnableIRQ(PWMx_IRQ);
    // Set the pre-scaler value
    LL_TIM_SetPrescaler(PWMx_BASE, __LL_TIM_CALC_PSC(SystemCoreClock, 100000));
    // Set the auto-reload value to have a counter frequency of 100 Hz
   LL_TIM_SetAutoReload(PWMx_BASE, __LL_TIM_CALC_ARR(SystemCoreClock, LL_TIM_GetPrescaler(PWMx_B
ASE), 100));
    // Set output mode
   LL_TIM_OC_SetMode(PWMx_BASE, PWMx_CHANNEL, LL_TIM_OCMODE_PWM1);
    LL_TIM_OC_SetMode(PWMx_BASE, PWMx_IRQ_CHANNEL, LL_TIM_OCMODE_PWM1);
    // Set external trigger to output on Capture/Compare Output Channel 1
   LL_TIM_SetTriggerOutput(PWMx_BASE, LL_TIM_TRGO_OC1REF);
    // Set compare value have a 0% duty cycle
    LL_TIM_OC_SetCompareCH2(PWMx_BASE, 0);
    LL_TIM_OC_SetCompareCH1(PWMx_BASE, 1);
    // Enable PWM register preload.
    LL_TIM_OC_EnablePreload(PWMx_BASE, PWMx_CHANNEL);
    LL_TIM_OC_EnablePreload(PWMx_BASE, PWMx_IRQ_CHANNEL);
    // Enable output channel
    LL_TIM_CC_EnableChannel(PWMx_BASE, PWMx_CHANNEL);
   LL_TIM_CC_EnableChannel(PWMx_BASE, PWMx_IRQ_CHANNEL);
    // Enable outputs
   LL_TIM_EnableAllOutputs(PWMx_BASE);
    // Enable the interrupts
   LL_TIM_EnableIT_CC1 (PWMx_BASE);
   LL_TIM_EnableIT_CC2 (PWMx_BASE);
    // Enable counter
    LL_TIM_EnableCounter(PWMx_BASE);
    // Force update generation
   LL_TIM_GenerateEvent_UPDATE(PWMx_BASE);
}
/* Callback for Compare/Capture 1 Interrupt */
void TimerCC1_Callback(void) {
    // Turn on LED
    SET_BIT(GPIOA->ODR, GPIO_ODR_OD8_Msk);
```

/* Callback for Compare/Capture 2 Interrupt */

pwm.c Page 2 of 2

```
void TimerCC2_Callback(void) {
    // Turn off LED
    CLEAR_BIT(GPIOA->ODR, GPIO_ODR_OD8_Msk);
}
```

spi.c Page 1 of 2

```
* @file spi.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 July 15
 * @brief Provides basic SPI functionality
 */
#include "spi.h"
/* Inialize the SPI interface */
void Init_SPI(void)
    // Enable the clock for the SPI
    SPIx_CLK_ENABLE();
    // Configure the SPI interface
   LL_SPI_SetBaudRatePrescaler(SPI_CJ125_BASE, LL_SPI_BAUDRATEPRESCALER_DIV256);
    LL_SPI_SetTransferDirection(SPI_CJ125_BASE, LL_SPI_FULL_DUPLEX);
    LL_SPI_SetClockPhase(SPI_CJ125_BASE, LL_SPI_PHASE_2EDGE);
    LL_SPI_SetClockPolarity(SPI_CJ125_BASE, LL_SPI_POLARITY_LOW);
   LL_SPI_SetDataWidth(SPI_CJ125_BASE, LL_SPI_DATAWIDTH_8BIT);
   LL_SPI_SetNSSMode(SPI_CJ125_BASE, LL_SPI_NSS_SOFT);
    LL_SPI_SetRxFIFOThreshold(SPI_CJ125_BASE, LL_SPI_RX_FIFO_TH_QUARTER);
    LL_SPI_SetMode(SPI_CJ125_BASE, LL_SPI_MODE_MASTER);
    // Enable the SPI interface
   LL_SPI_Enable(SPI_CJ125_BASE);
    // Enable select line
   MODIFY_REG(GPIOB->MODER, GPIO_MODER_MODE12, GPIO_MODER_MODE12_0);
    // Enable reset line
   MODIFY_REG(GPIOC->MODER, GPIO_MODER_MODE6, GPIO_MODER_MODE6_0);
    // Set SPI reset line high
    SET_BIT(GPIOC->ODR, GPIO_ODR_OD6_Msk);
}
/* Complete an SPI transfer */
uint16_t SPI_Transfer(uint16_t send)
{
   uint16_t recv;
    //int i;
    // Set SPI select line low
    CLEAR_BIT(GPIOB->ODR, GPIO_ODR_OD12_Msk);
    //for (i = 0; i < send_size; i++) {
        // Wait for TX buffer to be empty
        while(!LL_SPI_IsActiveFlag_TXE(SPI_CJ125_BASE));
        // Reverse byte order
        send = ((send << 8) & 0xff00) | ((send >> 8) & 0x00ff);
        // Transmit a byte
        LL_SPI_TransmitData16(SPI_CJ125_BASE, send);
        // Wait for transmit to finish
        while (SPI_CJ125_BASE->SR & SPI_SR_BSY);
    //for (i = 0; i < recv_size; i++) {
        // Wait for TX buffer to be empty
        while(!LL_SPI_IsActiveFlag_TXE(SPI_CJ125_BASE));
        // Receive a byte
        recv = LL_SPI_ReceiveData16(SPI_CJ125_BASE);
        // Reverse byte order
        recv = ((recv << 8) & 0xff00) | ((recv >> 8) & 0x00ff);
        // Wait for transmit to finish
        while (SPI_CJ125_BASE->SR & SPI_SR_BSY);
    //}
    // Set SPI select line high
```

```
spi.c Page 2 of 2
```

```
SET_BIT(GPIOB->ODR, GPIO_ODR_OD12_Msk);
return recv;
}
```

stm3214xx_it.c Page 1 of 2

```
* @file stm3214xx_it.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @brief Interrupt setup for STM32L4xx
 * @date 2018-11-27
* /
#include "stm3214xx.h"
#include "hw_map.h"
#include "adc.h"
#include "spi.h"
#include "pwm.h"
/* This function handles NMI exceptions */
void NMI_Handler(void) {
}
/* This function handles Hard Fault exceptions */
void HardFault_Handler(void) {
    // Enter an infinite loop
    while (1);
}
/* This function handles Memory Manage exceptions */
void MemManage_Handler(void) {
    // Enter an infinite loop
   while (1);
/* This function handles Bus Fault exceptions */
void BusFault_Handler(void) {
    // Enter an infinite loop
    while (1);
}
/* This function handles Fault exceptions */
void UsageFault_Handler(void) {
    // Enter an infinite loop
    while (1);
/* This function handles SVCall exceptions */
void SVC_Handler(void) {
/* This function handles Debug Monitor exceptions */
void DebugMon_Handler(void) {
/* This function handles PendSVC exceptions */
void PendSV_Handler(void) {
/* This function handles SysTick Handlers */
void SysTick_Handler(void) {
}
/* This function handles ADC1 interrupt requests */
void ADC1_2_IRQHandler(void) {
    // Check if the interupt is end of conversion
    if (LL_ADC_IsActiveFlag_EOS(ADCx_BASE) != 0) {
        // Clear the end of conversion flag
        LL_ADC_ClearFlag_EOS (ADCx_BASE);
        // Call the ADC conversion complete callback
        ADC_ConvComplete_Callback();
    // Check if the interupt is overrun
    if (LL_ADC_IsActiveFlag_OVR(ADCx_BASE) != 0) {
```

stm3214xx_it.c Page 2 of 2

```
// Clear the ADC overrun flag
       LL_ADC_ClearFlag_OVR(ADCx_BASE);
        // Call the ADC conversion complete callback
       ADC_OverrunError_Callback();
    }
}
/* This function handles DMA1 interrupts requests */
void DMA1_Channel1_IRQHandler(void) {
    // Check if the DMA transfer is complete
    if (LL_DMA_IsActiveFlag_TC1(DMAx_BASE) == 1) {
        // Clear the DMA interupt flag
       LL_DMA_ClearFlag_GI1(DMAx_BASE);
        // Call the DMA transfer complete callback
       ADC_DMA_TransferComplete_Callback();
    }
    // Check if the DMA transfer casused an error
    if (LL_DMA_IsActiveFlag_TE1(DMAx_BASE) == 1) {
        // Clear the DMA error flag
       LL_DMA_ClearFlag_TE1(DMAx_BASE);
       // Call the DMA transfer error callback
       ADC_DMA_TransferError_Callback();
}
/* This function handles TIM8 interrupt. */
void TIM8_CC_IRQHandler(void) {
    // Check whether CC1 interrupt is pending
   if(LL_TIM_IsActiveFlag_CC1(PWMx_BASE) == 1) {
        // Clear the update interrupt flag
       LL_TIM_ClearFlag_CC1(PWMx_BASE);
        // Timer capture/compare interrupt processing(function defined in main.c)
        TimerCC1_Callback();
    }
    // Check whether CC2 interrupt is pending
    if(LL_TIM_IsActiveFlag_CC2(PWMx_BASE) == 1) {
        // Clear the update interrupt flag
       LL_TIM_ClearFlag_CC2 (PWMx_BASE);
        // Timer capture/compare interrupt processing(function defined in main.c)
       TimerCC2_Callback();
   }
}
```

* @file system_stm3214xx.c * @author MCD Application Team * @brief CMSIS Cortex-M4 Device Peripheral Access Layer System Source File This file provides two functions and one global variable to be called from user application: - SystemInit(): This function is called at startup just after reset and before branch to main program. This call is made inside the "startup_stm3214xx.s" file. - SystemCoreClock variable: Contains the core clock (HCLK), it can be used by the user application to setup the SysTick timer or configure other parameters. - SystemCoreClockUpdate(): Updates the variable SystemCoreClock and must be called whenever the core clock is changed during program execution. After each device reset the MSI (4 MHz) is used as system clock source. Then SystemInit() function is called, in "startup_stm3214xx.s" file, to configure the system clock before to branch to main program. This file configures the system clock as follows: MSI System Clock source 4000000 SYSCLK (Hz) 4000000 HCLK(Hz) AHB Prescaler | 1 | 1 APB1 Prescaler APB2 Prescaler | 1 PLL M 8 | 7 PLL_P | 2 2 PLL_R NA PLLSAI1_P PLLSAI1_Q NA NA PLLSAI1_R NA PLLSAI2_P NA PLLSAI2 O PLLSAI2_R Disabled Require 48MHz for USB OTG FS, SDIO and RNG clock * @attention * <h2><center>© COPYRIGHT(c) 2017 STMicroelectronics</center></h2> * Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

```
1. Redistributions of source code must retain the above copyright notice,
        this list of conditions and the following disclaimer.
     2. Redistributions in binary form must reproduce the above copyright notice,
        this list of conditions and the following disclaimer in the documentation
        and/or other materials provided with the distribution.
     3. Neither the name of STMicroelectronics nor the names of its contributors
        may be used to endorse or promote products derived from this software
        without specific prior written permission.
 * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS"
 * AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
 * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE
 * DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE
 * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
  * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR
 * SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER
 * CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY,
 * OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE
 * OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
 *******************
 */
/** @addtogroup CMSIS
 * @ {
 */
/** @addtogroup stm3214xx_system
 */
/** @addtogroup STM32L4xx_System_Private_Includes
 */
#include "stm3214xx.h"
#if !defined (HSE_VALUE)
  #define HSE_VALUE ((uint32_t)8000000) /*!< Value of the External oscillator in Hz */
#endif /* HSE_VALUE */
#if !defined (MSI_VALUE)
 \#define MSI_VALUE ((uint32_t)4000000) /*!< Value of the Internal oscillator in Hz*/
#endif /* MSI_VALUE */
#if !defined (HSI_VALUE)
 #define HSI_VALUE ((uint32_t)16000000) /*! < Value of the Internal oscillator in Hz*/
#endif /* HSI_VALUE */
/**
 * @}
 */
/** @addtogroup STM32L4xx_System_Private_TypesDefinitions
 * @ {
 */
 * @ }
/** @addtogroup STM32L4xx_System_Private_Defines
 * @{
 */
/************************* Miscellaneous Configuration *********************/
/*!< Uncomment the following line if you need to relocate your vector Table in
    Internal SRAM. */
/* #define VECT_TAB_SRAM */
#define VECT_TAB_OFFSET 0x00 /*! < Vector Table base offset field.
                                 This value must be a multiple of 0x200. */
/****************************
```

```
* @ }
  */
/** @addtogroup STM32L4xx_System_Private_Macros
 */
/**
 * @}
  */
/** @addtogroup STM32L4xx_System_Private_Variables
  /* The SystemCoreClock variable is updated in three ways:

    by calling CMSIS function SystemCoreClockUpdate()

      2) by calling HAL API function HAL_RCC_GetHCLKFreq()
      3) each time HAL_RCC_ClockConfig() is called to configure the system clock frequency
         Note: If you use this function to configure the system clock; then there
               is no need to call the 2 first functions listed above, since SystemCoreClock
               variable is updated automatically.
  */
  uint32_t SystemCoreClock = 4000000;
 const uint8_t AHBPrescTable[16] = {0, 0, 0, 0, 0, 0, 0, 0, 1, 2, 3, 4, 6, 7, 8, 9};
const uint8_t APBPrescTable[8] = {0, 0, 0, 0, 1, 2, 3, 4};
  const uint32_t MSIRangeTable[12] = {100000, 200000, 400000, 800000, 1000000, 2000000, \
                                       4000000, 8000000, 16000000, 24000000, 32000000, 48000000);
/**
 * @ }
  */
/** @addtogroup STM32L4xx_System_Private_FunctionPrototypes
  */
/**
 * @ }
/** @addtogroup STM32L4xx_System_Private_Functions
  * @ {
  */
/**
  ^{\star} @brief Setup the microcontroller system.
  * @param None
  * @retval None
void SystemInit(void)
  /* FPU settings -----*/
  #if (__FPU_PRESENT == 1) && (__FPU_USED == 1)
   SCB->CPACR = ((3UL << 10*2))(3UL << 11*2)); /* set CP10 and CP11 Full Access */
  #endif
  /* Reset the RCC clock configuration to the default reset state -----*/
  /* Set MSION bit */
  RCC->CR |= RCC_CR_MSION;
  /* Reset CFGR register */
  RCC \rightarrow CFGR = 0x000000000;
  /* Reset HSEON, CSSON , HSION, and PLLON bits */
  RCC->CR &= (uint32_t)0xEAF6FFFF;
  /* Reset PLLCFGR register */
  RCC - PLLCFGR = 0x00001000;
  /* Reset HSEBYP bit */
  RCC->CR &= (uint32_t)0xFFFBFFFF;
```

```
/* Disable all interrupts */
 RCC->CIER = 0x00000000;
  #ifdef VECT TAB SRAM
 SCB->VTOR = SRAM_BASE | VECT_TAB_OFFSET; /* Vector Table Relocation in Internal SRAM */
 SCB->VTOR = FLASH_BASE | VECT_TAB_OFFSET; /* Vector Table Relocation in Internal FLASH */
#endif
/**
 * @brief Update SystemCoreClock variable according to Clock Register Values.
           The SystemCoreClock variable contains the core clock (HCLK), it can
           be used by the user application to setup the SysTick timer or configure
           other parameters.
   @note
          Each time the core clock (HCLK) changes, this function must be called
           to update SystemCoreClock variable value. Otherwise, any configuration
           based on this variable will be incorrect.
   @note
           - The system frequency computed by this function is not the real
            frequency in the chip. It is calculated based on the predefined
             constant and the selected clock source:
             - If SYSCLK source is MSI, SystemCoreClock will contain the MSI_VALUE(*)
             - If SYSCLK source is HSI, SystemCoreClock will contain the HSI_VALUE(**)
             - If SYSCLK source is HSE, SystemCoreClock will contain the HSE_VALUE(***)
             - If SYSCLK source is PLL, SystemCoreClock will contain the HSE_VALUE(***)
               or {\tt HSI\_VALUE(*)} or {\tt MSI\_VALUE(*)} multiplied/divided by the PLL factors.
           (*) MSI_VALUE is a constant defined in stm3214xx_hal.h file (default value
               4 MHz) but the real value may vary depending on the variations
               in voltage and temperature.
           (**) HSI_VALUE is a constant defined in stm3214xx_hal.h file (default value
                16 MHz) but the real value may vary depending on the variations
                in voltage and temperature.
           (***) HSE_VALUE is a constant defined in stm3214xx_hal.h file (default value
                8 MHz), user has to ensure that HSE_VALUE is same as the real
                frequency of the crystal used. Otherwise, this function may
               have wrong result.
           - The result of this function could be not correct when using fractional
             value for HSE crystal.
 * @param None
 * @retval None
void SystemCoreClockUpdate(void)
 uint32_t tmp = 0, msirange = 0, pllvco = 0, pllr = 2, pllsource = 0, pllm = 2;
 /* Get MSI Range frequency-----*/
 if((RCC->CR & RCC_CR_MSIRGSEL) == RESET)
 { /* MSISRANGE from RCC_CSR applies */
   msirange = (RCC->CSR & RCC_CSR_MSISRANGE) >> 8;
 }
 else
 { /* MSIRANGE from RCC_CR applies */
   msirange = (RCC->CR & RCC_CR_MSIRANGE) >> 4;
 /*MSI frequency range in HZ*/
 msirange = MSIRangeTable[msirange];
 /* Get SYSCLK source -----*/
 switch (RCC->CFGR & RCC_CFGR_SWS)
```

```
system_stm3214xx.c
   case 0x00: /* MSI used as system clock source */
     SystemCoreClock = msirange;
     break;
   case 0x04: /* HSI used as system clock source */
     SystemCoreClock = HSI_VALUE;
   case 0x08: /* HSE used as system clock source */
     SystemCoreClock = HSE_VALUE;
     break;
   case 0x0C: /* PLL used as system clock source */
     /* PLL_VCO = (HSE_VALUE or HSI_VALUE or MSI_VALUE/ PLLM) * PLLN
        SYSCLK = PLL_VCO / PLLR
     pllsource = (RCC->PLLCFGR & RCC_PLLCFGR_PLLSRC);
     pllm = ((RCC->PLLCFGR & RCC_PLLCFGR_PLLM) >> 4) + 1;
     switch (pllsource)
       case 0x02: /* HSI used as PLL clock source */
         pllvco = (HSI_VALUE / pllm);
         break:
       case 0x03: /* HSE used as PLL clock source */
         pllvco = (HSE_VALUE / pllm);
         break;
                  /* MSI used as PLL clock source */
       default:
         pllvco = (msirange / pllm);
         break;
     pllvco = pllvco * ((RCC->PLLCFGR & RCC_PLLCFGR_PLLN) >> 8);
     pllr = (((RCC->PLLCFGR & RCC_PLLCFGR_PLLR) >> 25) + 1) * 2;
     SystemCoreClock = pllvco/pllr;
     break;
   default:
     SystemCoreClock = msirange;
     break;
 /* Compute HCLK clock frequency -----*/
 /* Get HCLK prescaler */
 tmp = AHBPrescTable[((RCC->CFGR & RCC_CFGR_HPRE) >> 4)];
  /* HCLK clock frequency */
 SystemCoreClock >>= tmp;
  * @ }
  * @ }
 * @ }
 */
```

/************************* (C) COPYRIGHT STMicroelectronics *****END OF FILE****/

usart.c Page 1 of 1

```
* @file usart.c
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 September 12
 * @brief Provides basic USART functionality.
*/
#include "usart.h"
/** @brief Send counter */
uint8_t ubSend = 0;
/* Initialize the USART */
void Init_USART(void) {
   // Set transfer direction (Tx/Rx)
   LL_USART_SetTransferDirection(USARTx_BASE, LL_USART_DIRECTION_TX_RX);
   // Set 8 data bits, 1 start bit, 1 stop bit, and no parity
   LL_USART_ConfigCharacter(USARTx_BASE, LL_USART_DATAWIDTH_8B, LL_USART_PARITY_NONE, LL_USART_S
TOPBITS_1);
   // Set baud rate
   LL_USART_SetBaudRate(USARTx_BASE, SystemCoreClock, LL_USART_OVERSAMPLING_16, 115200);
   // Enable USART
   LL_USART_Enable(USARTx_BASE);
   // Polling USART initialisation
   BASE))));
/* Transmit data */
void USART_Transmit(uint8_t *send, uint8_t size) {
    // Send characters one per one, until last char to be sent
   while (ubSend < size) {
     // Wait for TXE flag to be raised
     while (!LL_USART_IsActiveFlag_TXE(USARTx_BASE));
     // If last char to be sent, clear TC flag
     if (ubSend == (size - 1)) {
       LL_USART_ClearFlag_TC(USARTx_BASE);
     // Write character in Transmit Data register. TXE flag is cleared by writing data in TDR re
gister
     LL_USART_TransmitData8(USARTx_BASE, send[ubSend++]);
   // Wait for TC flag to be raised for last char
   while (!LL_USART_IsActiveFlag_TC(USARTx_BASE));
   // Transmission is over, reset send amount
   ubSend = 0;
}
```

```
* @file adc.h
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 July 15
 * @brief Provides ADC functionality
#ifndef ___ADC_H
#define ___ADC_H
#include "hw_map.h"
* @brief Initialize the ADC with DMA
 * Initialization of the desired channels is done by taking the reverse of
 ^{\star} the binary expansion of the channels.
 ^{\star} Which results in a hexidecimal number of 0x01908
 * @param channels ADC channels to read from
 * @param values Array to store ADC values
 ^{\star} @param numValues Number of values in values array
 * @retval None
void Init_ADC(uint32_t channels, uint16_t * values, int numValues);
 \star @brief DMA transfer complete callback
 * @note This function is executed when the transfer complete interrupt
          is generated
 * @retval None
void ADC_DMA_TransferComplete_Callback(void);
 * @brief DMA transfer error callback
 * @note
          This function is executed when the transfer error interrupt
           is generated during DMA transfer
  * @retval None
void ADC_DMA_TransferError_Callback(void);
/**
 * Obrief ADC group regular end of sequence conversions interruption callback
 ^{\star} @note This function is executed when the ADC group regular
          sequencer has converted all ranks of the sequence.
 * @retval None
void ADC_ConvComplete_Callback(void);
/**
 * @brief ADC group regular overrun interruption callback
  ^{\star} @note This function is executed when ADC group regular
           overrun error occurs.
  * @retval None
void ADC_OverrunError_Callback(void);
```

adc.h Page 2 of 2

 $\texttt{\#endif} \ // \ __\texttt{ADC}_\texttt{H}$

cj125.h Page 1 of 1

```
* @file cj125.h
* @author Kyle Bernier
* @author Daeghan Elkin
\star @brief Definitons for the CJ125 registers
* @date 2018-11-27
*/
/**
* @defgroup CJ125 CJ125 Register definitions
*/
/** @brief Register value for identification request */
#define CJ125_IDENT_REG
                              0x4800
/** @brief Register value for diagnostic request */
#define CJ125_DIAG_REG
                               0x7800
/** @brief Diagnostic response from CJ125: Ready */
#define CJ125_DIAG_REG_OK 0x28ff
/** @brief Diagnostic response from CJ125: No/Low power */
#define CJ125_DIAG_REG_NOPWR
                               0x2855
/** @brief Diagnostic response from CJ125: No sensor */
#define CJ125_DIAG_REG_NOSNSR 0x287f
/** @brief Register value for setting CJ125 into calibration mode */
#define CJ125_CALIBRATE_MODE
                              0x569d
/** @brief Register value for setting CJ125 into V=8 mode */
#define CJ125_V8_MODE
                              0x5688
/** @brief Register value for setting CJ125 into V=17 mode */
#define CJ125_V17_MODE
                              0x5689
/** @} */
```

dac.h Page 1 of 1

```
* @file dac.h
* @author Kyle Bernier
* @author Daeghan Elkin
* @date 2018 July 29
* @brief Provides basic DAC functionality
*/
#ifndef __DAC_H
#define __DAC_H
#include "hw_map.h"
/**
* @brief Initialize the DAC interface
* @retval None
int Init_DAC(void);
* @brief Adjust the DAC output value
^{\star} @param value Value to set the DAC output to
* @retval None
*/
void DAC_SetValue(uint32_t value);
\#endif // \__DAC_H
```

hw_map.h Page 1 of 4

```
/**
 * @file hw_map.h
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 July 15
 * @brief Maps hardware peripherals to board specific features
 ^{\star} Sets up definitions required for hardware peripherals.
 * Includes: ADC, DAC, DMA, PWM, UART, SPI
#ifndef ___HW_MAP_H
#define __HW_MAP_H
#include "stm3214xx_ll_gpio.h"
#include "stm3214xx_11_adc.h"
#include "stm3214xx_ll_dma.h"
#include "stm3214xx_l1_dac.h"
#include "stm3214xx_ll_tim.h"
#include "stm3214xx_ll_usart.h"
#include "stm3214xx_ll_rcc.h"
#include "stm3214xx_11_spi.h"
#include "stm3214xx_l1_bus.h"
/**
* @defgroup ADC ADC Definitions
/**
 * @def ADCx_BASE
 * @ingroup ADC
 * @brief ADC channel used for all.
#define ADCx_BASE ADC1
/**
 * @def ADCx_SAMPLERATE
 * @ingroup ADC
 * @brief ADC sample rate
#define ADCx_SAMPLERATE LL_ADC_SAMPLINGTIME_640CYCLES_5
/**
 * @def ADCx_IRQ
 * @ingroup ADC
 * @brief STM ADC interrupt
#define ADCx_IRQ ADC1_2_IRQn
 * @defgroup ADC_BAT ADC Battery Voltage Monitor
 * @ingroup ADC
 * @brief ADC channel used to monitor battery voltage
 ^{\star} These definitions are for the ADC that reads the current battery voltage.
 * @ {
/** @brief STM ADC GPIO Pin*/
#define ADC_BAT_GPIO_PIN LL_GPIO_PIN_3
/** @brief STM ADC GPIO Port*/
#define ADC_BAT_GPIO_PORT GPIOA
/** @brief STM ADC Channel*/
#define ADC_BAT_CHANNEL LL_ADC_CHANNEL_8
/** @} */
/**
 * @defgroup ADC_LMD ADC Lambda Value Monitor
 * @ingroup ADC
 * @brief ADC channel used to read lambda value
```

```
* These definitions are for the ADC that reads the lambda value from the CJ125.
/** @brief STM ADC GPIO Pin*/
#define ADC_LMD_GPIO_PIN LL_GPIO_PIN_6
/** @brief STM ADC GPIO Port*/
#define ADC_LMD_GPIO_PORT GPIOA
/** @brief STM ADC Channel*/
#define ADC_LMD_CHANNEL LL_ADC_CHANNEL_11
/** @} */
/**
 * @defgroup ADC_RES ADC Resistance Monitor
 * @ingroup ADC
 * @brief ADC channel used to read sensor resitance
 ^{\star} These definitions are for the ADC that reads the oxygen sensor resistance
 \star from the CJ125.
 * @ {
/** @brief STM ADC GPIO Pin */
#define ADC_RES_GPIO_PIN_LL_GPIO_PIN_7
/** @brief STM ADC GPIO Port */
#define ADC_RES_GPIO_PORT GPIOA
/** @brief STM ADC Channel */
#define ADC_RES_CHANNEL LL_ADC_CHANNEL_12
/** @} */
/**
* @defgroup ADC_CRNT ADC PWM Current Sense
 * @ingroup ADC
 * @brief ADC channel used to sense current
 * @ {
/** @brief STM ADC GPIO Pin */
#define ADC_CRNT_GPIO_PIN LL_GPIO_PIN_1
/** @brief STM ADC GPIO Port */
#define ADC_CRNT_GPIO_PORT GPIOB
/** @brief STM ADC Channel */
#define ADC_CRNT_CHANNEL LL_ADC_CHANNEL_16
/** @} */
/**
* @def ADCx_CLK_ENABLE()
 * @ingroup ADC
 * @brief ADC definition for enabling peripheral clock.
#define ADCx_CLK_ENABLE() LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_ADC)
/**
 * @defgroup DMA DMA Definitions
 * @defgroup DMA_ADC ADC DMA
 * @ingroup DMA
 * @{
/** @brief STM DMA */
#define DMAx_BASE DMA1
/** @brief STM DMA Channel */
#define DMAx_CHANNEL LL_DMA_CHANNEL_1
/** @brief DMA Interrupt */
#define DMAx_IRQ DMA1_Channel1_IRQn
/** @} */
 * @def DMAx_CLK_ENABLE()
```

hw_map.h Page 3 of 4

```
* @ingroup DMA
* @brief Enable DMA peripheral clock
#define DMAx_CLK_ENABLE() LL_AHB1_GRP1_EnableClock(LL_AHB1_GRP1_PERIPH_DMA1);
* @defgroup DAC DAC Definitions
/**
* @def DACx_BASE
* @ingroup DAC
* @brief STM DAC
#define DACx_BASE DAC1
/**
* @defgroup DAC_LMD DAC Lambda Output
* @ingroup DAC
* @ {
/** @brief STM DAC GPIO Pin */
#define DAC_LMD_GPIO_PIN LL_GPIO_PIN_5
/** @brief STM DAC GPIO Port */
#define DAC_LMD_GPIO_PORT GPIOA
/** @brief STM DAC Channel */
#define DAC_LMD_CHANNEL LL_DAC_CHANNEL_2
/** @} */
/**
* @defgroup DAC_CLK DAC Clock
* @ingroup DAC
* @{
*/
/** @brief Enable DAC peripheral clock */
#define DACx_CLK_ENABLE() LL_APB1_GRP1_EnableClock(LL_APB1_GRP1_PERIPH_DAC1)
/** @} */
\star @defgroup PWM PWM Definitions
* @{
/** @brief STM PWM timer */
#define PWMx_BASE TIM8
/** @brief STM PWM Timer channel */
#define PWMx_CHANNEL LL_TIM_CHANNEL_CH2
/** @brief STM PWM Timer Interrupt */
#define PWMx_IRQ TIM8_CC_IRQn
/** @brief STM PWM Interrupt channel */
#define PWMx_IRQ_CHANNEL LL_TIM_CHANNEL_CH1
/** @brief Enable PWM peripheral clock */
#define PWMx_CLK_ENABLE() LL_APB2_GRP1_EnableClock(LL_APB2_GRP1_PERIPH_TIM8)
/** @brief Enable GPIO clock */
#define PWMx_GPIO_CLK_ENABLE() LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOC)
/** @brief STM PWM GPIO Pin */
#define PWMx_GPIO_PIN LL_GPIO_PIN_7
/** @brief STM PWM GPIO Port */
#define PWMx_GPIO_PORT GPIOC
/** @brief Set PWM alternative function */
#define PWMx_SET_GPIO_AF() LL_GPIO_SetAFPin_0_7(GPIOC, LL_GPIO_PIN_7, LL_GPIO_AF_3)
/** @} */
* @defgroup USART USART Definitions
* @ {
/** @brief STM USART */
#define USARTx_BASE USART1
/** @brief Enable peripheral clock */
```

hw_map.h Page 4 of 4

```
#define USARTx_CLK_ENABLE() LL_APB2_GRP1_EnableClock(LL_APB2_GRP1_PERIPH_USART1)
/** @brief Set USART clock source */
#define USARTx_CLK_SOURCE() LL_RCC_SetUSARTClockSource(LL_RCC_USART1_CLKSOURCE_PCLK2)
/** @brief Enable GPIO clock */
#define USARTx_GPIO_CLK_ENABLE() LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOA)
/** @brief STM USART Transmit GPIO Pin */
#define USARTx_TX_PIN LL_GPIO_PIN_9
/** @brief STM USART Transmit GPIO Port */
#define USARTx_TX_GPIO_PORT GPIOA
/** @brief Set Transmit alternative function */
#define USARTx_SET_TX_GPIO_AF() LL_GPIO_SetAFPin_8_15(GPIOA, LL_GPIO_PIN_9, LL_GPIO_AF_7)
/** @brief STM USART Receive GPIO Pin */
#define USARTx_RX_PIN LL_GPIO_PIN_10
/** @brief STM USART Receive GPIO Port */
#define USARTx_RX_GPIO_PORT GPIOA
/** @brief Set Receive alternative function */
#define USARTx_SET_RX_GPIO_AF() LL_GPIO_SetAFPin_8_15(GPIOA, LL_GPIO_PIN_10, LL_GPIO_AF_7)
/** @} */
/**
* @defgroup SPI SPI Definitions
* @{
 */
/** @brief Enable GPIO clock */
#define SPIx_GPIO_CLK_ENABLE() LL_AHB2_GRP1_EnableClock(LL_AHB2_GRP1_PERIPH_GPIOB)
/** @brief Enable peripheral clock */
#define SPIx_CLK_ENABLE() LL_APB1_GRP1_EnableClock(LL_APB1_GRP1_PERIPH_SPI2);
/** @brief STM SPI */
#define SPI_CJ125_BASE SPI2
/** @brief STM SPI Clock GPIO Pin */
#define SPI_CJ125_SCK_PIN LL_GPIO_PIN_13
/** @brief STM SPI Clock GPIO Port */
#define SPI_CJ125_SCK_PORT GPIOB
/** @brief STM SPI MISO GPIO Pin */
#define SPI_CJ125_MISO_PIN LL_GPIO_PIN_14
/** @brief STM SPI MISO GPIO Port */
#define SPI_CJ125_MISO_PORT GPIOB
/** @brief STM SPI MOSI GPIO Pin */
#define SPI_CJ125_MOSI_PIN LL_GPIO_PIN_15
/** @brief STM SPI MOSI GPIO Port */
#define SPI_CJ125_MOSI_PORT GPIOB
/** @brief STM SPI Select GPIO Pin */
#define SPI_CJ125_SEL_PIN LL_GPIO_PIN_12
/** @brief STM SPI Select GPIO Port */
#define SPI_CJ125_SEL_PORT GPIOB
/** @} */
* @brief Initializes hardware required by peripherals
 * @retval None
void HW_Init_GPIO(void);
#endif // __HW_MAP_H
```

pwm.h Page 1 of 1

```
* @file pwm.h
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 September 9
 * @brief Provides basic PWM functionality
*/
#ifndef ___PWM_H
#define ___PWM_H
#include "hw_map.h"
* @brief Initialize PWM
^{\star} Sets up the PWM peripheral. The PWM has a counter rate of 100Hz.
^{\star} Because the PWM signal is used to control the sensor heater, it
 ^{\star} is initialized to a 0% duty cycle. The Timer for PWM is also used
 * to trigger ADC conversions so the Capture/Compare Channel 1 is set
 * accordingly.
 * @retval None
void Init_PWM(void);
* @brief This function handles timer Compare/Capture 1 interrupt.
* This handler simply turns on the LED on PA8.
 * @retval None
void TimerCC1_Callback(void);
/**
\star @brief This function handles timer Compare/Capture 2 interrupt.
 * This handler simply turns off the LED on PA8.
 * @retval None
 */
void TimerCC2_Callback(void);
#endif /* ___PWM_H */
```

spi.h Page 1 of 1

```
* @file spi.h
* @author Kyle Bernier
* @author Daeghan Elkin
* @date 2018 July 15
* @brief Provides basic SPI functionality
*/
#ifndef __SPI_H
#define __SPI_H
#include "hw_map.h"
/**
* @brief Initialize the SPI Interface
* @retval None
*/
void Init_SPI(void);
* @brief Complete an SPI Transfer
\star @param send Value to send
* @returns Received data
uint16_t SPI_Transfer(uint16_t send);
#endif // __SPI_H
```

stm3214xx_it.h Page 1 of 2

```
* @file stm3214xx_it.h
#ifndef ___STM32L4XX_IT_H
#define __STM32L4XX_IT_H
/**
 * @brief This function handles NMI exception.
* @retval None
void NMI_Handler(void);
 * @brief This function handles Hard Fault exception.
 * @retval None
void HardFault_Handler(void);
* @brief This function handles Memory Manage exception.
* @retval None
void MemManage_Handler(void);
/**
* @brief This function handles Bus Fault exception.
* @retval None
void BusFault_Handler(void);
/**
* @brief This function handles Usage Fault exception.
* @retval None
void UsageFault_Handler(void);
* @brief This function handles SVCall exception.
* @retval None
void SVC_Handler(void);
* @brief This function handles Debug Monitor exception.
* @retval None
void DebugMon_Handler(void);
\star @brief This function handles PendSVC exception.
* @retval None
void PendSV_Handler(void);
 * @brief This function handles SysTick Handler.
* @retval None
void SysTick_Handler(void);
 * @brief This function handles ADC1 interrupt request.
  * @retval None
void ADC1_2_IRQHandler(void);
  \mbox{\ensuremath{^{\star}}} @brief This function handles DMA1 interrupt request.
  * @retval None
```

stm3214xx_it.h Page 2 of 2

```
void DMA1_Channel1_IRQHandler(void);

/**
  * @brief This function handles TIM2 interrupt.
  * @retval None
  */
void TIM8_CC_IRQHandler(void);
#endif // __STM32L4XX_IT_H
```

usart.h Page 1 of 1

```
* @file usart.h
 * @author Kyle Bernier
 * @author Daeghan Elkin
 * @date 2018 September 12
 * @brief Provides basic USART functionality.
*/
#ifndef ___USART_H
#define ___USART_H
#include "hw_map.h"
/**
\star @brief Initializes the USART.
^{\star} The USART initialization sets the UART to a TX/RX transmisson.
 ^{\star} The UART has the typical 8 data, 1 start, and 1 stop bits with no parity.
 ^{\star} The baudrate for the UART is set to 115200.
 * @retval None
void Init_USART();
/**
\mbox{\ensuremath{\star}} @brief Transfers data over the transmit line.
 * The UART is set up to handle both transmit and receive, however,
 * nothing is done with the received data. The receive line is
 * available for future changes.
 ^{\star} @param send Array of desired send data
 * @param size Size of data array
 * @retval None
 */
void USART_Transmit(uint8_t *send, uint8_t size);
#endif /* __USART_H */
```

Makefile Page 1 of 2

```
# @file Makefile
# @author Kyle Bernier and Daeghan Elkin
# @date 2018 May 27
# @brief Makefile to compile STM32L4 project with dependencies
# System configuration
CC = arm-none-eabi-gcc
RM = rm - f
MKDIR = mkdir -p
# Hardware architecture
ARCH = STM32L475xx
ARCH_LOW = stm321475xx
# Assembler, Compiler and Linker flags and linker script settings
LINKER_FLAGS = -lm -mthumb -mhard-float -mcpu=cortex-m4 -mfpu=fpv4-sp-d16 -W1,--gc-sections -T$(L
INK_SCRIPT) -static -W1, --start-group -lc -lm -W1, --end-group -specs=nano.specs -specs=nosys.spec
S
LINK_SCRIPT = linker_script.ld
ASSEMBLER_FLAGS = -c -g -00 -mcpu=cortex-m4 -mfpu=fpv4-sp-d16 -mthumb -mhard-float -specs=nano.sp
ecs -D"$(ARCH)" -D"ARM_MATH_CM4" -D"__FPU_PRESENT" -x assembler-with-cpp $(INCLUDE_FLAGS)
COMPILER_FLAGS = -c -g -mcpu=cortex-m4 -mfpu=fpv4-sp-d16 -00 -Wall -ffunction-sections -fdata-sec
tions -mthumb -mhard-float -specs=nano.specs -D"$(ARCH)" -D"STM32L4" -D"USBD_SOF_DISABLED" -D"ARM
_MATH_CM4" -D"__FPU_PRESENT" $ (INCLUDE_FLAGS)
# Define directories
BIN_DIR = bin
SRC_DIR = src
LIB_DIR = lib
# CMSIS directories
CMSIS_DIR = $(LIB_DIR)/cmsis
CMSIS_DEV_DIR = $ (CMSIS_DIR) / device
CMSIS_INC_DIR = $(CMSIS_DIR)/inc
CMSIS\_SRC\_DIR = $(CMSIS\_DIR)/src
# FreeRTOS directories
#FREERTOS_DIR = $(LIB_DIR)/freertos
#FREERTOS_INC_DIR = $ (FREERTOS_DIR) / include
#FREERTOS_PRT_DIR = $(FREERTOS_DIR)/portable
# HAL directories
HAL_DIR = \frac{(LIB_DIR)}{hal}
HAL_INC_DIR = $(HAL_DIR)/inc
HAL\_SRC\_DIR = $(HAL\_DIR)/src
# libUSB_stm32 directories
LIBUSB_DIR = $(LIB_DIR)/libusb_stm32
LIBUSB_INC_DIR = \$(LIBUSB_DIR)/inc
LIBUSB\_SRC\_DIR = $(LIBUSB\_DIR)/src
# Define include flags
INCLUDE_FLAGS = -I$(SRC_DIR) -I$(CMSIS_DEV_DIR) -I$(CMSIS_INC_DIR) -I$(CMSIS_SRC_DIR) -I$(HAL_DIR
) -I$(HAL_INC_DIR) -I$(HAL_SRC_DIR) -I$(LIBUSB_DIR) -I$(LIBUSB_INC_DIR) -I$(LIBUSB_SRC_DIR)
# Define sources
SRCS := $(wildcard $(HAL_SRC_DIR)/*.c) \
        $(wildcard $(HAL_SRC_LEG_DIR)/*.c) \
        $(wildcard $(SRC_DIR)/*.c) \
        $(wildcard $(CMSIS_SRC_DIR)/*.c) \
        $(wildcard $(LIBUSB_SRC_DIR)/*.c)
SRCSASM := $(CMSIS_SRC_DIR)/startup_$(ARCH_LOW).s
HDRS := $(wildcard $(HAL_INS_DIR)/*.h) \
        $(wildcard $(SRC_DIR)/*.h) \
        $(wildcard $(CMSIS_INC_DIR)/*.h) \
        $(wildcard $(CMSIS_DEV_DIR)/*.h)
        $(wildcard $(LIBUSB_INC_DIR)/*.h)
```

Define objects

Makefile Page 2 of 2

```
OBJS := $(SRCSASM:%.s=$(BIN_DIR)/%.o) $(SRCS:%.c=$(BIN_DIR)/%.o)
# Define the target file
TARGET = $(BIN_DIR)/main
all: $(TARGET)
# Link the objects into the target
$(TARGET): $(OBJS) $(HDRS)
       $(CC) -o $@ $(OBJS) $(LINKER_FLAGS)
# Compile c files
$(BIN_DIR)/%.o: %.c
        $(MKDIR) -p $(dir $@) 2> /dev/null
        $(CC) $(COMPILER_FLAGS) $< -o $@
# Compile assembly files
$(BIN_DIR)/%.o: %.s
        $(MKDIR) -p $(dir $@) 2> /dev/null
        $(CC) $(ASSEMBLER_FLAGS) $< -o $@
# Remove only src directory object files
clean:
        $(RM) $(wildcard $(BIN_DIR)/$(SRC_DIR)/*.o)
# Remove all object files and the target
cleaner:
        $(RM) $(OBJS) $(TARGET)
```

readdata.py Page 1 of 2

```
import serial
import struct
import statistics as stat
import matplotlib.pyplot as plt
import matplotlib.animation as anim
from collections import deque
# Connect to the USB serial device
ser = serial.Serial('/dev/ttyUSB0')
ser.baudrate = 115200
ser.flushInput()
# Create the lambda and temp arrays for graphing
lamb = deque([0] * 100);
temp = deque([0] * 100);
pwmv = deque([0] * 100);
x = range(100);
# Create the plots
fig, ax1 = plt.subplots()
# Plot Lambda
ax1.set_xlabel('time (s)')
ax1.set_ylabel('Lambda (mLam)', color='tab:blue')
ax1.plot(x, lamb, color='tab:blue')
ax1.tick_params(axis='y', labelcolor='tab:blue')
ax1.set_ylim(0, 10200)
# Create a second axes
ax2 = ax1.twinx()
# Plot Temperature
ax2.set_ylabel('Temperature (C)', color='tab:red')
ax2.plot(x, temp, color='tab:red')
ax2.tick_params(axis='y', labelcolor='tab:red')
ax2.set_ylim(0, 1200)
# Create a third axes
ax3 = ax1.twinx()
# Plot Temperature
ax3.set_ylabel('PWM Vrms(V)', color='tab:green')
ax3.plot(x, pwmv, color='tab:green')
ax3.tick_params(axis='y', labelcolor='tab:green')
ax3.set_ylim(0, 12)
ax3.spines["right"].set_position(("axes", 1.2))
ax3.spines["right"].set_visible(True)
fig.tight_layout()
fig.show()
# Flush the serial input of buffered data
ser.flushInput()
# Graph data forever
while True:
    # Check for preamble
    while True:
        rdbytes = ser.read(1)
        if rdbytes == b'\xff':
            rdbytes = ser.read(1)
            if rdbytes == b' \setminus xff':
                break
    # Read data
    rdbytes = ser.read(6)
    # Convert bytes to integers
    values = struct.unpack('<HHH', rdbytes)</pre>
    # Insert the lambda value into the array
    lamb.popleft()
    lamb.append(values[0]/1000)
    # Insert the temperature value into the array
    temp.popleft()
    temp.append(values[1])
    # Insert the PWM Vrms value into the array
    pwmv.popleft()
```

readdata.py Page 2 of 2

```
pwmv.append(values[2]/1000)
    # Print the lambda value the temperature and the PWM Vrms
   print(values)
    # Clear the plots and replot
   ax1.cla()
   ax2.cla()
   ax3.cla()
   ax1.set_ylabel('Lambda Value', color='tab:blue')
   ax2.set_ylabel('Temperature (C)', color='tab:red')
   ax3.set_ylabel('PWM Vrms (V)', color='tab:green')
   ax1.plot(x, lamb, color='tab:blue')
   ax2.plot(x, temp, color='tab:red')
    ax3.plot(x, pwmv, color='tab:green')
    # Reset the axes
   ax1.set_ylim(0, max(lamb)+0.5)
   ax2.set_ylim(0, max(temp)+200)
   ax3.set_ylim(0, max(pwmv)+1)
    ax3.spines["right"].set_position(("axes", 1.2))
    ax3.spines["right"].set_visible(True)
    # Print imformation about each plot
   ax1.text(0.01, 0.04, 'Current Lambda: ' + str(lamb[-1]), verticalalignment='bottom', horizont
alalignment='left', transform=ax2.transAxes, color='blue', fontsize=12)
    ax1.text(0.01, 0.01, 'Mean Lambda: ' + str(stat.mean(lamb)), verticalalignment='bottom', hori
zontalalignment='left', transform=ax2.transAxes, color='blue', fontsize=12)
    ax2.text(0.01, 0.13, 'Current Temp: ' + str(temp[-1]) + 'C', verticalalignment='bottom', hori
zontalalignment='left', transform=ax2.transAxes, color='red', fontsize=12)
    ax2.text(0.01, 0.10, 'Max Temp: ' + str(max(temp)) + 'C', verticalalignment='bottom', horizon
talalignment='left', transform=ax2.transAxes, color='red', fontsize=12)
    ax2.text(0.01, 0.07, 'Min Temp: ' + str(min(temp)) + 'C', verticalalignment='bottom', horizon
talalignment='left', transform=ax2.transAxes, color='red', fontsize=12)
    \texttt{ax3.text(0.01, 0.16, 'Current PWM Vrms: ' + str(pwmv[-1]) + 'V', vertical alignment='bottom', } \\
horizontalalignment='left', transform=ax2.transAxes, color='green', fontsize=12)
    # Draw the updated plot
   fig.canvas.draw()
    fig.canvas.flush_events()
```