

## Impedance Spectroscopy

J. Ross Macdonald

Department of Physics and Astronomy  
University of North Carolina  
Chapel Hill, NC

(Received 5/15/91; Revised 8/2/91)

*Impedance spectroscopy (IS) is a general term that subsumes the small-signal measurement of the linear electrical response of a material of interest (including electrode effects) and the subsequent analysis of the response to yield useful information about the physicochemical properties of the system. Analysis is generally carried out in the frequency domain, although measurements are sometimes made in the time domain and then Fourier transformed to the frequency domain. IS is by no means limited to the measurement and analysis of data at the impedance level (e.g., impedance vs. frequency) but may involve any of the four basic immittance levels: thus, most generally, IS stands for immittance spectroscopy.*

**Keywords**—*Impedance, Immittance, Complex dielectric constant, Complex modulus.*

### INTRODUCTION: SHORT HISTORY OF IMPEDANCE SPECTROSCOPY

Since impedance spectroscopy (IS) deals directly with complex quantities, its history really begins with the introduction of impedance into electrical engineering by Oliver Heaviside in the 1880s. His work was soon extended by A.E. Kennelly and C.P. Steinmetz to include vector diagrams and complex representation. It was not long before workers in the field began to make use of the Argand diagram of mathematics by plotting immittance response in the complex plane, with frequency an implicit variable. Electrical engineering examples were the circle diagram introduced by C.W. Carter (5) and the Smith-Chart impedance diagram of P.H. Smith (20). These approaches were soon followed in the dielectric response field by the introduction in 1941 of the Cole-Cole plot: a plot of  $\epsilon''$  on the  $y$  (or imaginary) axis vs.  $\epsilon'$  on the  $x$  (or real) axis. Such complex plane plots are now widely used for two-dimensional representation of the response of all four immittance types. Finally, three-dimensional perspective plots that involve a log-frequency axis were introduced to the IS area by the author and his colleagues in 1981 (10); these plots allow complete response at a given immittance level to be shown in a single diagram.

Because IS analysis generally makes considerable use of equivalent circuits to rep-

---

Revised and adapted from Encyclopedia of Physical Science and Technology, 1991 Yearbook, copyright © 1991 by Academic Press Inc., Orlando, FL, by permission.

Address correspondence to J. Ross Macdonald, University of North Carolina, Chapel Hill, NC 27599-3255.

resent experimental frequency response, the whole history of lumped-constant circuit analysis, which particularly flowered in the first third of the century, is immediately relevant to IS. Since then, much work has been devoted to the development of theoretical physicochemical response models and to the definition and analysis of various distributed circuit elements for use in IS-equivalent circuits along with ideal, lumped elements like resistance and capacitance. The preferred analysis method for fitting of IS data to either equivalent circuits or to a mathematical model is complex nonlinear least squares fitting (CNLS), introduced to the field in 1977 by Macdonald and Garber (8). In this procedure, all the parameters of a fitting model are simultaneously adjusted to yield an optimum fit to the data.

Early experimental work in the IS field is discussed in the 1987 book on IS (11) listed in the bibliography. Here it will suffice to mention the work of Grahame on electrolyte double-layer response, the technique of AC polarography pioneered by D.E. Smith (19), and the electrolyte studies of Randles and Somerton (15), Sluyters and Oomen (17), Buck and Krull (4), J.E. Bauerle (3), and the reviews of (1,2,18). Since the late 1960s, IS has developed rapidly, in large part because of the availability of new, accurate, and rapid measuring equipment. Modern developments are discussed in (6).

### **CATEGORIES OF IMPEDANCE SPECTROSCOPY: DEFINITIONS AND DISTINCTIONS**

There are two main categories of IS: electrochemical IS (EIS) and everything else. EIS involves measurements and analysis of materials in which ionic conduction strongly predominates. Examples of such materials are solid and liquid electrolytes, fused salts, ionically conducting glasses and polymers, and nonstoichiometric ionically bonded single crystals, where conduction can involve motion of ion vacancies and interstitials. EIS is also valuable in the study of fuel cells, rechargeable batteries, and corrosion.

The remaining category of IS applies to dielectric materials: solid or liquid nonconductors whose electrical characteristics involve dipolar rotation, and to materials with predominantly electronic conduction. Examples are single-crystal or amorphous semiconductors, glasses, and polymers. Of course, IS applies to more complicated situations as well, for example, to partly conducting dielectric materials with some simultaneous ionic and electronic conductivity. It is worth noting that although EIS is the most rapidly growing branch of IS, nonelectrochemical IS measurements came first and are still of great value and importance in both basic and applied areas.

In the EIS area in particular, an important distinction is made between supported and unsupported electrolytes. Supported electrolytes are ones containing a high concentration of indifferent electrolyte, one whose ions generally neither adsorb nor react at the electrodes of the measuring cell. Such an added salt can ensure that the material is very nearly electroneutral everywhere, thus allowing diffusion and reaction effects for a low-concentration ion of interest to dominate the AC response of the system. Support is generally only possible for liquid electrochemical materials: it is often, but not always, used in aqueous electrochemistry. Solid electrolytes are unsupported in most cases of interest, electroneutrality is not present, and Poisson's equation strongly couples charged species. Because of this difference, the formulas or models used to analyze supported and unsupported situations may be somewhat or completely different.

Another important distinction is concerned with static potentials and fields. In a material-electrode system without an applied static external potential difference (p.d.), internal p.d.s and fields are, nevertheless, generally present, producing space-charge layers at interfaces. For solids such regions are known as Frenkel layers and arise from the difference in work function between the electrode and the material. Because the static fields and charge concentrations in the material are inhomogeneous, exact small-signal solutions for the impedance of the system are impossible and numerical methods must be used.

In an electrolytic cell such static space-charge regions are only absent when the external static p.d. is adjusted so that the charge on the working electrode is zero—the point of zero charge (PZC)—a flat-band condition. Such adjustment is impossible for systems with two symmetrical electrodes because an applied static p.d. increases the space-charge region at one electrode while reducing it at the other. But the use of a working electrode of small area and a large-area counter electrode ensures that the overall impedance of the system is little influenced by what happens at the counter electrode; in this situation the PZC can be achieved for the working electrode. In general, the current distribution near this electrode is frequency dependent and thus makes a frequency-dependent contribution to the overall impedance of the system, which is dependent on electrode geometry and character.


Figure 1 shows a flow diagram for a complete IS study whose goal is characterization of important properties of the material-electrode system from its electrical response, one of the major applications of IS. The experimental data is denoted by  $Z_e(\omega)$ , the impedance predicted by a theoretical fitting model by  $Z_t(\omega)$ , and that of a possible electrical equivalent circuit by  $Z_{ec}(\omega)$ , where  $\omega = 2\pi f$  and  $f$  is frequency. When an appropriate detailed model for the physicochemical processes present is available, it should certainly be used for fitting. Otherwise, one would employ an equivalent electrical circuit whose elements and connectivity were selected, as far as possible, to represent the various mass and charge transport physical processes thought to be of importance for the particular system.

Note that a complete IS analysis often involves more than a single set of measurements of immittance vs. frequency. Frequently, full characterization requires that such sets of measurements be carried out over a range of temperatures and/or other externally controlled experimental variables. IS characterization may be used to yield basic scientific and/or engineering information on a wide variety of materials and devices, ranging from solid and liquid electrolytes to dielectrics and semiconductors, to electrical and structural ceramics, to magnetic ferrites, to polymers and protective paint films, and to secondary batteries and fuel cells. Other important applications of IS, not further discussed herein, have been made in the biological area, such as studies of polarization across cell membranes and of animal and plant tissues. Finally, the analysis techniques of IS are not limited to electrical immittance but apply as well to measurements of mechanical and acoustic immittance.

## ELEMENTS OF IMPEDANCE SPECTROSCOPY

### *Measurement Methods*

Although IS measurements are simple in principle, they are often complicated in practice. Part of the difficulty arises because the resistive and capacitive components of IS response have ranges, when one considers different materials, electrodes, and temperatures, that span 10 or more orders of magnitude. Measurements require com-



**FIGURE 1.** Flow diagram for the measurement and characterization of a material-electrode system. (Reprinted by permission of John Wiley & Sons, Inc., from "Impedance Spectroscopy—Emphasizing Solid Materials and Systems." J.R. Macdonald, ed. Copyright © 1987, John Wiley & Sons, Inc. [11].)

parison with standard values of these components and are thus only as accurate as the standards. Second, the IS frequency range may extend over 12 orders of magnitude or more: from as low as 10  $\mu$ Hz for adequate resolution of interfacial processes, up to 10 MHz or higher, sometimes needed to characterize bulk response of the material of interest.

Although IS measurements on solids or dielectric liquids usually involve cells with two identical plane, parallel electrodes, the situation is often much more complicated for measurements on liquid electrolytes. There, one usually employs one or more small working electrodes, a very small reference electrode, and a large counter electrode. Such an arrangement ensures that everything of interest (related to immittance) happens at or near the working electrode(s). Further, a rotating-disc working electrode is frequently used to control hydrodynamic conditions near the electrode.

Because the kinetics of electrode reactions often depend strongly on the static (dc) potential difference between the working electrode and the bulk, or, equivalently, the working electrode and the reference electrode, a potentiostat is needed to fix this p.d. to a known and controllable value. The simultaneous application of both ac and dc

signals to a three- or four-electrode cell makes it particularly difficult to obtain accurate frequency-response results above 50 kHz or so.

Although a calibrated double-beam oscilloscope, or the use of Lissajous figures with a single-beam instrument, can be used to determine immittance magnitude and phase, such measurements are generally insufficiently accurate, are time consuming, and apply only over a limited frequency range. A superior alternative is the use of audio-frequency or high-frequency bridges. Several such bridges are discussed in the IS book. Of particular interest is the Berberian-Cole bridge, which can cover a wide frequency range and can allow potentiostatic dc bias control. Another important technique using a bridge and special error reduction procedures has recently been developed by Schöne and co-workers (16) that allows potentiostatic control and yields very accurate impedance results up to 3 MHz. But manual balancing of a bridge is often disadvantageous because of its slowness, especially for corrosion studies where the properties of the system itself may be slowly changing.

Manual balancing is avoided in various automated network analyzers and impedance analyzers now commercially available. But the measuring instrument that has virtually revolutionized IS measurements and principally led to the burgeoning growth of the field in the past 20 years is the frequency-response analyzer (FRA). Typical examples are FRAs produced by Solartron and by Zahner. Although space does not allow a full description of their many features, such instruments allow potentiostatic control for three- or four-terminal measurements, they are highly digitized, they incorporate automatic frequency sweeps and automatic control of the magnitude of the applied ac signal, they can yield 0.1% accuracy, and they carry out measurements automatically.

Although FRAs such as the Solartron 1260 cover a frequency range from 10  $\mu$ Hz to 32 MHz, impedance results using them are not sufficiently accurate above about 50 kHz when potentiostatic control is used. A typical FRA determines impedance by correlating, at each frequency, the cell response with two synchronous signals, one in phase with the applied signal and the other phase-shifted by 90°. This process yields the in-phase and out-of-phase components of the response and leads to the various immittance components. A useful feature is autointegration, a procedure that averages results over an exact number of cycles, with the amount of such averaging automatically selected to yield statistically consistent results.

#### *Analysis and Interpretation of Data*

**Graphics.** Before carrying out a detailed analysis of IS immittance data, it is a good idea to examine the data graphically, both to search for any outliers and to examine the structure of the data, structure that will usually reflect, at least in part, the physical processes present that led to the data. From the experimental situation one will generally know whether one is dealing with an intrinsically insulating material, such as a nonconducting or a leaky dielectric, or whether the situation is of intrinsically conducting character: mobile charges dominate the response but may be completely or only partially blocked at the electrodes. For complete blocking no DC can pass, a case that could be confused with dielectric response. In the intrinsically conducting situation, dielectric effects are generally minimal, and  $Z$  and  $M$  representations of the data are often most useful. (See the list of definitions at the end of this article.) In the nonconducting case,  $Y$  and  $\epsilon$  are frequently most appropriate, but it

is nevertheless a good idea initially to examine plots of the data for all four imittance levels, whatever the conducting/nonconducting situation.

When mobile charges are present, five principal physical processes may influence the data: these are bulk resistive-capacitive effects, electrode reactions, adsorption at the electrodes, bulk generation-recombination effects (e.g., ion-pairing), and diffusion. The double-layer capacitance is the reaction capacitance  $C_R$ , and the reaction resistance  $R_R$  is inversely proportional to the reaction rate constant. It is important to distinguish  $C_R$  from the usually much larger low-frequency pseudocapacitance associated with the diffusion of mobile charge or with adsorption at an electrode. Note that in general a process that dissipates energy is represented in an IS equivalent circuit by a resistance, and energy storage is usually modeled by a capacitance. Detailed CNLS analysis of IS data can lead in favorable cases to estimates of such basic material-electrode quantities as electrode reaction and adsorption rates, bulk generation-recombination rates, charge valence numbers and mobilities, diffusion coefficients, and the (real) dielectric constant of the material.

There are many ways IS data may be plotted. In the IS field, where capacitive rather than inductive effects dominate, conventionally one plots  $-\text{Im}(Z) \equiv -Z''$  on the  $y$ -axis vs.  $\text{Re}(Z) \equiv Z'$  on the  $x$ -axis to give a complex-plane impedance plot. Such graphs have (erroneously) been termed Nyquist plots. They have the disadvantage of not indicating frequency response directly, but may nevertheless be very helpful in identifying conduction processes present. Another approach, the Bode diagram, is to plot  $\log[|Z|]$  and  $\phi$  vs.  $\log[f]$ . Alternatively, one can plot  $Z'$  (or any  $I'$ ) or  $-Z''$  (or  $-I''$ ), or the logs of these quantities vs.  $\log[f]$ .

An important IS building block is Debye response, response that involves a single time constant,  $\tau$ . A Cole-Cole plot of such response is shown in Fig. 2. The arrow shows the direction of increasing frequency. Debye response can be represented in complex form as  $\epsilon = \epsilon_\infty + [\epsilon_0 - \epsilon_\infty]/[1 + (i\omega\tau)]$  and, in circuit form, involves a capacitance  $\epsilon_\infty C_C$  in parallel with the series combination of a resistor  $R$ , modeling





FIGURE 2. Complex-plane plot of the complex dielectric constant for Debye frequency response.

dissipative effects, and a capacitor  $C \equiv (\epsilon_0 - \epsilon_\infty)C_C$ , representing stored charge. Finally, the time constant or relaxation time is given by  $\tau \equiv RC$ .

Three-dimensional perspective plots are particularly useful because they allow complete response to appear on a single graph. Figure 3 shows such plots at the impedance level for the analog of Debye response for a conducting system. By including projections of the 3-D curve of the response in all three perpendicular planes of the plot, one incorporates all relevant 2-D plots in the same diagram. Note that the curve in the back plane, the complex-plane impedance plot, is just the usual Debye semi-circle, one with its center on the real axis.



**FIGURE 3.** A simple circuit and 3-D perspective plots of its impedance response. (Reprinted by permission of John Wiley & Sons, Inc., from "Impedance Spectroscopy—Emphasizing Solid Materials and Systems." J.R. Macdonald, ed. Copyright © 1987, John Wiley & Sons, Inc. [11].)

To demonstrate some of the power and weaknesses of 3-D plots, Fig. 4 includes three types of such plots, all for the same EIS data taken on single-crystal Na  $\beta$ -alumina. Graph A is an impedance plot and shows that only two out of the four curves indicate that the lowest frequency point is in error. In this plot,  $\nu$  denotes frequency  $f$ . Clearly, one should not rely on the conventional  $\log[f]$  curves alone. Since the diagram shows that much high-frequency data are not resolved by this kind of plot, graph B involves the logarithms of the data. Although high-frequency response now appears, the error in the low-frequency point is nearly obscured by the reduced resolution inherent in a log plot.


Much improved results appear in graph C, a 3-D  $M$  plot. Resolution over the full frequency range is greatly increased; the error in the lowest frequency point is clearly shown; a mid-frequency glitch now appears that is not evident in the other plots and arises from a switch of measuring devices without adequate cross-calibration; and nonphysical behavior is now apparent at the highest frequencies. These results make it clear that even when 3-D plots are used, it is always desirable to explore the results of different transformations of the data and to pick the one with the best resolution.

*Complex Nonlinear Least Squares Data-Fitting.* Although graphic examination of IS data is an important analysis step, only in the simplest cases can it be used to obtain even rough estimates of some system parameters. Since good parameter estimates are needed for adequate characterization of the material-electrode system, a fitting technique such as CNLS must be applied to obtain them. In doing so, the data, at any I level, are fitted to a mathematical model involving the parameters or to the response of an equivalent circuit. Such fitting models are discussed in the Bulk Reaction and Response Section. Not only does CNLS fitting yield estimates of the parameters of the model, but it also provides estimates of their standard deviations, measures of how well they have been determined by the data fit. These standard deviation values are valuable in deciding which parameters are crucial to the model and which are useless, or at least not well determinable from the data.

CNLS fits are produced by a program that minimizes the weighted sum of squares of the real and imaginary residuals (12,14). A residual is the difference between a data value at a given frequency and the corresponding value calculated from the model. The weights used are the inverses of the estimated error variance for a given real data value and that for the corresponding imaginary value. Weighting is the most subjective part of least squares fitting, yet it can often have crucial effects on the results of such fitting and is thus of prime importance.

Since individual error-variance estimates are usually unavailable, it has been customary to use simplified variance models to obtain values to use in the fitting. The simplest such model is to take all weights equal to one: unity weighting (UWT). Another popular and important choice is to set the error variance of each data value equal to the square of that value. Since the uncertainty of the value is then proportional to the value itself, this defines proportional weighting (PWT). It has recently been shown, however, that such weighting leads to biased parameter estimates (14); it should be replaced, when the fitting model is well matched to the data, by function-proportional weighting (FPWT), where the calculated rather than the direct data value is employed in the weighting.

PWT or FPWT is particularly important because the range of typical IS data can be as large as  $10^3$  or even  $10^6$ . When UWT is used in fitting such data, only the largest parts of the data determine the parameter estimates, and the smaller values have




**FIGURE 4.** Three-dimensional perspective plots of Na β-alumina data at (A) the impedance level, (B) log impedance level, and (C) complex modulus level. (Reprinted by permission of John Wiley & Sons, Inc., from "Impedance Spectroscopy—Emphasizing Solid Materials and Systems." J.R. Macdonald, ed. Copyright © 1987, John Wiley & Sons, Inc. [11].)


little or no effect. Alternatively, with PWT or FPWT, which is equivalent to assuming a constant percentage random error, small and large data values contribute equally to the final parameter estimates.

Figure 5 presents the results of PWT CNLS fitting of  $\beta\text{-PbF}_2$  data using an equivalent circuit with a distributed element, the constant phase element (CPE). Both the original data and the fit results are shown in the 3-D plot. The figure indicates that seven free parameters have been quite well determined by the data, a remarkable result when one considers the apparent lack of much structure in the data themselves.

A detailed physico-chemical model is always preferable to an equivalent circuit for fitting, especially since such models often cannot be expressed in terms of an equivalent circuit involving standard elements. But most IS situations involve many-body




**FIGURE 5.** Three-dimensional perspective impedance plot of  $\beta\text{-PbF}_2$  data (—, ---) and fitted values and curves (— —); the fitting circuit used and parameter estimates and estimates of their standard deviations. (Reprinted by permission of John Wiley & Sons, Inc., from "Impedance Spectroscopy—Emphasizing Solid Materials and Systems," J.R. Macdonald, ed. Copyright © 1987, John Wiley & Sons, Inc. [11].)



**FIGURE 6.** Four two-time-constant circuits that exhibit the same impedance response over all frequencies. Units are  $M\Omega$  for resistances and  $\mu F$  for capacitances.

problems currently insolvable at the microscopic level. Thus one must usually be satisfied with simpler continuum models, often expressed as equivalent circuits. One weakness of equivalent circuits involving only ideal elements is their ambiguity. The same elements may be interconnected in different ways and yet, with appropriate values, yield exactly the same frequency response at all frequencies. Thus, IS fitting cannot distinguish between the different possible structures, and only other measurements, such as IS fitting of data over a range of temperatures and/or potentials, can help one establish which of the possible circuits is most physically reasonable.

Figure 6 shows all possible potentially equivalent conducting circuits involving two resistances and two capacitances. Specific parameter value choices that make them all have exactly the same response are also indicated. Here the values for circuit D were taken exact, and approximate values for the other elements are denoted with a  $\sim$  sign. Let the units of these elements be  $M\Omega$  for resistances and  $\mu F$  for capacitances. Note that the two RC time constants of circuit A, a series connection, are relatively close together. Can IS procedures resolve such a situation? Figure 7 shows the exact complex-plane response of these circuits at both the  $Z$  and  $M$  levels, compared



**FIGURE 7.** Complex-plane immittance responses, at the  $Z$  and  $M$  levels, of the circuits of Fig. 6.

to single time-constant Debye response. The  $M$  curve shows much better separation of the two response regions than does the  $Z$  curve. Thus, adequate graphical resolution is indeed possible. Further, it turns out that CNLS fitting of synthetic data calculated from any of these circuits with appreciable proportional random errors added still yields excellent parameter estimates. In fact, with reasonably good data, CNLS can resolve response involving much closer time constants than those involved here.

Although several CNLS fitting programs now exist for use on personal computers, two commercially available ones have been especially tailored for the IS field. The first, EQUIVCRT, can be obtained from Dr. B.A. Boukamp, Twente University, P.O. Box 217, 7500 AE Enschede, The Netherlands; the second, LEVM, can be obtained from the Department of Physics and Astronomy, University of North Carolina, Chapel Hill at nominal cost. The programs to some degree complement each other, but LEVM is more general and flexible in many ways and incorporates much more sophisticated weighting possibilities.

### APPLICATIONS TO BASIC ANALYSIS OF MATERIAL PROPERTIES AND ELECTRODE EFFECTS

#### *Bulk and Reaction Response*

Although IS is of great value for the characterization of the electrical properties of material-electrode systems, its use for this purpose requires that connections be known between model and/or equivalent circuit parameters and the basic characterization parameters. One must be able to pass from estimates of macroscopic quantities, such as resistances and capacitances, to estimates of average microscopic quantities. Here only a brief overview will be given of some of the large amount of theoretical IS-related work of the past 40 years. More details appear in the IS book (5).

Because of the charge decoupling present in a supported situation, it is often an excellent approximation to treat the effects of the various physical processes present independently. On the other hand, for unsupported conditions where strong coupling is present, a unified treatment of all the processes together is necessary. The most complete such theory, which incorporates all five of the processes mentioned in the Graphics Section, was published by Macdonald and Franceschetti in 1978 (9). It is a continuum (i.e., averaged, not microscopic) theory, includes intrinsic and extrinsic charge effects, and applies to either ionic or electronic conduction conditions. Even though it strictly applies only to flat-band conditions, its results are still sufficiently complicated that only in simplified cases does it lead to response that may be modeled by an equivalent circuit.

It is useful, particularly in the EIS area, to separate the electrical processes present into bulk- and electrode-related groups whenever possible. The first group includes bulk resistance and dielectric effects and the homogeneous reactions associated with dissociation and recombination of the charges present. It is generally associated with response effects at the high end of the frequency range, while electrode effects usually occur near the low end, possibly at very low frequencies. Bulk resistance and capacitance are extensive quantities, dependent on the effective separation between electrodes.

The second group involves what happens in the neighborhood of the electrodes (within a few Debye lengths of them) and is thus intensive. No charge is transferred

to an electrode if it is completely blocking for all mobile charges. The next simplest EIS situation is that where a mobile metallic ion is of the same species as the atoms of a metallic electrode: a parent-ion electrode. Then, in a symmetrical-electrode situation there is a sink/source of ions at each electrode, since electron transfer at an electrode can transform ions into atoms and vice versa, depending on the polarity of the electric field at the electrode. Such a reaction can be written



where Me denotes a metal atom and  $z$  the number of electrons transferred. An example of a symmetrical cell of this type is  $\text{Ag}|\text{AgCl}|\text{Ag}$ .

Particularly important for the aqueous electrolyte area is the redox electrode, where charge crosses the interface at the electrode only in the form of electrons. The species Red and Ox are usually soluble in the electrolyte, satisfy



and involve the forward and reverse reaction rate constants  $k_f$  and  $k_r$ , respectively. If  $z = n$ , the Red species is uncharged and may diffuse in the electrode, or may evolve if it is a gas.

#### *Distributed Circuit Element Response*

*Diffusion.* Since diffusion is not localized at a point in space but is distributed over a finite region, it leads to electrical response characteristic of a distributed circuit element (DCE). Such elements cannot be described by means of a finite number of ideal elements such as resistances and capacitances. Here, the response of several DCEs important to IS will be discussed (7).

In addition to possible diffusion of uncharged species within an electrode, diffusion of mobile species in the electrolyte may contribute significantly to the impedance of an IS system. Generally, diffusion response is neither intensive nor extensive. At sufficiently high frequencies, diffusion effects are confined to the immediate neighborhood of the electrode (or within a hydrodynamic boundary layer at a rotating electrode) and so are intensive; whereas at low enough frequencies, diffusion occurs throughout the material between electrodes, and the response becomes extensive as the frequency decreases and the effective diffusion length  $l_d$ , proportional to  $(\omega)^{-0.5}$ , becomes comparable to the size of the cell.

The diffusion impedance, appropriate when there is a fast electrode reaction, is of the form

$$Z_w(\omega) = Z_w(0) [\tanh\{i(l/l_d)^2\}^{0.5}] / \{i(l/l_d)^2\}^{0.5} \quad (3)$$

where  $l$  is the separation between symmetrical electrodes and  $Z_w(0)$  is a resistance proportional to  $l$  and thus is extensive. Such response is known as finite-length Warburg behavior. At high enough frequencies that the tanh term goes to unity,  $Z_w(\omega)$  becomes proportional to the intensive quantity  $l_d$  and is termed (ordinary) Warburg response.

As the electrode reaction rate decreases toward zero, a more complicated expression for  $Z_W(\omega)$  must be used, but it reduces to the form

$$Z_W(\omega) = Z_C [\operatorname{ctnh} \{i(l/l_d)^2\}^{0.5}] / \{i(l/l_d)^2\}^{0.5} \quad (4)$$

when the electrode is completely blocking (open circuit diffusion). Here  $Z_C$  is given by  $(l/l_d)^2 \omega C_{DOC}$  and  $C_{DOC}/C_C$  is the effective low-frequency limiting dielectric constant associated with the process.

For general unsupported situations, those with positive and negative charged species mobile and having diffusion coefficients of  $D_n$  and  $D_p$  and valence numbers of  $z_n$  and  $z_p$ ,

$$(l_d)^2 = (4D_n D_p / \omega) [(z_n + z_p) / (z_n D_n + z_p D_p)] \quad (5)$$

No diffusion effects appear when only charge of a single sign is mobile; this often is an excellent approximation for solid electrolytes.

For supported conditions, matters are different. Consider a single species with diffusion coefficient  $D$  and valence number  $z$  (possibly zero). Then  $(l_d)^2 = 4D/\omega$ , a result that follows from the above expression when one sets  $D_n = D_p = D$  and  $z_n = z_p = z$ . Further, when both positive and negative charges are mobile, diffusion under unsupported conditions leads to a single expression involving tanh, as above, but for supported conditions, as in the redox case, two such terms appear, one for each species—in keeping with the lack of coupling between the species.

*Other DCEs.* A characteristic signature of diffusion is  $(i\omega)^{\pm 0.5}$  response, but IS data more often exhibits CPE response  $(i\omega\tau)^{\pm\psi}$ , where  $0 \leq \psi \leq 1$ . But such response is not physically realizable over all frequencies, and so other DCEs have been introduced that approximate such behavior over a limited frequency range. They may be written as impedances or complex dielectric constants, depending upon which  $I$  level is appropriate. Here they will be given at the  $Z$  level.

An empirical DCE of the above type is Havriliak-Negami (HN) response, written as

$$Z_{HN}(\omega) = R_{HN} / [1 + (i\omega\tau)^\alpha]^\beta \quad (6)$$

where  $0 \leq \alpha \leq 1$  and  $0 \leq \beta \leq 1$ . It reduces to Cole-Davidson response when  $\alpha = 1$  and to Cole-Cole response (termed  $ZC$  response at the  $Z$  level) when  $\beta = 1$ . The first of these yields an asymmetric arc in a complex-plane plot and the second one a symmetric arc. Both shapes appear often in practice, and  $ZC$  fitting is frequently used to represent data that yield an arc of a semicircle with its center below the real axis. Such behavior is usually ascribed to the presence of a distribution of some physical quantity in space, time, or energy. Rough electrodes are one example. Although fitted values of  $\alpha$  and/or  $\beta$  often show appreciable temperature dependence, there exists no theory yielding such dependence for HN response.

Another important DCE is that of Kohlrausch-Williams-Watts (KWW) response. It yields a stretched exponential in the time domain, response proportional to  $\exp[-t/\tau]^\psi$ , with  $0 \leq \psi \leq 1$ . Here there are, if anything, too many different theories

yielding such response, but again they do not predict the temperature dependence of  $\psi$ . The corresponding frequency response is very difficult to calculate accurately, but an excellent approximation for it is available in LEVM. Complex plane plots of KWW response yield an asymmetric arc for any  $\psi < 1$  until  $\psi = 1$ , when a Debye semicircle appears.


Another DCE category is associated with the presence in a material of a distribution of activation energies (DAE). Such distributions are likely in IS materials and may be expected even in single crystals when there are many competing possibilities for the individual motion of mobile charges. Both Gaussian and exponential distributions have been considered in detail and can lead to either symmetric or asymmetric complex-plane arcs. But only an exponential DAE yields CPE-like fractional-exponent frequency response over a finite frequency region. This exponent,  $\phi$ , is not limited to the range from 0 to 1 but satisfies  $-\infty < \phi < \infty$ . Further, unlike the other DCEs considered, an exponential DAE predicts temperature dependence of  $\phi$  in good agreement with many experimental results (13).

### *Equivalent Circuits*

Many different equivalent circuits have been proposed over the years for IS fitting, and no one circuit structure is appropriate for all situations. Figure 8 shows a circuit, however, that has been found useful for a variety of materials and experimental conditions. Bulk properties are represented by  $C_g$ , the geometrical capacitance, and  $R_\infty$ , the high-frequency limiting resistance.  $C_R$ , associated with an electrode reaction, is the double-layer capacitance (possibly including both a compact inner-layer capacitance and a diffuse double-layer capacitance), and  $R_R$  is the reaction resistance. Finally,  $C_A$  and  $R_A$  are associated with adsorption at an electrode. The  $Z_D$  elements, when present, are DCEs. Also, not all the other elements need be present; for example, in the absence of adsorption  $C_A$  and  $R_A$  would not appear.

For an unsupported, fully dissociated material with charges of only a single sign mobile, the Fig. 8 circuit with all  $Z_D$ s absent has been found to yield an accurate representation of the impedance resulting from a flat-band theoretical analysis of the situation. Since only  $R_s$  and  $C_s$  are involved, ambiguity is present, and many other circuit structures with the same elements and the same frequency response are possible. Nevertheless, the present hierarchical ladder-network connection is more physically reasonable than the others for homogeneous material. It ensures that bulk charging and conduction effects take place before reaction/adsorption ones. For polycrystalline materials, however, circuits involving series rather than hierarchical connection of parallel  $RC$  subcircuits are often found appropriate.

For the conditions above, no diffusion DCE element is present. The  $Z_w(\omega)$  one discussed earlier appears, however, in the  $Z_{D3}$  position when charges of both signs are mobile and at least one of them reacts at an electrode. When static fields are present in the material, either intrinsic and/or externally produced, numerical analysis of the nonlinear transport equations governing the IS response shows that the Fig. 8 circuit still applies to good approximation but elements such as  $C_R$  and  $R_R$  then depend appreciably on the static p.d. present. Finally, the circuit of Fig. 8 has often been found appropriate for the fitting of data for supported conditions as well as unsupported ones.



**FIGURE 8.** An equivalent circuit of hierarchical structure useful in fitting much IS data. (Reprinted by permission of IEEE: "Interface Effects in the Electrical Response of Non-Metallic Conducting Solids and Liquids," J.R. Macdonald, *IEEE Trans. on Electrical Insulation*, Vol. EI-15, pp. 65-82, Fig. 3. Copyright © IEEE 1981.)

## DEFINITIONS

**Admittance.** A complex quantity usually symbolized by  $Y = Y' + iY''$ . It is the inverse of impedance and is sometimes called complex conductance. Here  $i = +(-1)^{0.5}$ , and the single and double primes denote in-phase and quadrature components, respectively.

**Complex Dielectric Constant.** The ratio of the (complex) dielectric displacement to the small-signal AC electric field that induces the displacement. Conventionally written as  $\epsilon = \epsilon' - ie''$ . It is given by  $Y/(i\omega C_C)$ , where  $C_C$  is the capacitance of the empty measuring cell.

**Complex Forms.** Impedance spectroscopy data may be expressed in two different forms. Rectangular:  $I = I' + iI''$ , where  $I'$  and  $I''$  are the real and imaginary parts of  $I$ , respectively; or Modulus:  $I = |I|e^{i\phi}$ , where  $|I|$  is the modulus, or absolute value, of  $I$  and  $\phi$  is its phase angle, or argument. Note that the complex conjugate of  $I$  is  $I^* = I' - iI'' = |I|e^{-i\phi}$ .

**Complex Modulus.**  $M = M' + iM''$ . It is the inverse of the complex dielectric constant and is also equal to  $i\omega C_C Z$ .

**Debye Length.** A characteristic length that determines the extent of a space charge region near a discontinuity. It depends on temperature, dielectric constant, and the valence numbers and bulk concentrations of the mobile charges present. The diffuse double-layer capacitance present near a non-ohmic electrode is inversely proportional to the Debye length.

**Immittance.** A general term denoting any of the four basic impedance spectroscopy response quantities:  $Y$ ,  $Z$ ,  $\epsilon$ , or  $M$ ;  $I = I' + iI''$ .

**Impedance.** The ratio of a sinusoidal voltage, applied across two terminals of a measurement cell, to the sinusoidal component of the current flowing between the terminals that results from the applied potential difference. Unless the system is purely resistive, impedance is a complex quantity because the current will have a different phase from the applied voltage:  $Z = Z' + iZ''$ .

## REFERENCES

1. Archer, W.I.; Armstrong, R.D. The application of AC impedance methods in solid electrolytes. *Electrochemistry* 7:157–202; 1980.
2. Armstrong, R.D.; Bell, M.F.; Metcalfe, A.A. The AC impedance of complex electrochemical reactions. *Electrochemistry* 6:98–127; 1978.
3. Bauerle, J.E. Study of solid electrolyte polarization by a complex admittance method. *J. Phys. Chem. Solids* 30:2657–2670; 1969.
4. Buck, R.P.; Krull, I. Transient electrical behavior of glass electrodes. Part III. Experimental. *J. Electroanal. Chem.* 18:387–399; 1968.
5. Carter, C.W. Impedance of networks containing resistances and two reactances. *Bell Sys. Tech. J.* 4:387–401; 1925.
6. Gabrielli, C., ed. *Proceedings of the First International Symposium on Electrochemical Impedance Spectroscopy*. *Electrochim. Acta* 35:1483–1670; S1–S18; 1990.
7. Hurt, R.L.; Macdonald, J.R. Distributed circuit elements in impedance spectroscopy: A unified treatment of conductive and dielectric systems. *Solid State Ionics* 20:111–124; 1986.
8. Macdonald, J.R.; Garber, J.A. Analysis of impedance and admittance data for solids and liquids. *J. Electrochem. Soc.* 124:1022–1030; 1977.
9. Macdonald, J.R.; Franceschetti, D.R. Theory of small-signal AC response of solids and liquids with recombining mobile charge. *J. Chem. Phys.* 68:1614–1637; 1978.
10. Macdonald, J.R.; Schoonman, J.; Lehnens, A.P. Three dimensional perspective plotting and fitting of immittance data. *Solid State Ionics* 5:137–140; 1981.
11. Macdonald, J.R., ed. *Impedance spectroscopy—Emphasizing solid materials and systems*. New York: Wiley-Interscience; 1987.
12. Macdonald, J.R.; Potter, Jr., L.D. A flexible procedure for analyzing impedance spectroscopy results: Description and illustrations. *Solid State Ionics* 23:61–79; 1987.
13. Macdonald, J.R. Response of systems with Gaussian or exponential energy distributions. *J. Electrochem. Soc.* 135:3067–3068; 1988.
14. Macdonald, J.R. Impedance spectroscopy: Old problems and new developments. In: Gabrielli, C., ed. *Proceedings of the First International Symposium on Electrochemical Impedance Spectroscopy*. *Electrochim. Acta* 35:1483–1492; 1990.
15. Randles, J.E.B.; Somerton, K.W. Kinetics of rapid electrode reactions. *Trans. Farad. Soc.* 48:937–950; 1952.
16. Schöne, G.; Wiesbeck, W.; Lorenz, W.J. High-frequency impedance spectroscopy of fast electrode reactions. *J. Electroanal. Chem.* 229:407–421; 1987.
17. Sluyters, J.H.; Oomen, J.J.C. On the impedance of galvanic cells. II. Experimental verification. *Rec. Trav. Chim.* 79:1101–1110; 1960.
18. Sluyters-Rehbach, M.; Sluyters, J.H. AC Techniques. In: Yeager, E.; Bockris, J.O'M.; Conway, B.E.; Sarangapani, S., eds. *Comprehensive treatise of electrochemistry*, Vol. 9. New York: Plenum Press; 1984: pp. 177–292.
19. Smith, D.E. AC polarography and related techniques: Theory and practice. In: Bard, A.J., ed. *Electroanalytical chemistry*, Vol. 1. New York: Marcel Dekker; 1966: pp. 1–157.
20. Smith, P.H. Transmission line calculator. *Electronics* 12:29–31; 1939.