APP RADIO PACKETS:

CMD = 0x30

Size = 26-80 b

Config Request Radio Packet + uint8 t: CMD + uint8 t: CMD + uint8 t: Seassion ID CMD = 0x20Size = 2 bJoin Reply Radio Packet + uint8 t: CMD + uint8 t: Seassion ID + uint8 t: Result + uint8 t: BW + uint8 t: SF + uint8_t: CR + uint16_t: Join Interval + uint8_t: App Mode CMD = 0x01CMD = 0x02Size = 9 bSize = 18 bStatusinfo Radio Packet + uint8 t: CMD + uint8_t: Seassion ID + uint8_t: Battery + uint16_t: Temperature + uint16_t: Rms + uint16_t: Vpp + float32 t: Kurtosis Ratio + uint16_t: Ringdown Counts + uint16_t: Rise Time + uint16_t: Threshold duration + uint8 t: fftPeaksNum + uint16_t []: fftPeakIndexes + float32_t[]: fftPeaksValues

+ uint8_t: Seassion ID + uint16_t: Statusinfo Interval + uint16_t: Statusinfo Listen Interva + uint8_t: Temp Averaging Num + uint8_t: ADC Sampling Time + uint8_t: ADC Divider + uint8_t: FFT Samples Num + uint8_t: FFT Peaks Num + uint16_t: DSP Threshold Voltage + uint8_t: DSP Kurtosis Trimmed S. + uint8_t: DSP RMS AC + uint8_t: DSP RMS AVeraging Nur

Config Reply Radio Packet

Restart Radio Packet + uint8_t: CMD + uint8_t: Seassion ID + uint8_t: Reset Config CMD = 0x20 Size = 3 b

+ uint8_t: CMD

+ uint8_t: Seassion ID

+ uint32_t: Unique ID

+ uint32_t: Time

+ uint8_t: FwVersion

CMD = 0x10

Join Request Radio Packet

Seassion ID = 0x00 Size = 11 b