

SOFLE v2 • ONE-PAGE LAYER CHEATSHEET

Colemak-DH • Bilateral Home-Row Mods • Semantic F13–F24 Protocol • 60 Positions • 2x Rotary Encoders

Layer Access / Transition

Transparent / Falthrough

Unused on this Layer

BASE BASE - L0 (Colemak-DH)

⌵	1	2	3	4	5											6	7	8	9	0	Del			
Esc	Q	W	F	P	B											J	L	U	Y	'	Bsp			
MEDIA	A	R	S	T	G											M	N	E	I	O	;			
Shift Sticky	Z	X	C	D	V	Caps Word	Mute											K	H	,	.	/	RShift	
					Cmd	Alt	Esc MOUSE	Space NAV	Tab HOST											Enter SYM	Bsp NUM	Del FUN	RAlt	RCmd

NAV NAV - L1 (Hold LH1 • Space)

⌵																										⌵
BOOT	Prev Tab	Next Tab	New Tab	Close Tab	Reopen Tab											Undo	Paste	Copy	Cut	Redo						
Sel All	Cmd	Alt	Ctrl	Shift	Save											Caps Word	←	DOWN	UP	→						
Find	Word ←	Word →	Find Next					⌵	⌵											Ins	Home	PgDn	PgUp	End		
		⌵	⌵	Esc	NAV held	Tab											Enter	Bsp	Del	⌵	⌵					

MOUSE MOUSE - L2 (Hold LH2 • Esc)

⌵																										⌵											
																				Undo	Paste	Copy	Cut	Redo													
										Cmd	Alt	Ctrl	Shift											Back	Pointer ←	Pointer ↓	Pointer ↑	Pointer →	Forward								
																				⌵	⌵											Scroll ←	Scroll ↓	Scroll ↑	Scroll →		
		⌵	⌵	MOUSE held																					Right click	Left click	Middle click	⌵	⌵								

MEDIA MEDIA - L3 (Hold LM5)

⌵																										⌵										
																				Bright-	Bright+															
MEDIA held	Cmd	Alt	Ctrl	Shift											Prev	Vol-	Vol+	Next																		
																				⌵	⌵											Stop	Play/ Pause	Mute	⌵	⌵
		⌵	⌵																																	

NUM NUM - L4 (Hold RH1 • Bsp)

⌵																										⌵	
/	[	7	8	9	]																					BOOT	
*	;	4	5	6	=											RShift Sticky	RCtrl Sticky	RAlt Sticky	RCmd Sticky								
+	⌵	1	2	3	\	⌵	⌵																				
		⌵	⌵	.	0	-																NUM held	⌵	⌵			

SYM SYM - L5 (Hold RH0 • Enter)

⌵																										⌵				
@	#	\$	]	}	)																									
!	<	>	[	{	(											RShift Sticky	RCtrl Sticky	RAlt Sticky	RCmd Sticky											
&		*	-	=	+	⌵	⌵																							
		⌵	⌵	\	/	_																SYM held	⌵	⌵						

FUN FUN - L6 (Hold RH2 • Del)

⌵																										⌵					
					F12	F7	F8	F9	PrtSc											Caps Lock											
					F11	F4	F5	F6	ScrLk											RShift Sticky	RCtrl Sticky	RAlt Sticky	RCmd Sticky								
					F10	F1	F2	F3	Pause	⌵	⌵																				
		⌵	⌵	Menu	Space	Tab																FUN held	⌵	⌵							

HOST HOST - L7 (Hold LH0 • Tab)

⌵																										⌵			
					Move→ WEB	Move→ DEV	Move→ COMMS	Move→ RUN	Move→ AUX											Width	Overview						Esc		
					WEB	DEV	COMMS	RUN	AUX											Prev Win	Focus ←	Focus ↓	Focus ↑	Focus →					
					Launch	QTerm	Term	LANG	⌵	⌵											Move ←	Move ↓	Move ↑	Move →					
		⌵	⌵																HOST held	⌵	⌵			Full	Prev WS	Float	⌵	⌵	

GAME GAME - L8 (Via ADJUST)

⌵	1	2	3	4	5											6	7	8	9	0	Del					
Esc	Q	W	E	R	T											Y	U	I	O	P	Bsp					
Tab	A	S	D	F	G											H	J	K	L	;	'					
Shift	Z	X	C	V	B	⌵	BASE	N	M	,	.	/	RShift													
					Ctrl	Alt	Space	Space	Tab											Enter	Bsp	Del	RAlt	RCmd		

ADJUST ADJUST - L9 (Hold NAV + NUM)

BOOT	RESET	BT Clear	Out USB	Out BLE	Ext On											Ext Off	BT Next	BT Prev	GAME	RESET	BOOT																												
		BT 1	BT 2	BT 3	BT 4	BT 5																Unlock																											
		⌵	⌵																NAV held											NUM held	⌵	⌵																	

ACCESS & SYSTEM NOTES

Layer Transitions & Recovery

LAYER ACCESS

- MEDIA Hold LM5
- MOUSE Hold L-thumb Esc (LH2)
- NAV Hold L-thumb Space (LH1)
- HOST Hold L-thumb Tab (LH0)
- SYM Hold R-thumb Enter (RH0)
- NUM Hold R-thumb Bsp (RH1)
- FUN Hold R-thumb Del (RH2)
- ADJUST Hold NAV + NUM (Space+Bsp)

SPECIAL MECHANICS

- ADJUST NAV + NUM conditional rule (L1+L4)
- GAME Entered via ADJUST RT3 (&to L_GAME)
- EXIT GAME Right Encoder press REC (&to L_BASE)
- NUMBER ROW Dedicated physical numbers on BASE/GAME

Gaming Architecture Note

- Plain QWERTY, no HRMs. Tap REC to exit.

HARDWARE RECOVERY

- BOOTLOADER SHORTCUTS Left side: NAV LTS / ADJUST LTS Right side: NUM RTS / ADJUST RTS
- Peripheral Bootloader Caveat Right BOOT requires split link. Use physical reset button if unlinked.

ENCODERS & PROTOCOL

EC11 Rotary Knobs & Host HID

LEFT ENCODER (LEC)

- ROTATION BEHAVIORS Default / NAV: Page Down / Page Up MEDIA layer: Previous / Next track MOUSE layer: Volume Down / Vol Up
- PUSH SWITCH (LEC) BASE: Caps Word toggle GAME: None (disabled)

RIGHT ENCODER (REC)

- ROTATION BEHAVIORS Default / NAV: Volume Down / Vol Up MOUSE layer: Page Down / Page Up
- PUSH SWITCH (REC) BASE: Mute toggle GAME: Exit to BASE (&to L_BASE)

HOST PROTOCOL (F13–F24)

- CROSS-PLATFORM HID F13–F17: Workspaces 1–5 Shift+F13..F17: Move to WS Ctrl+F13..F16: Directional Focus F21–F24: Copy / Paste / Cut / Undo
- Host Bridge Dependency Requires active Karabiner or AHK bridge.