

CORNE · ONE-PAGE LAYER CHEATSHEET

Colemak-DH · Bilateral Home-Row Mods · Semantic F13–F24 Protocol · 42 Positions · 6-Thumb Layer Model

☐ Layer Access / Transition

 Transparent / Fallthrough

☐ Unused on this Layer

BASE BASE · L0 (Colemak-DH)

Esc	Q	W	F	P	B	J	L	U	Y	'	Bsp
MEDIA	A Cmd	R Alt	S Ctrl	T Shift	G	M	N RShift	E RCtrl	I RAlt	O RCmd	;
Shift Sticky	Z	X	C	D	V	K	H	,	.	/	RShift
Esc MOUSE			Space NAV	Tab HOST	Enter SYM	Bsp NUM	Del FUN				

MEDIA MEDIA - L3 (Hold LMS)

[illegible]

FUN FUN · L6 (Hold RH2 · Del)

	F12	F7	F8	F9	PrtSc	Caps Lock			
	F11	F4	F5	F6	ScrLk		RShift Sticky	RCtrl Sticky	RAlt Sticky
	F10	F1	F2	F3	Pause				
			Menu	Space	Tab			FUN held	

ADJUST ADJUST · L9 (Hold NAV + NUM)

[illegible]

NAV NAV · L1 (Hold LH1 · Space)

[illegible]

NUM NUM · L4 (Hold RH1 · Bsp)

/	[	7	8	9	]					BOOT
*	;	4	5	6	=	RShift Sticky	RCtrl Sticky	RAIt Sticky	RCmd Sticky	
+	`	1	2	3	\					
		.	0	-		NUM held				

HOST HOST · L7 (Hold LH0 · Tab)

Move→ WEB	Move→ DEV	Move→ COMMS	Move→ RUN	Move→ AUX		Size	Overview		Esc
WEB	DEV	COMMS	RUN	AUX	Prev Win	Focus ←	Focus ↓	Focus ↑	Focus →
Launch	Quake	NewTerm	LANG			Move ←	Move ↓	Move ↑	Move →
			HOST held		Full	Prev WS	Float		

GAME_FN GAME_FN - L10 (Hold Esc / R-thumb FN)

↵	1	2	3	4	5	6	7	8	9	0	↵
↵	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	↵
↵	`	-	=	[	]	↵	↵	↵	↵	↵	↵
						↵	↵	BASE			

MOUSE MOUSE · L2 (Hold LH2 · Esc)

										Undo	Paste	Copy	Cut	Redo	
										Back	Pointer ←	Pointer ↓	Pointer ↑	Pointer →	Forward
											Scroll ←	Scroll ↓	Scroll ↑	Scroll →	
										Right click	Left click	Middle click			

MOUSE
held

SYM SYM · L5 (Hold RH0 · Enter)

@	#	\$	]	}	)						
!	<	>	[	{	(	RShift Sticky	RCtrl Sticky	RAlt Sticky	RCmd Sticky		
&		*	-	=	+						
			\	/	_	SYM held					

GAME GAME · L8 (Via ADJUST)

[illegible]

ACCESS & SYSTEM NOTES

Reference & Hardware Rules

LAYER ACCESS

- **MEDIA** Hold LM5
- **MOUSE** Hold L-thumb Esc (LH2)
- **NAV** Hold L-thumb Space (LH1)
- **HOST** Hold L-thumb Tab (LH0)
- **SYM** Hold R-thumb Enter (RH0)
- **NUM** Hold R-thumb Bsp (RH1)
- **FUN** Hold R-thumb Del (RH2)
- **ADJUST** Hold NAV + NUM (Space+Bsp)

SPECIAL MECHANICS

- ADJUST**
NAV + NUM conditional rule (L1+L4)
- GAME**
Entered via ADJUST RT3 (&to L_{GAME})
- GAME_FN**
Hold Esc (LT5) or Hold RH1 (&mo)

EXIT GAME

GAME_FN RH2 (&to L_BASE,

GAME RH2 Transparent Note

RH2 falls through to BASE Del/FUN. Not an exit

HARDWARE & PROTOCOL

BOOTLOADER SHORTCUTS

Right side: NUM RT5 / ADJUST RT5

Peripheral Bootloader Caveats

Right BOOT requires split link. Use physical reset button if unlinked.

HOST PROTOCOL (F13–F24)
HOST and edit semantic signals require the active macOS or Windows host bridge.