

B. Franke, R. Kensek, H. Schriner, L. Lorence, and F. Gelbard Sandia National Laboratories, 2001

Adjoint Charge Deposition and CAD Transport in ITS



Charge Deposition

- Net charge deposited is the difference between the removal and absorption of charged particles in a medium
- Charge removal
 - Interactions imparting energy to secondary charged particles
 - The production of secondary charged particles above the cutoff energy due to Boltzmann interactions
- Charge deposited
 - Due to the "absorption" of charged particles slowing down in the medium
 - Interactions that leave the particle with less than the cutoff energy due to either the CSD operator or an inelastic Boltzmann interaction
- Adjoint allows for an easier calculation of localized deposition
 - When electronic equilibrium exists with a photon source the charge deposition is highly localized near material interfaces



Adjoint Particle Source for Charge Deposition

- Extend MITS to charge deposition
 - Combination of ITS and CEPXS
- Developing a proper adjoint particle source
- Modifications to the cross section form
 - low-energy groups



Adjoint Electron-Photon with ITS

• Coupled electron-photon transport to solve Boltzmann-Fokker-Planck (BFP) equation

The adjoint BFP:

$$\begin{split} &-\overrightarrow{\Omega}\cdot\overrightarrow{\nabla}\psi^{\dagger}+\sigma_{t}(\mathring{r},E)\,\psi^{\dagger}=Q^{\dagger}\,(\mathring{r},E,\overrightarrow{\Omega})+\int_{0}^{\infty}dE\int_{0}^{4\pi}d\overrightarrow{\Omega}'\,\sigma_{s}(\mathring{r},E\to E,\overrightarrow{\Omega}\to\overrightarrow{\Omega}')\,\psi^{\dagger}\,(\mathring{r},E,\overrightarrow{\Omega}')\\ &+\frac{\alpha\,(\mathring{r},E)}{2}\,(\frac{\partial}{\partial\mu}\bigg[\,(1-\mu^{2})\frac{\partial}{\partial\mu}\psi^{\dagger}\,\bigg]+\frac{1}{1-\mu^{2}}\frac{d^{2}}{d\phi^{2}}\psi^{\dagger}\,)-\frac{\partial}{\partial E}\big[\,S\,(\mathring{r},E)\,\psi^{\dagger}\,\big]+(\frac{\partial}{\partial E}S\,(\mathring{r},E)\,)\,\psi^{\dagger} \end{split}$$

- The 1st line contains the Boltzmann terms
- The 2nd line contains the Fokker-Planck terms
 - Represent electron interactions with small deflections or energy loss
- α is the restrictive momentum transfer & S is the restrictive stopping power



MITS

- The Multigroup/Continuous-Energy (hybrid) Integrated TIGER Series (ITS)
- CEPXS/ONELD cross-section generator
- ITS input/output and combinational geometry routines
- Converts the multigroup-Legendre format cross sections into cumulative probability distributions for CM scattering
- A particle's group index is needed for Boltzmann scattering
- A particle's discrete energy is needed for Fokker-Planck energy loss

Boltzmann-Interaction Contributions to Charge Deposition

- Requires accurate modeling of the lowest-energy electron group
 - Most positive contributions to the electron deposition, will pass through the lowest-energy group
- Finite total cross-section required for adjoint
 - Cannot invert a non-finite cross section
 - Used in calculating higher energy adjoint particles

$$N_g = \Sigma_{g \to L} \cdot \frac{\Delta E_g}{\Delta E_L} \cdot \frac{1}{\Sigma_{tL}}$$

Lowest-Energy Cross-Section

- Introduce a Boltzmann interaction for the lowest group
 - A pseudo-group is created for the lowest-energy group to "scatter" into
- The Boltzmann-scattering cross section between adjoining groups
 - Based on the transfer of particles between adjoining groups
 - For the lowest group

$$\Sigma_{g \to g+1} = \frac{\beta_{g \to g+1}}{E_g^m - E_{g+1}^m} \longrightarrow \Sigma_{aL} = \frac{\beta_{L \to L+1}}{E_L^m - E_{L+1}^m}$$



Adjoint Particle Weight

- Adjoint particle weight at cutoff is equal to the stopping power
- When adjoint particle speeds up between groups, its weight is adjusted by the ration of stopping powers
 - Can use to determine the size of the pseudo-group
- Adjoint particle weight in the lowest group can be defined as

$$W_L = \Sigma_{aL} \Delta E_L$$

 Requires pseudo-group to have the same energy width as the lowest group

$$E_{L+1}^m = E_L^m - \Delta E_L$$



Modeling Geometries in ITS

ITS

- Uses simple geometric shapes (sphere, cylinder, etc)
- Combines geometries using Boolean operations
- Efficient for computational run-time
 - Combinational geometry makes intersection calculations for ray tracing easy
 - All spaces is defined, even void
- Enormous setup effort for complex geometries
 - Some objects just cannot be accurately modeled



Modeling Geometries

CAD

- More accurate geometric representation
- Faster setup time
 - Some models may be preexisting in CAD format
- Low geometric tolerances may result in history rejection
 - Code can no longer follow particle trajectory if it slips into the cracks
- Slower computationally
 - Additional face intersection calculations required for ray tracing
 - Not all space is well defined



Developing CAD routine for ITS

- ACIS file format was used
 - Format will be automatically updated, no maintenance required
 - Common format for several commercial CAD packages
- Routines can interrogate the geometry in the following manner:
 - Given a point and a direction, determine the closest boundary intersection.
 - Given a point, identify the region enclosing that point
 - Given a point on a surface, determine the outgoing surface normal
 - Given a point, determine the minimum distance to a boundary



Speeding up the CAD routine

- A regular grid is superposed on the entire geometry
 - A list is created of all regions that intersect each cell
 - Entering a void only requires not being in all other regions within a cell
- Create bounding volume around each part and each face
 - If the ray misses the bounding volume, it misses the object within
- Screens rays intersecting bounding volumes
 - Object interrogated only if distance is closer than the closest object found
- Code remembers which regions can be entered while exiting a given region
- Code prevents the remaining zones from being checked more than once when determining where it is headed



Questions?