

Shimano BT-E6000 BMS — CRC-16 Init Values

Source: CRC_inits.pmdx (PlanMaker) · SEQ values for known frame types only

SEQ (dec)	SEQ (hex)	SEQ (binary)	CRC Init (hex)	CRC Init (binary)	XOR (HI⊕LO)	Init swapped (hex)	Frame type
0	0x00	00000000	0x337D	00110011 01111101	01001110	0x7D33	Greeting
1	0x01	00000001	0x4A3B	01001010 00111011	01110001	0x3B4A	?
5	0x05	00000101	0x8683	10000110 10000011	00000101	0x8386	Charger Poll
7	0x07	00000111	0xD72D	11010111 00101101	11111010	0x2DD7	Auth Challenge
18	0x12	00010010	0x0746	00000111 01000110	01000001	0x4607	Capabilities?
22	0x16	00010110	0xF46E	11110100 01101110	10011010	0x6EF4	Batt Telemetry

XOR column = HI-byte ⊕ LO-byte of CRC Init. CRC algorithm: CRC-16/CCITT, poly=0x1021, refin=true, refout=true, xorout=0x0000. Init value depends on SEQ byte of the frame.