UNIVERSITETI I PRISHTINËS FAKULTETI I INXHINIERISË ELEKTRIKE DHE KOMPJUTERIKE



DOKUMENTACIONI I PROJEKTIT

Lënda:Mikroprocesorë dhe mikrokontrollerë **Tema:**Gjeneratori i frekuencave 0-40MHz AD9850 (MODBUS RTU)

Profesori: Mr.Sc Lavdim Kurtaj Studentët: Ardi Rexhepi

Blerta Krasniqi Elvisa Gashi Mirjetë Hajdari Mrika Govori Perparim Dubova Shpresarta Hamza

Përmbajtja

1	Hyrje	3
	Moduli AD9850	
	2.1 Tiparet dhe Perdorimi	
	2.1.1 Tiparet:	
	2.1.2 Aplikimet:	
	2.2 Definimi i pin-ave	
3	Pllaka Easy8051A	7
	Mikrokontrolleri dhe ndërfaqja	
5	MODBUS	8
6	Ndërfaqja grafike në PC (GUI)	10
7	Nderfaqja njeri-makine	12

1 Hyrje

Qëllimi i realizimit të këtij projekti është gjenerimi i sinjaleve 0-40MHz me AD9850 (MODBUS RTU). Do të shfrytëzohet moduli **AD9850**i cili përmes komunikimit paralel 8 bitësh do të komunikojë me mikrokontrollerin **AT89S8253** i cili i takon familjes të mikrokontrollerëve 8051.

Modbus shpesh përdoret për të lidhur një kompjuter mbikëqyrës me një njësi terminalesh të largët (RTU) në sistemet e mbikëqyrjes dhe mbledhjes së të dhënave (SCADA). Versionet e protokollit Modbus ekzistojnë për linjat serike (Modbus RTU dhe Modbus ASCII) dhe për Ethernet (Modbus TCP).

Modbus RTU mode është zbatimi më i zakonshëm, qe përdor kodimin binar dhe CRC kontrollin e gabimeve. Mesazhet ASCII Modbus (megjithëse paksa më të lexueshme për shkak se përdorin karaktere ASCII) janë më pak efikase dhe përdorin kontrollin e gabimeve më pak efektiv LRC.

2 **Moduli AD9850**

AD9850 është një pajisje më e integruar që përdor Teknologjin DDS të avancurte shoqëruar me një shpejtësi të brendshme të lartë, konvertues me performancë të lartë D/A dhe krahasues për të formuar një sintetizues të frekuencave të programueshme digjitale dhe funksion të gjeneratorëve të clockut. Kur referohet në një burim të saktë të clockut, AD9850 gjeneron një spekter të paster, frekuencë/ faze të programueshme, output analog i vales sinusoidale. Kjo vale sinus mund te perdoret drejtpersedrejti si burim I frekuences , ose mund te konvertohet ne nje vale katrore per aplikacionet e gjeneratoreve te agile-clock.

Arkitektura e qarkut AD9850 lejon prodhimin e frekuencave të prodhimit deri në gjysmën e frekuencës së clockut referues (ose 62.5 MHz), dhe frekuenca e daljes mund të ndryshohet në mënyrë digjitale (asinkrone) me një normë deri në 23 milionë frekuenca të reja për sekondë.




Figura 1. Pamje e modulit AD9850




Figura 2.

2.1 Tiparet dhe Perdorimi

2.1.1 Tiparet:

- Shpejtësia e prodhimit të sinjalit me frekuencë: 0-40MHz
- 4 Signal outputs
- 2 dalje të valës sinusoidale dhe 2 dalje në valë katrore
- DAC SFDR > 50 dB @ 40 MHz AOUT
- 32-Bit Frekuenca Tuning Word
- Interface i thjeshtuar i kontrollit: Bajta paralel ose format i ngarkimit serial
- Faza e Modulimit të Aftësis (Phase Modulation Capability)
- +3.3 V ose +5 V Operim i Vetëm i Furnizimit
- Low Power: 380 mW @ 125 MHz (+5 V)
- Low Power: 155 mW @ 110 MHz (+3.3 V)
- Funksioni Power-Down
- Size: 42 x 30 x 1.6 mm

2.1.2 Aplikimet:

- Frekuenca / Faza-agile Sintetizimi Sine-Wave
- Rigjenerim i clockut dhe Bllokimi i qarkut për Dixhital
- Komunikimi
- Digitally Controlled ADC Encode Generator
- Agile Local Oscillator Applications

2.2 Definimi i pin-ave




Figura 3. Permbajtja e modulit

Sensori per perdorim ka ne dalje pinat ZOUT2, ZOUT1, QOUT2, QOUT1, GND, RESET, DATA, FU UD, W CLK, VCC dhe GND, D7, D6, D5, D4, D3, D2, D1, D0, VCC.

PIN-i	Lidhja
ZOUT2	

ZOUT1	Osciloscope
QOUT2	Nuk lidhet
QOUT1	Nuk lidhet
GND	
RESET	P1.6
DATA	
FU_UD	P1.5
W_CLK	P.1.4
VCC	

Porti 0	
PIN-i	Lidhja
GND	GND
D7	P0.7
D6	P0.6
D5	P0.5
D4	P0.4
D3	P0.3
D2	P0.2
D 1	P0.1
D0	P0.0
VCC	VCC

3 Pllaka Easy8051A

Pllaka zhvillimore e mikrokontrollerit 8051 është përdorur për kontrollimin e sistemit, leximin e references dhe sensorit,leximin e nderprersave kufitar, kontrollin e AD9850 modulit dhe paraqitjen e nje interfejsi të thjeshtë me njeriun.




Figura 4. Pllaka Easy8051A dhe pjeset e saj

4 Mikrokontrolleri dhe ndërfaqja

Mikrokontrolleri i cili do të përdoret për realizimin e projektit do të jetë AT89S8253 i cili i takon familjes 8051.




Figura 5. Pinat e 8051 dhe pamje e pllakës Easy8051A

Disa nga specifikat teknike të mikrokontrollerit AT89S8253 janë:

- Kompatibil me produktet e familjes MCS51
- Memorie të brendshme flash 12K Bytes (10,000 cikle lexim/shkrim)
- Memorie për të dhëna EEPROM 2K Bytes
- Memorie RAM 256 x 8 bit
- 32 Linja I/O të programueshme
- Tre kohorë/numërues 16 bit

Mikrokontrolleri do të jetë i instaluar në pllakën zhvillimore **Easy8051A** e cila përmbanë të instaluar edhe disa nga butonat dhe display 7 segmentësh të cilët do i përdorim për të "shfletuar" vlerat e lexuara nga sensori.

5 MODBUS

Modbus është një protokoll i komunikimit që është zhvilluar nga Modicon systems. Përndryshe MODBUS është një metodë që përdoret për transmetim apo bartje të të informacioneve përgjatë linjave serike ndërmjet pajisjeve elektronike.

Protokolli Modbus definohet si një protokoll master / slave, që do të thotë një pajisje që vepron si një master do të drejtoje një ose më shumë pajisje që veprojnë si slaves. Kjo do të thotë që një pajisje slave nuk mund të japë informacion vullnetar; duhet të presë që të kërkohet. Masteri do të

mundet te shkruajë të dhëna në një regjistër të pajisjes slave dhe do të lexojë të dhëna nga regjistrat e një slave.

Forma më e përdorur e protokollit Modbus është RTU.

Modbus RTU është një protokoll serik relativisht i thjeshtë që mund të transmetohet nëpërmjet teknologjisë tradicionale UART. Të dhënat transmetohen në bytes 8-bit, një bit në një kohë, në normat e baud rate që shkojnë nga 1200 bit për sekondë (baud) deri në 115200 bit për sekondë. Shumica e pajisjeve të Modbus RTU mbështesin vetëm shpejtësinë deri në 38400 bit për sekondë.

Një rrjet Modbus RTU ka një Master dhe një ose më shumë slaves. Secili slave ka një adresë unike të pajisjes 8-bit ose numrin e njësisë. Paketat e dërguara nga master përfshijnë adresën e slave-it për të cilin është drejtuar mesazhi. Slave duhet të përgjigjet vetëm nëse adresa e tij është e njohur dhe duhet të përgjigjet brenda një periudhe të caktuar kohore ose masteri do ta quajë si gabim "asnjë përgjigje".



Figura 6 Paketa e Modbus

Çdo shkëmbim i të dhënave përbëhet nga një kërkesë nga masteri, e ndjekur nga një përgjigje nga slave. Çdo pakete e të dhënave, qoftë kërkesë ose përgjigje, fillon me adresën e pajisjes ose adresën e slave, e ndjekur nga kodi i funksionit, i ndjekur nga parametrat që përcaktojnë se çfarë kërkohet apo jepet.

Të dhënat Modbus janë më së shpeshti të lexuara dhe të shkruara si "regjistra" të cilët janë të dhëna 16-bitëshe. Zakonisht, regjistri është ose një numër i plotë signed ose unsigned 16-bit. Nëse kërkohet një numër i plotë 32-bit ose një floating point, këto vlera lexohen në të vërtetë si dy regjistra. Regjistri më i zakonshëm quhet Holding Register, dhe këto te dhena mund të lexohen ose shkruhen. Lloji tjetër i mundshëm është Input Register, i cili është vetëm i lexueshëm.

Përjashtimet për regjistrat që janë 16 bit janë coil dhe inputi diskret, të cilat janë vetëm 1 bit. Coil mund të lexohet ose të shkruhet, ndërsa inputet diskrete janë vetem të lexueshme.

Lloji i regjistrit që adresohet nga një kërkesë Modbus përcaktohet nga kodi i funksionit(Function Code). Kodi i funksionit 6 përdoret për të shkruar një regjistër të vetëm mbajtës(Holding Register). Kodi i funksionit 16 përdoret për të shkruar një ose më shumë regjistra mbajtës(Holding Register).




Figure 7. Modbus RTU RS232

Protokolli Modbus përcakton disa funksione kodesh për të hyrë në regjistrat Modbus.

Function Code	Register Type	
1	Read Coil	
2	Read Discrete Input	
3	Read Holding Registers	
4	Read Input Registers	
5	Write Single Coil	
6	Write Single Holding Register	
15	Write Multiple Coils	
16	Write Multiple Holding Registers	

^{***} Nëse jeni duke përdorur pajisje RS-232, ju mund të keni vetëm dy pajisje gjithsej, pavarësisht se si janë konfiguruar.

6 Ndërfaqja grafike në PC (GUI)

Të dhënat e lexuara nga sensori do të i dërgojmë edhe në PC për analizim. Për këtë arsye është zhvilluar një ndërfaqe grafike në gjuhën programuese C# së bashku me kornizën .NET (WinForms).





Figura 8. Pamje e faqës së ndërfaqës në PC

Nga këtu shihet se pasi të realizohet lidhja me mikrokontrollerin ,ne mund të zgjedhim portin dhe Baud Rate (10416) dhe pasi të dërgojmë kërkesën në HZ, KHZ ose MHZ rezultati do të shihet në osciloskop.

Baud Rate tregon numrin e bitave që porti serik mundet ti transmetojë brenda 1 sekondi. Për të shfaqur pamjen në GUI duhet të përcjellni shtegun si në vijim:

11P_2018-2019/11P AD9850/11P AD9850/obj/Debug/CuurentMeter.

Kjo do t'ua mundësojë që të shihni aplikacionin edhe nëse nuk e keni Visual Studio-n të instaluar.



1MHZ: 1KHZ:




Figura 9. Pamje ne osciloskop

7 Nderfaqja njeri-makine

Ndërfaqja ka 4 butona të cilin e lejon përdoruesin që të zgjedh modin e punës së sistemit, rregullimin e parametrave ose për kërkesë të shfaqjeve. Butonat janë të emëruara ESC, OK, UP dhe DOWN. Butoni OK e dergon Menyne në një hapë përpara, butoni ESC e kthen një hap mbrapa ndërsa UP dhe DOWN levizin poshtë dhe lartë.

BUTONI	Funksioni
P2.0	UP
P2.1	ESCAPE
P2.2	OK
P2.3	DOWN

8 Referencat

I.Scott MacKenzie and Raphael C.-W. Phan. The 8051 Microcontroller, Fourth Edition.

https://www.analog.com/media/en/technical-documentation/data-sheets/AD9850.pdf

https://www.schneider-electric.com/en/fags/FA168406/

https://www.csimn.com/CSI_pages/Modbus101.html?fbclid=IwAR09Ck9Z2COPdotm7-Uy4-gf0wKd2lpoL3cNXe21hFIPmKDWWZTCjBfTrCQ

9 Kodi ne Assembler

```
;DESCRIPTION
:=====DESCRIPTION END==============
·
......
      ;initialization
......
      display0 equ 030h;
display1 equ 031h;
display2 equ 032h;
display3 equ 033h;
                                  register for display 0
                                  register for display 1
                                  register for display 2
                                  register for display 3
      nestedsample equ 034h;
                                  sample time divider
      nestednum
                    equ 5;
                                  sample time constant
                                  sample time divider
       nestedsamplee equ 035h;
      nestednumm equ 40;
                                         sample time constant
      proc0 stat
                    egu 036h;
                                  process state
      proc1 stat
                    equ 037h;
                                  process state
      previousbuttonport equ 038h; saving previous scan of keyboards (for negative edge
detection)
      shownumH
                    egu 039h;
                                  data HIGH for displaying
                    equ 3ah;
      shownumL
                                  data LOW for displaying
      timer3p5
                    equ 03bh;
                                  waiting 3.5cahracter for modbus
      start3p5
                    equ 000h; BIT
                                         start 3.5 calculating time
                    equ 18h; bit
                                  set when user made all the erquests on meny
      menudone
                    egu 19h;bit
                                  send a request to lower the frequency
      regdown
                    equ 1ah;bit
                                  send a request to raise the freq
      requp
      limup
                    equ 1bh;bit
                                  limit raising frequency
                                         limit lowering frequency
      limdown
                           equ 1ch;bit
      data3
                    equ 40h;
                                  data sent to device for setting frequency, MSB
                    equ 41h;
                                  data sent to device for setting frequency, seond byte
      data2
                                  data sent to device for setting frequency, third byte
      data1
                    egu 42h;
                    equ 43h;
                                  data sent to device for setting frequency, LSB
      data0
      calculateforreading equ 001h;
                                         MODBUS parameter to calculate CRC for reading
or writing buffer
      writingbuffercount equ 03ch; MODBUS save number of bytes to send (reply)
       :Constants
```

MODBUS 3.5character constant tim3p5 egu 40h; CoilsNumber equ 64; MODBUS number of coils CoilsStartAdd equ 40h; MODBUS address of first coil HoldingRegStartAdd equ 30H; MODBUS start of first register HoldingRegNumber equ 10H; MODBUS number of registers StartofReadingBuffer equ 128; MODBUS start of readinf buffer StartofWritingBuffer equ 192; MODBUS start of writing buffer :for device w clk equ p1.4; DEVICE CLOCK used to load 8bit data fq ud equ p1.5; DEVICE FREQUENCY UPDATE loaded datas to output **DEVICE RESET** resett equ p1.6; constants compatible with 7-segment for showing characters Mhigh equ 00110011b Mlow equ 00100111b Ebig equ 01111001b Nbig equ 00110111b Xbig egu 01110110b Ybig egu 01100110b equ 01011011b Zbig Buttonport equ p2 :=======INITIALIZATION END======== PROGRAM INTERRUPT ORGANIZATION org 0000h ;reset interup limp main org 0bh :timer 0 isr limp t0isr org 023h ;serial port isr limp spisr ;======INTERRUPT ORGANIZARION END======== ;Main Code here org 030h

MODBUS SlaveID

SlaveID

egu 1;

```
main:
      ;CLEAN RAM
       ;Cleans all the registers on ram from
       ;$00 - $255 of general purpose ram
       ;leaving SFR un-changed
       ;calculation needed on proccesing time
       ;and program space
......
      mov r0, #01h
cleanram:
      mov @r0, #00
      inc r0
      cine r0, #00b, cleanram
CODE INITIALIZATION
       :This section initiates all the resources
      of MCu and selects their mode of
      ;operation
      mov sp, #50h; move stack pointer
mov tmod,#22h; Timer 0, mode 2 (8-bit autoreload), Working as time
; Timer 1, mode 2 (8-bit autoreload), Working as BaudRate
                                  Timer 0, mode 2 (8-bit autoreload), Working as timer
Generator
      mov th0, #-167;
mov th1, #-2;
                           Sampling f ~ 4000Hz;
                           10416 bps Baud rate
      mov th1, #-2;
      mov nestedsample, #nestednum; nest f ~ 800Hz
      mov nestedsamplee, #nestednumm;nest f ~ 20Hz
                           start timer 0
      setb tr0;
                  start timer 1
      setb tr1;
      mov scon, #50h;
                                  Mode 8bitUART r-enable
       mov ie, #10010010b; Enable interrupts
                                                Serial port + Timer 0
      mov 08, #StartOfReadingBuffer; start of reading buffer; R0 bank1
      mov 09, #StartOfWritingBuffer;start of writing buffer;R1 bank1
       mov proc1 stat, #0; Process 1 state initialization
       mov proc0 stat, #0; Process 0 state initialization
       mov timer3p5, #tim3p5;
      clr start3p5;
;====CODE INITIALIZATION END==========
       :DEVICE RESETING SEQUENCE
```

mov p0, #0 anl p1, #00001111b ;clr resett setb resett clr resett ;clr w clk setb w clk clr w_clk ;clr fq ud setb fq ud clr fq ud startitall: inb menudone, startitall; wait for user to select meny mov r2, shownumL; pass parameter to show on 7seg display low mov r1, shownumH; pass parameter to show on 7seg display high Lcall HextoDisplay; do the math jmp startitall; loop HexToDisplay: Icall HexToBcd; 16-bit (r2-LOW, r1-HIGHT) to r3-ones, r4-tenths, r5hundreds, r6-thousands, r7-tenthousands, mov a. r3: ones Icall nto7seg; make ones 7-segment compatible number mov display0,a; move data to show at display0 mov a, r4; tenths Icall nto7seg; make tens 7-segment compatible number move data to show at display1 mov display1,a; mov a, r5; hundreds Icall nto7seg; make hundreds 7-segment compatible number mov display2,a; move data to show at display2 mov a, r6; thousands Icall nto7seg; make thousands 7-segment compatible number mov display3,a; move data to show at display3 ret timer 0 interrupt service routine

	;		
	•		
	•		
	•		
	•		
	;		
;;;;;;;;; t0isr:			
WISI.	djnz nestedsample, fullfreq;	divide sample time	
	mov nestedsample, #nestednum; refresh divider for next use		
	;routines called in 4000Hz/n;		
	Icall display;	call display program that shows data in display	
	djnz nestedsamplee, fullfreq;	•	
		dnumm; refresh divider for next use	
	;routines called in 4000Hz/(n ⁻¹) lcall buttons;	rm); n=5; m=40; 20=HZ call button scaning (meny navigation) routine, and	
reques	•	can button scanning (meny havigation) routine, and	
	Icall LoopP;	display characters decoding	
	Icall request;	raise/lower frequency registers	
	Icall writedevice;	write registers to device	
fullfreq			
	;Routine called in 4000Hz		
	jnb start3p5, timerr3p5;	MODBUS; if start of frame detected start	
moabu	s3.5character timer djnz timer3p5, timerr3p5;	after 3.5character time finnishes	
	Icall modbus;	MODBUS	
	timerr3p5:		
	reti		
;=====	=======TIMER 0 INTE	RRUPT END=======	
	serial comm interrupt service	routine	
;		-	
	,		
	•		
	•		
	•		
	•		
	•		
	· ·		
	push psw; save p	sw	
mov psw, #00001000b; activate Bank1			
	jnb ri, transmit;if interrupt wasnt made by rec, then transmit		

```
clr ri;
                                 save data read at serial port buffer to reading buffer
      mov @r0, sbuf;
      inc r0;
                          increment pointer
                          start 3.5character timer
      setb start3p5;
                          replace Bank previously activated
      pop psw;
      reti
transmit:
      clr ti;
      dinz writingbuffercount, continue; count if not end of sending frame
      imp terminate
continue:
      mov sbuf, @r1;
                                 write data at serial port buffer for transmission
                          increment buffer for next time
      inc r1;
terminate:
      pop psw
      reti
:======SERIAL COMM INTERRUPT END=======
......
      ;DIAPLY
      ;source- WUS script-Prof. Lavdim Kurtaj
      :Routine that displays on 4 7-segments
      ;the datas on ram meories 30h - 33h
......
display:
      push acc;
                          save accumulator
      mov a,proc0 stat;
                          check process state
      rl a
      rl a
      mov dptr,#tabproc0; lookup table address
      anl p1,#11000000b; turnoff all displays
      imp @a+dptr
tabproc0:
      ljmp p0 s00
      nop
      Ijmp p0_s01
      nop
      ljmp p0 s02
      nop
      Ijmp p0_s03
      nop
                           display at 0 and set next time to process display 1
p0_s00:;
      mov p0,display0
      setb p1.0
      mov proc0 stat,#1
      ljmp p0 end
```

```
p0_s01:;
                           display at 1 and set next time to process display 2
       mov p0, display1
       setb p1.1
       mov proc0 stat,#2
       ljmp p0 end
p0 s02:;
                           display at 2 and set next time to process display 3
       mov p0,display2
       setb p1.2
       mov proc0 stat,#3
       ljmp p0 end
p0 s03:;;
                           display at 3 and set next time to process display 0
       mov p0,display3
       setb p1.3
       mov proc0 stat,#0
       ljmp p0 end
p0 end:
       pop acc; return accumulator
      ret
:==== END==========
......
       :WriteDevice
;routine that sends data3-0 to AD9850
;uses P0 as 8bit parallel data transmission mode
; and P1.4, P1.5 P1.6 as signalling pins
writedevice:
   mov p1, #0;
                    turn all displays off and device lines
   mov p0, #0;
                    send phase 0 and turnon sequence
   setb w clk;
                    clock
   clr w_clk
   mov p0, data3;
                    send LSB
   setb w clk;
                    clock
   clr w_clk
   mov p0, data2;
                    send second byte
   setb w clk;
                    clock
   clr w_clk
                    send third byte
   mov p0, data1;
   setb w clk;
                    clock
   clr w clk
```

```
mov p0, data0;
                 send MSB
   setb w clk;
                 clock
   clr w_clk
  setb fq_ud;
                 update frequency (output it)
   clr fq ud
  ret
;HEXIMAL TO BCD
     ;source
     ;http://www.iuma.ulpgc.es/~nunez/clases-sed-mai-8051/programas/16bit-t0-bcd.asm
     value in registers R1 and R2 will be
     turned to binary-coded-decimal in
     register R3 througg R7
HextoBCD:
    push acc
    MOV
           R3,#00D
    MOV
           R4,#00D
    MOV
           R5,#00D
    MOV
           R6,#00D
    MOV
           R7,#00D
     MOV B,#10D
    MOV
           A,R2
    DIV
           AΒ
    MOV
           R3,B
                       ;Resto en R3
   MOV
           B,#10
                       ; R7,R6,R5,R4,R3
    DIV
           AΒ
    MOV
           R4,B
                       ;Resto en R4
    MOV
           R5,A
    CJNE
           R1,#0H,HIGH BYTE ; CHECK FOR HIGH BYTE
    SJMP ENDD
HIGH BYTE:
     MOV A,#6
    ADD
           A,R3
     MOV B,#10
     DIV
           AΒ
    MOV
           R3,B
     ADD A,#5
    ADD
           A,R4
     MOV B,#10
     DIV
           AΒ
    MOV
           R4,B
     ADD A,#2
```

```
ADD
          A,R5
     MOV B,#10
     DIV
          AΒ
          R5,B
   MOV
          R6,#00D,ADD_IT
   CJNE
          CONTINUEue
   SJMP
ADD IT:
   ADD
          A.R6
CONTINUEue:
   MOV
          R6,A
   DJNZ
          R1,HIGH BYTE
   MOV
          B,#10D
   MOV
          A,R6
   DIV
          AB
   MOV
          R6,B
   MOV
          R7,A
ENDD:
     pop acc
     ret
;==== END==========
     ;NORMAL 0-9 TO 7-SEGMENT
     ;Value in A from 0-9 returns to
     ;7-segment compatabile value in A
......
nto7seg:
     inc a
     movc a, @a+pc
     db 63,6,91,79,102,109,125,7,127,111; 63=0-for 7seg, 6=1-for seg, ...
;==== END==========
     ;Button
......
buttons:
```

```
push acc
```

mov a, buttonport; save buttons state cpl a; complement, easy8051a uses click to low save data push acc; ;cpl a anl a, #00001111b; Assign only lower half for neg edg xrl a, previousbuttonport; check which ones have changed return buttons state pop b; accept only the ones that have negative edge anl a, b; mov previousbuttonport, b; save the data for next scan iz ended inb acc.0, nochangein0 ;change in pin 0 code UP jb menudone, requpp mov a, proc1 stat inc a cine a, #4, gottogo imp ended gottogo: inc proc1_stat jmp ended regupp: setb requp jmp ended nochangein0: jnb acc.1, nochangein1 ;change in pin 1 code ESC jb menudone, justplain mov proc1 stat, #0 justplain: clr limup clr menudone mov data0, #0 mov data1, #0 mov data2, #0 mov data3, #0 mov shownumL, #0 mov shownumh, #0 imp ended nochangein1: jnb acc.2, nochangein2 ;change in pin 2 code OK jb menudone, ended mov a, proc1 stat jz makeitone

```
setb menudone
      jmp ended
makeitone:
      mov proc1 stat, #1
      jmp ended
nochangein2:
      inb acc.3, nochangein3
      ;change in pin 3 code DOWN
      jb menudone, reqdownn
      mov a, proc1 stat
      dec a
      jz ended
      mov proc1_stat, a
      jmp ended
      regdownn:
      setb reqdown
      jmp ended
nochangein3:
      jnb acc.4, nochangein4
      ;change in pin 4 code
      jmp ended
nochangein4:
      jnb acc.5, nochangein5
      ;change in pin 5 code
      jmp ended
nochangein5:
      jnb acc.6, nochangein6
      ;change in pin 6 code
      jmp ended
nochangein6:
jnb acc.7, ended
      ;change in pin 7 code
      imp ended
ended:
      pop acc
      ret
;==== END==========
;MODBUS
```

```
MODBUS:
   push acc
   push psw
   mov psw, #00001000b
   mov timer3p5, #tim3p5
   clr start3p5
   mov r2, #startofreadingbuffer+2
   mov r3, 08
   setb calculateforreading
   Icall crc16
   mov a, @r0
   cine a, 14, failedCheckk; Check CRCHigh
   inc r0
   mov a, @r0
   cjne a, 15, failedCheckk; Check CRCLow
HereModbusdoes:
   mov r0, #StartOfReadingBuffer
   MOV R1, #StartOfWritingBuffer
   mov a, @r0
   cjne a, #slaveID, failedcheckk;Check slaveID
   mov @r1, a
   inc r1
   ;This device is addresed by modbus
   mov a, @r0;GetFunctionCode
   inc r0
   cjne a, #15, noFC15WriteMultipleCoils
   ,,,,,,,,,,,,,,,
   Ijmp Preparetransmit
noFC15WriteMultipleCoils:
   cine a, #16, noFC16WriteMultipleRegisters
   Icall AddressLavidation
      jc AddressPassFC16
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #90H
      inc r1
       mov @r1, #02
      inc r1
       Ijmp Preparetransmit
```

```
mov r1, #STARTOFWRITINGBUFFER+ 1
      mov a, #16
      MOv @r1, a
      inc r1
      mov a, #0
      mov @r1, a
      inc r1
      mov r0, #StartOfreadingBuffer+3
      ;mov r0, a
      mov a, @r0
      mov @r1, a
      inc r1
      rl a
      add a, #HoldingRegStartAdd
      ;mov r0, a; Start of registers requested to WRITE
      push acc
      mov a, #0
      mov @r1, a
      inc r1
      mov r0, #StartOfreadingBuffer+5
      mov a, @r0
      mov @r1, a
      inc r1
      mov r0, #startofreadingbuffer+6
      mov a, @r0
      mov r2, a
      MOV R1, #STARTOFREADINGBUFFER+7
      pop 08
LoopitFC16:
      mov a, @r1
      mov @r0, a
      inc r0
      inc r1
      djnz 10, LoopitFC16
      MOV R1, #STARTOFwritingBUFFER+6
   Ijmp Preparetransmit
noFC16WriteMultipleRegisters:
  dec a
      rl a
      rl a
      mov dptr,#tabFC
      jmp @a+dptr
```

AddressPassFC16:

```
tabFC:
       Ijmp FC01 ReadCoils
       Ijmp FC02 ReadDiscreteInputs
       Ijmp FC03 ReadHoldingRegisters
       nop
       Ijmp FC04 ReadInputRegisters
       nop
       Ijmp FC05 WriteSingleCoil
       nop
       Ijmp FC06 WriteSingleRegister
       nop
       failedcheckk:
       limp failedcheck
FC01_ReadCoils:
       cjne @r0, #0, sendexpectioncode
       inc r0
       inc r0
       cine @r0, #0, sendexpectioncode
       dec r0
       mov a, @r0
       inc r0
       inc r0
       cine a,#CoilsNumber, notCoilatend; Check address
       cine @r0, #1, sendExpectioncode; Reading Last Bit and only one
       limp allrightnow
notcoilatend:
       jc lessthanendcoil
       sendexpectioncode:;Addres above allowed, and/or number of coils above allowed
       mov @r1, #81h
       inc r1
       mov @r1, #2
       inc r1
       Ijmp preparetransmit
lessthanendcoil:
       dec r0
       dec r0
       mov a, @r0
       inc r0
       inc r0
       add a, @r0
       cine a, #CoilsNumber, NotalltheCoils; make sure doent overflow the address
```

```
simp allrightnow
        notAllthecoils:
       jnc sendexpectioncode
        allrightnow:
        dec r0
        dec r0
        mov a, @r0
        mov b, #8
        div ab
        add a, #CoilsStartAdd/8; we got the addres of first register to send
        add a, #20
        push acc; save the addres of first reg
        mov r0, #StartOfReadingBuffer + 4; number of bits
        mov a, @r0
        mov b, #8
        div ab
        mov r2, a; Loop number of registers
        inc b; mask; number of bits at the end
        mov a, #0ffh
shiftloop:
       djnz b, shiftit
        simp endshifting
        Shiftit:
       clr c
       rrc a
       sjmp shiftloop
endshifting:
        mov r3, a;save mask
        mov r1, #StartofWritingBuffer + 1;response
        mov @r1, #1;response fc code
        inc r1
       inc r2
        mov a, r2
        mov @r1, a
        inc r1
        pop 08
        loopwriting:
        mov a, @r0
        inc r0
        mov @r1, a
        inc r1
        djnz r2, loopwriting
        dec r1
        mov a, @r0
        anl a, r3
```

```
mov @r1, a
       inc r1
       Ijmp Preparetransmit
FC02 ReadDiscreteInputs:
       Ijmp Preparetransmit
FC03_ReadHoldingRegisters:
       Icall AddressLavidation
      jc AddressPass
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #83h
       inc r1
       mov @r1, #02
       inc r1
       Ijmp Preparetransmit
       AddressPass:
       mov r0, #StartOfreadingBuffer+3
       ;mov r0, a
       mov a, @r0
       rl a
       add a, #HoldingRegStartAdd
       ;mov r0, a; Start of registers requested to read
       push acc
       mov r0, #StartOfreadingBuffer+5
       mov a, @r0
       rl a
       mov r2, a
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #03
       inc r1
       mov @r1, a
       inc r1
       pop 08
LoopitFC3:
       mov a, @r0
       mov @r1, a
       inc r0
       inc r1
       djnz 10, LoopitFC3
       Ijmp Preparetransmit
```

```
FC04 ReadInputRegisters:
       Ijmp Preparetransmit
FC05 WriteSingleCoil:
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #85h
       inc r1
       mov @r1, #01
       inc r1
       Ijmp Preparetransmit
FC06 WriteSingleRegister:
       mov r0, #StartOfReadingBuffer+2
       cine @r0, #0, sendexpectionFC6
       simp addresspassFC6
sendexpectionFC6:
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #86h
      inc r1
       mov @r1, #02
       inc r1
       Ijmp Preparetransmit
addresspassFC6:
cine @r0, #HoldingRegNumber, notthelastregFC6
notthelastregFC6:
inc sendexpectionFC6
       mov r1, #StartOfWritingBuffer+1
       mov @r1, #06h
       inc r1
       mov @r1, #0
       inc r1
       mov r0, #StartOfreadingBuffer+3
       ;mov r0, a
       mov a, @r0
       mov @r1, a
       inc r1
       rl a
       add a, #HoldingRegStartAdd
       ;mov r0, a; Start of registers requested to read
       push acc
       mov r0, #StartOfreadingBuffer+4
       mov a, @r0
```

```
mov @r1, a
      inc r1
      80 qoq
      mov @r0, a
      inc 08
      push 08
      mov r0, #StartOfreadingBuffer+5
      mov a, @r0
      mov @r1, a
      inc r1
      pop 08
      mov @r0, a
       Ijmp Preparetransmit
Preparetransmit:
   push 09
   mov r2, #startofwritingbuffer
   mov r3, 09
   clr calculateforreading
   Icall crc16
   pop 09
   mov a, r6
   mov @ r1, a
   inc r1
   mov a, r7
   mov @r1, a
   inc r1
   mov a, r1
   inc a
   clr c
   subb a, #Startofwritingbuffer
   mov writingbuffercount, a
   setb ti
   failedcheck:
   mov r1, #startofwritingbuffer
   mov r0, #startofreadingbuffer
   pop psw
   pop acc
   ret
;==== END ==========
......
      ;CRC16
```

```
CRC16:
   mov a, r3;pass pointer
   subb a, r2;pass end of pointer, calculate length
   mov r5, a;
   jnb calculateforreading, forwriting
   mov r0, #startofreadingbuffer
   simp calculateCRC
   forwriting:
   mov r0, #startofwritingbuffer
   calculateCRC:
   mov r7, #0ffh
   mov r6, #0ffh
 outterloop:
   mov a, r6
   xrl a, @r0
   mov r6, a
   mov a, r7
   xrl a, #0
   mov r7, a
   mov r4, #8
   inc r0
 Innerloop:
   clr c
   mov a, r7
   rrc a
   mov r7, a
   mov a, r6
   rrc a
   mov r6, a
```

inc dontpol

```
mov a, r7
   xrl a, #0a0h
   mov r7, a
   mov a, r6
   xrl a, #01
   mov r6, a
   dontpol:
   djnz r4, innerloop
   djnz r5, outterloop
      ret
;Adress Validation
......
AddressLavidation:
mov r0, #StartOfReadingBuffer+2
cjne @r0, #0 ,failedaddress
inc r0
inc r0
cjne @r0, #0 ,failedaddress
dec r0
cine @r0, #HoldingREGNumber, notLastAddress
inc r0
inc r0
cjne @r0, #1, failedaddress
CheckGoodaddress:
setb c
ret
notlastaddress:
inc failedaddress
mov r0, #StartOfReadingBuffer+3
mov a, @r0
inc r0
inc r0
add a, @r0
cine a, #HoldingRegNumber, TestOverflow
simp CheckGoodAddress
```

```
TestOverflow:
jc CheckGoodAddress
failedaddress:
clr c
ret
LoopP:
      mov a, proc1 stat; process state
      rl a
      rl a
       mov dptr,#tabproc1s;
                                      lookup table address
      jmp @a+dptr
tabproc1s:
      ljmp p1_s00s
      nop
      ljmp p1 s01s
      nop
      ljmp p1 s02s
      nop
      ljmp p1_s03s
      nop
p1 s00s: ;move datas to 7seg to show MENU
       mov display3, #MHigh
       mov display2, #Mlow
       mov display1, #Ebig
       mov display0, #Nbig
       limp p1 ends
p1 s01s: ;move datas to 7seg to show HZ
       mov display3, #0
       mov display2, #Xbig
       mov display1, #Zbig
       mov display0, #0
       limp p1 ends
p1 s02s: ;move datas to 7seg to show KHZ
       mov display3, #01110100b
       mov display2, #00100000b
       mov display1, #Xbig
       mov display0, #Zbig
       Ijmp p1_ends
p1 s03s: ;move datas to 7seg to show MHZ
       mov display3, #Mhigh
       mov display2, #Mlow
       mov display1, #Xbig
```

```
mov display0, #Zbig
       limp p1 ends
p1 ends:
.....
request: ;process request to increase/decrease frequency
;UInt32.MAX=0xFFFFFFF=4294967295
;4294967295->125.000.000Hz frequency;
;34359738=0x20C49BA
                           ->1.000.000Hz; (1MHz constant)| 02h (MSB) |0Ch (third byte)| 49h
(second byte)| BAh (LSB)
;34359=0x8637
                           ->1.000Hz; (1KHz constant)|86h (MSB)| 37h (LSB)
:34=0x22
                    ->1HZ; (1HZ constant)| 22h
       jnb menudone, p1 s00
       mov a, proc1 stat
      rl a
      rl a
       mov dptr,#tabproc1
      jmp @a+dptr
tabproc1:
      Ijmp p1_s00
      nop
      ljmp p1 s01
      nop
      ljmp p1_s02
      nop
      ljmp p1 s03
      nop
p1 s00:
       ljmp p1 end1; meny state doesnt use request
p1 s01:; HZ state
       inb requp, notrequp; pass if theres no increase request, look for decrease request
                           clear parameters for next use
       clr requp;
       inc shownuml:
                                 increase data to show at display
       mov a, shownuml;
       inz contt;
                           if overflow
       inc shownumh;
                                 increase MSB too
       contt:
       clr c
       mov a, data0;
       add a, #022h;
                           add to data0 constant for 1HZ
       mov data0,a;
                           save it
       inc notregdown;
                           if no overflow pass
```

inc data1; else increase second register

mov a, data1

jnz notreqdown; case overflow

inc data2; increase third register

mov a, data2 jnz notreqdown

notrequp:

jnb reqdown, notreqdown; check for request to decrease frequency

clr reqdown; clear parameter for next use

dec shownuml; hower the data to show at 7seg

mov a, shownuml

cine a, #255, conttin; case of underflow

dec shownumh; lower the high part too

mov a, shownumH

cine a, #255, conttin; case of 2 underflows (high and low) then set to 0

mov shownuml, #0 mov shownumh, #0

jmp notreqdown; and dont touch device data

conttin:

clr c

mov a, data0;

subb a, #022h; subbstract LSB the 1Hz constant

mov data0, a

inc notregdown; if no underflow, pass

dec data1; else subbstract form second register

mov a, data1

cine a, #255, notregdown;if underflow

dec data2; decrease third register too

mov a, data2

cine a, #255, notregdown; if 3 underflows then set frequency to 0

mov data0, #0 mov data1, #0 mov data2, #0 notreqdown:

ljmp p1_end1

p1 s02: ;REQUEST for KHZ

jnb requp, notrequp1; check increase request

clr requp

inc shownuml mov a, shownuml jnz contt1

```
inc shownumh
contt1:
clr c
mov a, data0
add a, #37h;
                    increase 1KHz constant LOW
mov data0,a
 mov a, data1
                    increase 1KHz constant HIGH
addc a, #086h;
mov data1,a
mov a, data2
addc a, #00h
mov data2,a
jnc notregdown1
inc data3
notregup1:
jnb reqdown, notreqdown1; check for decrease request
clr reqdown
dec shownuml;decrease show number
mov a, shownuml
cjne a, #255, conttin1
dec shownumh
mov a, shownumH
cine a, #255, conttin1
mov shownuml, #0
mov shownumh, #0
;jmp notreqdown1
conttin1:
clr c
mov a, data0
subb a, #37h;
                    decrease 1KHz constant low
mov data0, a
 mov a, data1
subb a, #086h; decrease 1KHz constant HIGH
mov data1, a
 mov a, data2
subb a, #00h
mov data2, a
```

jnc notreqdown1

```
dec data3
       mov a, data3
       cjne a, #255, notreqdown1
         mov data0, #0
         mov data1, #0
         mov data2, #0
         mov data3, #0
       notreqdown1:
       ljmp p1 end1
p1_s03: ;REQUSTS for 1MHz
       jnb requp, notrequp2
       clr requp
       jb limup, notrequp2
       inc shownuml
       mov a, shownuml
       inz contt2
       inc shownumh
       contt2:
       clr c
       mov a, data0
       add a, #0bah;
                           add 1KHz constant LOW byte
       mov data0,a
        mov a, data1
       addc a, #049h; add 1KHz constant second byte
       mov data1,a
       mov a, data2
       addc a, #0ch; add 1KHz constant third byte
       mov data2,a
       mov a, data3
       addc a, #02h; add 1KHz constant MSB
       mov data3,a
       cjne a, #0ffh, notreqdown2
       setb limup
       mov data3, #0ffh
       mov data2, #0ffh
       mov data1, #0ffh
       mov data0, #0ffh
       notregup2:
       jnb reqdown, notreqdown2
       clr reqdown
       clr limup
```

```
dec shownuml
       mov a, shownuml
       cjne a, #255, conttin2
       dec shownumh
       mov a, shownumH
       cine a, #255, conttin2
       mov shownuml, #0
       mov shownumh, #0
       ;jmp notregdown2
       conttin2:
       clr c
       mov a, data0
       subb a, #0bah;
                           Subbstract 1MHz constant LSB
       mov data0, a
        mov a, data1
       subb a, #049h;
                           Subbstract 1MHz constant second byte
       mov data1, a
        mov a, data2
       subb a, #0ch; Subbstract 1MHz constant third byte
       mov data2, a
        mov a, data3
       subb a, #02h; Subbstract 1MHz constant MSB
       mov data3, a
       jnc notregdown2
         mov data0, #0
         mov data1, #0
         mov data2, #0
         mov data3, #0
       notreqdown2:
       ljmp p1_end1
p1 end1:
clr requp
clr reqdown
       ret
```

END