#### **ECE 395 Final Report**

"Colossal Avian" 30lb Combat Robot Telemetry System
Matthew Zhang (mjzhang4)
ECE 395
5/7/2024

#### **Abstract**

The iRobotics Combots teams design 30-lb combat robots that fight each other in an arena. The robot that I have been working on with the team is called "Colossal Avian." In order to design a robust robot, it is helpful to collect information from fights; both in real-time and in post. The telemetry system prototype that was designed over the duration of the semester integrates a microcontroller which interfaces with the various electronic speed controllers (ESCs) that control the robot to gather telemetry info and output that telemetry via a LoRa radio signal.

## Background 30lb Combat Robot - Colossal Avian




Figure 1: Image of Colossal Avian

Colossal Avian is a 30lb combat robot which features a high speed spinning disk mounted to the end of a pivoting arm, intended to deal impact damage to the tops of opposing robots. The design of the physical hardware and selection of the robot components were done out of ECE395, thus the entire robot was physically constructed and functional at the start of the class and the technical information presented here.

#### **Robot Electronics**

The whole robot is powered off of two 6 cell (22.2v nominal) lithium polymer batteries in parallel to reach a total capacity of 3000 mAh. There are a total of 4 brushless motors contained within the robot which are each individually driven by an electronic speed controller, or ESC. These ESCs are all capable of outputting telemetry data in varying formats (more detail in later sections).

- 22.2v 3000 mAh battery pack
- 2x AM32 Drive ESC
- 2x Castle Mamba X ESC
- FS2A Radio Reciever

# **Subsystem Overview Block Diagram**

## Telemetry/Data Logging Board Disc ESC RTC IMU Arm ESC SD Card Interface Serial Telemetry Serial Telemetry Microcontroller Serial Telemetry Drive ESC Serial Telemetry LoRa Module --LoRa------Drive ESC Voltage Regulator 4x PWM signal Reciever 22.2v Battery (22.2v)

Figure 2: Block Diagram including board components and robot components

#### AM32 Drive Electronic Speed Controller (ESC) Telemetry

The drive motors utilize AM32 drive ESCs that are designed for drones. These ESCs operate using the KISS telemetry protocol (<u>Outlined at this link</u>). This protocol is a one wire serial UART which transmits a 10 byte frame consisting of the ESC temperature, input voltage, current, total battery consumption, RPM, and a CRC value.

Reading in the serial telemetry from the AM32 ESCs involves reading in the telemetry via a UART RX line on the STM32 microcontroller.

#### Castle Arm/Disk ESC Telemetry

The disk and arm motors both utilize a Castle Mamba X ESC. These ESCs are also capable of providing a telemetry signal over the receiver wire using a proprietary communication protocol called "Castle Live Link" which requires passing control back and forth over the receiver connection, using the timing between low pulses to communicate information. To simplify communication for the purposes of the project, a "Castle Serial Link" was used which decodes this proprietary signal, and provides a digital serial interface (either UART, I2C, or SPI) while also allowing the receiver signal to pass-through the device. This is a product developed by Castle which was purchased from them.

The original intent was to utilize the UART interface with the Castle Serial Link. However, after designing the entire board, I realized that the UART interface also requires a TX line to talk to the Serial Link to request data. Instead of UART the Castle Serial Links were bodged to the IMU's i2c test points, taking advantage of the addressed bus to communicate between multiple devices.

#### LoRa Radio

In order to reliably transmit data, the board utilizes a LoRa module to send information over radio. LoRa is particularly suited for long range, low energy and low bandwidth signals. Given that the telemetry module only needs to send a small packet of numerical data, with reliability being a larger focus, LoRa was an attractive choice.

A RFM95W module was utilized and interfaced with the STM32 microcontroller via a SPI interface.

## **Hardware Design**

### **System Requirements:**

- Operable on max battery voltage (25.2 VDC)
- Reads telemetry from 4 different ESCs
- Can pass-through and read PWM command signals to ESCs
- Resistant to supply voltage spikes/dips
- Wireless communication is reliable in a noisy/enclosed environment inside robot
- Interfaces with Laptop
- Capable of logging data via SD Card
- USB connection for debugging via serial print statements
- Compact enough to fit within the robot

#### **Schematic**




Figure 3: Board Schematic

#### **PCB Layout**




Figure 3: Board Layout

#### Design Features:

- Capacitor bank at LDO output to prevent voltage spikes
- Power-on LED
- M3 mounting points for mounting within robot
- USB-C connection for USB serial debugging output
- Test points and headers for major connections
- External pull-ups for i2c and SD card SPI interface

#### **Major Components:**

#### Microcontroller: STM32G431RBT6

- Cortex M4 provides plenty of processing overhead for the task
- Provides the required number of peripherals (timers, UARTs, USB, etc) for the required connectivity

#### LDO: LD1086DT33TR

- Large voltage range, 4.5v 50v, provides flexibility for many different power sources including battery power, 5V, or other
- Large current capacity (1.5A) provides lots of overhead to not run out of current

#### LoRa Module: RFM95W

- Common in many projects involving LoRa radio
- 915 MHz

#### **IMU: BNO085**

- Provides on-board 9 axis sensor fusion of an accelerometer, gyro, and magnetometer, simplifying the process of getting sensor values
- I2c Interface

#### **Learnings from First Prototype**

LDO heat dissipation

- Excessive heat production when running off of battery voltage (22.2v) from dropping the voltage down to 3.3v, especially when the radio is active and drawing up to 100 mA
- Consider choosing a different type of regulator

#### Castle ESC Telemetry

- UART interface requires a transmit line as well to requires telemetry data from the ESC, had to bodge to IMU i2c
- Provide a dedicated i2c connection in the future

#### IO Protection

- During testing of the telemetry board in competition, a drive ESC went up in flames. This
  failure likely killed the STM32 in the board by sending a bad signal through the telemetry
  line.
- Future revisions could benefit from some sort of protection at the inputs to prevent component damage

#### LoRa signal strength

- During competition, the integrity of received LoRa signals was poor.
- A better antenna could be used on the receiver side (currently using a simple wire antenna)

#### Connectors

- Pin headers worked OK, but could be more compact. Within the robot space is limited, and headers were too tall in some cases
- Using other smaller connectors could be preferred

#### **Firmware**

The firmware for the telemetry board was written using STM32's CubeIDE, making use of the ST HAL and CubeIDE's pre-generated setup code.

#### Telemetry (I2C, UART)

The drive ESC telemetry system utilizes the UART peripherals in the STM32 in interrupt mode to capture the telemetry data. Upon reading a complete telemetry frame over UART, a callback function is triggered and used to store the telemetry data that was read.

Error handling became a necessity, as sometimes the UART interface would hit an "overrun" error, meaning that the microcontroller had become out of sync with the UART data coming in. In this case, the UART would lock up and no longer provide data. Since a single lost data point is not critical, the solution was to catch that the error had occurred, clear the error flag, and then re-enable the interrupt so that the next telemetry frame would be captured correctly.

For the Castle ESCs used for the arm and disk, telemetry data is acquired via register access through i2c. The program requests temperature, current, RPM and voltage through the i2c interface by sending the device address, then the register address, and then a checksum. The information is then sent back as a 16 bit value, accompanied by another checksum.

Error handling was important for the Castle I2C interface as well, sometimes hitting no-acknowledge errors and locking up the bus. To resolve this issue, the code would detect

errors thrown during a transmission, and restart the I2C peripheral, which would clear the error and allow the next set of data to be read in correctly.

#### LoRa Radio (SPI)

To communicate with the LoRa module, a SPI interface was used to read and write to various registers within the RFM95W module.

In order to set up the RFM95W to transmit, the following steps are taken:

- 1. Write to the RFM to put into LoRa mode
- 2. Set the FIFO address to 0
- 3. Put the RFM into standby mode
- 4. Write the signal bandwidth, coding rate, and spreading factor to the RFM
- 5. Write the desired signal frequency (915 MHz)
- 6. Set the desired transmit power

To transmit data, the following steps are taken:

- 1. Write the header as the first part of the LoRa transmission. This includes:
  - a. The address of the device to send to
  - b. The address of the device the signal is coming from
  - c. The message ID
  - d. Additional flags for the message
- 2. Then, at the FIFO address, burst write over SPI all of the data to send. In our case this will be the telemetry data
- 3. Switch the mode to transmit mode
- 4. Wait for the transmit done flag to be raised
- 5. Clear the flag, and set the RFM mode back to standby.

The above process is repeated as quickly as possible to send telemetry data out via the RFM module.

#### **Receiver PWM Capture**

To capture receiver PWM signals, the timer peripherals are used in input capture mode with interrupts. Upon seeing a rising and falling edge, the input capture callback is triggered and the duty cycle is read into the program from the timer peripheral as the time elapsed between rising and falling edges of the PWM.

## **Incomplete Subsystems**

#### **SD Card**

To record telemetry data locally without always needing a laptop connection, an SD card over SPI was designed into the board. In the interest of time and completion of the project within the semester, I followed a tutorial with example code by a user named "kiwih" posted online for using a SD card over SPI and the STM32 HAL (<u>Tutorial located at this link</u>). This implementation utilized the FatFS middleware along with a custom SPI driver to talk to the SD card. I was unsuccessful in getting the SD Card to mount, with an error code indicating inability to interface with the SD card. Potential issues include that the SD card I used is unable to write over SPI, or a potential code issue. I did not have time to fully investigate before the end of the project.

#### IMU

The BNO085 IMU used in this project is set to communicate to the microcontroller via i2c. However, it uses a proprietary method to communicate over this i2c interface called the Sensor Hub Transport Protocol or SHTP. Understanding this protocol took significant resources as opposed to a simple register access. In the time constraints of the semester, I was not able to fully understand and implement the communication between the microcontroller and the IMU.

#### RTC + Coin Battery

This feature was never explored much, although the hardware exists on the board for a coin cell battery to power the RTC while the device is idling. The RTC is included within the STM32, and needs some firmware code to ensure it works.

#### Laptop

#### LoRa Receiver

An Adafruit Feather 32u4 board with a pre-installed LoRa module was utilized as a dongle to allow the laptop to receive the LoRa signal. This was used over a custom solution as it was quick and easy, especially with the provided code and documentation for the device. The board is programmed to send any LoRa telemetry signals that it receives over a USB serial COM port, so that it may be read easily by a computer.

#### **Telemetry Application**

To view the telemetry data live, a python GUI was constructed to view the data in real-time using the PyQt interface. This interface features a live readout of all telemetry values, the ability to record and save data to a CSV, and live plots that update with the current telemetry values.

## Appendix A: Low-Level Code Main.c

```
/* USER CODE BEGIN Header */
************************
             : main.c
* @brief
            : Main program body
************************
* @attention
* Copyright (c) 2024 STMicroelectronics.
* All rights reserved.
* This software is licensed under terms that can be found in the LICENSE file
* in the root directory of this software component.
* If no LICENSE file comes with this software, it is provided AS-IS.
************************
/* USER CODE END Header */
/* Includes -----*/
#include "main.h"
#include "app_fatfs.h"
#include "usb device.h"
/* Private includes -----*/
/* USER CODE BEGIN Includes */
#include <stdio.h>
#include <string.h>
#include <stdarg.h> //for va_list var arg functions
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
/* USER CODE END PM */
/* Private variables -----*/
I2C HandleTypeDef hi2c2;
SPI_HandleTypeDef hspi1;
SPI_HandleTypeDef hspi2;
TIM HandleTypeDef htim1;
TIM_HandleTypeDef htim2;
TIM HandleTypeDef htim3;
TIM_HandleTypeDef htim4;
```

```
UART_HandleTypeDef huart4;
UART_HandleTypeDef huart1;
UART_HandleTypeDef huart2;
UART HandleTypeDef huart3;
/* USER CODE BEGIN PV */
uint8_t CH1_Val = 0;
uint8_t CH2_Val = 0;
uint8_t CH3_Val = 0;
uint8_t CH4_Val = 0;
uint16_t uart_err = 0;
uint8_t temp3;
float voltage3;
float current3;
uint16_t consumption3;
uint16 t RPM3;
uint8_t UART3_rxBuffer[10];
uint8_t UART4_rxBuffer[10];
uint8_t LoRaBuffer[251] = {1, 2, 3};
uint8_t txSize = 34;
uint8_t UART3Err = 0;
uint8 t UART4Err = 0;
uint8_t SpiErr = 0;
uint8_t CastleAddr1 = 8;
uint8_t CastleAddr2 = 9;
uint8_t BNOAddr = 0x4A << 1;</pre>
uint8_t errorcode = 0;
uint8_t BNOready = 0;
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock Config(void);
static void MX_GPIO_Init(void);
static void MX_SPI1_Init(void);
static void MX SPI2 Init(void);
static void MX_TIM1_Init(void);
static void MX TIM2 Init(void);
static void MX_TIM3_Init(void);
static void MX_TIM4_Init(void);
static void MX_UART4_Init(void);
static void MX USART1 UART_Init(void);
static void MX USART2 UART Init(void);
static void MX USART3 UART_Init(void);
static void MX I2C2 Init(void);
/* USER CODE BEGIN PFP */
extern uint8_t CDC_Transmit_FS(uint8_t* Buf, uint16_t Len);
/* USER CODE END PFP */
/* Private user code ------*/
/* USER CODE BEGIN 0 */
void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)
```

```
if(GPIO_Pin == GPIO_PIN_7) {
        //try to read if possible
        BNOready = 1;
} else {
}
}
void HAL_TIM_IC_CaptureCallback(TIM_HandleTypeDef *htim) {
      if (htim->Instance == TIM3) {
             CH3_Val = HAL_TIM_ReadCapturedValue(htim, TIM_CHANNEL_2);
      }
      else if(htim->Instance == TIM1){
             CH1 Val = HAL TIM ReadCapturedValue(htim, TIM CHANNEL 2);
      else if(htim->Instance == TIM2){
             CH2_Val = HAL_TIM_ReadCapturedValue(htim, TIM_CHANNEL_2);
      else if(htim->Instance == TIM4){
             CH4 Val = HAL TIM ReadCapturedValue(htim, TIM CHANNEL 1);
      }
}
void LoRaSPIWrite(uint8_t addr, uint8_t data){
      HAL_GPIO_WritePin(GPIOB, GPIO_PIN_12, GPIO_PIN_RESET); //pull SS low
      uint8_t transmit_buffer[2] = {addr|0x80u , data};
      if(HAL_SPI_Transmit(&hspi2, &transmit_buffer[0] , 1, 100) != HAL_OK){
             SpiErr++;
      }
      if(HAL_SPI_Transmit(&hspi2, &transmit_buffer[1] , 1, 100) != HAL_OK){
             SpiErr++;
      }
      HAL_GPIO_WritePin(GPIOB, GPIO_PIN_12, GPIO_PIN_SET); //pull SS high to end tx
}
void LoRaSPIWriteBurst(uint8 t addr, uint8 t* data, uint8 t len){
      HAL GPIO WritePin(GPIOB, GPIO PIN 12, GPIO PIN RESET); //pull SS low
      uint8 t spi addr = addr | 0x80u;
      if(HAL_SPI_Transmit(&hspi2, &spi_addr, 1, 100) != HAL_OK){
             SpiErr++;
      }
      if(HAL SPI Transmit(&hspi2, data , len, 100) != HAL OK){
             SpiErr++;
      }
      HAL GPIO WritePin(GPIOB, GPIO PIN 12, GPIO PIN SET); //pull SS high to end tx
uint8 t LoRaSPIRead(uint8 t addr){
      uint8_t buff = addr & 0x7F;
      HAL_GPIO_WritePin(GPIOB, GPIO_PIN_12, GPIO_PIN_RESET); //pull SS low
      if(HAL_SPI_Transmit(&hspi2, &buff, 1, 100)!= HAL_OK){
             SpiErr++;
```

```
}
      if(HAL_SPI_Receive(&hspi2, &buff, 1, 100) != HAL_OK){
             SpiErr++;
      }
      HAL_GPIO_WritePin(GPIOB, GPIO_PIN_12, GPIO_PIN_SET); //pull SS high to end tx
      return buff;
}
uint8_t LoRaTxDone(){
      uint8_t IRQFlags = LoRaSPIRead(0x12);//Check IRQ flags
      IRQFlags = (IRQFlags & 0x8 )>>3;
      return IRQFlags;
void process_telemetry(uint8_t *telemBuffer){
      temp3 = telemBuffer[0];
      voltage3 = (256*telemBuffer[1] + telemBuffer[2])/100.0;
      current3 = (256*telemBuffer[3] + telemBuffer[4])/100.0;
      consumption3 = 256*telemBuffer[5] + telemBuffer[6];
      RPM3 = ((256*telemBuffer[7] + telemBuffer[8])*100)/(24/2);
void try_UART3_IT(){
      if(HAL UART Receive IT (&huart3, UART3 rxBuffer, 10) != HAL OK){
             UART3Err = 1;
      }
      else{
             UART3Err = 0;
      }
}
void try_UART4_IT(){
      if(HAL_UART_Receive_IT (&huart4, UART4_rxBuffer, 10) != HAL_OK){
             UART4Err = 1;
      }
      else{
             UART4Err = 0;
      }
}
void HAL_UART_RxCpltCallback(UART_HandleTypeDef *huart)
      if(huart->Instance == USART3){
             try_UART3_IT();
      }
      else if(huart->Instance == UART4){
             try_UART4_IT();
      }
}
void HAL_UART_ErrorCallback(UART_HandleTypeDef *huart) {
      if(huart->Instance == USART3){
             UART3Err = 1;
      }
```

```
else if(huart->Instance == UART4){
             UART4Err = 1;
      }
}
void writeAM32TelemLoRa(){
      //drive esc 1 telem
      for (int i=0; i<9; i++){
             LoRaBuffer[i] = UART3_rxBuffer[i];
      }
      //drive esc 2 telem
      for (int i=0; i<9; i++){
             LoRaBuffer[i+9] = UART4_rxBuffer[i];
      }
      /*
       */
}
/*
void startAccelerometer(){
      HAL I2C Master Transmit(&hi2c2, BNOAddr ,TX Buffer,1,100);
void startBNO(){
      HAL_GPIO_WritePin(GPIOC, GPIO_PIN_9, GPIO_PIN_RESET); //hit reset
      HAL_Delay(10);
      HAL GPIO WritePin(GPIOC, GPIO PIN 9, GPIO PIN SET); //unreset
      HAL_Delay(4000); //wait for bno
      //enable accel
      uint8_t <u>txbuf</u>[21] = {0x15, 0, 0x02, 0, 0xFD, 0x1, 0, 0, 0, 0x60, 0xEA};
      HAL_I2C_Master_Transmit_IT(&i2c2, BNOAddr, txBuf, 21);
}
void readBNO(){
      if(BNOready == 1){ //check if there is data availible
             uint8_t headerBuf[4] = {0};
       HAL I2C Master Receive IT(&i2c2, BNOAddr, headerBuf, 4, 100); //read in the
header
       uint8 t dataLen = ((headerBuf[0]) + (headerBuf[1]<<8) - 4); //get length from</pre>
header msb/lsb, double check this
       HAL I2C Master Receive IT(&i2c2, BNOAddr, bnoDataBuf, dataLen , 100); //read
everythign else
      }
      BNOready = 0;
}*/
uint16 t readCastle(uint8 t esc addr, uint8 t reg addr){
   uint8_t buf[3] = {0};
   //int8_t tx_buf[4] = {reg_addr, 0, 0, -(reg_addr + (esc_addr<<1))};//try computing</pre>
correct checksum to send back
   uint8_t tx_buf[4] = {reg_addr, 0, 0, (~(reg_addr + (esc_addr<<1)))+1 };//try
computing correct checksum to send back
   //uint8_t tx_buf[4] = {reg_addr, 0, 0, 0xf0};
```

```
HAL_StatusTypeDef ret1;
   HAL StatusTypeDef_ret2;
      ret1 = HAL_I2C_Master_Transmit(&hi2c2, (esc_addr<<1), tx_buf, 4, 100);
   ret2 = HAL_I2C_Master_Receive(&hi2c2, (esc_addr<<1), buf, 3, 100);</pre>
   uint16_t val = (buf[0]<<8) + buf[1];
   if (ret1 != HAL_OK){
      val = HAL_I2C_GetError(&hi2c2);
      __HAL_I2C_DISABLE(&hi2c2); // stop i2c
                                              // start i2c
      __HAL_I2C_ENABLE(&hi2c2);
   }
   /*
   if (ret2 != HAL_OK){
      val = 2;
   }*/
   return val;
}
void writeLoRaCastle(){
      uint16_t castle0Temp = readCastle(8, 6);
      LoRaBuffer[18] = castle0Temp>>8;
      LoRaBuffer[19] = castle0Temp & 0xFF;
      uint16 t castle0Voltage = readCastle(8, 0);
      LoRaBuffer[20] = castle0Voltage>>8;
      LoRaBuffer[21] = castleOVoltage & OxFF;
      uint16 t castle0Current = readCastle(8, 2);
      LoRaBuffer[22] = castle0Current>>8;
      LoRaBuffer[23] = castle0Current & 0xFF;
      uint16_t castle0RPM = readCastle(8, 5);
      LoRaBuffer[24] = castleORPM>>8;
      LoRaBuffer[25] = castleORPM & OxFF;
      uint16 t castle1Temp = readCastle(9, 6);
      LoRaBuffer[26] = castle1Temp>>8;
      LoRaBuffer[27] = castle1Temp & 0xFF;
      uint16 t castle1Voltage = readCastle(9, 0);
      LoRaBuffer[28] = castle1Voltage>>8;
      LoRaBuffer[29] = castle1Voltage & 0xFF;
      uint16_t castle1Current = readCastle(9, 2);
      LoRaBuffer[30] = castle1Current>>8;
      LoRaBuffer[31] = castle1Current & 0xFF;
      uint16 t castle1RPM = readCastle(9, 5);
      LoRaBuffer[32] = castle1RPM>>8;
      LoRaBuffer[33] = castle1RPM & 0xFF;
void myprintf(const char *fmt, ...) {
static char buffer[256];
va_list args;
va_start(args, fmt);
 vsnprintf(buffer, sizeof(buffer), fmt, args);
va_end(args);
```

```
int len = strlen(buffer);
CDC_Transmit_FS((uint8_t*)buffer, len);
}
/*
uint16_t clearCastle(uint8_t esc_addr){
  uint8_t tx_buf[5] = {0, 0, 0, 0, 0};
      HAL_I2C_Master_Transmit(&hi2c2, esc_addr<<1, tx_buf, 5, HAL_MAX_DELAY);</pre>
}*/
/* USER CODE END 0 */
/**
* @brief The application entry point.
* @retval int
*/
int main(void)
/* USER CODE BEGIN 1 */
/* USER CODE END 1 */
/* MCU Configuration----*/
/* Reset of all peripherals, Initializes the Flash interface and the Systick. */
HAL Init();
/* USER CODE BEGIN Init */
/* USER CODE END <a href="Init">Init</a> */
/* Configure the system clock */
SystemClock Config();
/* USER CODE BEGIN SysInit */
/* USER CODE END SysInit */
/* Initialize all configured peripherals */
MX_GPIO_Init();
MX_SPI1_Init();
MX_SPI2_Init();
MX_TIM1_Init();
MX_TIM2_Init();
MX TIM3 Init();
MX_TIM4_Init();
MX_UART4_Init();
MX_USART1_UART_Init();
MX_USART2_UART_Init();
MX_USART3_UART_Init();
//MX USB Device Init();
MX I2C2 Init();
if (MX FATFS Init() != APP OK) {
  Error Handler();
/* USER CODE BEGIN 2 */
HAL_TIM_IC_Start_IT(&htim1, TIM_CHANNEL_1); // Primary channel - rising edge
HAL_TIM_IC_Start(&htim1, TIM_CHANNEL_2); // Secondary channel - falling edge
HAL_TIM_IC_Start_IT(&htim2, TIM_CHANNEL_1); // Primary channel - rising edge
 HAL_TIM_IC_Start(&htim2, TIM_CHANNEL_2); // Secondary channel - falling edge
```

```
HAL_TIM_IC_Start_IT(&htim3, TIM_CHANNEL_1); // Primary channel - rising edge
 HAL_TIM_IC_Start(&htim3, TIM_CHANNEL_2); // Secondary channel - falling edge
 HAL_TIM_IC_Start_IT(&htim4, TIM_CHANNEL_1); // Primary channel - rising edge
                                           // Secondary channel - falling edge
 HAL TIM IC Start(&htim4, TIM CHANNEL 2);
 HAL_UART_Receive_IT(&huart3, UART3_rxBuffer, 10); //start receiving telemetry on ch3
 HAL UART Receive IT(&huart4, UART4 rxBuffer, 10); //start receiving telemetry on ch4
 HAL_GPIO_WritePin(GPIOB, GPIO_PIN_12, GPIO_PIN_SET); //pull SS high by default
 //for printing
 uint8_t printBuffer[100] = {'\0'};
 //init LoRa
 LoRaSPIWrite(0x01, 0x00); //Put in sleep
 HAL Delay(10);
 LoRaSPIWrite(0x01, 0x80); //Put in LoRa mode and in sleep
 HAL Delay(10);
 uint8 t reg = LoRaSPIRead(0x01);
 if(reg != 0x80){
             sprintf(printBuffer, "Lora Failed, %u %u\n", reg, SpiErr);
             //CDC_Transmit_FS(printBuffer, sizeof(printBuffer));
 }
 else{
             sprintf(printBuffer, "Lora Success");
             //CDC_Transmit_FS(printBuffer, sizeof(printBuffer));
 LoRaSPIWrite(0x0E, 0); //Write 0 to RegFifoTxBaseAddr
 LoRaSPIWrite(0x0F, 0); //Write 0 to RegFifoRxBaseAddr
 HAL Delay(10);
 LoRaSPIWrite(0x01, 0b10000001); //Put in LoRa mode and in standby
HAL Delay(10);
LoRaSPIWrite(0x1D, 0x72); // (0b01110010) write RegModemConfig 1 for signal
bandwidth (125 khz -> 0111), coding rate (4/5 001), Explicit header??
 LoRaSPIWrite(0x1E, 0x74); // (0b01110100 ) write RegModemConfig 2 for
SpreadingFactor (7 -> 0111), TxContinuousMode (off, 0), RxPayloadCrcOn ON (1),
SymbTimeout(9:8)
 //Fstep = 61.03515625hz, so to make 915 mhz, write 14991360 to frequency registers
uint32_t LoRaFreq= 14991360;
LoRaSPIWrite(0x06, (LoRaFreq&0xFF0000)>>16); //Write MSB
 LoRaSPIWrite(0x07, (LoRaFreq&0x00FF00)>>8); //Write middle
 LoRaSPIWrite(0x08, (LoRaFreq&0x0000FF)); //Write LSB
 LoRaSPIWrite(0x09, 0x80 | (18-2));//Set TX power to 18 (PA Select = 1) (boost)
HAL Delay(10);
 LoRaSPIWrite(0x0D, 0); // Position at the beginning of the FIFO
 LoRaSPIWrite(0x00, 255); //WRite (to) to fifo
 LoRaSPIWrite(0x00, 1); //WRite header (from) to fifo
 LoRaSPIWrite(0x00, 0); //WRite header (ID) to flafifo
 LoRaSPIWrite(0x00, 0); //WRite header (flags) to fifo
 //sprintf(LoRaBuffer, "MODULE POWER ON");
LoRaSPIWriteBurst(0x00, LoRaBuffer, txSize);
 //LoRaSPIWrite(0x00, 97); //WRite char 97 to fifo
```

```
/*LoRaSPIWrite(0x00, 98); //WRite char 97 to fifo*/
LoRaSPIWrite(0x22, txSize+4); //write length
HAL_Delay(50);
 LoRaSPIWrite(0x01, 0b10000011); //Put in LoRa mode and in transmit */
 //u_int8_t buffer[] = "Hello World";
uint8 t DebugMode = 0;
 NOTE THIS IS NOT WRITTEN BY ME, THIS IS TAKEN FROM A STM32 SPI SD CARD INTERFACE
TUTORIAL LOCATED AT <a href="https://01001000.xyz/2020-08-09-Tutorial-STM32CubeIDE-SD-card/">https://01001000.xyz/2020-08-09-Tutorial-STM32CubeIDE-SD-card/</a>
myprintf("\r\n~ SD card demo by kiwih ~\r\n\r\n");
HAL_Delay(1000); //a short delay is important to let the SD card settle
//some variables for FatFs
FATFS FatFs;
                  //Fatfs handle
FIL fil;
                    //File handle
FRESULT <a href="fres">fres</a>; //Result after operations
//Open the file system
fres = f_mount(&FatFs, "", 1); //1=mount now
 if (fres != FR OK) {
      myprintf("f_mount error (%i)\r\n", fres);
      while(1);
 }
 //Let's get some statistics from the SD card
DWORD free clusters, free sectors, total sectors;
FATFS* getFreeFs;
fres = f_getfree("", &free_clusters, &getFreeFs);
 if (fres != FR_OK) {
      myprintf("f_getfree error (%i)\r\n", fres);
      while(1);
 //Formula comes from ChaN's documentation
total sectors = (getFreeFs->n fatent - 2) * getFreeFs->csize;
free sectors = free clusters * getFreeFs->csize;
myprintf("SD card stats:\r\n%10lu KiB total drive space.\r\n%10lu KiB
available.\r\n", total sectors / 2, free sectors / 2);
 //Now let's try to open file "test.txt"
fres = f open(&fil, "test.txt", FA READ);
if (<u>fres</u> != FR OK) {
      mvprintf("f open error (%i)\r\n");
      while(1);
 }
myprintf("I was able to open 'test.txt' for reading!\r\n");
 //Read 30 bytes from "test.txt" on the SD card
BYTE readBuf[30];
 //We can either use f_read OR f_gets to get data out of files
 //f_gets is a wrapper on f_read that does some string formatting for us
```

```
TCHAR* rres = f_gets((TCHAR*)readBuf, 30, &fil);
 if(<u>rres</u> != 0) {
      myprintf("Read string from 'test.txt' contents: %s\r\n", readBuf);
 } else {
      myprintf("f_gets error (%i)\r\n", fres);
 //Be a tidy kiwi - don't forget to close your file!
 f_close(&fil);
//Now let's try and write a file "write.txt"
fres = f_open(&fil, "write.txt", FA_WRITE | FA_OPEN_ALWAYS | FA_CREATE_ALWAYS);
 if(<u>fres</u> == FR OK) {
      myprintf("I was able to open 'write.txt' for writing\r\n");
 } else {
      myprintf("f_open error (%i)\r\n", fres);
//Copy in a string
strncpy((char*)readBuf, "a new file is made!", 19);
UINT bytesWrote;
fres = f write(&fil, readBuf, 19, &bytesWrote);
 if(fres == FR OK) {
      myprintf("Wrote %i bytes to 'write.txt'!\r\n", bytesWrote);
} else {
      myprintf("f_write error (%i)\r\n");
 //Be a tidy kiwi - don't forget to close your file!
f close(&fil);
 //We're done, so de-mount the drive
f_mount(NULL, "", 0);
 */
/* USER CODE END 2 */
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
   /* USER CODE END WHILE */
  /* USER CODE BEGIN 3 */
        /*
      sprintf(printBuffer, "CH1 RX: %d CH2 RX: %d CH3 RX: %d CH4 RX: %d \r\n",
CH1 Val, CH2 Val, CH3 Val, CH4 Val);
      CDC_Transmit_FS(printBuffer, sizeof(printBuffer));*/
        //HAL Delay(50);
      if(DebugMode == 0){
             if(LoRaTxDone()){
                    LoRaSPIWrite(0x01, 0b10000001); //Put in LoRa mode and in standby
                    LoRaSPIWrite(0x12, 0xFF); //Clear IRQ
                    //write updated telemetry data to buffer
                    writeAM32TelemLoRa();
                    writeLoRaCastle();
```

```
LoRaSPIWrite(0x0D, 0); // Position at the beginning of the FIFO
                   LoRaSPIWrite(0x00, 255); //WRite (to) to fifo
                   LoRaSPIWrite(0x00, 1); //WRite header (from) to fifo
                   LoRaSPIWrite(0x00, 0); //WRite header (ID) to flafifo
                   LoRaSPIWrite(0x00, 0); //WRite header (flags) to fifo
                   LoRaSPIWriteBurst(0x00, LoRaBuffer, txSize);
                   LoRaSPIWrite(0x01, 0b10000011); //Put in LoRa mode and in
transmit */
             }
      }
      else{
             process_telemetry(UART3_rxBuffer);
             sprintf(printBuffer, "%u C , %.2f V , %.2f A , %u mAh , %u RPM, ch3: %u
%u \r\n", temp3, voltage3, current3, consumption3, RPM3, CH3 Val, uart err);
             CDC_Transmit_FS(printBuffer, sizeof(printBuffer));
             HAL Delay(100);
      }
      /*HAL_GPIO_TogglePin(GPIOB,GPIO_PIN_12);
      HAL Delay(500);*/
      //transmit address and then data to LoRA
      //handle UART errors
      if(UART3Err){
             //sprintf(printBuffer, "attempting to recover");
             //CDC_Transmit_FS(printBuffer, sizeof(printBuffer));
             uart err++;
          __HAL_UART_FLUSH_DRREGISTER(&huart3);
             __HAL_UART_CLEAR_FLAG(&huart3, UART_CLEAR_OREF);
             try_UART3_IT();
      if(UART4Err){
             uart err++;
           __HAL_UART_FLUSH_DRREGISTER(&huart4);
             HAL UART CLEAR FLAG(&huart4, UART CLEAR OREF);
             try_UART4_IT();
      }
/* USER CODE END 3 */
}
 * @brief System Clock Configuration
 * @retval None
void SystemClock_Config(void)
{
 RCC_OscInitTypeDef RCC_OscInitStruct = {0};
 RCC ClkInitTypeDef RCC ClkInitStruct = {0};
 /** Configure the main internal regulator output voltage
 */
```

```
HAL_PWREx_ControlVoltageScaling(PWR_REGULATOR_VOLTAGE_SCALE1);
 /** Initializes the RCC Oscillators according to the specified parameters
 * in the RCC_OscInitTypeDef structure.
 RCC_OscInitStruct.OscillatorType = RCC_OSCILLATORTYPE_HSI|RCC_OSCILLATORTYPE_HSI48;
 RCC OscInitStruct.HSIState = RCC HSI ON;
 RCC_OscInitStruct.HSICalibrationValue = RCC_HSICALIBRATION_DEFAULT;
 RCC_OscInitStruct.HSI48State = RCC_HSI48_ON;
 RCC_OscInitStruct.PLL.PLLState = RCC_PLL_NONE;
 if (HAL_RCC_OscConfig(&RCC_OscInitStruct) != HAL_OK)
 {
   Error_Handler();
 }
 /** Initializes the CPU, AHB and APB buses clocks
 RCC_ClkInitStruct.ClockType = RCC_CLOCKTYPE_HCLK|RCC_CLOCKTYPE_SYSCLK
                             |RCC CLOCKTYPE PCLK1|RCC CLOCKTYPE PCLK2;
 RCC ClkInitStruct.SYSCLKSource = RCC SYSCLKSOURCE HSI;
 RCC ClkInitStruct.AHBCLKDivider = RCC SYSCLK DIV1;
 RCC ClkInitStruct.APB1CLKDivider = RCC HCLK DIV1;
 RCC ClkInitStruct.APB2CLKDivider = RCC HCLK DIV1;
 if (HAL_RCC_ClockConfig(&RCC_ClkInitStruct, FLASH_LATENCY_0) != HAL_OK)
   Error_Handler();
 }
}
 * @brief I2C2 Initialization Function
 * @param None
 * @retval None
static void MX_I2C2_Init(void)
/* USER CODE BEGIN I2C2_Init 0 */
/* USER CODE END I2C2 Init 0 */
/* USER CODE BEGIN I2C2 Init 1 */
 /* USER CODE END I2C2 <u>Init</u> 1 */
hi2c2.Instance = I2C2;
hi2c2.Init.Timing = 0x00303D5B;
 hi2c2.Init.OwnAddress1 = 0;
 hi2c2.Init.AddressingMode = I2C ADDRESSINGMODE 7BIT;
hi2c2.Init.DualAddressMode = I2C DUALADDRESS DISABLE;
 hi2c2.Init.OwnAddress2 = 0;
 hi2c2.Init.OwnAddress2Masks = I2C OA2 NOMASK;
 hi2c2.Init.GeneralCallMode = I2C_GENERALCALL_DISABLE;
 hi2c2.Init.NoStretchMode = I2C NOSTRETCH DISABLE;
 if (HAL_I2C_Init(&hi2c2) != HAL_OK)
 {
```

```
Error_Handler();
 }
 /** Configure Analogue filter
 if (HAL_I2CEx_ConfigAnalogFilter(&hi2c2, I2C_ANALOGFILTER_ENABLE) != HAL_OK)
 {
  Error_Handler();
 /** Configure Digital filter
 if (HAL_I2CEx_ConfigDigitalFilter(&hi2c2, 0) != HAL_OK)
  Error_Handler();
/* USER CODE BEGIN I2C2_Init 2 */
 /* USER CODE END I2C2 Init 2 */
}
* @brief SPI1 Initialization Function
* @param None
 * @retval None
*/
static void MX_SPI1_Init(void)
{
/* USER CODE BEGIN SPI1 Init 0 */
/* USER CODE END SPI1 Init 0 */
/* USER CODE BEGIN SPI1_Init 1 */
/* USER CODE END SPI1 Init 1 */
 /* SPI1 parameter configuration*/
 hspi1.Instance = SPI1;
 hspi1.Init.Mode = SPI_MODE_MASTER;
 hspi1.Init.Direction = SPI_DIRECTION_2LINES;
hspi1.Init.DataSize = SPI DATASIZE 8BIT;
 hspi1.Init.CLKPolarity = SPI_POLARITY_LOW;
 hspi1.Init.CLKPhase = SPI_PHASE_1EDGE;
 hspi1.Init.NSS = SPI_NSS_SOFT;
 hspi1.Init.BaudRatePrescaler = SPI BAUDRATEPRESCALER 64;
hspi1.Init.FirstBit = SPI_FIRSTBIT_MSB;
 hspi1.Init.TIMode = SPI_TIMODE_DISABLE;
 hspi1.Init.CRCCalculation = SPI CRCCALCULATION DISABLE;
 hspi1.Init.CRCPolynomial = 7;
hspi1.Init.CRCLength = SPI CRC LENGTH DATASIZE;
 hspi1.Init.NSSPMode = SPI_NSS_PULSE_ENABLE;
 if (HAL_SPI_Init(&hspi1) != HAL_OK)
 {
   Error_Handler();
/* USER CODE BEGIN SPI1 Init 2 */
```

```
/* USER CODE END SPI1_Init 2 */
}
/**
* @brief SPI2 Initialization Function
 * @param None
* @retval None
static void MX_SPI2_Init(void)
{
/* USER CODE BEGIN SPI2 Init 0 */
/* USER CODE END SPI2 Init 0 */
/* USER CODE BEGIN SPI2 Init 1 */
/* USER CODE END SPI2 Init 1 */
 /* SPI2 parameter configuration*/
hspi2.Instance = SPI2;
 hspi2.Init.Mode = SPI MODE MASTER;
 hspi2.Init.Direction = SPI_DIRECTION_2LINES;
 hspi2.Init.DataSize = SPI_DATASIZE_8BIT;
 hspi2.Init.CLKPolarity = SPI POLARITY LOW;
 hspi2.Init.CLKPhase = SPI PHASE 1EDGE;
 hspi2.Init.NSS = SPI_NSS_SOFT;
 hspi2.Init.BaudRatePrescaler = SPI_BAUDRATEPRESCALER_8;
 hspi2.Init.FirstBit = SPI_FIRSTBIT_MSB;
hspi2.Init.TIMode = SPI_TIMODE_DISABLE;
 hspi2.Init.CRCCalculation = SPI_CRCCALCULATION_DISABLE;
 hspi2.Init.CRCPolynomial = 7;
 hspi2.Init.CRCLength = SPI_CRC_LENGTH_DATASIZE;
 hspi2.Init.NSSPMode = SPI_NSS_PULSE_DISABLE;
 if (HAL_SPI_Init(&hspi2) != HAL_OK)
 {
   Error_Handler();
/* USER CODE BEGIN SPI2_Init 2 */
/* USER CODE END SPI2 Init 2 */
}
 * @brief TIM1 Initialization Function
 * @param None
* @retval None
static void MX TIM1 Init(void)
{
/* USER CODE BEGIN TIM1_Init 0 */
/* USER CODE END TIM1 Init 0 */
TIM_SlaveConfigTypeDef sSlaveConfig = {0};
TIM_IC_InitTypeDef sConfigIC = {0};
TIM_MasterConfigTypeDef sMasterConfig = {0};
 /* USER CODE BEGIN TIM1 Init 1 */
```

```
/* USER CODE END TIM1 Init 1 */
htim1.Instance = TIM1;
htim1.Init.Prescaler = 160;
htim1.Init.CounterMode = TIM_COUNTERMODE_UP;
 htim1.Init.Period = 2000;
 htim1.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
 htim1.Init.RepetitionCounter = 0;
 htim1.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_DISABLE;
 if (HAL_TIM_IC_Init(&htim1) != HAL_OK)
   Error_Handler();
 }
 sSlaveConfig.SlaveMode = TIM SLAVEMODE RESET;
 sSlaveConfig.InputTrigger = TIM_TS_TI1FP1;
 sSlaveConfig.TriggerPolarity = TIM INPUTCHANNELPOLARITY RISING;
 sSlaveConfig.TriggerPrescaler = TIM_ICPSC_DIV1;
 sSlaveConfig.TriggerFilter = 0;
 if (HAL_TIM_SlaveConfigSynchro(&htim1, &sSlaveConfig) != HAL_OK)
 {
   Error_Handler();
 }
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_RISING;
 sConfigIC.ICSelection = TIM_ICSELECTION_DIRECTTI;
sConfigIC.ICPrescaler = TIM_ICPSC_DIV1;
 sConfigIC.ICFilter = 0;
 if (HAL_TIM_IC_ConfigChannel(&htim1, &sConfigIC, TIM_CHANNEL_1) != HAL_OK)
{
   Error_Handler();
 sConfigIC.ICPolarity = TIM INPUTCHANNELPOLARITY FALLING;
 sConfigIC.ICSelection = TIM_ICSELECTION_INDIRECTTI;
 if (HAL_TIM_IC_ConfigChannel(&htim1, &sConfigIC, TIM_CHANNEL_2) != HAL_OK)
 {
   Error_Handler();
 }
 sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
 sMasterConfig.MasterOutputTrigger2 = TIM TRGO2 RESET;
 sMasterConfig.MasterSlaveMode = TIM_MASTERSLAVEMODE_DISABLE;
 if (HAL TIMEx MasterConfigSynchronization(&htim1, &sMasterConfig) != HAL OK)
   Error Handler();
/* USER CODE BEGIN TIM1_Init 2 */
/* USER CODE END TIM1 Init 2 */
}
 * @brief TIM2 Initialization Function
 * @param None
```

```
* @retval None
 */
static void MX_TIM2_Init(void)
/* USER CODE BEGIN TIM2 Init 0 */
/* USER CODE END TIM2 Init 0 */
TIM_SlaveConfigTypeDef sSlaveConfig = {0};
TIM_IC_InitTypeDef sConfigIC = {0};
TIM_MasterConfigTypeDef sMasterConfig = {0};
/* USER CODE BEGIN TIM2 Init 1 */
/* USER CODE END TIM2 Init 1 */
 htim2.Instance = TIM2;
 htim2.Init.Prescaler = 160;
 htim2.Init.CounterMode = TIM COUNTERMODE UP;
htim2.Init.Period = 2000;
 htim2.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
 htim2.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_DISABLE;
 if (HAL_TIM_IC_Init(&htim2) != HAL_OK)
 {
   Error_Handler();
 }
 sSlaveConfig.SlaveMode = TIM_SLAVEMODE_RESET;
 sSlaveConfig.InputTrigger = TIM_TS_TI1FP1;
 sSlaveConfig.TriggerPolarity = TIM_INPUTCHANNELPOLARITY_RISING;
 sSlaveConfig.TriggerPrescaler = TIM_ICPSC_DIV1;
 sSlaveConfig.TriggerFilter = 0;
 if (HAL_TIM_SlaveConfigSynchro(&htim2, &sSlaveConfig) != HAL_OK)
 {
   Error_Handler();
 }
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_RISING;
 sConfigIC.ICSelection = TIM_ICSELECTION_DIRECTTI;
sConfigIC.ICPrescaler = TIM ICPSC DIV1;
 sConfigIC.ICFilter = 0;
 if (HAL TIM IC ConfigChannel(&htim2, &sConfigIC, TIM CHANNEL 1) != HAL OK)
 {
   Error Handler();
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_FALLING;
 sConfigIC.ICSelection = TIM ICSELECTION INDIRECTTI;
 if (HAL TIM IC ConfigChannel(&htim2, &sConfigIC, TIM CHANNEL 2) != HAL OK)
 {
   Error_Handler();
 sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
 sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
 if (HAL_TIMEx_MasterConfigSynchronization(&htim2, &sMasterConfig) != HAL_OK)
```

```
Error_Handler();
}
/* USER CODE BEGIN TIM2 Init 2 */
/* USER CODE END TIM2 Init 2 */
}
/**
* @brief TIM3 Initialization Function
 * @param None
 * @retval None
*/
static void MX_TIM3_Init(void)
/* USER CODE BEGIN TIM3 Init 0 */
/* USER CODE END TIM3 Init 0 */
TIM_SlaveConfigTypeDef sSlaveConfig = {0};
TIM_IC_InitTypeDef sConfigIC = {0};
TIM_MasterConfigTypeDef sMasterConfig = {0};
 /* USER CODE BEGIN TIM3_Init 1 */
 /* USER CODE END TIM3 Init 1 */
htim3.Instance = TIM3;
 htim3.Init.Prescaler = 160 -1;
htim3.Init.CounterMode = TIM_COUNTERMODE_UP;
 htim3.Init.Period = 3999;
htim3.Init.ClockDivision = TIM CLOCKDIVISION DIV1;
htim3.Init.AutoReloadPreload = TIM_AUTORELOAD_PRELOAD_DISABLE;
 if (HAL_TIM_IC_Init(&htim3) != HAL_OK)
{
   Error_Handler();
 sSlaveConfig.SlaveMode = TIM SLAVEMODE RESET;
 sSlaveConfig.InputTrigger = TIM_TS_TI1FP1;
 sSlaveConfig.TriggerPolarity = TIM_INPUTCHANNELPOLARITY_RISING;
 sSlaveConfig.TriggerPrescaler = TIM ICPSC DIV1;
 sSlaveConfig.TriggerFilter = 0;
 if (HAL TIM SlaveConfigSynchro(&htim3, &sSlaveConfig) != HAL OK)
 {
   Error Handler();
 sConfigIC.ICPolarity = TIM INPUTCHANNELPOLARITY RISING;
 sConfigIC.ICSelection = TIM_ICSELECTION_DIRECTTI;
 sConfigIC.ICPrescaler = TIM ICPSC DIV1;
sConfigIC.ICFilter = 0;
 if (HAL_TIM_IC_ConfigChannel(&htim3, &sConfigIC, TIM_CHANNEL_1) != HAL_OK)
 {
   Error_Handler();
 }
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_FALLING;
 sConfigIC.ICSelection = TIM_ICSELECTION_INDIRECTTI;
```

```
if (HAL_TIM_IC_ConfigChannel(&htim3, &sConfigIC, TIM_CHANNEL_2) != HAL_OK)
 {
   Error_Handler();
 sMasterConfig.MasterOutputTrigger = TIM_TRGO_RESET;
 sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
 if (HAL_TIMEx_MasterConfigSynchronization(&htim3, &sMasterConfig) != HAL_OK)
 {
   Error_Handler();
/* USER CODE BEGIN TIM3 Init 2 */
/* USER CODE END TIM3 Init 2 */
}
/**
* @brief TIM4 Initialization Function
 * @param None
 * @retval None
static void MX TIM4 Init(void)
{
/* USER CODE BEGIN TIM4 Init 0 */
/* USER CODE END TIM4 Init 0 */
TIM_SlaveConfigTypeDef sSlaveConfig = {0};
TIM IC InitTypeDef sConfigIC = {0};
TIM_MasterConfigTypeDef sMasterConfig = {0};
 /* USER CODE BEGIN TIM4 Init 1 */
 /* USER CODE END TIM4 Init 1 */
htim4.Instance = TIM4;
htim4.Init.Prescaler = 160;
htim4.Init.CounterMode = TIM COUNTERMODE UP;
 htim4.Init.Period = 2000;
 htim4.Init.ClockDivision = TIM_CLOCKDIVISION_DIV1;
 htim4.Init.AutoReloadPreload = TIM AUTORELOAD PRELOAD DISABLE;
 if (HAL TIM IC Init(&htim4) != HAL OK)
 {
   Error_Handler();
 }
 sSlaveConfig.SlaveMode = TIM_SLAVEMODE_RESET;
 sSlaveConfig.InputTrigger = TIM_TS_TI2FP2;
 sSlaveConfig.TriggerPolarity = TIM INPUTCHANNELPOLARITY FALLING;
sSlaveConfig.TriggerPrescaler = TIM ICPSC DIV1;
 sSlaveConfig.TriggerFilter = 0;
 if (HAL_TIM_SlaveConfigSynchro(&htim4, &sSlaveConfig) != HAL_OK)
 {
   Error_Handler();
 }
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_RISING;
 sConfigIC.ICSelection = TIM_ICSELECTION_INDIRECTTI;
```

```
sConfigIC.ICPrescaler = TIM_ICPSC_DIV1;
 sConfigIC.ICFilter = 0;
 if (HAL_TIM_IC_ConfigChannel(&htim4, &sConfigIC, TIM_CHANNEL_1) != HAL_OK)
   Error_Handler();
 }
 sConfigIC.ICPolarity = TIM_INPUTCHANNELPOLARITY_FALLING;
 sConfigIC.ICSelection = TIM_ICSELECTION_DIRECTTI;
 if (HAL_TIM_IC_ConfigChannel(&htim4, &sConfigIC, TIM_CHANNEL_2) != HAL_OK)
   Error_Handler();
 }
 sMasterConfig.MasterOutputTrigger = TIM TRGO RESET;
 sMasterConfig.MasterSlaveMode = TIM MASTERSLAVEMODE DISABLE;
 if (HAL TIMEX MasterConfigSynchronization(&htim4, &sMasterConfig) != HAL OK)
{
   Error Handler();
 }
 /* USER CODE BEGIN TIM4 Init 2 */
/* USER CODE END TIM4 Init 2 */
}
* @brief UART4 Initialization Function
 * @param None
* @retval None
static void MX_UART4_Init(void)
/* USER CODE BEGIN UART4_Init 0 */
/* USER CODE END UART4 Init 0 */
/* USER CODE BEGIN UART4 Init 1 */
/* USER CODE END UART4 Init 1 */
huart4.Instance = UART4;
huart4.Init.BaudRate = 115200;
 huart4.Init.WordLength = UART_WORDLENGTH_8B;
 huart4.Init.StopBits = UART_STOPBITS_1;
 huart4.Init.Parity = UART PARITY NONE;
 huart4.Init.Mode = UART_MODE RX;
 huart4.Init.HwFlowCtl = UART_HWCONTROL_NONE;
 huart4.Init.OverSampling = UART_OVERSAMPLING 16;
 huart4.Init.OneBitSampling = UART ONE BIT SAMPLE DISABLE;
 huart4.Init.ClockPrescaler = UART PRESCALER DIV1;
 huart4.AdvancedInit.AdvFeatureInit = UART_ADVFEATURE_NO_INIT;
 if (HAL UART Init(&huart4) != HAL OK)
 {
   Error_Handler();
 if (HAL_UARTEX_SetTxFifoThreshold(&huart4, UART_TXFIFO_THRESHOLD_1_8) != HAL_OK)
```

```
Error_Handler();
 if (HAL_UARTEX_SetRxFifoThreshold(&huart4, UART_RXFIFO_THRESHOLD_1_8) != HAL_OK)
   Error_Handler();
 if (HAL_UARTEx_DisableFifoMode(&huart4) != HAL_OK)
  Error_Handler();
 /* USER CODE BEGIN UART4_Init 2 */
/* USER CODE END UART4 Init 2 */
}
/**
 * @brief USART1 Initialization Function
* @param None
* @retval None
 */
static void MX_USART1_UART_Init(void)
/* USER CODE BEGIN USART1 Init 0 */
/* USER CODE END USART1 Init 0 */
/* USER CODE BEGIN USART1 Init 1 */
/* USER CODE END USART1 Init 1 */
 huart1.Instance = USART1;
 huart1.Init.BaudRate = 115200;
 huart1.Init.WordLength = UART_WORDLENGTH_8B;
 huart1.Init.StopBits = UART_STOPBITS_1;
 huart1.Init.Parity = UART PARITY NONE;
huart1.Init.Mode = UART_MODE_RX;
 huart1.Init.HwFlowCtl = UART_HWCONTROL_NONE;
 huart1.Init.OverSampling = UART_OVERSAMPLING 16;
 huart1.Init.OneBitSampling = UART_ONE_BIT_SAMPLE_DISABLE;
 huart1.Init.ClockPrescaler = UART_PRESCALER_DIV1;
 huart1.AdvancedInit.AdvFeatureInit = UART_ADVFEATURE_NO_INIT;
 if (HAL UART Init(&huart1) != HAL OK)
{
   Error_Handler();
 if (HAL UARTEX SetTxFifoThreshold(&huart1, UART TXFIFO THRESHOLD 1 8) != HAL OK)
 {
   Error_Handler();
 if (HAL_UARTEX_SetRxFifoThreshold(&huart1, UART_RXFIFO_THRESHOLD_1_8) != HAL_OK)
 {
   Error_Handler();
 }
```

```
if (HAL_UARTEx_DisableFifoMode(&huart1) != HAL_OK)
 {
   Error_Handler();
 /* USER CODE BEGIN USART1_Init 2 */
/* USER CODE END USART1 Init 2 */
}
/**
 * @brief USART2 Initialization Function
 * @param None
* @retval None
static void MX USART2 UART Init(void)
/* USER CODE BEGIN USART2 Init 0 */
/* USER CODE END USART2 Init 0 */
/* USER CODE BEGIN USART2 Init 1 */
/* USER CODE END USART2 Init 1 */
 huart2.Instance = USART2;
 huart2.Init.BaudRate = 115200;
 huart2.Init.WordLength = UART WORDLENGTH 8B;
 huart2.Init.StopBits = UART_STOPBITS_1;
 huart2.Init.Parity = UART_PARITY_NONE;
 huart2.Init.Mode = UART MODE RX;
huart2.Init.HwFlowCtl = UART_HWCONTROL_NONE;
 huart2.Init.OverSampling = UART OVERSAMPLING 16;
 huart2.Init.OneBitSampling = UART_ONE_BIT_SAMPLE_DISABLE;
 huart2.Init.ClockPrescaler = UART_PRESCALER_DIV1;
 huart2.AdvancedInit.AdvFeatureInit = UART_ADVFEATURE_NO_INIT;
 if (HAL UART Init(&huart2) != HAL OK)
 {
   Error_Handler();
 if (HAL UARTEX SetTxFifoThreshold(&huart2, UART TXFIFO THRESHOLD 1 8) != HAL OK)
 {
   Error_Handler();
 if (HAL_UARTEX_SetRxFifoThreshold(&huart2, UART_RXFIFO_THRESHOLD_1_8) != HAL_OK)
   Error_Handler();
 if (HAL UARTEX DisableFifoMode(&huart2) != HAL OK)
  Error_Handler();
/* USER CODE BEGIN USART2 Init 2 */
/* USER CODE END USART2 Init 2 */
}
```

```
/**
 * @brief USART3 Initialization Function
 * @param None
* @retval None
static void MX_USART3_UART_Init(void)
/* USER CODE BEGIN USART3 Init 0 */
/* USER CODE END USART3_Init 0 */
/* USER CODE BEGIN USART3 Init 1 */
/* USER CODE END USART3 Init 1 */
huart3.Instance = USART3;
 huart3.Init.BaudRate = 115200;
 huart3.Init.WordLength = UART_WORDLENGTH_8B;
 huart3.Init.StopBits = UART_STOPBITS 1;
 huart3.Init.Parity = UART_PARITY_NONE;
huart3.Init.Mode = UART_MODE_RX;
huart3.Init.HwFlowCt1 = UART_HWCONTROL_NONE;
 huart3.Init.OverSampling = UART_OVERSAMPLING 16;
 huart3.Init.OneBitSampling = UART_ONE_BIT_SAMPLE_DISABLE;
 huart3.Init.ClockPrescaler = UART PRESCALER DIV1;
huart3.AdvancedInit.AdvFeatureInit = UART_ADVFEATURE_NO_INIT;
 if (HAL_UART_Init(&huart3) != HAL_OK)
 {
   Error_Handler();
 if (HAL_UARTEX_SetTxFifoThreshold(&huart3, UART_TXFIFO_THRESHOLD_1_8) != HAL_OK)
  Error_Handler();
 if (HAL_UARTEX_SetRxFifoThreshold(&huart3, UART_RXFIFO_THRESHOLD_1_8) != HAL_OK)
  Error Handler();
 if (HAL UARTEX DisableFifoMode(&huart3) != HAL OK)
   Error_Handler();
/* USER CODE BEGIN USART3 Init 2 */
/* USER CODE END USART3 <u>Init</u> 2 */
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
static void MX_GPIO_Init(void)
```

```
GPIO_InitTypeDef GPIO_InitStruct = {0};
/* USER CODE BEGIN MX GPIO Init 1 */
/* USER CODE END MX_GPIO_Init_1 */
/* GPIO Ports Clock Enable */
__HAL_RCC_GPIOC_CLK_ENABLE();
 HAL RCC GPIOF CLK ENABLE();
__HAL_RCC_GPIOA_CLK_ENABLE();
 HAL RCC GPIOB CLK ENABLE();
/*Configure GPIO pin Output Level */
HAL GPIO_WritePin(SD_CS_GPIO_Port, SD_CS_Pin, GPIO_PIN_SET);
/*Configure GPIO pin Output Level */
HAL GPIO WritePin(GPIOB, GPIO PIN 12, GPIO PIN SET);
/*Configure GPIO pin Output Level */
HAL GPIO WritePin(GPIOC, GPIO PIN 8 GPIO PIN 9, GPIO PIN SET);
/*Configure GPIO pin : SD CS Pin */
GPIO InitStruct.Pin = SD CS Pin;
GPIO InitStruct.Mode = GPIO MODE OUTPUT PP;
GPIO InitStruct.Pull = GPIO PULLUP;
GPIO InitStruct.Speed = GPIO SPEED FREQ VERY HIGH;
HAL GPIO Init(SD CS GPIO Port, &GPIO InitStruct);
/*Configure GPIO pin : PB12 */
GPIO_InitStruct.Pin = GPIO_PIN_12;
GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
GPIO InitStruct.Pull = GPIO PULLUP;
GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_MEDIUM;
HAL GPIO Init(GPIOB, &GPIO InitStruct);
/*Configure GPIO pin : PC7 */
GPIO InitStruct.Pin = GPIO PIN 7;
GPIO_InitStruct.Mode = GPIO_MODE_IT_FALLING;
GPIO InitStruct.Pull = GPIO NOPULL;
HAL_GPIO_Init(GPIOC, &GPIO_InitStruct);
/*Configure GPIO pin : PC8 */
GPIO InitStruct.Pin = GPIO PIN 8;
GPIO InitStruct.Mode = GPIO MODE OUTPUT PP;
GPIO InitStruct.Pull = GPIO PULLUP;
GPIO InitStruct.Speed = GPIO SPEED FREQ LOW;
HAL GPIO Init(GPIOC, &GPIO InitStruct);
/*Configure GPIO pin : PC9 */
GPIO InitStruct.Pin = GPIO PIN 9;
GPIO InitStruct.Mode = GPIO MODE OUTPUT PP;
GPIO InitStruct.Pull = GPIO NOPULL;
GPIO InitStruct.Speed = GPIO SPEED FREQ LOW;
HAL_GPIO_Init(GPIOC, &GPIO_InitStruct);
/* EXTI interrupt init*/
HAL_NVIC_SetPriority(EXTI9_5_IRQn, 0, 0);
HAL NVIC EnableIRQ(EXTI9 5 IRQn);
/* USER CODE BEGIN MX_GPIO_Init_2 */
/* USER CODE END MX GPIO Init 2 */
```

```
/* USER CODE BEGIN 4 */
/* USER CODE END 4 */
/**
 * @brief This function is executed in case of error occurrence.
* @retval None
void Error_Handler(void)
{
/* USER CODE BEGIN Error Handler Debug */
/* User can add his own implementation to report the HAL error return state */
 __disable_irq();
while (1)
 {
}
/* USER CODE END Error Handler Debug */
}
#ifdef USE_FULL_ASSERT
 * @brief Reports the name of the source file and the source line number
          where the assert param error has occurred.
* @param file: pointer to the source file name
 * # @param line: assert_param error line source number
* @retval None
void assert_failed(uint8_t *file, uint32_t line)
/* USER CODE BEGIN 6 */
/* User can add his own implementation to report the file name and line number,
    ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
 /* USER CODE END 6 */
#endif /* USE FULL ASSERT */
```

#### **Appendix B: Python GUI Code**

```
import sys
from PyQt5.QtWidgets import QApplication, QWidget, QLabel, QVBoxLayout,
QHBoxLayout, QGridLayout, QPushButton, QComboBox
from PyQt5.QtGui import QFont
from PyQt5.QtCore import QTimer, QThread, pyqtSignal
from PyQt5.QtWidgets import QApplication, QMainWindow, QVBoxLayout, QWidget
import pyqtgraph as pg
```

```
import csv
import serial
from serial.tools import list ports
from datetime import datetime
import random
# font styles
font_family = 'Bahnschrift'
avian_font = QFont(font_family, 20, QFont.Bold)
esc_label_font = QFont(font_family, 12, QFont.Bold)
measurement_font = QFont(font_family, 10)
value_font = QFont(font_family, 28, QFont.Bold)
min_max_font = QFont(font_family, 10)
# consts
DRIVE_ESC_1 = 'Drive ESC 1'
DRIVE_ESC_2 = 'Drive ESC 2'
WEAPON_ESC = 'Weapon ESC'
ARM\_ESC = 'Arm ESC'
TEMP = 'Temp'
RPM = 'RPM'
CURRENT = 'Current'
CONSUMPTION = 'Consumption'
VOLTAGE = 'Voltage'
BATTERY_VOLTAGE = 'Battery Voltage'
TOTAL CURRENT = 'Total Current'
TOTAL CONSUMPTION = 'Total Consumption'
SIGNAL STRENGTH = 'Signal Strength'
class SerialReaderThread(QThread):
    new_data = pyqtSignal(str)
   timestamps = []
    raw_data = []
    def __init__(self, port, parent=None):
        super().__init__(parent)
```

```
self.baudrate = 115200
       self.serial port = serial.Serial(port, self.baudrate)
       self.serial port.flushInput()
   def set_port(self, port):
       self.serial_port = serial.Serial(port, self.baudrate)
       self.serial port.flushInput()
   def run(self):
       while True:
           if self.serial port.in waiting:
               line = self.serial_port.readline().decode().strip()
               self.new_data.emit(line)
               self.timestamps.append(datetime.now())
               self.raw data.append(line)
               print(line)
   def export_raw_data(self):
       now = datetime.now().strftime('%Y_%m_%d_%H_%M_%S')
       file name = f"avian data {now} raw.csv"
       with open(file_name, "w", newline="") as csv_file:
           writer = csv.writer(csv_file)
           writer.writerows(self.raw_data)
class Avian():
   def __init__(self, serial_port):
       self.data = {}
       if not serial port == None:
            self.serial reader = SerialReaderThread(serial port)
           self.serial_reader.new_data.connect(self.handle_data)
           self.serial reader.start()
       self.data_timestamps = []
       self.esc names = [DRIVE ESC 1, DRIVE ESC 2, WEAPON ESC, ARM ESC]
       self.esc_measurement_names = [TEMP, RPM, CURRENT, CONSUMPTION, VOLTAGE]
       self.esc_measurement_units = ["°C", "", "A", "mAh", "V"]
```

```
for esc name in self.esc names:
        esc_data = {}
        for measurement_name in self.esc_measurement_names:
            esc data[measurement name] = {
                'values': [],
                'min': None,
                'max': None,
            }
        self.data[esc_name] = esc_data
    self.robot measurement names = [
        BATTERY_VOLTAGE, TOTAL_CURRENT, TOTAL_CONSUMPTION, SIGNAL_STRENGTH
    ]
    for measurement_name in self.robot_measurement_names:
        self.data[measurement_name] = {
            'values': [],
            'min': None,
            'max': None,
        }
def get_esc_names(self):
    return self.esc_names
def get_esc_measurement_names(self):
    return self.esc_measurement_names
def get esc measurement units(self):
    return self.esc measurement units
def get_displayed_esc_measurement_names(self):
    return self.esc measurement names[:4]
def get_displayed_esc_measurement_units(self):
    return self.esc_measurement_units[:4]
def get_robot_measurement_names(self):
    return self.robot_measurement_names
```

```
def get all values(self, measurement, esc=None):
    obj = (self.data if esc == None else self.data[esc])
    return obj[measurement]['values']
def get last n values(self, measurement, n, esc=None):
    obj = (self.data if esc == None else self.data[esc])
    return obj[measurement]['values'][-n:]
def get_current_value(self, measurement, esc=None):
    obj = (self.data if esc == None else self.data[esc])
   values = obj[measurement]['values']
    return values[-1] if len(values) > 0 else None
def get_min_value(self, measurement, esc=None):
    obj = (self.data if esc == None else self.data[esc])
    return obj[measurement]['min']
def get_max_value(self, measurement, esc=None):
    obj = (self.data if esc == None else self.data[esc])
    return obj[measurement]['max']
def add_value(self, measurement, value, esc=None):
    obj = (self.data if esc == None else self.data[esc])
    obj[measurement]['values'].append(value)
   min_value = self.get_min_value(measurement, esc)
   if min_value == None or value < min_value:</pre>
        obj[measurement]['min'] = value
   max value = self.get max value(measurement, esc)
   if max value == None or value > max value:
        obj[measurement]['max'] = value
def export to csv(self):
    timestamp = datetime.now().strftime('%Y %m %d %H %M %S')
    csv data = []
    headers = ['Timestamp']
    for esc in self.get_esc_names():
        for measurement in self.get_esc_measurement_names():
            headers.append(f"{esc} {measurement}")
```

```
for measurement in self.robot measurement names:
        headers.append(measurement)
    csv data.append(headers)
   # one row per timestamp
    for i in range(len(self.data timestamps)):
        data row = [self.data timestamps[i].strftime('%H %M %S %f')]
        for esc in self.get esc names():
            for measurement in self.get_esc_measurement_names():
                all_values = self.get_all_values(measurement, esc)
                data row.append(all values[i] if len(
                    all values) > i else None)
        for measurement in self.robot_measurement_names:
            all values = self.get all values(measurement)
            data row.append(all values[i] if len(
                all values) > i else None)
        csv_data.append(data_row)
   file_name = f"avian_data_{timestamp}.csv"
   with open(file_name, "w", newline="") as csv_file:
        writer = csv.writer(csv_file)
       writer.writerows(csv_data)
    self.serial_reader.export_raw_data()
def print_data(self):
    print(self.data)
def handle_data(self, data):
   if (not "Data:" in data):
        return
    now timestamp = datetime.now()
   self.data_timestamps.append(now_timestamp)
    data array = list(map(lambda str: int(str), data.split()[1:]))
    split data = {
        DRIVE_ESC_1: data_array[0:9], # first 9
        DRIVE_ESC_2: data_array[9:18], # next 9
```

```
WEAPON ESC: data array[18:26], # next 8
    ARM ESC: data array[26:34], # last 8
    SIGNAL STRENGTH: data array[34]
}
def merge_bytes(byte1, byte2):
    return (byte1 << 8) + byte2
parsed_esc_data = {}
for esc in [DRIVE_ESC_1, DRIVE_ESC_2]:
    esc data = split data[esc]
    parsed_esc_data[esc] = {
        TEMP: esc_data[0],
        VOLTAGE: merge_bytes(esc_data[1], esc_data[2]) / 100,
        CURRENT: merge_bytes(esc_data[3], esc_data[4]) / 100,
        CONSUMPTION: merge_bytes(esc_data[5], esc_data[6]),
        RPM: int(merge_bytes(esc_data[7], esc_data[8]) * 100 / 6)
    }
for esc in [WEAPON_ESC, ARM_ESC]:
    esc_data = split_data[esc]
    scale_val = 2042
    current = merge_bytes(esc_data[4], esc_data[5]) / scale_val * 50
    delta_time_hours = (
        now_timestamp - self.data_timestamps[-1]).total_seconds() / 3600
    consumption = current * 1000 * delta_time_hours
    parsed_esc_data[esc] = {
        TEMP: merge bytes(esc data[0], esc data[1]) / scale val * 30,
        VOLTAGE: merge bytes(esc data[2], esc data[3]) / scale val * 20,
        CURRENT: current,
        CONSUMPTION: consumption,
        RPM: int(merge bytes(
            esc_data[6], esc_data[7]) / scale_val * 20416.66 / 7)
    }
for esc in parsed esc data:
    for measurement in parsed_esc_data[esc]:
        parsed_esc_data[esc][measurement] = round(
            parsed_esc_data[esc][measurement], 2)
```

```
self.add value(
                    measurement, parsed esc data[esc][measurement], esc)
       parsed robot data = {}
       parsed robot data[BATTERY VOLTAGE] =
parsed_esc_data[DRIVE_ESC_1][VOLTAGE]
        parsed robot data[TOTAL CURRENT] = sum(
            list(map(lambda esc: parsed esc data[esc][CURRENT], self.esc names)))
       parsed_robot_data[TOTAL_CONSUMPTION] = sum(
            list(map(lambda esc: parsed_esc_data[esc][CONSUMPTION],
self.esc names)))
        parsed robot data[SIGNAL STRENGTH] = split data[SIGNAL STRENGTH]
        for measurement in parsed_robot_data:
            self.add value(
                measurement, round(parsed_robot_data[measurement], 2)
            )
class TelemetryGUI(QWidget):
   def __init__(self):
       super().__init__()
       self.com_port_dropdown = QComboBox()
       ports = list_ports.comports()
       self.port_names = list(map(lambda port: port.name, ports))
       self.com_port_dropdown.addItems(self.port_names)
       if len(self.port names) > 0:
            self.avian = Avian(self.port names[0])
       else:
            self.avian = Avian(None)
       self.displayed data = {}
       # OPTIONS
       self.should show plots = True
       self.use fake data = False
       self.num_values_to_plot = 50
```

```
self.initialize gui()
   # TODO: hook up properly
   def on select port(self, index):
        selected port = self.port names[index]
        self.avian = Avian(selected_port)
   def initialize gui(self):
        self.main layout = QHBoxLayout()
       self.setLayout(self.main_layout)
        esc_layout = QGridLayout()
        self.main_layout.addLayout(esc_layout)
        for esc_index, esc_name in enumerate(self.avian.get_esc_names()):
            esc_square = QVBoxLayout()
            esc_label = QLabel(esc_name)
            esc_label.setFont(esc_label_font)
            esc square.addWidget(esc label)
           measurement_grid = QGridLayout()
            measurement_grid.setSpacing(4)
            displayed measurements =
self.avian.get_displayed_esc_measurement_names()
            displayed_measurement_units =
self.avian.get displayed esc measurement units()
            for measurement index, measurement name in
enumerate(displayed measurements):
               units = displayed measurement units[
                    measurement index
                ]
               measurement square = QWidget()
               measurement square style = "background-color: #ccccc;"
               measurement square.setStyleSheet(measurement square style)
                esc_layout.addWidget(measurement_square)
```

```
value column = QVBoxLayout(measurement square)
                self.create measurement display(
                    value_column, measurement_name, units, esc_name
                )
                measurement_grid.addWidget(
                    measurement_square, measurement_index // 2, measurement_index
% 2
                )
            esc_square.addLayout(measurement_grid)
            esc_layout.addLayout(esc_square, esc_index // 2, esc_index % 2)
       # right side
        robot_column = QVBoxLayout()
        self.main_layout.addLayout(robot_column)
        avian label = QLabel("Colossal Avian")
        avian_label.setFont(avian_font)
        robot_column.addWidget(avian_label)
        self.create_measurement_display(
            robot_column, BATTERY_VOLTAGE, 'V'
        )
       self.total_current_label = self.create_measurement_display(
            robot_column, TOTAL_CURRENT, 'A'
        self.total_consumption_label = self.create_measurement_display(
            robot column, TOTAL CONSUMPTION, 'mAh'
        self.total consumption label = self.create measurement display(
            robot_column, SIGNAL_STRENGTH, 'dBm'
        )
        dropdown_title = QLabel("COM Port")
        dropdown title.setFont(measurement font)
        robot column.addWidget(dropdown title)
        robot column.addWidget(self.com port dropdown)
        export_button = QPushButton("Export to CSV")
```

```
export button.clicked.connect(self.avian.export to csv)
        robot column.addWidget(export button)
       # flex
       self.main layout.setStretch(0, 8)
        self.main layout.setStretch(1, 2)
        self.setWindowTitle('Colossal Avian')
        self.setGeometry(100, 100, 500, 300)
       self.timer = QTimer()
        self.timer.timeout.connect(self.update gui)
        self.timer.start(100)
   def update_gui(self):
       if (self.use fake data):
            print('using fake data')
            for measurement in self.avian.get_robot_measurement_names():
                self.avian.add_value(measurement, random.randint(-100, 0)
                                     if measurement == SIGNAL STRENGTH
                                     else random.randint(0, 100)
                                     )
            for esc in self.avian.get_esc_names():
                for measurement in
self.avian.get_displayed_esc_measurement_names():
                   self.avian.add_value(
                        measurement, random.randint(0, 100), esc)
       # update labels and plots
        for measurement in self.avian.get robot measurement names():
            self.update_label_and_plot(measurement)
        for esc in self.avian.get esc names():
            for measurement in self.avian.get displayed esc measurement names():
                self.update_label_and_plot(measurement, esc)
   def create measurement display(self, layout, measurement, units, esc=None):
        name label = QLabel(measurement)
        name label.setFont(measurement font)
        layout.addWidget(name label)
```

```
current value = self.avian.get current value(measurement, esc)
       value label = QLabel(str(current value))
       value label.setFont(value font)
       layout.addWidget(value label)
       data = self.avian.get all values(
           measurement, esc
       )
       min value = self.avian.get min value(measurement, esc)
       max value = self.avian.get max value(measurement, esc)
       min_max_label = QLabel(
           f"{min_value} | {max_value}"
       min max label.setFont(min max font)
       layout.addWidget(min max label)
       if self.should_show_plots and measurement != SIGNAL_STRENGTH:
           pg.setConfigOption('background', 'w')
           # pg.setConfigOption('foreground', 'k')
           plot = pg.PlotWidget()
           # plot.setMaximumHeight(50)
           layout.addWidget(plot)
       else:
           plot = None
       display data = {'value label': value label, 'units': units,
min max label': min max label,
                       'plot': plot, 'data': data}
       if esc == None:
           self.displayed data[measurement] = display data
       else:
           if not esc in self.displayed data:
               self.displayed_data[esc] = {}
           self.displayed data[esc][measurement] = display data
   def update_label_and_plot(self, measurement, esc=None):
```

```
obj = self.displayed data[measurement] if esc == None else
self.displayed data[esc][measurement]
        value = self.avian.get current value(measurement, esc)
       value text = f"{str(value)} {obj['units']}"
        min max text = f"{str(self.avian.get min value(measurement, esc))} |
{str(self.avian.get_max_value(measurement, esc))}"
       if esc == None:
            self.displayed_data[measurement]['value_label'].setText(value_text)
            if measurement == TOTAL CONSUMPTION and value != None:
                percent = round(100 * value / 3000, 2)
                self.displayed data[measurement]['value label'].setText(
                    f"{value_text} ({percent}%)"
                )
            elif measurement == SIGNAL STRENGTH and value != None:
               if value < -90:
                    style sheet = 'background-color: red;'
                elif value < -80:
                    style_sheet = 'background-color: orange;'
               elif value < -70:
                    style_sheet = 'background-color: yellow;'
               else:
                    style_sheet = 'color: black;'
                self.displayed data[measurement]['value label'].setStyleSheet(
                    style_sheet
                )
            self.displayed data[measurement]['min max label'].setText(
               min max text
        else:
            self.displayed data[esc][measurement]['value label'].setText(
               value text
            if measurement == TEMP and value != None:
               if value >= 80:
                    style_sheet = 'background-color: red;'
               elif value >= 70:
                    style_sheet = 'background-color: orange;'
```

```
elif value >= 60:
                    style_sheet = 'background-color: yellow;'
                else:
                    style sheet = 'color: black;'
self.displayed_data[esc][measurement]['value_label'].setStyleSheet(
                    style sheet
                )
            self.displayed_data[esc][measurement]['min_max_label'].setText(
               min max text
            )
       # self.should show plots = self.displayed data[measurement][
              'ax'] != None if esc == None else
self.displayed data[esc][measurement]['ax'] != None
        measurements_to_plot_all = [CONSUMPTION,
                                    BATTERY_VOLTAGE, TOTAL_CONSUMPTION, TEMP]
       if self.should show plots and measurement != SIGNAL STRENGTH:
            if measurement in measurements to plot all:
                data = self.avian.get_all_values(measurement, esc)
            else:
                data = self.avian.get_last_n_values(
                    measurement, self.num_values_to_plot, esc
                )
            pen options = pg.mkPen('k', width=1)
            if esc == None:
                self.displayed data[measurement]['data'] = data
                self.displayed data[measurement]['plot'].clear()
                self.displayed data[measurement]['plot'].plot(
                    self.displayed data[measurement]['data'],
                    pen=pen options
                )
            else:
                self.displayed data[esc][measurement]['data'] = data
                self.displayed_data[esc][measurement]['plot'].clear()
                self.displayed data[esc][measurement]['plot'].plot(
```