



D8.1.3 – Power plant safety scenario
Part I: The Backup Power Supply (BPS) Case
Study

WP8.1 – Power Plants WP8 – Demonstrators

MODRIO (11004)

Version 1.0

Date 01/05/2016

Authors

Thuy NGUYEN EDF

Accessibility : PUBLIC



Executive summary

This document is Part I of deliverable MODRIO D8.1.3 Power plant safety scenario. It describes in detail an example of property modelling based on a Backup Power Supply (*BPS*) system. This system is relatively simple in terms of physics but introduces relatively complex control logic. It is a realistic example of a reactive hybrid system, illustrating the modelling of timing issues and the use of discrete time domains.

The *BPS* case study aims at several goals. The first one is to serve as a self-consistent public case study that can be freely communicated and easily understood even by readers who did not participate in the MODRIO project. To that end, it has been designed to be independent from any industrial sector. The second goal of the case study is to provide concrete examples of the use of the FORM-L, covering if not all, at least a large part of the language. The third goal is to illustrate various possible uses of modelling and simulation in systems engineering, in particular verification that the functional, timing and operational requirements specified for a given system are appropriate with respect to the environment of the system, and verification that overall design, and then detailed design, satisfy the specified requirements.

The methodology followed is the one proposed in [Thuy Nguyen, "MODRIO D2.1.2 Properties modelling method".]. In particular, it suggests that separate models are developed for requirements specification, system specification, overall design and detailed design. Whereas the first three models are composed of property models developed early in the system engineering lifecycle, the last one is generally a behavioural model based on a precise knowledge of the characteristics and behaviour of the components constituting the system. In addition to models representing the system itself, models for the entities (technical systems or humans) constituting the environment of the system are used in order to provide a context for, and interact with, the models for the system under study. In practice, different models are developed at different stages of the system engineering lifecycle, by different persons who have different viewpoints, different backgrounds and different modelling constraints.

The property models for system requirements, system specification and system overall design are developed based on the FOrmal Requirements Modelling Language (FORM-L) proposed in [Thuy Nguyen, "MODRIO D2.1.1 Part III: FOrmal Requirements Modelling Language (FORM-L)", also available as EDF technical report, H-P1A-2014-00550-EN.]. The interfaces between property models or with behavioural models are based on the modelling architecture proposed by [Bouskela D., "MODRIO D2.1.1 Part II: Modeling Architecture for the Verification of Requirements", also available as EDF technical report, H-P1C-2014-15188-EN, 2015.]. As a perspective (i.e. after the end of MODRIO), it is planned to continue the work at EDF on this case study. The property models presented here will be complemented with a (Modelica) behavioural model representing the detailed design and the physical behaviour of the electrical and electromechanical components. Component failure modes will also be modelled using the multi-modelling concepts and languages proposed by WP4.



Summary

Executive summary	2
Summary	3
Acronyms	5
Glossary	6
1. Introduction	
1.1. Context	
1.2. Objectives	
1.3. Structure of the document	
1.4. Notation	
2. BPS System Requirements	8
2.1. Brief Introduction to the BPS	8
2.2. BPS Non-Formal System Requirements	
2.3. Modelling Organisation	
2.4. The mpsMonitoring Contract	
2.5. The hsi Contract	
2.6. The bep Standard Contract	
2.7. Clients	
2.8. The bpsReq Reference Model	
3. BPS System Specification	14
3.1. Brief Introduction to Systems Organisation	
3.1.1. BPS and Clients Divisions	
3.1.2. BPS States	
3.1.3. Operator	
3.1.4. Fault-Tolerance and Sensors	
3.2. BPS Non Formal System Specification	
3.3. Modelling Organisation	
3.4. The <i>HsiDiv</i> Standard Contract	
3.5. The op Model	
3.6. The ClientAb and ClientDiv Classes	19
3.7. The ClientSpec Standard Contract	
3.8. Clients	
3.9. The Component Class	
3.10. The ProtectedComponent Class	
3.11. The BpsDivSpec Class	
3.11.2. Validation of Operator Requests	
3.11.3. Operational States	
3.11.4. Fault-Tolerance	
3.11.5. Alarms	
3.11.6. Activity	
3.11.7. Powering Clients	
3.11.8. Specification	
3.12. The bpsSpec Object	
3.13. The spec Contract	
4. BPS Overall Design	
4.1. Brief Introduction to the Overall Design	31



D8.1.3 – Part I MODRIO (ITEA 2 – 11004)

Page 4 of 57

4.2.	Modelling Organisation of the Overall Design	33
4.3.	The Breaker Class	
4.4.	The MSensor Class	36
4.5.	The Voltmeter Class	37
4.6.	The FreqMeter Class	37
4.7.	The PSensor Class	37
4.8.	The Step Class	38
4.9.	The DG (Diesel Generator) Class	40
4.10		
4.	10.1. Time Domain	42
4.	10.2. Main States	42
4.	10.3. Inputs	43
4.	10.4. Outputs	44
4.	10.5. Main Events and Conditions	47
4.	10.6. State Transitions and Actions	49
4.11	. The BpsDivOds Class	53
4.12	. The Ods Standard Contract	55
4.13	. The Models for the Overall Design of the Two BPS Divisions	56
5.	To be Provided by Scenarios or Detailed Design	56
6.	Conclusion	56
7.	References	56

Acronyms

BPS Backup Power Supply

CTL Continuous Time Locator

Computation Tree Logic

DG Diesel Generator

FORM-L FOrmal Requirements Modelling Language

LS Load Sequencer

LTL Linear Temporal Logic
MPS Main Power Supply

SRI Intermediate Cooling System

WP Work Package

Glossary

Assumption Property that is supposed to be satisfied: simulation scenarios

assume / ensure that it is satisfied.

Conditional Probability Real value (not a function) in the [0., 1.] range that states the

probability of an event occurring at least once during a specified time period (a CTL). The time period specifies the condition

Continuous Time

Domain

Time domain where time is perceived continuously. There is only

one continuous time domain

Continuous Time

Locator

Expression that specifies one or more time intervals

Contract Property model specifying the mutual obligations of two or more

parties.

Discrete Time Domain
Time domain where time is perceived not continuously but at

specific, defined instants. Different discrete time domains may

specify different sets of instants

Event Named expression that characterises the occurrences of a fact

that has no duration

Event-Based Property An event-based property states that an event does or does not

occur at a specified time locator, possibly with a count constraint

Finite State Automaton Function of time the values of which belong to an enumerated set

Guard Property that states the conditions that must be satisfied for a

model to be valid

Probability Function of *time*, the result of which is a **real** value in the [0., 1.]

range. Its value represents the probability that a given event

has already occurred at least once

Property Expression of something that is desirable, expected or required.

Reference Model Top-level model for a system under study that serves as a

reference for subsequent models

Requirement Property that must be satisfied: it is the objective of simulation to

verify that it is not violated

Surrogate Model Property model for an entity that just satisfies the contracts to

which that entity is a party.

Time Domain Part of a model where objects have the same perception of time

Time Domain Interface Part of a model where events and variables in one time domain

is made perceptible by objects belonging to another time domain

Time Instant Position in time that has no duration

Time Interval Period of time that has a duration (as opposed to an event, which

is instantaneous and has no duration)

Time Locator See Continuous Time Locator and Discrete Time Locator

Accessibility : PUBLIC

1. Introduction

1.1. Context

This document is Part I of deliverable MODRIO D8.1.3 *Power plant safety scenario*. It describes in detail an example of property modelling based on a Backup Power Supply (*BPS*) system. This system is relatively simple in terms of physics but introduces relatively complex control logic. It is a realistic example of a reactive hybrid system, illustrating the modelling of timing issues and the use of discrete time domains.

The methodology followed is the one proposed in [13]. In particular, it suggests that separate models are developed for requirements specification, system specification, overall design and detailed design. Whereas the first three models are composed of property models developed early in the system engineering lifecycle, the last one is generally a behavioural model based on a precise knowledge of the characteristics and behaviour of the components constituting the system. In addition to models representing the system itself, models for the entities (technical systems or humans) constituting the environment of the system are used in order to provide a context for, and interact with, the models for the system under study. In practice, different models are developed at different stages of the system engineering lifecycle, by different persons who have different viewpoints, different backgrounds and different modelling constraints.

The property models for system requirements, system specification and system overall design are developed based on the FOrmal Requirements Modelling Language (FORM-L) proposed in [14]. The interfaces between property models or with behavioural models are based on the modelling architecture proposed by [12]. As a perspective (i.e. after the end of MODRIO), it is planned to continue the work at EDF on this case study. The property models presented here will be complemented with a (Modelica) behavioural model representing the detailed design and the physical behaviour of the electrical and electromechanical components. Component failure modes will also be modelled using the multi-modelling concepts and languages proposed by WP4.

1.2. Objectives

The BPS (Back-up Power Supply) case study aims at several goals. The first one is to serve as a self-consistent public case study that can be freely communicated and easily understood even by readers who did not participate in the MODRIO project. To that end, it has been designed to be independent from any industrial sector. The second goal of the case study is to provide concrete examples of the use of the FORM-L, covering if not all, at least a large part of the language.

The third goal is to illustrate the methodology proposed in [13] to support various systems engineering activities, in particular for verifying that the behavioural requirements specified for a given system are appropriate with respect to the environment and the operation of the system, and for verifying that a system specification, an overall design, and then a detailed design, satisfy the specified requirements.

Although it is a fictitious and does not describe a specific real-life system, the case study is representative of what could be required of a high-power backup electric power supply system. Also, though it is relatively simple, it is reasonably complete from a behavioural standpoint, with requirements covering the normal and failure situations (including probabilistic requirements regarding failures). Non-behavioural requirements such as volume, weight, ambient conditions, seismic conditions, electromagnetic compatibility, human factors, cyber security, practical aspects of maintenance and testing, installation on site, authorised noise levels, HVAC, power supply for the *BPS* are not covered.

1.3. Structure of the document

Section 2 presents an overview of the *BPS*, of its environment and of its system requirements. It then provides a detailed presentation of the modelling of the system requirements in FORM-L.

Section 3 presents an overview of the *BPS* system specification, and then provides a detailed presentation of the modelling of the system specification in FORM-L.

Accessibility : PUBLIC	

Section 4 presents an overview of the *BPS* overall design, and then provides a detailed presentation of the modelling of the overall design in FORM-L.

Section 5 presents the external features that need to be provided either by scenario models or by detailed design models if one wants to go further in the verification methodology (i.e. to test the models by simulation or to complete them with a detailed design).

1.4. Notation

FORM-L statements are written in a bold Courier New font.

FORM-L keywords are in blue italics.

The names of property models, of classes and types begin with an upper-case letter.

The names of objects and variables begin with a lower-case letter.

Event names begin with an 'e'.

Names for desirable properties begin with a 'p', whereas names for requirements begin with an 'r'.

The names of configurations are in upper-case.

The use of a predefined FORM-L library defining physical constants of various types is assumed. For example:

- 1*s 1 second

10*s
 10 seconds

- 1*h 1 hour

- 100*ms 100 milliseconds

- 1000*kw 1000 kilowatts

2. BPS System Requirements

2.1. Brief Introduction to the BPS

The objective of the *BPS* is to provide electric power to a number of "clients" in case of loss of the Main Power Supply (*MPS*). Such clients could be important to safety (e.g., in an industrial installation or in a hospital) or could be essential for preventing unacceptable economic losses (e.g., in a manufacturing plant). Figure 2-1 places the *BPS* within its environment. In addition to the *MPS* and a human operator, three clients (*client1*, *client2* and *client3*) have been identified. Each has specific expectations with respect to the *BPS*.




Figure 2-1
The BPS and its environment. The entities constituting the environment are shown in green. The BPS itself is shown on a yellow background.

2.2. BPS Non-Formal System Requirements

Each client has a certain potential for tolerating loss of electric power. That potential is quantitatively represented as a Real variable in range [0., 100.]. When the client is active and not powered, its potential is consumed. When the client is powered, its potential is replenished

- pa The BPS should ensure that when the MPS is not available, no client tolerance potential reaches zero.
- r1 The probability of not satisfying pa must be less than 10⁻³ per BPS demand.

Once activated, the *BPS* is put back to rest by a *Reset* signal issued by the operator. A *Reset* is valid if and only if it occurs after the *MPS* is available again, and at least 10 minutes after the *BPS* activation.

- When a valid Reset is issued by the operator, if the MPS is not lost again, then the normal powering conditions (i.e., all clients powered by the MPS) should be restored within 10 seconds.
- r2 The probability of not satisfying *pb* must be less than 10⁻³ per *BPS* demand.

The operator needs to be informed of *BPS* failures, so that he or she can take any necessary mitigating actions, as specified by operating procedures.

- pc When pa or pb are violated, a failure signal should be sent to the operator.
- r3 The probability of not sending a failure signal when necessary must be less than 10⁻³ per demand.
- The rate of spurious failure signal must be less than what it would be if there were a constant failure rate of 10⁻² per year.

2.3. Modelling Organisation

The modelling organisation for the *BPS* system requirements is summarised in Figure 2-2. It is based on six object models:

- Reference object model *bpsReq* specifies the system requirements placed on the *BPS* (see Section 2.2 *BPS Non-Formal System Requirements*).
- Object model mps represents the MPS. This model could simply be a surrogate model (just satisfying the mpsMonitoring contract) or one among a set of generic scenario models (also complying with mpsMonitoring).

Accessibility : PUBLIC	

- Object model op represents the human operator. The same principles as for mps apply, mutatis mutandis.
- Class model Client specifies the general characteristics of a BPS client. It has three instances (client1, client2 and client3) representing the three clients of the BPS. The same principles as for mps and op apply.

The bpsReq model has five contracts with the models of its environment entities:

- Contract mpsMonitoring with mps.
- Contract hsi (for Human-System Interface) with op.
- Contracts *bep1*, *bep2* and *bep3*, respectively with *client1*, *client2* and *client3*. They are instantiations of a standard contract named *Bep* (for Backup Electric Power).

Most of the BPS system requirements are specified in the contracts.

Note. The system names (e.g., *MPS*) are different from the model names (e.g., *mps*) to highlight the fact that a model is NOT a system, and to avoid ambiguities when explaining the modelling.




Figure 2-2

Overall organisation of the BPS system requirements modelling. The reference object model is shown in yellow, the other object models in green, and the contracts in blue. Classes and standard contracts are shown with round corners.

```
configuration BPS REQ
  reference object model "*bpsReq*" alias bpsReq; // *xxx* : file name
                  "*mps*"
  object
                                     alias mps;
                                    alias op;
  object
                  "*op*"
                  "*Client*"
  class
                                    alias Client;
  property model "*CLIENTS*"
                                     alias CLIENTS; // Instances of Client
                  "*mpsMonitoring*" alias mpsMonitoring;
  contract
                  "*hsi*"
                                alias ns1;
alias Bep; // Standard contract
                                     alias hsi;
  contract
                  "*Bep*"
  contract
                  bps1 = Bep(client1, powering1);
  contract
  contract
                  bps2 = Bep(client2, powering2);
                  bps3 = Bep(client3, powering3);
  contract
  end BPS REQ;
```

2.4. The mpsMonitoring Contract

The property model for the *MPS* does not need to be a detailed model: any surrogate model satisfying the *mps* part of contract *mpsMonitoring* will be sufficient. In practice, one can chose one among various property models, each representing one generic test scenario of *MPS* behaviour.

Contract mpsMonitoring can be read as follows:

- It is set between two parties: the mps and the bpsReq.
- There is only one deliverable in this contract: the *voltage* at the terminals of the *MPS*, and it is under the responsibility of the *mps* party. mps guarantees that *voltage* will be in the 0.-240. volt range.
- The bpsReq party has no obligation in this contract.

2.5. The hsi Contract

```
contract hsi
  party op
    // Reset button
    Boolean resetBtn;
    requirement b1 =
       after resetBtn becomes true for 0.5*s check resetBtn;
    requirement b2 =
       after resetBtn becomes false for 0.5*s check not resetBtn;
    end op;
  party bpsReq
                         // BPS failure
    event eFailure;
    event eAlarm;
                          // Alarm signal sent to operator
    // Inform operator in case of BPS failure
    property pc = after eFailure within 200*ms check once eAlarm;
    requirement r3 =
       after eFailure check probability (pc.violated becomes true) < 10^{-3};
    // No spurious failure signal
    property pd = before eFailure check no eAlarm;
    requirement r4 =
       check probability (pd.violated becomes true) < 1.-exp(-10<sup>-2</sup>*time/y);
    end bpsReq;
  end hsi;
```

Contract hsi can be read as follows:

- It is set between two parties: the op model and the bpsReq model.
- Party *op* delivers a Boolean variable named *resetBtn* representing the state of a *Reset* button. The variable is *true* when the *Reset* button is pressed, and *false* otherwise. The *BPS* interprets the variable becoming *true* as a *Reset* request.

Accessibility : PUBLIC	

- Requirements *b1* and *b2* address the fact that no real system can detect an arbitrarily brief signal. Thus, the *Reset* button is in fact a device ensuring that the associated Boolean variable remains in the same *true* / *false* state for at least 0.5 second after a transition.
- Party *bpsReq* delivers two events: *eFailure* and *eAlarm*. *eFailure* occurs when the *BPS* fails to satisfy properties *pa* and / or *pb*. *eAlarm* is raised by the *BPS* as per requirements *r*3 and *r*4 (see Section 2.2 *BPS Non-Formal System Requirements*).

2.6. The bep Standard Contract

Each client has a contract with the *BPS*. As these contracts are similar, they are based on standard contract *Bep* (for *backup electric power*).

```
contract Bep (client, powering)
  party client
    Boolean active;
    Boolean powered;
    Real tolPot;
    end client;
  party bpsReq
    assumption c1 = check no active becomes false;
     event eVReset;
    Boolean powering;
    assumption c2 = during powering check powered;
    property pa = check tolPot > 0.;
    requirement r1 =
       after (active and not powered) becomes true
       check probability (pa.violated) < 10<sup>-3</sup>;
    property pb =
       after eVReset within 10*s check powered and not powering;
     requirement r2 = after eVReset check probability (pb.violated) < 10-3;
    end bpsReq;
  end Bep;
```

The contract can be read as follows:

- it has two parameters: *client* is the client, and *powering* is the variable that tells whether the client is powered by the *BPS*.
- It has two roles: *bpsReq* and a *client* (that needs to be powered when active, by the *bpsReq* or by any other source). The identity of the *client* needs to be specified at each *bep* instantiation.
- active is a Boolean deliverable of the *client* that indicates whether it is active and needs to be powered. bpsReq asumes (assumption c1) that once the *client* is active, it will remain so.
- powered is a Boolean deliverable of the *client* that indicates whether it is powered (by *bpsReq* or by any other source).
- *tolPot* is a Real deliverable of the *client* that determines its potential to tolerate loss of electric power (see Section 2.2 *BPS Non-Formal System Requirements*).
- eVReset is an event delivered by bpsReq indicating that the human operator has issued a valid BPS reset.
- powering is a Boolean delivered by bpsReq indicating whether it is providing power to the client. Assumption c2 states that when bpsReq is powering the client, then powered must be true.

2.7. Clients

For the pupose of this case study, and at this stage of the system development process, a property model for *client1*, *client2* or *client3* just needs to provide the information necessary to instantiate standard contract *bep*:

- For *client1*, Boolean *active* is declared external and will be provided by subsequent models (design models in FORM-L or behavioural models in Modelica). For *client2* and *client3*, Boolean *active* is always true.
- For all three clients, Boolean *powered* and Real *tolPot* are declared external and will be provided by subsequent models.

```
class Client
  Boolean active;
  external Boolean powered;
  external Real tolPot
    start = 100.;
    end tolPot;
  end Client;
property model CLIENTS
  Client client1
    external Boolean active;
     contract bep1;
    end client1;
  Client client2
     active = true;
     contract bep2;
     end client2;
  Client client3
     active = true;
     contract bep3;
     end client3;
  end CLIENTS;
```

2.8. The bpsReq Reference Model

```
contract hsi;
                                                        // with op
event eFailure =
                                                        // for hsi
  when (bepl.pa.violated or bepl.pb.violated
     or bep2.pa.violated or bep2.pb.violated
     or bep3.pa.violated or bep3.pb.violated) becomes
                                                       true:
external event eAlarm;
                                                        // for hsi
event eVReset =
                                                        // for bep
  after (mpsAvailable becomes false + 10.*mn) and
  when (resetBtn and mpsAvailable) becomes true;
external Boolean powering1;
                                                        // for bep
external Boolean powering2;
                                                        // for bep
external Boolean powering3;
                                                        // for bep
contract bep1;
                                                        // with client1
contract bep2;
                                                        // with client2
contract bep3;
                                                        // with client3
// The final evaluation of the properties can be made only after the BPS
// has attempted to restore normal powering conditions
after eVReset + 15.*s then stop;
end bpsReq;
```

The bpsReq model can be read as follows:

- Two guards specify the conditions of validity of the *bpsReq* model: *g1* states that the *MPS* should be initially available; *g2* states that the *MPS* should be lost only once.
- It cites the five contracts with the models for the *BPS* environment (*mpsMonitoring*, *hsi*, *bep1*, *bep2* and *bep3*). For the last three, it specifies the variable that provides the *powering* parameter (whether the *BPS* powers the *client*).
- Event eFailure is directly defined as a violation of pa or pb.
- Event eVReset is directly defined as a reset request at least 10 minutes after the MPS has become unavailable, and when it is available again.
- The other deliverables the *bpsReq* model is responsible for are declared external and will be defined by specification or design models.
- The last statement specifies that the final evaluation of the properties in the model can be made only after the *BPS* has attempted to restore normal powering conditions.

3. BPS System Specification

System specification is the first step in the definition of a solution that will meet the system requirements specified and modelled in Section 2 BPS System Requirements.

3.1. Brief Introduction to Systems Organisation

3.1.1. BPS and Clients Divisions

As the *BPS* and its clients are required to be continuously available over long periods (e.g., a year or more), to allow maintenance while in operation and to tolerate components failures, each is divided into two identical *divisions* (named *a* and *b*). At any given time, a client division is connected to one and only one *BPS* division. Switching from one *BPS* division to the other takes a very short time (in the order of a second) compared to the time interval between real demands to the *BPS* (in the order of once per year or per decade). Maintenance of a *BPS* division can be performed when all the client divisions are connected to the other division. Figure 3-1 presents this more detailed view of the *BPS* and of its environment.

Accessibility : PUBLIC	




Figure 3-1
The BPS divisions and their environment. In the case shown, client divisions a are all connected to BPS division a, and client divisions b are all connected to BPS division b.

3.1.2. *BPS* States

When in operation, a BPS division can be in one of three main states:

- Nominal state: the BPS division is available and ready to perform its mission.
- Test state: as MPS loss is rare and the BPS is seldom active, periodic testing is necessary to ensure that when needed, the BPS division will indeed be able to perform its mission.
- Maintenance state: the BPS division is not in service, all clients are connected to the other division, and the BPS mission is ensured by the other division.

3.1.3. Operator

In addition to the reset button seen previously, the operator in the control room has:

- Two buttons, one for each BPS division, to signal the beginning of a maintenance session. In order to ensure their independence, the two divisions do not communicate. It is assumed that the operator will not put the two divisions into maintenance at the same time. It is also assumed that before one division is put into maintenance, field operators have connected all the clients to the other division.
- One button to signal the end of an on-going maintenance session.
- Two buttons, one for each BPS division, to order the start a periodic test.

3.1.4. Fault-Tolerance and Sensors

A *BPS* division is composed of a number of components of different types, including sensors. Sensors are relatively inexpensive but are subject to drift and failure. To further enhance fault-tolerance capability, the *BPS* specification requires that each division must be able to tolerate the failure of any single sensor.

3.1.5. Critical Components

A *BPS* division has components such as a diesel generator that are expensive and difficult to replace. They must be protected against damage whenever possible, in particular during periodic tests.

Accessibility : PUBLIC	

3.2. BPS Non Formal System Specification

As previously mentioned, the *BPS* is composed of two identical, redundant divisions. As they are fully independent from one another, the *BPS* system specification is expressed relative to each division. To avoid unnecessary complexity, each *BPS* division acts as if all client divisions were connected to it.


- When the *BPS* division is in maintenance, it must not be activated. (Otherwise, maintenance personnel could be harmed. The division might not be operable anyway.)
- s2 In the absence of any *BPS* division component failure or in the presence of a single sensor failure, when the division is not in maintenance, and in case of loss of *MPS*:
 - a) If *client1* is active, its divisions must be powered within 25 seconds. Power must be provided until a valid reset from the operator.
 - b) The divisions of *client2* must be powered within 35 seconds. Power must be provided until a valid reset from the operator.
 - c) The divisions of *client3* must be powered within 45 seconds. Power must be provided until a valid reset from the operator.
- s3 Probabilities of not satisfying requirements s2 due to the BPS division components failures:
 - a) The probability of not powering one or more client divisions in the allocated time must be less than 10⁻³ per demand.
 - b) The *BPS* division failure rate while it powers its clients must be less than what it would be if there was a constant failure rate of 10⁻³ per day.
- s4 In the absence of any *BPS* division component failure or in the presence of a single sensor failure, the division must not be spuriously activated.
- The probability of spuriously activating the *BPS* division must be lower than what it would be if there were a constant occurrence rate of spurious activation equal to 10⁻³ per year.
- s6 When the BPS division is active:
 - a) If it mitigates a loss of the *MPS*, its protected components must be operated at any cost, even if this means damaging or eventually destroying them in the long run.
 - b) If it is operated for a periodic test, the risk of damaging its protected components must be minimised.

Once activated, the *BPS* division can be put back to rest by a *Reset* signal issued by the operator. A *Reset* is valid when and only when it occurs after the *MPS* is available again, and at least 10 minutes after the *BPS* activation.

- s7 In the absence of any *BPS* division component failure or in the presence of a single sensor failure, when a valid *Reset* is issued by the operator, and if the *MPS* is not lost again:
 - a) The normal powering conditions for the client divisions (i.e., powered by the *MPS*) must be restored within 10 seconds.
 - b) No client division should be unpowered for more than a total of 5 seconds after the *Reset*. (A brief depowering is necessary, for some *BPS* components must not be connected to the available *MPS*, otherwise, they could be seriously damaged.)
- The probability of not restoring the normal powering conditions for all the client divisions within 10 seconds after a valid *Reset* must be less than 10⁻³ per *BPS* demand.
- psa If any client division cannot be powered as specified in s2 and s7, a failure signal should be sent in the control room to inform the operator. (He or she can then take any necessary mitigating action specified in the operating procedures.)
- s9 The probability of not sending a failure signal when required must be less than 10⁻³ per demand.

Accessibility : PUBLIC	

s10 The rate of spurious failure signal must be less than what it would be if there were a constant failure rate of 10⁻² per year.



3.3. Modelling Organisation

The modelling for the BPS system specification is summarised in

Figure 3-2:

- Class BpsDivSpec models the system specification of a BPS division.
- Object *bpsSpec* specifies the *BPS* system specification, and models the *BPS* as two divisions (instances of *BpsDivSpec*, named *bpsASpec* and *bpsBSpec*) and six Boolean switches.
- Contract spec is set between bpsSpec and the reference model bpsReq that specifies the BPS system requirements.
- Generic contract *HsiDiv* models the mutual obligations between *op* (representing the operator) and a *BPS* division. It has two instances: *hsiA* (between *op* and *bpsASpec*) and hsiB (between *op* and *bpsBSpec*).
- Class ClientDiv models a BPS client division.
- Class ClientAb models a BPS client as two divisions, instances of ClientDiv.
- Generic contract *ClientSpec* models the mutual obligations between *client_xAb* and *client_x*. It has three instances: *client1Spec*, *client2Spec* and *client3Spec*.
- Object *client1Ab* is an instance of *ClientAb* and models *client1* as two divisions (*client1a* and *client1b*). Similarly, object *client2Ab* models *client2* as two divisions (*client2a* and *client2b*), and object *client3Ab* models *client3* as two divisions (*client3a* and *client3b*).

Figure 3-2

Overall organisation of the BPS system specification modelling. The models in the top half of this diagram are those presented in Section 2.3 Modelling Organisation for system requirements. The same colour convention applies.

Noococibility - DLIDLIC	
Accessibility : PUBLIC	

```
configuration BPS SPEC
  // For System Requirements
  . . .
  // For System Specifications
                 "*BpsDivSpec*" alias BpsDivSpec;
"*Component*" alias Component;
  class
  class
                 "*ProtectedComponent*" alias ProtectedComponent;
  class
                 "*bpsSpec*" alias bpsSpec;
  object
                 "*spec*"
                                   alias spec;
  contract
                 "*ClientDiv*" alias ClientDiv;
  class
                 "*ClientAb*" alias ClientAb;
  class
                "*ClientSpec*" alias ClientSpec;
  contract
  contract
                client1Spec = ClientSpec(client1, clientAb1);
  contract     client2Spec = ClientSpec(client2, clientAb2);
contract     client3Spec = ClientSpec(client3, clientAb3);
  property model "*CLIENTS AB*" alias CLIENTS AB;
                 "*HsiDiv*"
                                   alias HsiDiv;
  contract
  contract
                 hsiA = HsiDiv(bpsASpec, maintBtn1, testBtn1);
  contract
                 hsiB = HsiDiv(bpsBSpec, maintBtn2, testBtn2);
  end BPS SPEC;
```

3.4. The HsiDiv Standard Contract

Through the instantiation of this standard contract, the *op* model provides 4 buttons to the *BPS* division given as the first argument: to start and end a maintenance session, to start a test and to reset. The *end maintenance* and the *reset* buttons are shared by the two *BPS* divisions. The *maintenance* and the *test* buttons are specific to each division, and are therefore also given as arguments to the standard contract.

```
contract HsiDiv
  (object bpsDiv, Boolean maintBtn, Boolean testBtn)
  party op
    Boolean maintBtn;
    requirement b3 =
      after maintBtn becomes true for 0.5*s check maintBtn;
    requirement b4 =
      after maintBtn becomes false for 0.5*s check not maintBtn;
    Boolean endMaintBtn;
    requirement b5 =
       after endMaintBtn becomes true for 0.5*s check endMaintBtn;
    requirement b6 =
      after endMaintBtn becomes false for 0.5*s check not endMaintBtn;
    Boolean testBtn;
    requirement b7 =
      after testBtn becomes true for 0.5*s check testBtn;
    requirement b8 =
      after testBtn becomes false for 0.5*s check not testBtn;
    end op;
    Boolean resetBtn;
    requirement b1;
    requirement b2;
  party bpsDiv
    end bpsDiv;
```

```
end HsiDiv;
```

3.5. The op Model

Values for the six buttons will be given by scenario models, and are therefore declared external. The eAlarm event is delivered by the *bpsReq* model (through contract *hsi*) and is also declared external.

```
object model op

external Boolean maintBtn1;
external Boolean maintBtn2;
external Boolean endMaintBtn;
external Boolean testBtn1;
external Boolean testBtn2;
external Boolean resetBtn;
external event eAlarm;

contract hsi; // with bpsReq
contract hsiA; // with bpsASpec
contract hsiB; // with bpsBSpec
end op;
```

3.6. The ClientAb and ClientDiv Classes

Class *ClientAb* models a client as two divisions. Features that are identical for both divisions are directly modelled in the *ClientAb* class:

- Whether the client is active.
- The parameters of the formula determining how fast the tolerance potential *tolPot* of a division is consumed or replenished: *kc* determines the linear rate at which the potential is consumed when the client is active and the division not powered, and *kr* the linear rate at which the potential is replenished when the division is powered.

Features that are different are modelled in embedded class ClientDiv:

- Each division is powered independently of the other.
- Consequently, its tolerance potential tolPot is also its own.

```
class ClientAb
  // Shared by the two divisions
  external Boolean active;
  specific constant Rate kc;
  specific constant Rate kr;
  class ClientDiv
    external Boolean powered;
    Real tolPot
       start = 100.;
       during not powered and active and tolPot > 0.
         then derivative(tolPot) = -kc;
       during powered and tolPot < 100. then derivative(tolPot) = kr;</pre>
       else fixed;
       end tolPot;
    end ClientDiv;
  ClientDiv divA;
  ClientDiv divB;
  // Consolidation across divisions
  Boolean powered = divA.powered or divB.powered;
  Real tolPot = largest {divA.tolPot, divB.tolPot};
```

```
end ClientAb;
```

3.7. The ClientSpec Standard Contract

This standard contract specifies the mutual obligations between the model of a client viewed at the level of the *BPS* system requirements (where the client is viewed as a black box), and of the model of the same client viewed at the level of the *BPS* system specification (where the client divisions are identified).

```
contract ClientSpec (client, clientAb)

party client
   Boolean active;
   requirement cl;
   end client;

party clientAb
   Boolean powered;
   Real tolPot;
   end clientAb;
end ClientSpec;
```

3.8. Clients

```
property model ClientsAB
  ClientAb client1Ab
    kc = 4./s;
    kr = 0.15/s;
    contract client1Spec;
    end client1Ab;
  ClientAB client2Ab
    kc = 2.5/s;
    kr = 0.3/s;
    contract client2Spec;
    end client2Ab;
  ClientAB client3Ab
    kc = 2./s;
    kr = 0.15/s;
    contract client3Spec;
    end client3Ab;
  ClientDiv{} clientDivs =
     {client1Ab.divA, client1Ab.divB,
     client2Ab.divA, client2Ab.divB,
      client3Ab.divA, client3Ab.divB};
  end ClientsAB;
```

3.9. The Component Class

The *BPS* specification has fault-tolerance requirements, even though the *BPS* components are yet unknown at specification time. Thus, components are represented by external sets of instances of class *Component*. For the purposes of the *bpsSpec* model, the only information that is needed on a component is whether it is in a failed state. This is represented by a Boolean attached to each component and declared as external to specify that for all components, its value is to be obtained later from the design. It is assumed that there are no components repairs during periods where the *BPS* is needed.

```
partial class Component
  external Boolean failed;
assumption noRepair =
   during voltage < 190.*v check no failed becomes false;
end Component;</pre>
```

3.10. The ProtectedComponent Class

Some components are of particular importance and difficult to replace. Thus, they are subject to particular care during operation and are modelled as instances of partial class *ProtectedComponent*, which is an extension of class *Component*. A protected component can be operated either in a *protected* mode (for example during tests, in which case it will be stopped if there is a risk of damaging it) or in a *workToDeath* mode (when the *BPS* is really needed, in which case the component will be operated even if there is a risk of damaging it).

```
partial class ProtectedComponent extends Component
  specific automaton mode = (protected, workToDeath);
  end ProtectedComponent;
```

3.11. The BpsDivSpec Class

This class models a BPS division.

class BpsDivSpec

3.11.1.Monitoring of the MPS

Inputs from the MPS

The only input from the *MPS* to be provided to the *BPS* division is the electric tension at the *MPS* terminals. It will be defined by each instance.

```
specific Voltage voltage;
```

Guards

The *BPS* division applies a time filtering scheme that could last up to 3 seconds to determine whether the *MPS* is available. The following guard states that no demand should be placed on the *BPS* division in the 3 first seconds of an operational case, to give the time filtering scheme time to initialise. In real life, an *MPS* loss in this time period is also very unlikely, and as the overall installation has not had time to really operate, this is considered to have no damaging consequences anyway.

```
guard g1 = until time = 3.*s check voltage > 215.*v;
```

Instantaneous on / off State

The main information regarding the *MPS* is whether it is available or not. The *BPS* division does not determine that itself: how that is done will be decided at a later stage by a *BPS* design. It just puts constraints on how the decision is made.

Based on *voltage*, the *BPS* division first determines the instantaneous *on / off* state of the *MPS*. That state is represented by a Boolean named *mpsOn* (that will be obtained at a later stage from the design). For legibility and to facilitate understanding, Boolean *mpsOff* is defined as the negation of *mpsOn*. *BpsDivSpec* specifies the constraints that apply to these Booleans (see Figure 3-3):

- Initially, the MPS is assumed to be on.
- It CAN be declared off when voltage gets below 190 volts.
- It MUST be declared off when voltage gets below 180 volts.
- It CAN be declared on again when voltage gets above 200 volts.
- It MUST be declared on again when voltage gets above 210 volts.

Accessibility : PUBLIC	






Figure 3-3

In requirements specification, boundaries must be specified with a certain "thickness" and hysteresis. The design must ensure that the transitions are indeed performed within the specified boundaries.

```
external Boolean mpsOn;
Boolean mpsOff = not mpsOn;
assumption aMps1 = during voltage > 190*v check not mpsOff;
assumption aMps2 = during voltage < 180*v check mpsOff;
assumption aMps3 = during voltage < 200*v check not mpsOn;
assumption aMps4 = during voltage > 210*v check mpsOn;
```

Time-filtred available | unavailable State

The *BPS* division should not be needlessly activated in case of short, transient voltage drops at the *MPS* terminals. Thus, whether the *MPS* is really available is represented by another external Boolean named *mpsAvailable* (also to be obtained from the design). The constraints specified by *BpsDivSpec* are based on a time-filtering scheme applied to *mpsOn* (see Figure 3-4):

- Initially, the MPS is assumed to be available.
- It CAN be declared unavailable when it has been off for more than 2 consecutive seconds.
- It MUST be declared unavailable when it has been off for more than 3 consecutive seconds.
- It CAN be declared available again when it has been on for more than 8 consecutive seconds.
- It MUST be declared available again when it has been on for more than 10 consecutive seconds.




Figure 3-4
The Available / Unavailable transitions

For legibility and to facilitate understanding, Boolean *mpsUnavailable* is defined as the negation of *available*, and two events are introduced:

- Event eMpsLoss signals that the MPS has transited from available to unavailable.
- Event *eMpsRestore* signals that the *MPS* has transited from *unavailable* to *available*.

```
external Boolean mpsAvailable;
Boolean mpsUnavailable = not mpsAvailable;
event eMpsLoss = when mpsAvailable becomes false;
event eMpsRestore = when mpsAvailable becomes true;
```

```
private property off2s = duringAny 2*s check mpsOff;
private property off3s = duringAny 3*s check mpsOff;
private property on8s = duringAny 8*s check mpsOn;
private property on10s = duringAny 10*s check mpsOn;
assumption aMps5 =
   during (mpsAvailable and not off2s) check no eMpsLoss;
assumption aMps6 = during off3s check mpsUnavailable;
assumption aMps7 =
   during (mpsUnavailable and not on8s) check no eMpsRestore;
assumption aMps8 = during on10s check mpsAvailable;
```

3.11.2. Validation of Operator Requests

Operator Inputs

A *BPS* division receives four Boolean signals from the operator. They will be obtained by each instance through an instantiation of standard contract *hsiDiv*.

```
external Boolean maintBtn;
external Boolean endMBtn;
external Boolean testBtn;
external Boolean resetBtn;
```

Guards

The following guards state that the operator will not place a demand to the *BPS* division in the 3 first seconds of an operational case, to give the time filtering scheme time to initialise.

```
guard g2 = until time = 3.*s check not maintBtn;
guard g3 = until time = 3.*s check not endMBtn;
guard g4 = until time = 3.*s check not testBtn;
guard g5 = until time = 3.*s check not resetBtn;
```

The operator can issue orders to the *BPS* division, but the *BPS* division should verify that these orders are valid:

- A maintenance request is valid if and only if it is made when the MPS is available and the BPS is not active (i.e., it is not providing power to any of its clients).
- A test request is valid if and only if it is made when the MPS is available, the BPS is not active and no maintenance is being performed.
- A reset request is valid if and only if it is made when the *MPS* is available, the *BPS* is active, and at least 10 minutes after the *BPS* has started to operate.

```
// For legibility
event eMaint = when maintBtn becomes true;
event endMaint = when endMBtn becomes true;
event eTest = when testBtn becomes true;
event eReset = when resetBtn becomes true;
// Defined later in the model
automaton state = (normal, maintenance, test);
event eBegins;  // When BPS becomes active
Boolean needed;  // Whether the BPS is needed
                   // Whether the BPS is needed
// Validating operator requests
event eVMaint =
  (during mpsAvailable and normal and not needed) and eMaint;
event eVTest =
  (during mpsAvailable and normal and not needed) and eTest;
event eVReset =
  (during mpsAvailable) and (after eBegins + 10*mn) and eReset;
```

3.11.3. Operational States

The three states introduced in Section 3.1.2 BPS States and the associated transition criteria are represented by an automaton named state, as shown in Figure 3-5:

- The initial state is the *normal* state. In that state, the *BPS* stands ready to perform, or is performing, its main mission, which is to provide electric power to its clients should the *MPS* become unavailable.
- In the *test* state, the *BPS* division acts as if the *MPS* had become unavailable. The difference with a loss of *MPS* in the *normal* state is that in the *test* state, the *BPS* division operates its critical components in the *protection* mode, whereas in the *normal* state, it operates them in the *workToDeath* mode.
- In the *maintenance* state, the *BPS* division must remain inactive, even when the *MPS* is or becomes unavailable.




Figure 3-5
The main states of the BPS, and the corresponding state transitions

```
automaton state = (normal, maintenance, test)
    start = normal;
    when normal and eVMaint then state = maintenance;
    when normal and eVTest then state = test;
    when maintenance and endMaint then state = normal;
    when test and (eMpsLoss or eVReset) then state = normal;
    else fixed;
    end state;
```

3.11.4. Fault-Tolerance

Some of the requirements of the *BPS* system specification express conditions like "*in the absence of any component failure*" or "*in the presence of at most a single sensor failure*". To that end, *BpsDivSpec* declares three sets of components:

- sensors is the set of all the sensors of the *BPS* division. Its precise membership is unknown to *BpsDivSpec*: the information will be obtained from the design.
- *nonSensors* is the set of all components of the *BPS* division that are not sensors. Like the previous set, its membership will be obtained from the design.
- *components* is the set of all the components of the *BPS* division. It is the union of the two previous sets.

```
external Component{} nonSensors;
external Component{} sensors;
Component{} components = nonSensors union sensors;
```

Some of the *BPS* system specification requirements concern critical components that should be protected during tests. To that end, *BpsDivSpec* declares the set of such components:

```
external ProtectedComponent() protectedComponents;
```

Accessibility : PUBLIC	



Condition "in the absence of any BPS component failure or in the presence of a single BPS sensor failure" is represented by a Boolean named tolerance:

```
Boolean tolerance =
  (cardinal {c in nonSensors suchThat c.failed} = 0) and
  (cardinal {c in sensors suchThat c.failed} \leq 1);
```

3.11.5.Alarms

When due to component failures the *BPS* division cannot perform its main mission, it must send a signal to the operators in the control room. This signal is represented by an event named *eAlarm*. Its precise instants of occurrence are to be obtained from the design and it is therefore declared external.

```
external event eAlarm;
```

3.11.6. Activity

When in *normal* state, the *BPS* division can either be in standby (it then just monitors the availability of the *MPS* and the operator requests) or be active (it then performs whatever is necessary to provide electric power to its clients).

Boolean *needed* specifies when the *BPS* division needs to be active.

```
Boolean needed =
   after
      (not maintenance and (eMpsLoss or eVTest))
      or (mpsUnavailable and endMaint)
   until eVReset;
```

Boolean active specifies when the BPS division is indeed active. As it is determined by design, it is declared external.

```
external Boolean active;
```

To enhance clarity, two derived events signal when the BPS becomes, or ceases to be, active.

```
event eBegins = when active becomes true;
```

3.11.7. Powering Clients

Whether a *BPS* division is configured to provide power to one of the six client divisions is represented by six Booleans. They are external since they will be determined by the design: the system specification expresses constraints on when they should become true.

```
external Boolean powering1a;
external Boolean powering2a;
external Boolean powering2b;
external Boolean powering3a;
external Boolean powering3a;
external Boolean powering3b;
```

3.11.8. Specification

Specification s1

s1: When the *BPS* division is under maintenance, it must not be activated.

This translates as:

```
requirement s1 = during maintenance check not active;
```

Specification s2a

s2a: In the absence of any *BPS* division component failure or in the presence of a single sensor failure, when the division is not in maintenance, and in case of loss of *MPS*, if *client1* is active:

Accessibility : PUBLIC	

- Its divisions must be powered within 25 seconds.
- Power must be provided until a valid reset from the operator.

Note. The grace times specified in the informal requirements specification for *s2a*, *s2b* and *s2c* include the time needed to confirm that the *mps* is indeed unavailable, which can take up to 3 seconds. Therefore, these grace times must be reduced by 3 seconds.

```
private property p2a =
   during (needed and clientlActive) trunc 22*s
   check powering1a and powering1b;

requirement s2a = during tolerance check not p2a.violated;
```

If *client1* is not active, it must not be powered.

```
private property p2A =
    during (needed and not clientlActive)
    check not (powering1a or powering1b);

requirement s2A = during tolerance check not p2A.violated;
```

Specification s2b

s2b: In the absence of any BPS division component failure or in the presence of a single sensor failure, when the division is not in maintenance, and in case of loss of *the MPS*:

- The divisions of *client2* must be powered within 35 seconds.
- Power must be provided until a valid reset from the operator.

```
private property p2b =
   during needed trunc 32*s
   check powering2a and powering2b;

requirement s2b = during tolerance check not p2b.violated;
```

Specification s2c

s2c: In the absence of any BPS division component failure or in the presence of a single sensor failure, when the division is not in maintenance, and in case of loss of *the MPS*:

- The divisions of *client3* must be powered within 45 seconds.
- Power must be provided until a valid reset from the operator.

```
private property p2c =
   during needed trunc 42*s
   check powering3a and powering3b;
requirement s2C = during tolerance check not p2C.violated;
```

Specification s3a

s3a: The probability of not powering one or more client divisions in the allocated time (due to *BPS* component failures) must be less than 10^{-3} per demand.

```
private property p3a =
  when (needed and client1.active) becomes true + 22.*s
  check powering1a and powering1b;

private property p3b =
  when needed becomes true + 32.*s
  check powering2a and powering2b;

private property p3c =
  when needed becomes true + 42.*s
```

```
check powering3a and powering3b;
requirement s3a = check probability
  ((p3a.violated or p3b.violated or p3c.violated) becomes true) < 10-3;</pre>
```

Specification s3b

s3b: The BPS division failure rate while it powers its clients must be less than what it would be if there was a constant failure rate of 10⁻³ per day.

```
requirement s3b = check probability
  ((p2a.violated or p2b.violated or p2c.violated) becomes true)
  < 1-exp(-10<sup>-3</sup> * duration(needed) /day);
```

Specification s4

s4: In the absence of any *BPS* division component failure or in the presence of a single sensor failure, the division must not be spuriously activated.

```
private property p4 = during not needed check not active;
requirement s4 = during tolerance check not p4.violated;
```

Specification s5

s5: The probability of spuriously activating the *BPS* division must be lower than what it would be if there were a constant occurrence rate of spurious activation equal to 10⁻³ per year.

```
requirement s5 = check probability (p4.violated becomes true)
< 1 - exp(-10<sup>-3</sup> * duration(not needed) / year);
```

Specification s6a

s6a: When the BPS division is active to mitigate a loss of the MPS, its protected components must be operated at any cost, even if this means damaging or eventually destroying them in the long run.

Here again, the 200 milliseconds give time for the BPS to react:

```
requirement s6a =
   during (normal and active) trunc 200*ms
   check AND{c.mode = workToDeath forAll c in protectedComponents};
```

Specification s6b

s6b: When the *BPS* division is operated for a periodic test, the risk of damaging its protected components must be minimised..

```
requirement s6b =
  during (test and active) trunc 200*ms
  check AND{c.mode = protection forAll c in protectedComponents};
```

Specification s7a

s7a: In the absence of any BPS division component failure or in the presence of a single sensor failure, when a valid Reset is issued by the operator, and if the MPS is not lost again, the normal condition for powering the client divisions (i.e., powered by the MPS) must be restored within 10 seconds.

normalPower is an intermediate Boolean defining normal power conditions, where all the clients are powered by the *MPS* and the *BPS* is not active:

```
private Boolean normalPower =
   mpsAvailable
    and (not active)
   and AND{d.powered forAll d in clientDivs};

requirement s7a =
   during tolerance and after eVReset + 10*s
   check normalPower;
```

Specification s7b

s7b: In the absence of any BPS component failure or in the presence of a single BPS sensor failure, when a valid Reset is issued by the operator, no client division should be unpowered for more than a total of 5 seconds after the *Reset*.

```
property p7b =
    after eVReset until normalPower
    check AND{inPDuration(not d.powered) < 5*s forAll d in clientDivs};

requirement s7b = during tolerance check not p7b.violated;</pre>
```

Specification s8

s8: The probability of not restoring the normal powering conditions for all the client divisions within 10 seconds after a valid Reset must be less than 10⁻³ per *BPS* demand.

```
requirement s8 =
   after eVReset within 10.*s
   check probability (p7a.violated becomes true) < 10<sup>-3</sup>;
```

Specification s9

psa: If any client cannot be powered as specified in s2 and s7, a failure signal should be sent in the control room to inform the operator.

```
property psa =
   after (
      ( s2a.violated
      or s2b.violated
      or s2c.violated
      or s7.violated) becomes true) within 200.*ms
   check once eAlarm;
```

s9 The probability of not sending a failure signal when required must be less than 10⁻³ per demand.

```
requirement s9 = check probability (psa.violated becomes true) < 10<sup>-3</sup>;
```

Specification s10

s10: That failure signal should not be raised spuriously. The rate of spurious failure signal must be less than what it would be if there was a constant failure rate of 10^{-2} per year.

```
property p10 =
   during not(
      ( s2a.violated
      or s2b.violated
      or s2c.violated
      or s7.violated) becomes true)
      check no eAlarm;
end BpsDivSpec;
```

3.12. The bpsSpec Object

This object models the *BPS* as two divisions (*bpsASpec* and *bpsBSpec*) and six switches, each connecting a client division to one and only one *BPS* division.

```
object bpsSpec
```

Contracts

By this contract declaration, the *bpsSpec* model acknowledges the contract that binds it to the *bpsReq* model: the *bpsReq* model is the reference model, and the *bpsSpec* model is a solution model.

```
contract spec;
```

ccessibility : PUBLIC
100000101111111111111111111111111111111

Switches

The six switches connecting the six client divisions to a *BPS* division are represented by a Boolean vector: when a switch is true, then the corresponding client division is connected to the *BPSa* division; else it is connected to the *BPSb* division. The normal situation is that *BPSa* services one division of each client, and *BPSb* the other division. When one *BPS* division is set in maintenance mode, then the client divisions it normally services are switched to the other *BPS* division. They are retunned to it when it is no longer in maintenance.

```
Boolean[6] switch
    start[1, 3, 5] = true;
    start[2, 4, 6] = false;
    when bpsASpec.maintenance becomes true then switch[1, 3, 5] = false;
    when bpsASpec.maintenance becomes false then switch[1, 3, 5] = true;
    when bpsBSpec.maintenance becomes true then switch[2, 4, 6] = true;
    when bpsASpec.maintenance becomes false then switch[2, 4, 6] = false;
    else fixed;
    end switch;
```

BPS Divisions

```
BpsDivSpec bpsASpec
    contract hsiA;
    contract odsA;

voltage = bpsSpec.voltage;
    active =
        (if switch[1] then clientla.active else false) or
        (if switch[2] then clientlb.active else false);
    end bpsASpec;

BpsDivSpec bpsBSpec
    contract hsiB;
    contract odsB;

voltage = bpsSpec.voltage;
    active =
        (if switch[1] then false else clientla.active) or
        (if switch[2] then false else clientlb.active);
    end bpsBSpec;
```

Deliverables to bpsReq

The *bpsReq* model expects 4 deliverables from any solution model: the three powering Booleans and the *eAlarm* event. The following consolidates the powering determinations made separately by *bpsASpec* and *bpsBSpec* concerning the client divisions they service.

```
Boolean powering1a = // whether division a of client 1 is powered by BPS
   if switch[1] then bpsASpec.powering1a else bpsBSpec.powering1a;
Boolean powering1b = // whether division b of client 1 is powered by BPS
   if switch[2] then bpsASpec.powering1b else bpsBSpec.powering1b;
Boolean powering1 = // client 1 is powered if any of its division is
   powering1a or powering1b;

Boolean powering2a =
   if switch[3] then bpsASpec.powering2a else bpsBSpec.powering2a;
Boolean powering2b =
   if switch[4] then bpsASpec.powering2b else bpsBSpec.powering2b;
Boolean powering2 =
   powering2a or powering2b;

Boolean powering3a =
   if switch[5] then bpsASpec.powering3a else bpsBSpec.powering3a;
Boolean powering3b =
```

```
if switch[6] then bpsASpec.powering3b else bpsBSpec.powering3b;
Boolean powering3 =
   powering3a or powering3b;

// An alarm is signalled if any of the BPS divisions detects a failure
event eAlarm = bpsASpec.eAlarm or bpsBSpec.eAlarm;
end bpsSpec;
```

3.13. The spec Contract

The BPS system specification is modelled as a contract named spec between bpsReq and bpsSpec. Here, the contract just declares the mutual deliverables and the requirements that bpsSpec guarantees to bpsReq: the definitions are provided by the bpsSpec model. Specifications 6a and 6b are not listed, because the are not required by bpsReq but have been added by bpsSpec. For a configuration where bpsReq is declared as a reference model and bpsSpec as a solution model, a test case generator will consider bpsSpec's requirements as assumptions to emulate an implementation consistent with the model.

```
contract spec
  party bpsReq
    Voltage voltage;
                                    // at the terminals of the mps
    end bpsReq;
  party bpsSpec
    // Deliverables
    Boolean powering1;
    Boolean powering2;
    Boolean powering3;
    event eAlarm;
    // Guarantees
    requirement bpsASpec.s1;
    requirement bpsBSpec.s1;
    requirement bpsASpec.s2a;
    requirement bpsBSpec.s2a;
    requirement bpsASpec.s2A;
    requirement bpsBSpec.s2A;
    requirement bpsASpec.s2b;
    requirement bpsBSpec.s2b;
    requirement bpsASpec.s2c;
    requirement bpsBSpec.s2c;
    requirement bpsASpec.s3a;
    requirement bpsBSpec.s3a;
    requirement bpsASpec.s3b;
    requirement bpsBSpec.s3b;
    requirement bpsASpec.s4;
    requirement bpsBSpec.s4;
    requirement bpsASpec.s5;
    requirement bpsBSpec.s5;
    requirement bpsASpec.s7a;
    requirement bpsBSpec.s7a;
    requirement bpsASpec.s7b;
    requirement bpsBSpec.s7b;
    requirement bpsASpec.s8;
    requirement bpsBSpec.s8;
    requirement bpsASpec.s9;
    requirement bpsBSpec.s9;
     requirement bpsASpec.s10;
```

```
requirement bpsBSpec.s10;
end bpsSpec;
end spec;
```

4. BPS Overall Design

4.1. Brief Introduction to the Overall Design

The Overall Design:

- Identifies the main components of a BPS division.
- Specifies the interactions between these components.
- States the assumptions made regarding the behaviour of each component.

Diesel Generator DG

As the level of power required by the clients is in the megawatts range and the duration of the backing-up could last up to several days, a *BPS* division is based on a Diesel Generator, or *DG*. This generator has a number of constraints. In particular, if all clients divisions were connected simultaneously, it would be overloaded and stall. In addition, when electric power is restored to a given component, there is an important, transient call for current and power (see Figure 4-1). Thus, much like a conventional car engine needs a gearbox, the *BPS* division and its *DG* need an active control system to ensure a progressive and orderly increase of requested power (hence the presence of circuit breakers).




Figure 4-1
Transient call for current when electric power is supplied to an electric component.

Other BPS Components

Figure 4-2 presents the overall design of a *BPS* division and its main components. It introduces a number of design decisions compared with Figure 3-1. In particular:

- The *DG* is the only protected component.
- Each client division has a circuit breaker named *brki*, where i = 1a, 1b, 1c, 2a, 2b and 2c. It can isolate the client division from the *Backed-Up Electric Panel*.
- The breakers are controlled by a digital control system called the *Load Sequencer*, or *LS*. Its role is to send control signals to the *DG* and the various circuit breakers, based on information provided by the sensors and the human operators. It also sends a failure signal to the operators when necessary.
- The MPS has a circuit breaker named brkMps. The breaker is controlled by the LS and can isolate the MPS from the Backed-Up Electric Panel.
- The *DG* has a circuit breaker named *brkDg*. The breaker is controlled by the *LS* and can isolate the *DG* from the *Backed-Up Electric Panel*.
- In addition to the circuit breakers of the *BPS* division, the two divisions of *client1* have each a second circuit breaker named respectively *brk1* and *brk2* that are controlled by *client1* itself. They are closed when *client1* is active, independently of the *BPS*.
- Sensors have been added. In Figure 4-2, they are represented as circles. All provide Boolean outputs:

Accessibility : PUBLIC	

Page 32 of 57

- *nbV1* and *nbV2* are two redundant voltmeters that determine whether the tension at the terminals of the *Non-Backed-Up Electric Panel* is *on* or *off*.
- *bV1* and *bV2* are two redundant voltmeters that determine whether the tension at the terminals of the *Backed-Up Electric Panel* is *on* or *off*.
- dgV1 and dgV2 are two redundant voltmeters that determine whether the tension at the terminals
 of the DG is on or off.
- *dgF1* and *dgF2* are two redundant frequency meters that determine whether the current frequency at the terminals of the *DG* is appropriate or not.
- mpsPos1 and mpsPos2 are two redundant position sensors signalling the open / close position of the MPS breaker.
- dgPos1 and dgPos2 are two redundant position sensors signalling the open / close position of the DG breaker.
- brk1Pos is a position sensor signalling the open / close position of the brk1 breaker.
- *brk2Pos* is a position sensor signalling the *open / close* position of the *brk2* breaker.




Figure 4-2 Overall Design of a BPS division.

Note. This overall design may not comply with all the system requirements and the system specification specified in Sections 2 *BPS System Requirements* and 3 *BPS System Specification*. Indeed, it is very likely that it does not comply with some of the fault tolerance requirements. It will be up to the verification to identify discrepancies, and to the engineering team to decide whether it is the requirements, the specification or the design that needs to be amended, possibly on the basis of a cost-benefit analysis.

Overall Design Assumptions

The Overall Design presented here "allocates" the system specification of Section 4 to the identified components. This is done in the form of requirements specified for each component. However, at that stage, the choices of products to be used for the components are not made yet: this will be decided by the Detailed Design. Therefore, the precise characteristics of these components (such as the start-up time of the *DG*, the accuracy and response time of sensors, the response time of breakers) are not known yet.



The following pattern is used to model these requirements and unknowns:


4.2. Modelling Organisation of the Overall Design

Following the decision made in the previous Section, the overall design of the BPS is composed of two identical divisions. Since the relationships between these divisions and the complete BPS have already been specified and modelled in the previous Section, the overall design (*ODS*) presented here concerns a single BPS division. It is mainly organised into class definitions, and Figure 4-4 shows their extension hierarchy) that are intantiated for each of the divisions. Figure 4-3 shows the main objects modelling the overall design:


- Classes Component and ProtectedComponent (an extension of Component) have already been introduced.
- Class Breaker, an extension of Component, models the electric circuit breakers.
- Class *MSensor*, an extension of *Component*, models the measurement sensors, and is itself extended by classes *Voltmeter* and *FreqMeter*.
- Class *PSensor*, an extension of *Component*, models the sensors informing on the open / close position of electric circuit breakers.
- Class *Dg*, an extension of *ProtectedComponent*, models the diesel generator that produces backup electricity for the *BPS* division.
- Class Ls models the synchronous, digital control system that orchestrates the actions of the BPS division.
- Class *BpsDivOds* models the overall design of a *BPS* division, based on the preceding classes.Olt has two instances: *bpsAOds* and *bpsBOds*.
- Standard contract *Ods* models the mutual obligations between an instance of *BpsDivSpec* (which models the specification of a *BPS* division) and the corresponding instance of *BpsDivOds*. It is instantiated into *odsA* (between *bpsASpec* and *bpsAOds*) and *odsB* (between *bpsBSpec* and *bpsBOds*).
- Class Step models additional information regarding a client division. Indeed, each client is itself in
 a parallel design process to the BPS, and new information is made available at each step. The six
 client divisions are modelled as a single Step vector named step and shared by the two BPS
 divisions.

Note. A client division is called a *step*, due to the fact that a *BPS* division will address them sequentially.





The two objects bpsAOds and bpsBOds model the overall design of the BPS disivsions. Object step models the clients divisions from the point of view of the overall design of the BPS.



Extension hierarchy of the classes used in the overall design of a BPS division.

```
configuration BPS ODS
   // For System Requirements
   . . .
  // For System Specifications
  // For System Overall Design
                                      alias Step;
   class "*Step*"
                 "*Breaker*"
"*MSensor*"
  class
                                      alias Breaker;
  class
                                      alias MSensor;
                 "*Voltmeter*" alias Voltmeter;
"*FreqMeter*" alias FreqMeter;
"*PSensor*" alias PSensor;
"*Dg*" alias Dg;
"*Ls*" alias Ls;
  class
  class
                  "*BpsDivOds*" alias BpsDivOds;
  property mode "*BpsOds*" alias BpsO
contract "*Ods*" alias Ods;
                                      alias BpsOds;
                  odsA = Ods(bpsASpec, bpsAOds);
  contract
  contract ods = Ods (bpsBSpec, bpsBOds);
  end BPS SPEC;
```

4.3. The Breaker Class

```
class Breaker extends Component
```

A BPS circuit breaker can receive two Boolean signals, one to open (openCmd) and one to close (closeCmd).

```
Boolean openCmd;
Boolean closeCmd;
```

Opening starts when *openCmd* becomes true. This is represented by event *eOpenCmd*. Closing starts when *closeCmd* becomes true. This is represented by event *eCloseCmd*.

```
event eOpenCmd = when openCmd becomes true;
event eCloseCmd = when closeCmd becomes true;
```

The open / close signals are in fact issued by the LS. It is assumed that there are no contradictions:

```
assumption noContradiction = no (eOpenCmd and eCloseCmd);
```

A real circuit breaker cannot open or close instantly. The maximum delay for a given breaker (realTMax) depends on the specific product that will be chosen. That choice is made by detailed design and is not known yet at the time of overall design. The overall design just puts an upper bound value (tMax) for realTMax. That value is not necessarily the same for all the BPS breakers.

The two following events represent the real instants when the breaker finishes opening or closing. They are to be provided by the detailed design behavioural model and are therefore declared external:

```
external event eOpeningCompleted;
external event eClosingCompleted;
```

A circuit breaker can be in one of four states: *open*, *closed*, *opening* and *closing*. This is represented by automaton *state*. The initial state depends on the instance: therefore, it is declared **specific**:

```
automaton state = (open, closed, opening, closing)
start = specific;
```

A A A A A SHEET WAY A POINT OF THE PARTY OF	
ccessibility : PUBLIC	
100000101111111111111111111111111111111	



```
when state ≠ open and eOpenCmd then opening;
when eOpeningCompleted then open;
when state ≠ closed and eCloseCmd then closing;
when eClosingCompleted then closed;
else fixed;
end state;
```

The purpose of the following is to state formally the meaning of *tMax*: after an open / close order (events *eOpenCmd* / *eCloseCmd*), the breaker will complete the action (events *eOpeningCompleted* / *eClosingCompleted*) within a *tMax* delay, provided that in the meantime it does not receive a counter command:

```
requirement openInTime =
   after eOpenCmd within tMax check eOpeningCompleted or eCloseCmd;
requirement closeInTime =
   after eCloseCmd within tMax check eClosingCompleted or eOpenCmd;
end Breaker;
```

4.4. The MSensor Class

This class represents the measurement sensors (voltmeters and frequency meters) used in the *BPS* division overall design. It is later extended by classes *Voltmeter* and *FreqMeter*.

```
partial class MSensor extends Component
```

input is the true analog signal to be measured. It will be provided by a behavioural or stimulation model.

```
external Real input;
```

on is the output of the sensor. It is a Boolean signal stating the on / off state of the *input*. It will also be provided by the behavioural or stimulation model.

```
external Boolean on;
```

IB1, *IB2*, *uB1* and *uB2* determine whether the output *on* must be true or not (see Figure 4-5). They are declared but their values will be specified by *Voltmeter* and *FregMeter*.

```
constant Real lB1;
constant Real uB1;
constant Real uB2;
requirement consistency = (lB1 < lB2) and (lB2 < uB1) and (uB1 < uB2);

check no on becomes true

check no on becomes false

check on = false

lB1 lB2 uB1 uB2 input</pre>
```

Figure 4-5
Constraints on output value

Measurement sensors need a time delay to adjust the output to the input. The real duration of that delay (realTMax) is declared external and will be provided by the detailed design model. The overall design just specifies an upper bound (tMax). This upper bound is specific to each type of MSensor and will be specified in the extension models:

Accessibility: PUBLIC



Measurement sensors have also a limited accuracy. However, this is taken into account in the determination of *IB1*, *IB2*, *uB1* and *uB2* and does not need to appear explicitly in the model.

Finally, the following specifies the overall design requirements regarding the output of the sensor:

```
requirement r1 = during input > uB2 trunc tMax check on;
requirement r2 = during input < 1B1 trunc tMax check not on;;
requirement r3 = during input > 1B2 trunc tMax check no on becomes false;
requirement r4 = during input < uB1 trunc tMax check no on becomes true;
end MSensor;</pre>
```

4.5. The Voltmeter Class

All the voltmeters have the same features:

4.6. The FreqMeter Class

All the frequency meters have the same features:

```
class FreqMeter extends MSensor

1B1 = 47*hz; 1B2 = 48*hz;
uB1 = 48*hz; uB2 = 49*hz;
tMax = 100*ms;  // Assumed by ODS
end FreqMeter;
```

4.7. The PSensor Class

```
class PSensor extends Component
```

brk is the circuit breaker associated with the position sensor: i.e., the sensor determines the open/close state of brk. It is specific since each position sensor is associated to a specific breaker:

```
specific associated Breaker brk;
```

open is the output of the sensor. It is a Boolean signal stating the Open / Close state of *brk*. It is declared external because it will be provided by the behavioural model of the detailed design:

```
external Boolean open;
```

Position sensors need a time delay to adjust the output to the input. The real duration of that delay (*realTMax*) is declared external and will be provided by the detailed design model. The overall design just specifies an upper bound (*tMax*):

Finally, the following specifies the overall design requirements regarding the output of the sensor:

```
requirement r1 = during brk.state.closed trunc tMax check not open;
requirement r2 = during brk.state.open trunc tMax check open;
```

Accessibility : PUBLIC	



end PSensor;

4.8. The Step Class

In the same way as the overall design of the BPS has added new information on the BPS, the overall design of the clients have added information on each client, in particular regarding the electric power required by each client division. In addition, the BPS overall design has assigned them a priority order: when required and allowed, the highest priority client division is reloaded first.

Class

```
class Step
```

Each *step* embeds a circuit breaker named *brk* that is used for shedding (disconnection from the Backed-Up Electric Panel) or reloading (reconnection to the Backed-Up Electric Panel) as illustrated by Figure 4-1. The shedding and reloading orders are issued by the *LS*. The *LS* has a unique Boolean signal to shed all the *Steps* (*Is.shedAll*), but it has a specific Boolean signal to reload each individual *step*. Therefore, the reloading signal (*reload*) is declared as specific.

Events *eShed* and *eReload* mark the instants when the *LS* orders the *step* to open or close its breaker. The events occur when the signals become true:

```
event eShed = when LS.shedAll becomes true;
event eReload = when reload becomes true;
```

The LS property model requires that shedding and reloading signals do not become true at the same instant, but nonetheless, the *Step* class also states a requirement to this end:

```
requirement noContradiction = no (eShed and eReload);
```

A *step* may be required or not (*step1a* and *step1b* are required when and only when *client1* is active; the other *steps* are always required). The corresponding condition will be specified separately for each instance:

```
specific Boolean required;
```

For a step to be powered, several conditions need to be satisfied:

- Its breaker must be closed (brk.closed).
- To be powered by the MPS, the MPS must be available (MPS.available) and its own breaker must be closed (brkMps.closed).
- To be powered by the *BPS*, the *DG* must be ready (*DG.ready*) and its own breaker must be closed (*brkDg.closed*).

```
Boolean powered =
    brk.closed and
    ((MPS.available and brkMps.closed) or (DG.ready and brkDg.closed));

Boolean poweredByBPS = brk.closed and DG.ready and brkDg.closed;
```

The demand of a *step* for *BPS* electric power is a function of time (see Figure 4-6). The effective demand is represented by a Real function named *demand*. It will be provided at a later stage by a behavioural model. For overall design verification purposes, one just puts constraints on this demand:

- When the step is not active, the demand is null.

- TURE DURING

Accessibility : PUBLIC	
------------------------	--

- When it is just reloaded, it generates a spike demand that could last up to, but no more than, a given duration (settleTime) and that could rise up to, but no more than, a given value (initialDemand).
- After settleTime, the demand is at most stabilisedDemand.

initialDemand, settleTime and stabilisedDemand are specific to each step:

```
external Real demand;
                                              // Demand for power
assumption a1 = demand \geq 0.*w;
specific constant Real initialDemand;
assumption a2 = initialDemand > 0.*w;
specific constant Real stabilisedDemand;
assumption a3 = stabilisedDemand > 0.*w;
assumption a4 = stabilisedDemand < initialDemand;</pre>
constant Duration maxSettleTime = 4.*s;
                                             // Assumed by ODS
constant specific Duration settleTime;
assumption a5 = settleTime > 0.*s;
assumption a6 = settleTime ≤ maxSettleTime;
Real demandToBPS
  during poweredByBPS then demand;
  else 0.*w;
  end demandToBPS;
assumption a7 =
  after poweredByBPS becomes true for maxSettleTime
  check demand ≤ initialDemand;
assumption a8 =
  during poweredByBPS trunc maxSettleTime
  check demand ≤ stabilisedDemand;
end Step;
                                Settle
                                 Time
                           Initial
                         Demand
                                                Stabilised
                                    Powered
                                                Demand
                                  Figure 4-6
                   Assumptions on the demand for power of a step
```

Instances

The 9 *steps* are declared as a single 9 element vector. The priority order is given by the order in the vector, the first element having the highest priority.

```
Step step[6]
  step[1, 2].required = client1.active;
  step[3, 4].required = client2.active;
  step[5, 6].required = client3.active;
  step[1..6].initialDemand = 500.*kw;
  step[1..6].settleTime = 4.*s;
  step[1..6].stabilisedDemand = 70.*kw;
  step[1].Reload = ls.reload1;
```



```
step[2].Reload = ls.reload2;
step[3].Reload = ls.reload3;
step[4].Reload = ls.reload4;
step[5].Reload = ls.reload5;
step[6].Reload = ls.reload6;
end step;
```

4.9. The DG (Diesel Generator) Class

```
class dg extends ProtectedComponent
```

Start, Stop, Ready, Stall

The DG receives two Boolean start / stop signals from the LS:

- When Is.startDg becomes true, the engine starts. This is represented by event eStart.
- When Is.stopDg becomes true, the engine stops. This is represented by event eStop.

```
event eStart = when ls.startDG becomes true;
event eStop = when ls.stopDG becomes true;
```

The *ls* model requires that both signals do not become true at the same instant, but nonetheless, the *dg* model also states a requirement to this end (just in case):

```
requirement noContradiction = no (eStart and eStop);
```

The *LS* assesses the readiness of the *DG* to provide power to the required *steps*, based on the voltmeters and the frequency meters at the *DG* terminals. This assessment is represented by the *Is.eDgReady* event. This event is internal to the *Is* model: i.e., it is not one of the output signals of the *LS*. Therefore, it cannot be used to trigger actual, physical action on any *BPS* component: it can be used only for verification. Event *eReady* marks the instant when the *LS* considers the *DG* to be ready:

```
event eReady = ls.eDgReady;
```

When the DG is overloaded, it can stall. This is represented by an external event that will be signalled by the behavioural model:

```
external event eStall;
```

DG States

The *DG* can be in one of three states:

- In state stopped, it does not function at all. This is the initial state.
- In state *starting*, it is functioning, but the tension and frequency at its terminals are not yet appropriate.
- In state ready, it is functioning and fully operational.

The state transitions are triggered by events eStart, eReady, eStop and eStall.

```
automaton state = (stopped, starting, ready)
    start = stopped;
    when stopped and eStart then starting;
    when eReady then ready;
    when eStop or eStall then stopped;
    else fixed;
    end State;
```

When the *DG* is not ready, its breaker must be open:

```
requirement brkOpen = during not ready check brkDg.open;
```

Accessibility : PUBLIC	

Startup Time

When the *DG* is ordered to start, it needs a certain time to get ready and to provide the right tension and frequency at its terminals. Since at the time of overall design no actual product has been chosen yet for the *DG*, the maximum delay *realTMax* is still unknown. The overall design just puts an upper bound *tMax* on this value. The purpose of the following is to declare the value of *tMax* and to ensure that the *realTmax* of the chosen product will be less than *tMax*:

```
constant Duration tMax = 5.*s;  // Value assumed by ODS
external constant Duration realTMax; // From detailed design
assumption a1 = realTMax > 0.*s;
assumption a2 = realTmax ≤ tMax;
```

The meaning of *tMax* is as follows: after a start order (event *eStart*), the *DG* will be ready (event *eReady*) within a *tMax* delay, provided that in the meantime it does not receive a stop order (event *eStop*):

```
requirement r1 = after eStart within tMax check (eReady or eStop);
```

Electric Load

The *load* of the *DG* is a Real function that is the sum of the demands for power from the 6 *Step*s. When the *DG* is stopped or its breaker is open, its load is null:

```
Real load
  during ((starting or ready) and brkDg.closed)
    then SUM {s.demandToBPS forAll s in step};
  else 0.*w;
  end load;
```

The *DG* has a maximum load *realMaxLoad* beyond which it may stall (event *eStall*) and cease to provide power. Since this value is still unknown, a lower bound *maxLoad* is assumed:

```
constant Power maxLoad = 1200.*kw;  // Value assumed by ODS
external constant Power realMaxLoad;
assumption a3 = realMaxLoad ≥ maxLoad;
assumption a4 = during load ≤ maxLoad check no eStall;
```

The overall design requires that the DG shall never be used at more than 80% of the maximum load:

```
requirement r2 = load ≤ 0.80 * maxLoad;
```

DG Mode

As specified by the *mode* automaton inherited from *ProtectedComponent*, the *DG* can run on one of two modes: *protection* or *workToDeath*. It switches between the two based on Boolean signal *dgProtect* sent by the *LS*: when the signal is true, the *DG* runs in the *protection* mode; otherwise, the *DG* runs in the *workToDeath* mode. The following provides a closed definition for the automaton:

```
automaton mode = (workToDeath, protection)
start = workToDeath;
when workToDeath and (ls.dgProtect becomes true) then protection;
when protection and (ls.dgProtect becomes false) then workToDeath;
else fixed;
end mode;
```

When the *DG* is not required to operate, its breaker MUST be opened when the Backed-Up Panel is powered by the *MPS*, otherwise the *DG* could be damaged or destroyed.

```
requirement r3 =
   during mpsAvailable and brkMps.closed check brkDg.open;
end dg;
```

Accessibility: Po	BLIC
-------------------	------

TOTAL DISTRICT

4.10. The Ls (Load Sequencer) Class

The *LS* is a digital control system in charge of monitoring the *BPS* division sensors, of receiving events issued by the operator, and of sending control signals to the other *BPS* division components (*DG*, circuit breakers).

class Ls

4.10.1.Time Domain

The *LS* is a synchronous digital control system that has its own discrete time domain named *tdLS*: the *LS* is the only object in that time domain. The time domain is periodic, with a period of 50 milliseconds. Its phase is random (see Figure 4-7).

```
in timeDomain tdLs
  constant Duration cycleTime = 50.*ms;
  private fixed Duration phase = random (CycleTime);
  clock = (every CycleTime) + phase;
  end tdLs;

Phase

Cycle

Time

Figure 4-7

The tdLs time domain
```

4.10.2.Main States

The main *LS* state automaton is shown in Figure 4-8.




Figure 4-8

The LS main state automata

It is composed of three states:

- In the *operational* state, the *LS* is ready to perform, or is performing, its mission. This state is the initial state and is the Cartesian product of two sub-automata: *sequence* and *mode*:
 - The sequence sub-automaton indicates at which sequencing stage the LS is. It is composed of three sub-states:
 - In standby, no action is necessary yet, but the LS is ready to act.
 - In active, sequencing is being performed so that the required steps are powered by the DG.
 - In *finished*, all *steps* are powered by the *DG* and the *LS* waits for a valid reset signal to restore normal power conditions where the *steps* are powered by the *MPS*.
 - The *mode* sub-automaton is composed of two sub-states (*normal* and *test*) indicating in which operating mode (respectively *workToDeath* and *protection*) the *LS* should run the *DG* when it is needed. If the *MPS* becomes unavailable during a test, the *LS* continues sequencing, but the operating mode of the *DG* is switched to *worktoDeath*.
- The maintenance state of the LS corresponds to the maintenance state of the BPS division.
- The *failure* state is taken when the *LS* detects a failure preventing the *BPS* division from performing its mission.

This is modelled as follows:

```
automaton sequence = (standby, active, finished);
automaton mode = (normal, test);
automaton state = (operational = sequence & mode, maintenance, failure)
start = operational(standby, normal);
// State transitions will be specified in a scattered manner
// throughout the Ls class
end state;
```

4.10.3.Inputs

All the inputs and outputs of the *LS* are Boolean signals. As seen in previous sections, it is the role of the sensors to convert analog tension or frequency signals into Boolean signals.

One needs to remember that the LS is in its own discrete time domain and that all the inputs are issued from the continuous time domain. Therefore, the continuous input signals are "sampled" and transformed by the LS prior to any utilisation, based on the following pattern:

```
//Boolean lsName = clock and inputName;
```

In principle, it should not be necessary to explicitly state these interfaces, since a FORM-L compiler would be able to do it automatically. However, it is done so here, just in case. The input signals and their *LS* translations are:

Input Name	LS Name	Description
bV1.on bV2.on	bV1 bV2	Redundant on / off signals for the tension at the terminals of the Backed-Up Panel
nbV1.on nbV2.on	nbV1 nbV2	Redundant on / off signals for the tension at the terminals of the Non-Backed-Up Panel
dgV1.on dgV2.on	dgV1 dgV2	Redundant on / off signals for the tension at the terminals of the <i>DG</i>
dgF1.on, dgF2.on	dgF1 dgF2	Redundant on / off signals for the frequency at the terminals of the <i>DG</i>



brk1MpsPos.open brk2MpsPos.open	brkMps1Open brkMps2Open	Redundant open / closed signals for the position of the MPS circuit breaker
brk1DgPos.open brk2DgPos.open	brkDg1Open brkDg2Open	Redundant open / closed signals for the position of the <i>DG</i> circuit breaker
brk1Pos.open	brk1Open	open / closed signal position for the specific breaker of step[1]
brk2Pos.open	brk2Open	open / closed signal position for the specific circuit breaker of step[2]
maintBtn	maint	Operator request for maintenance
endMaintBtn	endMaint	Operator signal informing the LS of the end of maintenance
testBtn	pTest	Operator request for a periodic test
resetBtn	reset	Operator request to reset the BPS

```
Boolean bV1 = clock and bV1.on;
Boolean bV2 = clock and bV2.on;
Boolean nbV1 = clock and nbV1.on;
Boolean nbV2 = clock and nbV2.on;
Boolean dgV1 = clock and dgV1.on;
Boolean dgV2 = clock and dgV2.on;
Boolean dgF1 = clock and dgF2.on;
Boolean brk1MpsOpen = clock and brk1MpsPos.open;
Boolean brk2MpsOpen = clock and brk2MpsPos.open;
Boolean brk1DgOpen = clock and brk1DgPos.open;
Boolean brk2DgOpen = clock and brk2DgPos.open;
Boolean brk2Open = clock and brk1Pos.open;
Boolean brk2Open = clock and brk2Pos.open;
Boolean brk2Open = clock and brk2Pos.open;
Boolean brk2Open = clock and brk2Pos.open;
Boolean maint = clock and maintBtn;
Boolean pTest = clock and resetBtn;
Boolean reset = clock and resetBtn;
```

4.10.4.Outputs

The outputs of the *LS* are modelled as Boolean signals to reflect the effective interfaces of the actual system. Initially, all are set to **false**. They are:

dgProtect	Sets the DG mode of operation (true: protection; false: workToDeath)
startDG	Starts the DG when it becomes true
stopDG	Stops the DG when it becomes true
openBrkMps	Opens the MPS breaker when it becomes true
closeBrkMps	Closes the MPS breaker when it becomes true
openBrkDg	Opens the DG breaker when it becomes true
closeBrkDg	Closes the DG breaker when it becomes true
shedAll	Sheds all the steps when it becomes true
reload1	Reloads step1 when it becomes true

Accessibility : PUBLIC	

reload2	Reloads step2 when it becomes true
reload3	Reloads step3 when it becomes true
reload4	Reloads step4 when it becomes true
reload5	Reloads step5 when it becomes true
reload6	Reloads step6 when it becomes true
failure	When true, informs the human operators that the main <i>BPS</i> mission has failed

The first output signal is solely under the control of the *mode* automaton. It is completely defined (i.e., in a closed manner) as follows:

```
Boolean dgProtect
    start = false;
    when state becomes operational(current, normal) then false;
    when state becomes operational(current, test) then true;
    else fixed;
    end dgProtect;
```

Note that no delay is specified here, since the *mode* state transitions are already delayed by one clock tick of the *LS* discrete time domain.

The other outputs are under the control of the *sequence* automaton. They all start as false, and reset to false when the automaton enters the *Standby* state (note again that no delay is specified here, since the *sequence* state transitions are also already delayed by 1 clock tick of the *LS* discrete time domain). All except the reload signals are defined in a closed manner and are associated with an event: they are set to true one clock tick after their associated event is raised. The reload signals have an open definition: in particular, they will be directly set to true in the course of the reloading sequence (see Section 4.10.6 *State Transitions and Actions*) without the need for an associated event.

```
event eStartDg;
Boolean startDq
  start = false;
  when eStartDg + clock(1) then true;
  when state becomes operational(standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end startDg;
event eStopDq;
Boolean stopDq
  start = false:
  when eStopDg + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed:
  end StopDg;
event eOpenBrkMps;
Boolean openBrkMps
  start = false;
  when eOpenBrkMps + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end openBrkMps;
event eCloseBrkMps;
```



Page 46 of 57

```
Boolean closeBrkMps
  start = false;
  when eCloseBrkMps + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end closeBrkMps;
event eOpenBrkDg;
Boolean openBrkDg
  start = false;
  when eOpenBrkDg + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end openBrkDg;
event eCloseBrkDg;
Boolean closeBrkDg
  start = false;
  when eCloseBrkDg + clock(1) then true;
  when state becomes operational(standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end closeBrkDq;
event eShedAll:
Boolean shedAll
  start = false:
  when eShedAll + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed:
  end shedAll;
Boolean reload1
  start = false;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  end reload1;
Boolean reload2
  start = false;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  end reload2;
Boolean reload3
  start = false;
  when state becomes operational(standby, current) then false;
  when state becomes maintenance then false;
  end reload3;
Boolean reload4
  start = false;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  end reload4;
Boolean reload5
  start = false;
  when state becomes operational (standby, current) then false;
```



```
when state becomes maintenance then false;
  end reload5;
Boolean reload6
  start = false;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  end reload6;
event eFailure;
Boolean failure
  start = false;
  when eFailure + clock(1) then true;
  when state becomes operational (standby, current) then false;
  when state becomes maintenance then false;
  else fixed;
  end failure;
Boolean {} sequencingOutputs = {
  startDg, stopDg,
  openBrkMps, closeBrkMps,
  openBrkDg, closeBrkDg,
  shedAll,
  reload1, reload2, reload3, reload4, reload5, reload6,
  failure };
```

4.10.5.Main Events and Conditions

The 18 inputs signals of the LS are not all independent from one another. For the LS, they can be compounded and abstracted into 9 main events and conditions that will be used later on to complete the requirements specification:

Name	Туре	Description
eMaint	event	Start a maintenance session
eEndMaint	event	End an on-going maintenance session
eTest	event	Start a periodic test
client1Active	Boolean	Client1 is active
eBrkMpsOpen	event	MPS breaker is open
eBrkDgClosed	event	DG breaker is closed
eMpsLoss	event	Loss of MPS
eDgReady	event	DG is ready
eVReset	event	Valid reset to restore normal power conditions

Some of these events and conditions have been defined in the other property models.

Also, some features declared external by other property models are defined by the LS.

Start a Maintenance Session

End an On-going Maintenance Session

Start a Periodic Test

The start maintenance, end maintenance and test signals issued by the operator:

```
event eMaint = when maint becomes true;
```

Accessibility : PUBLIC	



```
D8.1.3 - Part I
MODRIO (ITEA 2 - 11004)
```

Page 48 of 57

```
event eEndMaint = when endMaint becomes true;
event eTest = when pTest becomes true;
```

Client1 is Active

The information is provided by the sensors monitoring the positions of the specific breakers of the two client1 divisions (brk1 and brk2); client1 is considered to be active when either of the specific breakers is closed.

```
condition client1Active = when (not brk1Open) or (not brk2Open);
```

MPS Breaker is Open

The LS determines the position of the MPS breaker based on the inputs from the two redundant position sensors:

```
Boolean brkMpsOpen = brk1MpsOpen or brk2MpsOpen
Boolean brkMpsClosed = not brkMpsOpen;
event eBrkMpsOpen = when brkMpsOpen becomes true;
event eBrkMpsClosed = when brkMpsOpen becomes false;
```

DG Breaker is Closed

The LS also determines the position of the DG breaker based on the inputs from two redundant position sensors, but with a different logic:

```
Boolean brkDgOpen = brk1DgOpen or brk2DgOpen
Boolean brkDgClosed = not brkDgOpen;
event eBrkDgOpen = when brkDgOpen becomes true;
event eBrkDgClosed = when brkDgOpen becomes false;
```

MPS On I Off

The LS can make a decision regarding the on / off state and the Availability of the MPS based on the inputs from the four voltmeters at the Backed-Up and Non-Backed-Up Panels terminals.

A significant part of the on / off decision is made by the voltmeters. (Indeed, had there been only one voltmeter, the complete decision would have been made by that voltmeter.) One role of the LS on that issue is to decide when to rely on the voltmeters of the Backed-Up Panel (bV1 and bV2), and when to rely on those of the Non-Backed-Up Panel (nbV1 and nbV2). Normally, it relies on the first pair. However, if the MPS breaker is open (during a test), these voltmeters are disconnected from the MPS and the LS will then need to rely on the second pair.

Another role of the LS is to manage redundancy. When it uses the first pair (which is most of the time), it is preferable not to fail to activate the BPS when it is needed. Thus, any one of the pair must be sufficient to declare the tension off. When it uses the second pair (i.e., during a test), the consequences of a single voltmeter failure are much less important (the DG will run in Protection mode instead of WorkToDeath). The overall BPS design minimises the risk of damaging the DG and requires that both voltmeters agree before declaring the tension off.

```
Boolean mpsOn = (brkMpsClosed and bV1 and bV2) or
                 (brkMpsOpen and (nbV1 or nbV1));
Boolean mpsOff = not mpsOn;
```

MPS Availability - MPS Loss

The available / unavailable state of the MPS is decided by the LS based on the following criteria:

- The LS declares the MPS to be unavailable when it sees it off during 2.5 consecutive seconds.
- It declares the MPS to be back again and available when it sees it on during 9 consecutive seconds.

Accessibility : PUBLIC	

```
private property offEnough = duringAny 2.5*s check mpsOff;
private property onEnough = duringAny 9.*s check mpsOn;
Boolean mpsAvailable
    start = true;
    when (mpsAvailable and offEnough.satisfiedNow) becomes true
        then false;
    when (not mpsAvailable and onEnough.satisfiedNow) becomes true
        then true;
    else fixed;
    end mpsAvailable;
Boolean mpsUnavailable = not mpsAvailable;
```

For its own purposes, the LS marks the loss of the MPS by the following event:

```
event eMpsLoss = when mpsAvailable becomes false;
```

DG Ready

When the *DG* becomes necessary, it will be started by the *LS*. The *DG* needs some time to be fully ready. It is the *LS* that makes the decision that the *DG* is ready, based on the tension and frequency at the *DG* terminals: both tension and frequency must be appropriate.

```
event eDgReady = when ((dgV1 or dgV2) and (dgF1 or dgF2)) becomes true;
```

Valid Reset

The reset signal needs a little more processing than the other operator signals, since in the following, only valid reset signals will be taken into consideration. Deciding whether a reset signal is valid is based on whether the *MPS* is available and also whether the *BPS* is active:

```
event eReset = when resetBtn becomes true;
event eVReset =
   (during mpsAvailable)
and (after state becomes operational(active, current) trunc 10*mn)
and eReset;
```

One can note that the last expression is close to the one given in Section 4. There are a few differences though:

- The beginning of the BPS division activity is marked by a transition to operational(active; current).
- The eReset event here is the one in the tdLS time domain.

4.10.6. State Transitions and Actions

In this Section, the states specified in Section 4.10.2 *Main States* are analysed in terms of reaction to the 9 events and conditions of Section 4.10.5 *Main Events and Conditions*. The analysis of each state follows the same pattern:

- It begins with the actions that must be performed unconditionally upon entry to the state.
- Next are the requirements that must be satisfied while in the state.
- Next is the list of events and conditions that are taken into consideration in that state for the subsequent actions. The others are ignored. The actions include transition to other states.

Standby State

Upon entry to this state, all outputs except *dgProtect* are already set to false (see Section 4.10.4 *Outputs*). The following requirement states that they must be maintained at that value all the time the *LS* is in that state.

```
requirement ls1 = during operational(standby, current)
    check AND {not s forAll s in sequencingOutputs};
```

Accessibility : PUBLIC	

In this state, the LS reacts to:

- eMpsLoss
- eTest
- eMaint

Upon receiving a maintenance request (eMaint), the LS enters the Maintenance state. The +clock(1) is a grace period that gives time for the LS to react to its inputs:

```
when (operational(standby; current) and eMaint) + clock(1)
then state = maintenance;
```

Upon receiving an MPS loss event (eMpsLoss), the LS enters the operational(active; normal) state, unless it receives at the same time a maintenance request. The maintenance request has a higher priority than the MPS loss event.

```
when
  (operational(standby; current) and
  eMpsLoss and not eMaint) + clock(1)
  then state = operational(active, normal);
```

Upon receiving a test request (eTest), the LS enters the operational(active; test) state, unless it receives at the same time a maintenance request or an MPS loss event:

```
when
  (operational(standby; current) and
  eTest and not eMpsLoss and not eMaint) + clock(1)
  then state = operational(active, test);
```

Active State

Upon entry to this state, the *LS* must also issue a sequence of orders. The beginning of that sequence is shown in Figure 4-9. *shedAllTmax* is the maximum time for the *step* breakers to open, plus a half second margin.




Figure 4-9
Beginning of the LS sequencing

```
event eReloadSequence;
Duration shedAllTMax = 500.*ms + LARGEST{ s.brk.tMax forAll s in step};
when state becomes operational(active, current) then sequence
    raise eStartDG;
wait eDgReady then raise eOpenBrkMps;
wait eBrkMpsOpen then raise eShedAll;
simultaneous
    wait (shedAllTmax + 0.5*s) then raise eCloseBrkDg;
    wait 5.*s then raise eReloadSequence;
end;
end;
```

The *steps* reloading sequence must comply with the following constraints:

- Only the required *steps* are to be reloaded. The fact that a *step* is required or not is modelled by its *required* attribute (see Section 4.8 *The Step* Class).
- Required *steps* must be reloaded one by one, following their priority order. That order is determined by the order in the *step* vector, the first element having the highest priority.
- There must be at least *maxSettleTime* between two consecutive reloadings.
- Each required step must be reloaded as soon as it is possible.
- The first required step must be reloaded immediately at the beginning of the reloading sequence.

The following event marks all the instants where a reloading occurred:

```
event eReloads = OR {s.eReload forAll s in step};
```

The following condition covers the time periods where no reloading should occur:

```
Boolean noReload =
   (until eReloadSequence) or
   (after eReloads for maxSettleTime) or
   (after eVReset);
requirement during noReload check no eReloads;
```

The following subset contains the indexes of all the required steps not reloaded yet:

```
Integer{} candidates =
{i forAll i in 1..6
    suchThat step[i].required and not step[i].brk.closed};
```

Finally:

```
when ((not noReload) and (cardinal candidates)>0) becomes true + clock(1)
then step[SMALLEST(candidates)].reload = true;
```

One clock tick after all the *steps* are reloaded, the *LS* enters the *finished* state:

```
when ((cardinal candidates) becomes 0) + clock(1)
then state = operational(finished, current);
```

In the *active* state, the *LS* also reacts to the *eVReset* event: when it occurs, it executes the reset sequence (see next Section and Figure 4-10).

Finished State - Resetting the ODS Model

In this state, the LS just waits for a valid reset event (eVReset). It then performs the reset sequence (see Figure 4-10).




Figure 4-10 Reset Sequence

```
when
  (operational(active; current) or operational(finished, current))
    and eVReset then
sequence
    raise eStopDG;
    wait 1.*s then raise eOpenBrkDg;
    wait eBrkDgOpen then raise eCloseBrkMps;
    wait eBrkMpsClosed + clock(1) then
        forAll s in step then s.reload = true;
end;
```

Test State

If in test mode, the LS returns to normal mode in case of loss of MPS:

```
when (operational(current, test) and eMpsLoss) + clock(1)
then state = operational(current, normal);
```

Maintenance State

In the maintenance state, the LS returns to the operational(standby, normal) state upon event eEndMaint.

```
when (maintenance and eEndMaint) + clock(1)
    then state = operational(standby, normal);
```

Failure State

This state is taken when the *LS* detects failures of other *BPS* components that prevent the *BPS* from performing its main mission, i.e., the timely reloading of the required *steps*. In case of a failure of the *LS* itself, the design includes a watchdog external to the *LS* that monitors its well-being, that raises the failure signal when necessary. This mechanism is not modelled here.

The LS can only detect failures of the MPS and DG breakers, and of the DG itself, i.e., when they fail to open, close or be ready in a timely manner, or when they open, close or stop spuriously.

Failure to open, or close, or be ready, in a timely manner:

```
when ((eOpenBrkMps + brkMps.tMax) and brkMpsClosed) + clock(1)
    then state = failure;
when ((eCloseBrkMps + brkMps.tMax) and brkMpsOpen) + clock(1)
    then state = failure;
when ((eOpenBrkDg + brkDg.tMax) and brkDgClosed) + clock(1)
    then state = failure;
when ((eCloseBrkDg + brkDg.tMax) and brkDgOpen) + clock(1)
    then state = failure;
when ((eStartDG + dg.tMax) and not dg.ready) + clock(1)
    then state = failure;
```

Spurious opening, closing or stopping:

```
private property noOpenBrkMpsOrder =
  duringAny brkMps.tMax check no eOpenBrkMps;
when eBrkMpsOpen and noOpenBrkMpsOrder.satisfiedNow + clock(1)
  then state = failure;
private property noCloseBrkMpsOrder =
  duringAny brkMps.tMax check no eCloseBrkMps;
when eBrkMpsClose and noCloseBrkMpsOrder.satisfiedNow + clock(1)
  then state = failure;
private property noOpenBrkDgOrder =
  duringAny brkDg.tMax check no eOpenBrkDg;
when eBrkDgOpen and noOpenBrkDgOrder.satisfiedNow + clock(1)
  then state = failure;
private property noCloseBrkDgOrder =
  duringAny brkDg.tMax check no eCloseBrkDg;
when eBrkDgClose and noCloseBrkDgOrder.satisfiedNow + clock(1)
  then state = failure;
private property noStopDgOrder =
  duringAny dg.tMax check no eStopDg;
when dg.ready becomes false and noSopDgOrder.satisfiedNow + clock(1)
  then state = failure;
```

When entering the failure state, event efailure is raised to set the failure output signal:

```
when state becomes failure then raise eFailure;
```

end Ls;

4.11. The BpsDivOds Class

This class models the overall design of a BPS division.

```
class BpsDivOds
```

Load Sequencer

Each division has one load sequencer:

```
Ls ls;
```

Diesel Generator

Each division also has one diesel generator:

```
Dg dg;
```

Accessibility	•	PUBLIC
---------------	---	--------

Breakers

The following breaker is associated with the MPS. The instantiation specifies the values of the features declared as *specific*:

The following breaker is associated with the *DG*:

The breakers associated with the client divisions are declared as part of the divisions.

Voltmeters

```
Voltmeter bV1; // For the Backed-up panel
Voltmeter bV2;
Voltmeter nbV1; // For the Non-Backed-up panel
Voltmeter nbV2;
Voltmeter dgV1; // For the Diesel Generator
Voltmeter dgV2;
```

FreqMeters

```
FreqMeter dgF1; // Redundant frequency meters for the DG FreqMeter dgF2;
```

Breaker Position Sensors

```
MPensor brk1Pos
  brk = brk1;
  tMax = 20.*ms;
  end brk1Pos;
MPensor brk2Pos
  brk = brk2;
  tMax = 20.*ms;
  end brk2Pos;
MPensor mps1Pos
  brk = brkMps;
  tMax = 20.*ms;
  end mps1Pos;
MPensor mps2Pos
  brk = brkMps;
  tMax = 20.*ms;
  end mps2Pos;
MPensor dg1Pos
  brk = brkDg;
  tMax = 20.*ms;
  end dg1Pos;
```

```
MPensor dg2Pos
brk = brkDg;
tMax = 20.*ms;
end dg2Pos;
```

Obligation from the Ods Contract

```
Boolean active =
  ls.operational(active, current) or ls.operational(finished, current);
Boolean mpsOn = ls.mpsOn;
Boolean mpsAvailable = ls.mpsAvailable;
Boolean poweringla = dq.ready and brkDq.closed and clientla.brk.closed;
Boolean powering1b = dq.ready and brkDq.closed and client1b.brk.closed;
Boolean powering2a = dg.ready and brkDg.closed and client2a.brk.closed;
Boolean powering2b = dg.ready and brkDg.closed and client2b.brk.closed;
Boolean powering3a = dg.ready and brkDg.closed and client3a.brk.closed;
Boolean powering3b = dg.ready and brkDg.closed and client3b.brk.closed;
event eFailure = ls.eFailure;
Component {} sensors = {
  bV1, bV2,
  nbV1, nbV2,
  dgV1, dgV2,
  dgF1, dgF2,
  brk1Pos, brk2Pos,
  mps1Pos, mps2Pos;
  dg1Pos, dg2Pos};
Component {} nonSensors = {brkMps, brkDg, {s.brk forAll s in step}, dg};
ProtectedComponent {} protectedComponents = {dg};
```

```
end BpsDivOds;
```

4.12. The Ods Standard Contract

The *Ods* standard contract models the mutual obligations between the model of a *BPS* division stating its system specification (an instance of class *BpsDivSpec*) and the corresponding overall design model (an instance of class *BpsDivOds*).

```
contract Ods (BpsDivSpec divSpec, BpsDivOds divOds)
  party divSpec
    Boolean maintBtn;
    Boolean endMaintBtn;
    Boolean testBtn;
    Boolean resetBtn;
    Boolean client1Active;
    Voltage voltage;
    end divSpec;
  party divOds
    Boolean active;
    Boolean mpsOn;
    Boolean mpsAvailable;
    Boolean poweringla;
    Boolean powering1b;
    Boolean powering2a;
    Boolean powering2b;
    Boolean powering3a;
    Boolean powering3b;
    event eFailure;
```

```
Component {} sensors;
Component {} nonSensors;
ProtectedComponent {} protectedComponents;
end divOds;
end Ods;
```

4.13. The Models for the Overall Design of the Two BPS Divisions

```
property model BpsOds

BpsDivOds bpsAOds
    contract odsA;
    end bpsAOds;

BpsDivOds bpsBOds
    contract odsB;
    end bpsBOds;
end bpsBOds;
```

5. To be Provided by Scenarios or Detailed Design

A number of external features need to be provided either by scenario models or by detailed design models:

```
event Dg.eStall
                                   // For diesel generator
                                   // For diesel generator
constant Duration Dg.realTMax
constant Real Dg.realMaxLoad
                                   // For diesel generator
constant Duration Breaker.realTMax // For each breaker
event Breaker.eOpeningCompleted
                                   // For each breaker
event Breaker.eClosingCompleted
                                   // For each breaker
Real MSensor.input
                                   // For each measurement sensor
Boolean MSensor.on
                                   // For each measurement sensor
constant Duration MSensor.realTMax // For each measurement sensor
                                   // For each position sensor
Boolean PSensor.open
constant Duration PSensor.realTMax // For each position sensor
Real Step.demand
                                   // For each Step
```

6. Conclusion

This case study is representative of reactive systems that require significant control functions (generally provided by digital systems). As a perspective (after the end of MODRIO), it is planned to continue the work at EDF on this case study. The property models presented here will be complemented with a (Modelica) behavioural model representing the detailed design and the physical behaviour of the electrical and electromechanical components. Component failure modes will also be modelled using the multi-modelling concepts and languages proposed by WP4.

7. References

[1] Fritzson P., "Principles of Object-Oriented Modelling and Simulation with Modelica", IEEE Press, 2003.

Accessibility : PUBLIC	

- [2] Harel D., "Statecharts: A Visual Formalism For Complex Systems", in Science of Computer Programming, vol. 8, pp. 231-274, 1987.
- [3] Schamai W., "Model-Based Verification of Dynamic System Behavior Against Requirements", Dissertation No. 1547, Linköping University, 2013.
- [4] Rapin N., "ARTiMon: Outil de Monitoring de Propriétés".
- [5] SPEEDS: Contract Specification Language (CSL)
- [6] Jardin A., "EuroSysLib sWP7.1 Properties Modelling", EDF technical report, H-P1C-2011-00913-EN, 2011.
- [7] Duriaud Y., "EuroSysLib Deliverable 7.1b Etude des Langages de Spécifications de Propriétés", EDF technical report, H-P1A-2007-01326-FR, 2007.
- [8] Duriaud Y., "EuroSysLib Deliverable 7.1a Collected needs within EDF", EDF technical report, H-P1A-2007-01712-FR, 2008.
- [9] Marcon F., "EuroSysLib WP7.1 Synthesis of needs within EDF", EDF technical report, 2009.
- [10] Thomas E., "EuroSysLib WP7.1 Dysfunctional: Use Cases and User Requirements", Dassault Aviation technical report, DGT116083, 2008.
- [11] Thomas E., Chastanet L., "EuroSysLib WP7.1 Dysfunctional: Use Cases and User Requirements", Dassault Aviation technical report, DGT116083B, 2009.
- [12] Bouskela D., "MODRIO D2.1.1 Part II: Modeling Architecture for the Verification of Requirements", also available as EDF technical report, H-P1C-2014-15188-EN, 2015.
- [13] Thuy Nguyen, "MODRIO D2.1.2 Properties modelling method".
- [14] Thuy Nguyen, "MODRIO D2.1.1 Part III: FOrmal Requirements Modelling Language (FORM-L)", also available as EDF technical report, H-P1A-2014-00550-EN.
- [15] Jardin A., Thuy Nguyen, "MODRIO D8.1.3 Part II: The Intermediate Cooling System (SRI) Case Study".
- [16] Feiler P., Gluch D., Hudak J., "The Architecture Analysis & Design Language (AADL): An Introduction", Software Engineering Institute, 2006.
- [17] Selic B., Gérard S., "Modeling and Analysis of Real-Time and Embedded Systems with UML and MARTE", Elsevier, 2014.